


Quick Installation Guide

Nuclias Connect AC1200 Wave 2 Wall-Plated Access Point

DAP-2620



Contents

English

1

Before You Begin

This installation guide provides instructions for installing the DAP-2620 on your network. Additional documentation is also available on the D-Link support website.

- **Nuclias Connect Manual:** For additional information and instructions on how to configure the device using Nuclias Connect.
- **DAP-2620 User Manual:** For additional information and instructions on how to configure the device using the web user interface.

Package Contents

This DAP-2620 package includes the following items:

- DAP-2620 Access Point
- Mounting Plate and Hardware
- Quick Start Guide

If any of the above items are damaged or missing, please contact your local D-Link reseller.

Note: No power adapter is supplied with this product. To power the unit, use an 802.3af PoE Switch or an 802.3af PoE Injector.

System Requirements

- Computers with Windows®, Macintosh®, or Linux-based operating systems with an installed Ethernet Adapter
- Internet Explorer 11, Safari 7, Firefox 28, or Google Chrome 33 and above (for configuration)

Hardware Overview

LED Indicators




Figure 1: Front Panel LED

| # | LED | Description |
|---|--------------|--|
| 1 | Power/Status | <p>Green (Solid) - Device operational</p> <p>Red (Flashing) - Device booting up/Device malfunctioned</p> <p>Red (Solid) - Device boot up has failed</p> |

Table 1: LED Description

Interface Connectors




Figure 2: Bottom Connectors

| # | Connector | Description |
|---|----------------|--|
| 1 | LAN Port | Gigabit RJ-45 port for data. |
| 2 | Telephone Port | RJ-11 port for connection to phones. |
| 3 | Reset | Press and hold for 10 seconds to factory reset the device. |

Table 2: Interface Description




Figure 3: Rear Connectors

| # | Connector | Description |
|---|----------------|--|
| 1 | Telephone Port | RJ-11 port for connection to phones. |
| 2 | LAN(PoE) Port | Gigabit RJ-45 port for data and Power over Ethernet (PoE) power. |

Table 3: Interface Description

Installation

Using Power over Ethernet (PoE)

- Use a standard Ethernet cable to connect the LAN (PoE) port on the DAP-2620 to a PoE power source device such as an 802.3af PoE switch or 802.3af PoE injector.

Configuration

Using Nuclias Connect

The DAP-2620 is designed to be managed through Nuclias Connect. Refer to the **Nuclias Connect Manual** for detailed configuration instructions.

Manual Configuration

Note: D-Link recommends manually configuring the device before mounting it. The management computer, DHCP server and DAP-2620 must be in the same subnet.

Use one of the following methods to access the web user interface:

Connecting through Ethernet

- Use an Ethernet cable to connect the DAP-2620 to the management computer, or to the switch or router the management computer is connected to.
- Manage the access point from a computer. Enter **dap2620.local** in the address field of your browser.
- Log in to the administration user interface. The default login information is

Username: **admin**

Password: **admin**

Connecting Wirelessly

1. Connect the management computer to the default SSID of the DAP-2620, "dlink".
2. Manage the access point from a computer. Enter **dap2620.local** in the address field of your browser.
3. Log in to the administration user interface. The default login information is

Username: **admin**

Password: **admin**

Mounting

Mounting on a Solid Wall

For optimal coverage, mount the DAP-2620 on the wall. An Ethernet cable running through an electrical wall box should be pre-installed before mounting.




Figure 4: Attaching the Mounting Plate

1. Place the mounting plate over an electrical wall box and mark the location where to drill the holes in the wall. The Ethernet cable and the telephone cable (optional) should pass through the mounting plate.
2. Drill holes on the markings and place the included anchors into the drilled holes.

3. Align and place the mounting plate on top of the anchors and use the included screws to secure the mounting plate to the surface.




Figure 5: Attaching the Cables

4. Plug the Ethernet cable into the LAN (PoE) port of the device. **(Optional)** Plug the telephone cable to the telephone port of the device.




Figure 5: Mounting the Device

5. Attach the DAP-2620 to the mounting plate by snapping the device onto the plate and use the Allen key to lock it in at the top.

Appendix - Statements

ErP Power Usage

This device is an Energy Related Product (ErP) that automatically switches to a power-saving Network Standby mode within 1 minute of no packets being transmitted. It can also be turned off through a power switch to save energy when it is not needed.

Network Standby: 5.92 watts

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Non-modifications Statement:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter except in accordance with FCC multi-transmitter product procedures. For product available in the USA/Canada market, only channel 1~11 can be operated. Selection of other channels is not possible.

Note

The country code selection is for non-USA models only and is not available to all USA models. Per FCC regulations, all WiFi product marketed in the USA must be fixed to USA operational channels only.

RF Frequency Requirements

This device is for indoor use only when using all channels in the 5.15 to 5.25 GHz frequency range. High power radars are allocated as primary users of the 5.25 to 5.35 GHz and 5.65 to 5.85 GHz bands. These radar stations can cause interference with and/or damage this device. This device will not operate on channels which overlap the 5600-5650 MHz band.

It is restricted to indoor environments only.

IMPORTANT NOTICE:

Innovation, Science and Economic Development Canada (ISED) Statement:

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Innovation, Science and Economic Development Canada (ISED) Statement:

This device complies with ISED licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

(i) the device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;

(ii) les dispositifs fonctionnant dans la bande 5150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux;

Operations in the 5.25-5.35 GHz band are restricted to indoor usage only.

Les opérations dans la bande de 5.25-5.35 GHz sont limitées à un usage intérieur seulement.

Radiation Exposure Statement

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0.28 m between the radiator and your body.

Déclaration d'exposition aux radiations

Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 0.28 m de distance entre la source de rayonnement et votre corps.

Japan Voluntary Control Council for Interference Statement

この装置は、クラス B 情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。

Japan Voluntary Control Council for Interference Statement

This is a Class B product based on the standard of the VCCI Council. If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual.

電波法により5GHz帯は屋内使用に限ります。

Product and Warranty Information

To find out more about D-Link Nuclias product or marketing information, please visit the website <http://www.dlink.com> or <https://www.nuclias.com>.

The D-Link Limited Lifetime Warranty information is available at <http://www.dlink.com/warranty>

VCCI-B

Notes

Notes

D-Link[®]
Building Networks for People



Ver. 1.00(WW)_130x183
2019/12/12