



X S T A C K

CLI Reference Guide

Product Model: xStack[®] DGS-3600 Series

Layer 3 Managed Gigabit Ethernet Switch

Release 2.8



TABLE OF CONTENTS

INTRODUCTION	1
USING THE CONSOLE CLI.....	3
COMMAND SYNTAX	6
BASIC SWITCH COMMANDS.....	8
BASIC IP COMMANDS.....	22
BPDU TUNNELING COMMANDS.....	28
802.1X COMMANDS.....	31
ACCESS AUTHENTICATION CONTROL COMMANDS	52
ACCESS CONTROL LIST (ACL) COMMANDS.....	73
ACL FLOW METERING COMMANDS	84
ADDRESS RESOLUTION PROTOCOL (ARP) COMMANDS	89
ARP SPOOFING PREVENTION COMMANDS.....	93
BORDER GATEWAY PROTOCOL (BGP) DEBUG COMMANDS	95
BORDER GATEWAY PROTOCOL (BGP) COMMANDS	111
BPDU ATTACK PROTECTION COMMANDS	156
CABLE DIAGNOSTICS COMMAND LIST	160
COMMAND HISTORY LIST.....	162
COMMAND LOGGING COMMANDS.....	165
COMPOUND AUTHENTICATION COMMANDS.....	167
CONFIGURATION COMMANDS.....	174
COUNTER COMMANDS	179
DEBUG COMMANDS	183
DHCP LOCAL RELAY COMMANDS	189
DHCP RELAY COMMANDS.....	191
DHCP SERVER SCREENING COMMANDS.....	201
DHCP SERVER COMMANDS	205
DHCPV6 CLIENT COMMANDS.....	220
DHCPV6 RELAY COMMANDS	223
DHCPV6 SERVER COMMANDS.....	229
D-LINK SINGLE IP MANAGEMENT COMMANDS.....	241
D-LINK UNIDIRECTIONAL LINK DETECTION (DULD) COMMANDS	252
DOMAIN NAME SERVER (DNS)RELAY COMMANDS.....	254
DOMAIN NAME SYSTEM (DNS) RESOLVER COMMANDS	258
DVMRP COMMANDS	263
ETHERNET RING PROTECTION SWITCHING (ERPS) COMMANDS	268
FILTER DATABASE (FDB) COMMANDS.....	278
FLASH FILE SYSTEM (FFS) COMMANDS	285
GRATUITOUS ARP COMMANDS.....	291
IEEE 802.1Q VLAN COMMANDS	295
IEEE 802.1QINQ COMMANDS.....	305
IGMP AND MLD SNOOPING COMMANDS.....	310

INTERNET GROUP MANAGEMENT PROTOCOL (IGMP) COMMANDS	329
IP DIRECTED BROADCAST COMMANDS	334
IP MULTICASTING COMMANDS.....	336
IP ROUTE FILTER COMMANDS.....	338
IP-MAC-PORT BINDING (IMPB) COMMANDS	349
IPV6 NEIGHBOR DISCOVER COMMANDS	365
IPV6 ROUTE COMMANDS.....	371
IPV6 TUNNEL COMMANDS.....	374
JAPANESE WEB-BASED ACCESS CONTROL (JWAC) COMMANDS	380
JUMBO FRAME COMMANDS	398
LIMITED IP MULTICAST ADDRESS COMMANDS.....	400
LINK AGGREGATION COMMANDS.....	407
LINK LAYER DISCOVERY PROTOCOL (LLDP) COMMANDS.....	412
LOOPBACK INTERFACE COMMANDS	428
LOOPBACK INTERFACE COMMANDS	432
MAC NOTIFICATION COMMANDS	435
MAC-BASED ACCESS CONTROL COMMANDS	439
MESSAGE-DIGEST ALGORITHM 5 (MD5) COMMANDS	452
MIRROR COMMANDS.....	455
MSTP DEBUG ENHANCEMENT COMMANDS	460
IGMP SNOOPING MULTICAST (ISM) VLAN COMMANDS.....	467
MULTIPLE SPANNING TREE PROTOCOL (MSTP) COMMANDS	472
NETWORK LOAD BALANCING (NLB) COMMANDS.....	483
OPEN SHORTEST PATH FIRST (OSPFV3) COMMANDS	486
OSPF COMMANDS	500
OSPF DEBUG ENHANCEMENT COMMANDS	517
PASSWORD ENCRYPTION COMMANDS	534
PING COMMANDS	538
POLICY ROUTE COMMANDS	542
PORT SECURITY COMMANDS	545
PROTOCOL INDEPENDENT MULTICAST (PIM) COMMANDS	548
PROTOCOL VLAN GROUP COMMANDS.....	564
QUALITY OF SERVICE (QOS) COMMANDS	569
REMOTE COPY PROTOCOL (RCP) COMMANDS.....	582
REMOTE SWITCHED PORT ANALYZER (RSPAN) COMMANDS.....	593
RIPNG COMMANDS.....	599
ROUTING INFORMATION PROTOCOL (RIP) COMMANDS	604
SAFEGUARD ENGINE COMMANDS	607
SECURE SHELL (SSH) COMMANDS	610
SECURE SOCKETS LAYER (SSL) COMMANDS.....	616
SFLOW COMMANDS	621
SIMPLE NETWORK MANAGEMENT PROTOCOL (SNMP) COMMANDS	630

STACKING COMMANDS	643
STATIC MAC-BASED VLAN COMMANDS	648
STATIC MULTICAST ROUTE COMMANDS.....	650
SUBNET VLAN COMMANDS.....	652
SUPER VLAN COMMANDS	656
SWITCH PORT COMMANDS	660
SYSLOG OR TRAP SOURCE-INTERFACE COMMANDS	666
SYSTEM LOG COMMANDS.....	669
TECHNICAL SUPPORT COMMANDS	680
TELNET CLIENT COMMANDS	683
TFTP CLIENT COMMANDS	684
TIME AND SNTP COMMANDS	689
TIME RANGE COMMANDS.....	695
TRACE ROUTE COMMANDS	697
TRAFFIC CONTROL COMMANDS.....	700
TRAFFIC SEGMENTATION COMMANDS.....	704
TRUSTED HOST COMMANDS	706
UNICAST ROUTE COMMANDS.....	708
UTILIZATION COMMANDS.....	722
VLAN TRUNKING COMMANDS	725
VRRP DEBUG COMMANDS	728
VRRP COMMANDS	734
WEB-BASED ACCESS CONTROL (WAC) COMMANDS.....	740
PASSWORD RECOVERY COMMANDS.....	750
TECHNICAL SPECIFICATIONS.....	751

INTRODUCTION

The Switch can be managed through the Switch's serial port, Telnet, or the Web-based management agent. The Command Line Interface (CLI) can be used to configure and manage the Switch via the serial port or Telnet interfaces.

The DGS-3600 Layer 3 stackable Gigabit Ethernet switch series are members of the D-Link xStack® family. Ranging from 10/100Mbps edge switches to core gigabit switches, the xStack® switch family has been future-proof designed to provide a stacking architecture with fault tolerance, flexibility, port density, robust security and maximum throughput with a user-friendly management interface for the networking professional.

This manual provides a reference for all of the commands contained in the CLI for the xStack® DGS-3612, DGS-3612G, DGS-3627, DGS-3627G, DGS-3627, DGS-3627G and DGS-3650 series of switches. Configuration and management of the Switch via the Web-based management agent is discussed in the User's Guide.



NOTE: For the remainder of this manual, all versions of the DGS-3612, DGS-3612G, DGS-3627, DGS-3627G, DGS-3627, DGS-3627G and DGS-3650 switches will be referred to as simply the Switch or the DGS-3627.

Accessing the Switch via the Serial Port

The Switch's serial port's default settings are as follows:

1. **115200 baud**
2. **no parity**
3. **8 data bits**
4. **1 stop bit**

A computer running a terminal emulation program capable of emulating a VT-100 terminal and a serial port configured as above is then connected to the Switch's serial port via an RS-232 DB-9 cable.

With the serial port properly connected to a management computer, the following screen should be visible. If this screen does not appear, try pressing Ctrl+r or refresh the console screen.

```
DGS-3627 Gigabit Ethernet Switch
Command Line Interface

Firmware: Build 2.80.B31
Copyright(C) 2010 D-Link Corporation. All rights reserved.
UserName:
```

Figure 1-1. Initial CLI screen

There is no initial username or password. Just press the Enter key twice to display the CLI input cursor –DGS-3627:admin# . This is the command line where all commands are input.

Setting the Switch's IP Address

Each Switch must be assigned its own IP Address, which is used for communication with an SNMP network manager or other TCP/IP application (for example BOOTP, TFTP). The Switch's default IP address is 10.90.90.90. You can change the default Switch IP address to meet the specification of your networking address scheme.

The Switch is also assigned a unique MAC address by the factory. This MAC address cannot be changed, and can be found on the initial boot console screen – shown below.

```

Boot Procedure 1.10-B09
-----
Power On Self Test ..... 100 %

MAC Address   : 00-19-5B-F5-26-C0
H/W Version   : 1A1G

Please wait, loading V2.80.B31 Runtime image ..... 100 %
UART init     ..... 100 %
Device Discovery ..... -
    
```

Figure 1-2. Boot screen

The Switch’s MAC address can also be found in the Web management program on the **Switch Information (Basic Settings)** window in the **Configuration** menu.

The IP address for the Switch must be set before it can be managed with the Web-based manager. The Switch IP address can be automatically set using BOOTP or DHCP protocols, in which case the actual address assigned to the Switch must be known.

The IP address may be set using the Command Line Interface (CLI) over the console serial port as follows:

1. Starting at the command line prompt, enter the commands **config ipif System ipaddress xxx.xxx.xxx.xxx/yyy.yyy.yyy.yyy**. Where the **x**’s represent the IP address to be assigned to the IP interface named **System** and the **y**’s represent the corresponding subnet mask.
2. Alternatively, you can enter **config ipif System ipaddress xxx.xxx.xxx.xxx/z**. Where the **x**’s represent the IP address to be assigned to the IP interface named **System** and the **z** represents the corresponding number of subnets in CIDR notation.

The IP interface named **System** on the Switch can be assigned an IP address and subnet mask which can then be used to connect a management station to the Switch’s Telnet or Web-based management agent.

```

DGS-3627:admin# config ipif System ipaddress 10.24.22.200/255.0.0.0
Command: config ipif System ipaddress 10.24.22.200/8

Success.

DGS-3627:admin#
    
```

Figure 1-3. Assigning an IP Address

In the above example, the Switch was assigned an IP address of 10.24.22.200 with a subnet mask of 255.0.0.0. The system message **Success** indicates that the command was executed successfully. The Switch can now be configured and managed via Telnet, SNMP MIB browser and the CLI or via the Web-based management agent using the above IP address to connect to the Switch.

USING THE CONSOLE CLI

The Switch supports a console management interface that allows the user to connect to the Switch's management agent via a serial port and a terminal or a computer running a terminal emulation program. The console can also be used over the network using the TCP/IP Telnet protocol. The console program can be used to configure the Switch to use SNMP-based network management software over the network.

This chapter describes how to use the console interface to access the Switch, change its settings, and monitor its operation.



NOTE: Switch configuration settings are saved to non-volatile RAM using the save command. The current configuration will then be retained in the Switch's NV-RAM, and reloaded when the Switch is rebooted. If the Switch is rebooted without using the save command, the last configuration saved to NV-RAM will be loaded.

Connecting to the Switch

The console interface is used by connecting the Switch to a VT100-compatible terminal or a computer running an ordinary terminal emulator program (e.g., the **HyperTerminal** program included with the Windows operating system) using an RS-232C serial cable. Your terminal parameters will need to be set to:

- **VT-100 compatible**
- **115200 baud**
- **8 data bits**
- **No parity**
- **One stop bit**
- **No flow control**

Users can also access the same functions over a Telnet interface. Once an IP address has been set for the Switch, users can use a Telnet program (in VT-100 compatible terminal mode) to access and control the Switch. All of the screens are identical, whether accessed from the console port or from a Telnet interface.

After the Switch reboots and you have logged in, the console looks like this:

```
DGS-3627 Gigabit Ethernet Switch
Command Line Interface

Firmware: Build 2.80.B31
Copyright(C) 2010 D-Link Corporation. All rights reserved.

UserName:
PassWord:

DGS-3627:admin# _
```

Figure 2- 1. Initial Console Screen after logging in

Commands are entered at the command prompt, **DGS-3627:admin#** .

There are a number of helpful features included in the CLI. Entering the ? command will display a list of all of the top-level commands.

```

DGS-3627:admin# ?
Command: ?

..
?
cable_diag ports
cd
clear
clear address_binding dhcp_snoop binding_entry ports
clear address_binding nd_snoop binding_entry ports
clear arptable
clear attack_log
clear bgp
clear bgp dampening
clear bgp flap_statistics
clear counters
clear dhcp_binding
clear dhcpv6 binding
clear fdb
clear ip_prefix_list counter
clear jvac auth_state
clear log
clear mac_based_access_control auth_state
clear port_security_entry port
clear wac auth_state
CTRL+C ESC q Quit SPACE n Next Page Enter Next Entry a All

```

Figure 2- 2. The ? Command

When users enter a command without its required parameters, the CLI will prompt a **Next possible completions:** message.

```

DGS-3627:admin# config account
Command: config account
Next possible completions:
<username>

DGS-3627:admin#

```

Figure 2- 3. Example Command Parameter Help

In this case, the command **config account** was entered with the parameter **<username>**. The CLI will then prompt to enter the **<username>** with the message, **Next possible completions:**. Every command in the CLI has this feature, and complex commands have several layers of parameter prompting.

In addition, after typing any given command plus one space, all of the next possible sub-commands can be seen, in sequential order, by repeatedly pressing the **Tab** key.

To re-enter the previous command at the command prompt, press the up arrow cursor key. The previous command will appear at the command prompt.

```

DGS-3627:admin# config account
Command: config account
Next possible completions:
<username>

DGS-3627:admin# config account

```

Figure 2- 4. Using the Up Arrow to Re-enter a Command

In the above example, the command **config account** was entered without the required parameter **<username>**, the CLI returned the **Next possible completions: <username>** prompt. The up arrow cursor control key was pressed to re-enter the previous command (**config account**) at the command prompt. Now the appropriate username can be entered and the **config account** command re-executed.

All commands in the CLI function in this way. In addition, the syntax of the help prompts are the same as presented in this manual – angle brackets **< >** indicate a numerical value or character string, braces **{ }** indicate optional parameters or a choice of parameters, and brackets **[]** indicate required parameters.

If a command is entered that is unrecognized by the CLI, the top-level commands will be displayed under the **Available commands:** prompt.

```
DGS-3627:admin# the
Available commands:
..          ?          cable_diag          cd
clear       config          copy                create
debug       delete          dir                 disable
download    enable          erase               login
logout      no              ping               ping6
reboot      reconfig        rename              reset
save        show            telnet              traceroute
traceroute6 upload

DGS-3627:admin#
```

Figure 2- 5. Available Commands

The top-level commands consist of commands such as **show** or **config**. Most of these commands require one or more parameters to narrow the top-level command. This is equivalent to **show what?** or **config what?** Where the **what?** is the next parameter.

For example, if you enter the **create** command with no additional parameters, the CLI will then display all of the possible next parameters.

```
DGS-3627:admin# create
Command: create
Next possible completions:
802.1x      access_profile    account            address_binding
arpentry    authen            authen_enable     authen_login
authentication bgp                cpu                dhcp
dhcpv6      dot1v_protocol_group double_vlan
erps        fdb                host_name          igmp_snooping
ip          ip_tunnel         ipif               ipmroute
iproute     ipv6              ipv6route          jwac
link_aggregation loopback          mac_based_access_control
mac_based_access_control_local mac_based_vlan    md5
mirror      multicast_fdb     multicast_range    nlb
ospf        ospfv3            pim                policy_route
route       route_map         rspan              sflow
snmp        stp                subnet_vlan        super_vlan
syslog      trusted_host      vlan                vlan_translation
vrrp        wac

DGS-3627:admin#
```

Figure 2- 6. Next possible completions: Create command

In the above example, all of the possible next parameters for the **create** command are displayed.

COMMAND SYNTAX

The following symbols are used to describe how command entries are made and values and arguments are specified in this manual. The online help contained in the CLI and available through the console interface uses the same syntax.



NOTE: All commands are case-sensitive. Be sure to disable Caps Lock or any other unwanted function that changes text case.

<angle brackets>

Purpose	Encloses a variable or value that must be specified.
Syntax	create ipif <ipif_name 12> <network_address> (<ip_addr/netmask>) <vlan_name 32> {secondary state [enable disable]}
Description	In the above syntax example, users must supply an IP interface name in the <ipif_name> space, a VLAN name in the <vlan_name 32> space, and the network address, including the netmask, in the <network_address> (<ip_addr/netmask>) space. Do not type the angle brackets.
Example Command	create ipif Engineering 10.24.22.5/255.0.0.0 Design

[square brackets]

Purpose	Encloses a required value or set of required arguments. One value or argument can be specified.
Syntax	create account [admin operator user] <username 15>
Description	In the above syntax example, users must specify the admin , operator , or user level account to be created. Do not type the square brackets.
Example Command	create account admin ctsnow

| vertical bar

Purpose	Separates two or more mutually exclusive items in a list, one of which must be entered.
Syntax	create account [admin operator user] <username 15>
Description	In the above syntax example, you must specify the admin , operator , or user level account to be created. Do not type the backslash.
Example Command	create account admin ctsnow

{braces}

Purpose	Encloses an optional value or set of optional arguments.
---------	--

{braces}

Syntax	reset {[config system]}
Description	In the above syntax example, users have the option to specify config or system . It is not necessary to specify either optional value, however the effect of the system reset is dependent on which, if any, value is specified. Therefore, with this example there are three possible outcomes of performing a system reset. See the following chapter, Basic Commands for more details about the reset command.
Example command	reset config

Line Editing Key Usage

Delete	Deletes the character under the cursor and then shifts the remaining characters in the line to the left.
Backspace	Deletes the character to the left of the cursor and then shifts the remaining characters in the line to the left.
Left Arrow	Moves the cursor to the left.
Right Arrow	Moves the cursor to the right.
Up Arrow	Repeats the previously entered command. Each time the up arrow is pressed, the command previous to that displayed appears. This way it is possible to review the command history for the current session. Use the down arrow to progress sequentially forward through the command history list.
Down Arrow	The down arrow will display the next command in the command history entered in the current session. This displays each command sequentially as it was entered. Use the up arrow to review previous commands.
Tab	Shifts the cursor to the next field to the left.

Multiple Page Display Control Keys

Space	Displays the next page.
CTRL+c	Stops the display of remaining pages when multiple pages are to be displayed.
ESC	Stops the display of remaining pages when multiple pages are to be displayed.
n	Displays the next page.
p	Displays the previous page.
q	Stops the display of remaining pages when multiple pages are to be displayed.
r	Refreshes the pages currently displayed.
a	Displays the remaining pages without pausing between pages.
Enter	Displays the next line or table entry.

BASIC SWITCH COMMANDS

The basic switch commands in the Command Line Interface (CLI) are listed (with the appropriate parameters) in the following table.

Command	Parameters
create account	[admin operator user] <username 15>
config account	<username> {encrypt [plain_text sha_1] <password>}
show account	
delete account	<username> {<string>}
show session	
show switch	
show serial_port	
config serial_port	{baud_rate [9600 19200 38400 115200] auto_logout [never 2_minutes 5_minutes 10_minutes 15_minutes]}
enable clipaging	
disable clipaging	
enable telnet	{<tcp_port_number 1-65535>}
disable telnet	
telnet	[<ipaddr> <domain_name 255>] {tcp_port <value 0-65535>}
enable web	{<tcp_port_number 1-65535>}
disable web	
save	{[config {<drive_id> <pathname 64> log all]}
reboot	{<string>}
reset	{[config system]} {<string>}
login	
logout	
show device_status	
config command_prompt	[<string 16> username default]
config greeting_message	{default}
show greeting_message	

Each command is listed, in detail, in the following sections.

create account

Purpose	Used to create user accounts.
Syntax	create account [admin operator user] <username 15>
Description	The create account command is used to create user accounts that consist of a username of 1 to 15 characters and a password of 0 to 15 characters. Up to eight user accounts can be created.
Parameters	<p><i>admin <username 15></i> – Enter a name between 1 and 15 alphanumeric characters to define the administrator account created here.</p> <p><i>operator <username 15></i> – Enter a name between 1 and 15 alphanumeric characters to define the operator account created here.</p> <p><i>user <username 15></i> – Enter a name between 1 and 15 alphanumeric characters to define the user account created here.</p>
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To create an administrator-level user account with the username “dlink”.

```
DGS-3627:admin# create account admin dlink
Command: create account admin dlink

Enter a case-sensitive new password:****
Enter the new password again for confirmation:****

Success.

DGS-3627:admin#
```

To create an operator-level user account with the username “frazier”.

```
DGS-3627:admin# create account operator frazier
Command: create account operator frazier

Enter a case-sensitive new password:****
Enter the new password again for confirmation:****

Success.

DGS-3627:admin#
```

To create a user-level user account with the username “reed”.

```
DGS-3627:admin# create account user reed
Command: create account user reed

Enter a case-sensitive new password:****
Enter the new password again for confirmation:****

Success.

DGS-3627:admin#
```

config account

Purpose	Used to configure user accounts.
Syntax	config account <username> {encrypt [plain_text] sha_1} <password>
Description	The config account command configures a user account that has been created using the create account command.
Parameters	<p><i><username></i> – Enter a name between 1 and 15 alphanumeric characters to define the administrator account to configure here.</p> <p><i>encrypt</i> - Select the encrypted form of password.</p> <p><i>plain_text</i> - Passwords should be between 0 and 15 characters.</p> <p><i>sha_1</i> - Passwords should be fixed to 35 bytes long.</p> <p><i><password></i> - The password for the user account.</p>
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To configure the user password of “dlink” account:

```
DGS-3627:admin# config account dlink
Command: config account dlink

Enter a old password:****
Enter a case-sensitive new password:****
Enter the new password again for confirmation:****

Success.

DGS-3627:admin#
```

show account

Purpose	Used to display user accounts
Syntax	show account
Description	Displays all user accounts created on the Switch. Up to eight user accounts can exist at one time.
Parameters	None.
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To display the accounts that have been created:

```
DGS-3627:admin# show account
Command: show account

Current Accounts:
Username          Access Level
-----          -
dlink             Admin

DGS-3627:admin#
```

delete account

Purpose	Used to delete an existing user account.
Syntax	delete account <username> {<string>}
Description	The delete account command deletes a user account that has been created using the create account command.
Parameters	<username> <string> – Enter an alphanumeric string of up to 15 characters to define the username.
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To delete the user account “System”:

```
DGS-3627:admin# delete account System
Command: delete account System

Are you sure to delete the last administrator account?(y/n)y
Success.

DGS-3627:admin#
```

show session

Purpose	Used to display a list of currently logged-in users.
Syntax	show session
Description	This command displays a list of all the users that are logged-in at the time the command is issued.
Parameters	None
Restrictions	None.

Example usage:

To display the way that the users logged in:

```
DGS-3627:admin# show session
Command: show session

ID      Live Time      From           Level  Name
--      -
8       03:36:27      Serial Port    5      Anonymous

Total Entries: 1

CTRL+C  ESC  q  Quit  SPACE  n  Next Page  p  Previous Page  r  Refresh
```

show switch

Purpose	Used to display general information about the Switch.
Syntax	show switch
Description	This command displays information about the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the Switch's information:

```
DGS-3627:admin# show switch
Command: show switch

Device Type       : DGS-3627 Gigabit Ethernet Switch
MAC Address       : 00-1C-F0-B5-40-00
IP Address        : 10.24.73.21 (Manual)
VLAN Name         : default
Subnet Mask       : 255.0.0.0
Default Gateway   : 0.0.0.0
Boot PROM Version : Build 1.10-B09
Firmware Version  : Build 2.80.B31
Hardware Version  : A1
Serial Number     : P4F7191000001
System Name       :
System Location   :
System Contact    :
Spanning Tree     : Disabled
GVRP              : Disabled
IGMP Snooping     : Disabled
MLD Snooping      : Disabled
RIP               : Disabled
DVMRP            : Disabled
PIM               : Disabled
OSPF              : Disabled
TELNET           : Enabled (TCP 23)
CTRL+C ESC q Quit SPACE n Next Page p Previous Page r Refresh
```

show serial_port

Purpose	Used to display the current serial port settings.
Syntax	show serial_port
Description	This command displays the current serial port settings.
Parameters	None.
Restrictions	None

Example usage:

To display the serial port setting:


```
DGS-3627:admin# show serial_port
```

```
Command: show serial_port
```

```
Baud Rate       : 115200
Data Bits       : 8
Parity Bits     : None
Stop Bits      : 1
Auto-Logout    : 10 mins
```

```
DGS-3627:admin#
```

config serial_port

Purpose	Used to configure the serial port.
Syntax	config serial_port {baud_rate [9600 19200 38400 115200] auto_logout [never 2_minutes 5_minutes 10_minutes 15_minutes]}
Description	This command is used to configure the serial port's baud rate and auto logout settings.
Parameters	<i>baud_rate [9600 19200 38400 115200]</i> – The serial bit rate that will be used to communicate with the management host. There are four options: <i>9600</i> , <i>19200</i> , <i>38400</i> , and <i>115200</i> . <i>never</i> – No time limit on the length of time the console can be open with no user input. <i>2_minutes</i> – The console will log out the current user if there is no user input for 2 minutes. <i>5_minutes</i> – The console will log out the current user if there is no user input for 5 minutes. <i>10_minutes</i> – The console will log out the current user if there is no user input for 10 minutes. <i>15_minutes</i> – The console will log out the current user if there is no user input for 15 minutes.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure baud rate:

```
DGS-3627:admin# config serial_port baud_rate 115200
```

```
Command: config serial_port baud_rate 115200
```

```
Success.
```

```
DGS-3627:admin#
```

enable clipaging

Purpose	Used to pause the scrolling of the console screen when the show command displays more than one page.
Syntax	enable clipaging
Description	This command is used when issuing the show command which causes the console screen to rapidly scroll through several pages. This command will cause the console to pause at the end of each page. The default setting is enabled.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable pausing of the screen display when the show command output reaches the end of the page:

```
DGS-3627:admin# enable clipaging
Command: enable clipaging

Success.

DGS-3627:admin#
```

disable clipaging

Purpose	Used to disable the pausing of the console screen scrolling at the end of each page when the show command displays more than one screen of information.
Syntax	disable clipaging
Description	This command is used to disable the pausing of the console screen at the end of each page when the show command would display more than one screen of information.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable pausing of the screen display when show command output reaches the end of the page:

```
DGS-3627:admin# disable clipaging
Command: disable clipaging

Success.

DGS-3627:admin#
```

enable telnet

Purpose	Used to enable communication with and management of the Switch using the Telnet protocol.
Syntax	enable telnet {<tcp_port_number 1-65535>}
Description	This command is used to enable the Telnet protocol on the Switch. The user can specify the TCP or UDP port number the Switch will use to listen for Telnet requests.
Parameters	{<tcp_port_number 1-65535>} – The TCP port number. TCP ports are numbered between 1 and 65535. The “well-known” TCP port for the Telnet protocol is 23.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable Telnet and configure port number:

```
DGS-3627:admin# enable telnet 23
Command: enable telnet 23

Success.

DGS-3627:admin#
```

disable telnet

Purpose	Used to disable the Telnet protocol on the Switch.
Syntax	disable telnet
Description	This command is used to disable the Telnet protocol on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the Telnet protocol on the Switch:

```
DGS-3627:admin# disable telnet
Command: disable telnet

Success.

DGS-3627:admin#
```

telnet

Purpose	Used to login remote system with telnet protocol.
Syntax	telnet [<ipaddr> <domain_name 255>] {tcp_port <value 0-65535>}
Description	This command is used to login remote system with Telnet protocol on the Switch.
Parameters	<p><i><ipaddr></i> – Specify the IP address of telnet server system</p> <p><i><domain_name 255></i> - Specify the domain name used.</p> <p><i>tcp_port</i> – The TCP port number. TCP ports are numbered between 1 and 65535. The “well-known” TCP port for the Telnet protocol is 23.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To login to the remote system using telnet on the Switch:

```
DGS-3627:admin# telnet 10.0.0.8
Command: telnet 10.0.0.8

Success.

DGS-3627:admin#
```

enable web

Purpose	Used to enable the HTTP-based management software on the Switch.
Syntax	enable web {<tcp_port_number 1-65535>}
Description	This command is used to enable the Web-based management software on the Switch. The user can specify the TCP port number the Switch will use to listen for Telnet requests.
Parameters	{<tcp_port_number 1-65535>} – The TCP port number. TCP ports are numbered between 1 and 65535. The “well-known” port for the Web-based management software is 80.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable HTTP and configure port number:

```
DGS-3627:admin# enable web 80
Command: enable web 80

Note: SSL will be disabled if web is enabled.
Success.

DGS-3627:admin#
```

disable web

Purpose	Used to disable the HTTP-based management software on the Switch.
Syntax	disable web
Description	This command disables the Web-based management software on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable HTTP:

```
DGS-3627:admin# disable web
Command: disable web

Success.

DGS-3627:admin#
```

save

Purpose	Used to save changes in the Switch's configuration to non-volatile RAM.
Syntax	save {[config {<drive_id>} <pathname 64> log all]}
Description	This command is used to enter the current switch configuration or log file into non-volatile RAM. The saved switch configuration will be loaded into the Switch's memory each time the Switch is restarted.
Parameters	<i>config</i> <drive_id> – Specify to save current settings to the Flash memory of the switch. <drive_id> – Specify the ID of the drive where the log or configuration file will be placed. <pathname 64> – Enter a name of up to 64 characters to define the file to be saved on the flash drive. <i>log</i> – Specify to save current Switch log to NV-RAM. <i>all</i> – Use to save the configuration and log file to NV-RAM.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To save the Switch's current configuration to non-volatile RAM:

```
DGS-3627:admin# save
Command: save

Saving all configurations to NV-RAM... Done.

DGS-3627:admin#
```

reboot

Purpose	Used to restart the Switch.
Syntax	reboot {<string>}
Description	This command is used to restart the Switch.
Parameters	None.
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To restart the Switch:

```
DGS-3627:admin# reboot
Command: reboot
Are you sure want to proceed with the system reboot? (y|n) y
Please wait, the switch is rebooting...
```

reset

Purpose	Used to reset the Switch to the factory default settings.
Syntax	reset {[config system]} {<string>}
Description	This command is used to restore the Switch's configuration to the default settings assigned from the factory.
Parameters	<p><i>config</i> – If the keyword 'config' is specified, all of the factory default settings are restored on the Switch including the IP address, user accounts, and the switch history log. The Switch will not save or reboot.</p> <p><i>system</i> – If the keyword 'system' is specified all of the factory default settings are restored on the Switch. The Switch will save and reboot after the settings are changed to default. Rebooting will clear all entries in the Forwarding Data Base.</p> <p>If no parameter is specified, the Switch's current IP address, user accounts, and the switch history log are not changed. All other parameters are restored to the factory default settings. The Switch will not save or reboot.</p>
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To restore all of the Switch's parameters to its default values:

```
DGS-3627:admin# reset config
Command: reset config

Are you sure to proceed with system reset?(y/n) y

Success.

DGS-3627:admin#
```

login

Purpose	Used to log in a user to the Switch's console.
Syntax	login
Description	This command is used to initiate the login procedure. The user will be prompted for a Username and Password.
Parameters	None.
Restrictions	None.

Example usage:

To initiate the login procedure:

```
DGS-3627:admin# login
Command: login

UserName:
```

logout

Purpose	Used to log out a user from the Switch's console.
Syntax	logout
Description	This command terminates the current user's session on the Switch's console.
Parameters	None.
Restrictions	None.

Example usage:

To terminate the current user's console session:

```
DGS-3627:admin# logout
```

show device_status

Purpose	Used to display the current status of the hardware of the Switch.
Syntax	show device_status
Description	This command displays the current status of the power and fans on the system. In the fan status display there are fans on the left of the switch, on the right, at the back and a CPU fan, if the fans are working normally the display will read "OK" in the fan field. If any of the fans fail the corresponding field will read 'Fail'.
Parameters	None.
Restrictions	None.

Example usage:

To show the device status of the Switch:

```
DGS-3627:admin# show device_status
```

```
Command: show device_status
```

```
Unit 1:
```

```
Internal Power: Active
```

```
External Power: Fail
```

```
Left Fan      : OK
```

```
Right Fan     : OK
```

```
Back Fan      : OK
```

```
CPU Fan       : OK
```

```
CTRL+C ESC q Quit SPACE n Next Page p Previous Page r Refresh
```

config command_prompt

Purpose	Used to configure the command prompt for the Command Line Interface.
Syntax	config command_prompt [<string 16> username default]
Description	This command is used to configure the command prompt for the CLI interface of the Switch. The current command prompt consists of "product name + : + user level + product name" (ex. DGS-3627:admin#). The user may replace all parts of the command prompt, except the # by entering a string of 16 alphanumeric characters with no spaces, or the user may enter the current login

	username configured on the Switch.
Parameters	<p><string 16> – Enter an alphanumeric string of no more than 16 characters to define the command prompt for the CLI interface.</p> <p><i>username</i> – Entering this parameter will replace the current CLI command prompt with the login username configured on the Switch.</p> <p><i>default</i> – Entering this parameter will return the command prompt to its original factory default setting.</p>
Restrictions	<p>The reset command will not alter the configured command prompt, yet the reset system command will return the command prompt to its original factory default setting.</p> <p>Only Administrator and Operator-level users can issue this command.</p>

Example usage:

To configure the command prompt:

```
DGS-3627:admin# config command_prompt Tiberius
Command: config command_prompt Tiberius

Success.

Tiberius:admin#
```

config greeting_message

Purpose	Used to configure the greeting message or banner for the opening screen of the Command Line Interface.
Syntax	config greeting_message {default}
Description	This command is used to configure the greeting message or login banner for the opening screen of the CLI.
Parameters	<i>default</i> – Adding this parameter will return the greeting command to its original factory default configuration.
Restrictions	<p>The reset command will not alter the configured greeting message, yet the reset system command will return the greeting message to its original factory default setting.</p> <p>The maximum character capacity for the greeting banner is 6 lines and 80 characters per line. Entering Ctrl+W will save the current configured banner to the DRAM only. To save it into the FLASH memory, the user must enter the save command.</p> <p>Only Administrator and Operator-level users can issue this command.</p>

Example usage:

To configure the greeting message:


```
DGS-3627:admin# config greeting_message
```

```
Command: config greeting_message
```

```
Greeting Messages Editor
```

```
=====
                        DGS-3627 Gigabit Ethernet Switch
                        Command Line Interface

                        Firmware: Build 2.80.B31
                        Copyright(C) 2010 D-Link Corporation. All rights reserved.
=====
```

<Function Key>		<Control Key>	
Ctrl+C	Quit without save	left/right/	
Ctrl+W	Save and quit	up/down	Move cursor
		Ctrl+D	Delete line
		Ctrl+X	Erase all setting
		Ctrl+L	Reload original setting

show greeting_message

Purpose	Used to view the currently configured greeting message configured on the Switch.
Syntax	show greeting_message
Description	This command is used to view the currently configured greeting message on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To view the currently configured greeting message:

```
DGS-3627:admin# show greeting_message
```

```
Command: show greeting_message
```

```
=====
                        DGS-3627 Gigabit Ethernet Switch
                        Command Line Interface

                        Firmware: Build 2.80.B31
                        Copyright(C) 2010 D-Link Corporation. All rights reserved.
=====
```

```
DGS-3627:admin#
```

BASIC IP COMMANDS

The Basic IP commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create ipif	<ipif_name 12> {<network_address>} <vlan_name 32> { secondary state [enable disable] proxy_arp [enable disable] {local [enable disable]}}
config ipif	<ipif_name 12> [{ ipaddress <network_address> vlan <vlan_name 32> state [enable disable] proxy_arp [enable disable] {local [enable disable]}}] bootp dhcp ipv6 ipv6address <ipv6networkaddr> ip_mtu <value 512-1712> dhcpv6_client [enable disable] ip_directed_broadcast [enable disable]]
enable ipif	[<ipif_name 12> all]
disable ipif	[<ipif_name 12> all]
enable ipif_ipv6_link_local_auto	[<ipif_name 12> all]
disable ipif_ipv6_link_local_auto	[<ipif_name 12> all]
show ipif	{<ipif_name 12>}
show ipif_ipv6_link_local_auto	{<ipif_name 12>}
delete ipif	[<ipif_name 12> {ipv6address <ipv6networkaddr>} all]

Each command is listed, in detail, in the following sections.

create ipif

Purpose	This command creates a L3 interface. □
Syntax	create ipif <ipif_name 12> {<network_address>} <vlan_name 32> { secondary state [enable disable] proxy_arp [enable disable] {local [enable disable]}}
Description	<p>This interface can be configured with IPv4 or IPv6 address. Currently, it has a restriction. An interface can have only one IPv4 address defined. But it can have multiple IPv6 addresses defined. Thus, the multinetting configuration of IPv4 must be done through creation of a secondary interface on the same VLAN, instead of directly configuring multiple IPv4 addresses on the same interface. Configuration of IPv6 address must be done through the command config ipif.</p> <p>Note that for IPv4 case, the multicast routing protocol state in secondary IP interfaces must follow master IP interface's state. For example, if dvmrp state in master IP interface is enabled, the secondary IP interfaces need to be the same.</p>
Parameters	<p><i>ipif_name</i> - The name of the interface.</p> <p><i>network_address</i> - IPv4 network address (xxx.xxx.xxx.xxx/xx). It specifies a host address and length of network mask.</p> <p><i>vlan_name</i> - The name of a vlan.</p> <p><i>secondary</i> - IPv4 secondary interface to be created.</p> <p><i>state</i> - State of interface.</p> <p><i>proxy_arp</i> - Enable/disable of proxy ARP function. It is for IPv4 function. Default: Disabled.</p> <p><i>local</i> - This setting controls whether the system provides the proxy reply for the ARP packets destined for IP address located in the same interface as the received interface. When proxy ARP is enabled for an interface, the system will do the proxy reply for the ARP packets destined for IP address located in a different interface. For ARP packets destined for IP</p>

create ipif

address located in the same interface, the system will check this setting to determine whether to reply. Default: Disabled.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To create an interface Intface_1 on vlan vlan_1.

```
DGS-3627:admin# create ipif Intface_1 vlan_1
```

```
Command: create ipif Intface_1 vlan_1
```

```
Success.
```

```
DGS-3627:admin#
```

config ipif

Purpose Configures the parameters for a L3 interface.

Syntax **config ipif <ipif_name 12> [{ ipaddress <network_address> | vlan <vlan_name 32> | state [enable|disable] | proxy_arp [enable|disable] {local [enable|disable]}}] bootp | dhcp | ipv6 ipv6address <ipv6networkaddr> | ip_mtu <value 512-1712> | dhcpv6_client [enable | disable] | ip_directed_broadcast [enable | disable]]**

Description For IPv4, only the system interface can be specified for the way to get the IP address. If the mode is set to BOOTP or DHCP, then the IPv4 address will be obtained through the operation of protocols. The manual configuration of the IP address will be of no use. If you configures the mode to the BOOTP or DHCP first, and configure IP address later, the mode will be changed to manual configured mode. For IPv6, multiple addresses can defined on the same L3 interface. For IPv4, multi-netting must be done by creation of a secondary interface. Note that IPv6 address is not allowed to be configured on a secondary interface.

Only the system interface is allowed to set to DHCP mode

Parameters

- ipif_name* - The name of the interface.
- network_address* - Configures a network on an ipif. The address should specify a host address and length of network mask. Since an ipif can have only one IPv4 address, the new configured address will overwrite the original one.
- vlan* - Name of the vlan where the IPIF is operated.
- proxy_arp* - Enable/disable of proxy ARP function. It is for IPv4 function. Default: Disabled.
- local* - This setting controls whether the system provides the proxy reply for the ARP packets destined for IP address located in the same interface as the received interface. When proxy ARP is enabled for an interface, the system will do the proxy reply for the ARP packets destined for IP address located in a different interface. For ARP packets destined for IP address located in the same interface, the system will check this setting to determine whether to reply.
- bootp* - Use BOOTP to obtain the IPv4 address.
- dhcp* - Use DHCP to obtain the IPv4 address.
- ipv6networkaddr* - IPv6 network address. The address should specify a host address and length of network prefix. There can be multiple V6 addresses defined on an interface. Thus, as a new address is defined, it is added on this ipif.
- state* - Enable or disable state of the ipif.
- ip_mtu* - Specifies the IP layer mtu. The range is 512-1712. The default setting is 1500 bytes.
- dhcpv6_client* - See below:
 - enable* - Enable the DHCPv6 client state of the interface.
 - disable* - Disable the DHCPv6 client state of the interface.
- ip_directed_broadcast* - See below:

config ipif

enable - Enabled the IP directed-broadcast state of the interface.
disable - Disabled the IP directed-broadcast state of the interface.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To configure an interface's IPv4 network address:

```
DGS-3627:admin# config ipif Interface_1 ipaddress 10.0.0.1/8
Command: config ipif Interface_1 ipaddress 10.0.0.1/8
```

Success

```
DGS-3627:admin#
```

enable ipif

Purpose Enable the admin state for an interface.

Syntax **enable ipif [<ipif_name 12> | all]**

Description Enable the state for an IPIF.

When the state is enabled, the IPv4 processing will be started when the IPv4 address is configured on the IPIF. The IPv6 processing will be started when the IPv6 address is explicitly configured on the IPIF.

Parameters *ipif_name* - Specifies the name of the IP interface used.

all - Specifies that all the interfaces will be enabled.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

Enable the state for an interface.

```
DGS-3627:admin# enable ipif Interface_1
Command: enable ipif Interface_1
```

Success

```
DGS-3627:admin#
```

disable ipif

Purpose Disables interface's admin state.

Syntax **disable ipif [<ipif_name 12> | all]**

Description Disables the state for an IP interface.

Parameters *ipif_name* - Specifies the name of the IP interface used.

all - Specifies that all the interfaces will be disabled.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To disable an interface's state.

```
DGS-3627:admin# disable ipif Intface_1
```

```
Command: disable ipif Intface_1
```

```
Success
```

```
DGS-3627:admin#
```

enable ipif_ipv6_link_local_auto

Purpose	Enable the auto configuration of link local address when no IPv6 address is configured.
Syntax	enable ipif_ipv6_link_local_auto [<ipif_name 12> all]
Description	Enable the auto configuration of link local address when there are no IPv6 addresses explicitly configured. When an IPv6 address is explicitly configured, the link local address will be automatically configured, and the IPv6 processing will be started. When there is no IPv6 address explicitly configured, by default, link local address is not configured and the IPv6 processing will be disabled. By enable this automatic configuration, the link local address will be automatically configured and IPv6 processing will be started.
Parameters	<i>ipif_name</i> - Specifies the name of the IPv6 interface used. <i>all</i> - Specifies that all the interfaces will be enabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Enable the automatic configuration of link local address for an interface:

```
DGS-3627:admin# enable ipif_ipv6_link_local_auto Intface_1
```

```
Command: enable ipif_ipv6_link_local_auto Intface_1
```

```
Success
```

```
DGS-3627:admin#
```

disable ipif_ipv6_link_local_auto

Purpose	Disable the auto configuration of link local address when no IPv6 address are configured.
Syntax	disable ipif_ipv6_link_local_auto [<ipif_name 12> all]
Description	Disable the auto configuration of link local address when no IPv6 address is explicitly configured.
Parameters	<i>ipif_name</i> - Specifies the name of the IPv6 interface used. <i>all</i> - Specifies that all the interfaces will be disabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Disable the automatic configuration of link local address for an interface:

```
DGS-3627:admin# disable ipif_ipv6_link_local_auto Intface_1
```

```
Command: disable ipif_ipv6_link_local_auto Intface_1
```

```
Success
```

```
DGS-3627:admin#
```

show ipif

Purpose	This command is used to display the interface's information.
Syntax	show ipif {<ipif_name 12>}
Description	To show an interface's information. Configuration for both IPv4 and IPv6' addresses will be displayed.
Parameters	<i>ipif_name</i> - Specifies the name of the IP interface used.
Restrictions	None.

Example usage:

Show interface's information:

```
DGS-3627:admin# show ipif
Command: show ipif

IP Interface           : n6
VLAN Name              : 6
Interface Admin State  : Enabled
DHCPv6 Client State   : Disabled
IPv4 Address           : 192.168.6.105/24 (Manual) Primary
Proxy ARP              : Disabled (Local : Disabled)
IP Directed Broadcast  : Disabled
IPv6 Link-Local Address : FE80::202:3FF:FE03:202/128
IPv6 Global Unicast Address : 3006::105/64 (Manual)
IP MTU                 : 1500

DGS-3627:admin#
```

show ipif_ipv6_link_local_auto

Purpose	Display the link local address automatic configuration state.
Syntax	show ipif_ipv6_link_local_auto {<ipif_name 12>}
Description	Display the link local address automatic configuration state.
Parameters	<i>ipif_name</i> - Specifies the name of the IP interface used.
Restrictions	None.

Example usage:

Show interface's information:

```
DGS-3627:admin# show ipif_ipv6_link_local_auto
Command: show ipif_ipv6_link_local_auto

IPIF : System           Automatic Link Local Address: Enabled.
IPIF : FirstFloor       Automatic Link Local Address: Disabled.

DGS-3627:admin#
```

delete ipif

Purpose	Delete an interface.
---------	----------------------

delete ipif

Syntax	delete ipif [<ipif_name 12> {ipv6address <ipv6networkaddr>} all]
Description	Delete an interface or all the interfaces. Note that the system interface can not be deleted. By using this command, a IPv6 address can be deleted from the ipif.
Parameters	<i>ipif_name</i> - Specifies the name of the IP interface. <i>all</i> - All ipif except the System IP interface will be deleted. <i>ipv6networkaddr</i> - Specifies the IPv6 network address.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete interface Intface_1:

```
DGS-3627:admin# delete ipif Intface_1
Command: delete ipif Intface_1

Success.

DGS-3627:admin#
```

BPDU TUNNELING COMMANDS

The BPDU Tunneling commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config bpdu_tunnel	ports [<portlist> all] type [tunnel {stp gvrp} (1) uplink none]
show bpdu_tunnel	
enable bpdu_tunnel	
disable bpdu_tunnel	

Each command is listed, in detail, in the following sections.

config bpdu_tunnel

Purpose	Used to config BPDU Tunneling ports setting.
Syntax	config bpdu_tunnel ports [<portlist> all] type [tunnel {stp gvrp} (1) uplink none]
Description	<p>BPDU tunneling is used to tunnel layer 2 protocol packet.</p> <p>This command is used to config BPDU Tunneling ports type</p> <p>When the device is operated with QinQ enabled, DA will be replaced by the tunnel multicast address, and the BPDU will be tagged with the tunnel VLAN based on the QinQ VLAN configuration and the tunnel/uplink setting.</p> <p>When the device is operated without QinQ enabled, the BPDU will have its DA replaced by the tunnel multicast address and be transmitted out based on the VLAN configuration and the tunnel/uplink setting.</p> <p>The tunnel multicast address for STP BPDU is 01-05-5d-00-00-00. The tunnel multicast address for GVRP BPDU is 01-05-5d-00-00-21.</p>
Parameters	<p><i>ports</i> - Specify the ports on which the BPDU Tunneling will be enabled or disabled.</p> <p><i>type</i> - Specify the type on the ports.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To config BPDU_Tunneling tunnel ports:

```
DGS-3627:admin# config bpdu_tunneling ports 1-4 type tunnelstp
Command: config bpdu_tunneling ports 1-4 type tunnel stp

Success.

DGS-3627:admin#
```


show bpdu_tunnel

Purpose	Used to show BPDU Tunneling global state, tunnel destination MAC address and ports state.
Syntax	show bpdu_tunnel
Description	This command is used to show BPDU Tunneling global state, tunnel destination MAC address and ports state.
Parameters	None.
Restrictions	None,

Example usage:

To show BPDU tunneling state of all ports:

```
DGS-3627:admin# show bpdu_tunnel
Command: show bpdu_tunnel

BPDU Tunnel                : Enabled
STP Tunnel Multicast Address : 01-05-5d-00-00-00
STP Tunnel Ports           : 1,2
GVRP Tunnel Multicast Address : 01-05-5d-00-00-21
GVRP Tunnel Port          : 5,6
Uplink Ports               : 3,4

DGS-3627:admin#
```

enable bpdu_tunnel

Purpose	Used to enable the BPDU Tunneling function.
Syntax	enable bpdu_tunnel
Description	Enable the BPDU Tunneling function. By default, BPDU Tunneling is disable.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the BPDU Tunneling function:

```
DGS-3627:admin# enable bpdu_tunnel
Command: enable bpdu_tunnel

Success.

DGS-3627:admin#
```

disable bpdu_tunnel

Purpose	Used to disable the BPDU Tunneling function.
Syntax	disable bpdu_tunnel
Description	Disable the BPDU Tunneling function.
Parameters	None.

disable bpdu_tunnel

Restrictions	Only Administrator and Operator-level users can issue this command.
--------------	---

Example usage:

To disable the BPDU Tunneling function:

```
DGS-3627:admin# disable bpdu_tunnel
Command: disable bpdu_tunnel

Success.

DGS-3627:admin#
```

802.1X COMMANDS

The Switch implements the server-side of the IEEE 802.1X Port-based and MAC-based Network Access Control. This mechanism is intended to allow only authorized users, or other network devices, access to network resources by establishing criteria for each port on the Switch that a user or network device must meet before allowing that port to forward or receive frames.

The 802.1X commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
enable 802.1x	
disable 802.1x	
create 802.1x user	< username 15 >
delete 802.1x user	< username 15 >
show 802.1x user	
config 802.1x auth_protocol	[local radius_eap]
config 802.1x fwd_pdu system	[enable disable]
config 802.1x fwd_pdu ports	[< portlist > all] [enable disable]
config 802.1x authorization network radius	[enable disable]
show 802.1x	{ [auth_state auth_configuration] ports { < portlist > } }
config 802.1x capability ports	[< portlist > all] [authenticator none]
config 802.1x max_users	[<value 1 – 4000> no_limit]
config 802.1x auth_parameter ports	[<portlist> all][default [{ direction [both in]] port_control [force_unauth auto force_auth] quiet_period < sec 0-65535> tx_period < sec 1-65535> supp_timeout < sec 1-65535> server_timeout < sec 1-65535> max_req < value 1-10> reauth_period < sec 1-65535> enable_reauth [enable disable] max_users [< value 1 – 128 > no_limit]} (1)]
config 802.1x auth_mode	[port_based mac_based]
config 802.1x init	[port_based ports [< portlist all >] mac_based ports [< portlist > all] { mac_address < macaddr > }]
config 802.1x reauth	[port_based ports [< portlist all >] mac_based ports [< portlist > all] { mac_address < macaddr > }]
create 802.1x guest_vlan	{ < vlan_name 32 > }
delete 802.1x guest_vlan	{ < vlan_name 32 > }
config 802.1x guest_vlan ports	[< portlist > all] state [enable disable]
show 802.1x guest_vlan	
config radius add	< server_index 1-3 > [< server_ip > < ipv6addr >] key < passwd 32 > [default { auth_port < udp_port_number 1-65535 > acct_port < udp_port_number 1-65535 > timeout < int 1-255 > retransmit < int 1-20 > } (1)]
config radius delete	< server_index 1-3 >
config radius	<server_index 1-3> { ipaddress [<server_ip> <ipv6addr>] key <passwd 32> auth_port [<udp_port_number> default] acct_port [<udp_port_number> default] timeout [<int 1-255> default] retransmit [<int 1-20> default]} (1)
show radius	
show auth_statistics	{ports [<portlist> all]}
show auth_diagnostics	{ports [<portlist> all]}
show auth_session_statistics	{ports [<portlist> all]}
show auth_client	
show acct_client	
config accounting service	[network shell system] state [enable disable]
show accounting service	

Each command is listed, in detail, in the following sections.

enable 802.1x

Purpose	Used to enable the 802.1X function.
Syntax	enable 802.1x
Description	The enable 802.1x command enables 802.1X function.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Used to enable the 802.1X function:

```
DGS-3627:admin#enable 802.1x
Command: enable 802.1x

Success.

DGS-3627:admin#
```

disable 802.1x

Purpose	Used to disable the 802.1X function.
Syntax	disable 802.1x
Description	The disable 802.1x command disable 802.1X function.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the 802.1X function:

```
DGS-3627:admin# disable 802.1x
Command: disable 802.1x

Success.

DGS-3627:admin#
```

create 802.1x user

Purpose	Used to create an 802.1X user.
Syntax	create 802.1x user < username 15 >
Description	The create 802.1x user command create an 802.1X user.
Parameters	<i>username</i> - Specifies adding user name.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create an 802.1x user “test”:

```
DGS-3627:admin# create 802.1x user test
Command: create 802.1x user test

Enter a case-sensitive new password:
Enter the new password again for confirmation:

Success.

DGS-3627:admin#
```

delete 802.1x user

Purpose	Used to delete an 802.1X user.
Syntax	delete 802.1x user < username 15 >
Description	The delete 802.1x user command delete an 802.1X user.
Parameters	<i>username</i> - Specifies the adding user name.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete user “test”:

```
DGS-3627:admin# delete 802.1x user test
Command: delete 802.1x user test

Are you sure to delete the user?(y/n)

Success.

DGS-3627:admin#
```

show 802.1x user

Purpose	Used to display the 802.1X user.
Syntax	show 802.1x user
Description	The show 802.1x user command displays the 802.1X user account information.
Parameters	None.
Restrictions	None.

Example usage:

To display the 802.1X user information:

```
DGS-3627:admin# show 802.1x user
```

```
Command: show 802.1x user
```

```
Username      Password
-----
user1         abcds
```

```
Total Entries : 1
```

```
DGS-3627:admin#
```

config 802.1x auth_protocol

Purpose	Used to configure the 802.1X auth protocol.
Syntax	config 802.1x auth_protocol [local radius_eap]
Description	The config 802.1x auth_protocol command configures the 802.1X authentication protocol.
Parameters	<i>local</i> - Specifies the authentication protocol as local. <i>radius_eap</i> - Specifies the authentication protocol as RADIUS EAP.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the 802.1X authentication protocol to RADIUS EAP:

```
DGS-3627:admin# config 802.1x auth_protocol radius_eap
```

```
Command: config 802.1x auth_protocol radius_eap
```

```
Success.
```

```
DGS-3627:admin#
```

config 802.1x fwd_pdu system

Purpose	Used to configure forwarding of EAPOL PDU when 802.1X is disabled.
Syntax	config 802.1x fwd_pdu system [enable disable]
Description	This is a global setting to control the forwarding of EAPOL PDU. When 802.1X functionality is disabled globally or for a port, and if 802.1X fwd_pdu is enabled both globally and for the port, a received EAPOL packet on the port will be flooded in the same VLAN to those ports for which 802.1X fwd_pdu is enabled and 802.1X is disabled (globally or just for the port). The default state is disabled.
Parameters	<i>enable</i> - Enable the forwarding of EAPOL PDU. <i>disable</i> - Disable the forwarding of EAPOL PDU.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure forwarding of EAPOL PDU system state enable:

```
DGS-3627:admin# config 802.1x fwd_pdu system enable
Command: config 802.1x fwd_pdu system enable

Success.

DGS-3627:admin#
```

config 802.1x fwd_pdu ports

Purpose	Used to configure if the port will flood EAPOL PDU when 802.1X functionality is disabled.
Syntax	config 802.1x fwd_pdu ports [< portlist > all] [enable disable]
Description	This is a per port setting to control the forwarding of EAPOL PDU. When 802.1X functionality is disabled globally or for a port, and if 802.1X fwd_pdu is enabled both globally and for the port, a received EAPOL packet on the port will be flooded in the same VLAN to those ports for which 802.1X fwd_pdu is enabled and 802.1X is disabled (globally or just for the port). The default state is disabled.
Parameters	<i>ports</i> - Specifies a range of ports to be configured. <i>all</i> - All ports. <i>enable</i> - Enable forwarding EAPOL PDU receive on the ports. <i>disable</i> - Disable forwarding EAPOL PDU receive on the ports.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure 802.1X fwd_pdu for ports:

```
DGS-3627:admin# config 802.1x fwd_pdu ports 1,2 enable
Command: config 802.1x fwd_pdu ports 1,2 enable

Success.

DGS-3627:admin#
```

config 802.1x authorization network radius

Purpose	The enable or disable the acceptance of an authorized configuration.
Syntax	config 802.1x authorization network radius [enable disable]
Description	The command config 802.1x authorization attributes is used to enable or disable the acceptance of authorized configuration. When the authorization is enabled for 802.1X's RADIUS authentication, the authorized attributes assigned by the RADIUS server will be accepted if the global authorization status is enabled.
Parameters	<i>radius</i> - If specified to enable, the authorization attributes assigned by the RADIUS server will be accepted if the global authorization status is enabled. The default state is enabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

The following example will disable to accept the authorized data assigned from the RADIUS server:


```
DGS-3627:admin# config 802.1x authorization attributes radius disable
Command: config 802.1x authorization attributes radius disable

Success.

DGS-3627:admin#
```

show 802.1x

Purpose	Used to display the 802.1X state or configurations.
Syntax	show 802.1x { [auth_state auth_configuration] ports { < portlist > } }
Description	The show 802.1x command displays the 802.1X state or configurations.
Parameters	<p><i>auth_state</i> - Used to display 802.1X authentication state machine of some or all ports</p> <p><i>auth_configuration</i> - Used to display 802.1X configurations of some or all ports.</p> <p><i>portlist</i> - Specifies a range of ports to be displayed.</p> <p>If no port is specified, all ports will be displayed.</p> <p>If no parameter is specified, the 802.1X system configurations will be displayed.</p>
Restrictions	None.

Example usage:

To display the 802.1X states:

```
DGS-3627:admin# show 802.1x auth_state ports 1-4
Command: show 802.1x auth_state ports 1-4
Status:  A - Authorized; U - Unauthorized; (P): Port-Based 802.1X
```

Port	MAC Address	PAE State	Backend State	Status	VID	Priority
1	00-00-00-00-00-01	Authenticated	Idle	A	4004	3
1	00-00-00-00-00-02	Authenticated	Idle	A	1234	-
1	00-00-00-00-00-04	Authenticating	Response	U	-	-
2	-	(P) Authenticating	Request	U	-	-
3	-	(P) Connecting	Idle	U	-	-
4	-	(P) Held	Idle	U	-	-

```
Total Authenticating Hosts : 2
Total Authenticated Hosts  : 2

DGS-3627:admin#
```

To display the 802.1X system level configurations:

```
DGS-3627:admin# show 802.1x
Command: show 802.1x
```

802.1X	: Enabled
Authentication Mode	: Port_based
Authentication Protocol	: Radius_Eap
Forward EAPOL PDU	: Enabled
Max Users	: no_limit
RADIUS Authorization	: Enabled

```
DGS-3627:admin#
```

To display the 802.1X port level configurations:

```
DGS-3627:admin# show 802.1x auth_configuration ports 1:1
Command: show 802.1x auth_configuration ports 1:1

Port number                : 1:1
Capability                  : None
AdminCrldir                : Both
OpenCrldir                 : Both
Port Control                : Auto
QuietPeriod                 : 60 sec
TxPeriod                   : 30 sec
SuppTimeout                 : 30 sec
ServerTimeout              : 30 sec
MaxReq                      : 2 times
ReAuthPeriod               : 3600 sec
ReAuthenticate              : Disabled
Forward EAPOL PDU On Port  : Enabled
Max Users On Port          : 10

DGS-3627:admin#
```

config 802.1x capability

Purpose	Used to configure the port capability.
Syntax	config 802.1x capability ports [< portlist > all] [authenticator none]
Description	The config 802.1x capability command configures the port capability.
Parameters	<i>portlist</i> - Specifies a range of ports to be configured. <i>all</i> - Specifies all ports to be configured. <i>authenticator</i> - The port that wishes to enforce authentication before allowing access to services that are accessible via that port adopts the authenticator role. <i>none</i> - Disable authentication on the specified ports.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the port capability:

```
DGS-3627:admin# config 802.1x capability ports 1:1-1:10 authenticator
Command: config 802.1x capability ports 1:1-1:10 authenticator

Success.

DGS-3627:admin#
```

config 802.1x max_users

Purpose	Used to configure the maximum number of users that can be learned via 802.1X authentication.
Syntax	config 802.1x max_users [<value 1 – 4000> no_limit]
Description	The setting is a global limitation on the maximum number of users that can be learned via 802.1X authentication. In addition to the global limitation, maximum user for per port is also limited. It is specified by config 802.1x auth_parameter command.

config 802.1x max_users

Parameters	<i>max_users</i> - Specifies the maximum number of users. The range is 1 to 4000. By default, there is no limit on the maximum users.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure 802.1X number of users to be limited to 200:

```
DGS-3627:admin# config 802.1x max_users 200
```

```
Command: config 802.1x max_users 200
```

Success.

```
DGS-3627:admin#
```

config 802.1x auth_parameter

Purpose	Used to configure the parameters that control the operation of the authenticator associated with a port.
Syntax	config 802.1x auth_parameter ports [<portlist> all][default [{ direction [both in] port_control [force_unauth auto force_auth] quiet_period < sec 0-65535> tx_period < sec 1-65535> supp_timeout < sec 1-65535> server_timeout < sec 1-65535> max_req < value 1-10> reauth_period < sec 1-65535> enable_reauth [enable disable] max_users [<value 1 – 128> no_limit]} (1)]
Description	The config 802.1x auth_parameter command configures the parameters that control the operation of the authenticator associated with a port.
Parameters	<p><i>portlist</i> - Specifies a range of ports to be configured.</p> <p><i>all</i> - All ports.</p> <p><i>default</i> - Sets all parameter to be default value.</p> <p><i>direction</i> - Sets the direction of access control.</p> <p><i>both</i> - For bidirectional access control.</p> <p><i>in</i> - For unidirectional access control.</p> <p><i>port_control</i> - You can force a specific port to be unconditionally authorized or unauthorized by setting the parameter of port_control to be force_authorized or force_unauthorized. Besides, the controlled port will reflect the outcome of authentication if port_control is auto.</p> <p><i>force_authorized</i> - Force a specific port to be unconditionally authorized.</p> <p><i>auto</i> - The controlled port will reflect the outcome of authentication.</p> <p><i>force_unauthorized</i> - Force a specific port to be unconditionally unauthorized.</p> <p><i>quiet_period</i> - It is the initialization value of the quietWhile timer. The default value is 60 seconds and can be any value among 0 to 65535.</p> <p><i>tx_period</i> - It is the initialization value of the txWhen timer. The default value is 30 seconds and can be any integer value among 1 to 65535.</p> <p><i>supp_timeout</i> - The initialization value of the aWhile timer when timing out the supplicant. Its default value is 30 seconds and can be any integer value among 1 to 65535.</p> <p><i>server_timeout</i> - The initialization value of the aWhile timer when timing out the authentication server. Its default value is 30 seconds and can be any integer value among 1 to 65535.</p> <p><i>max_req</i> - The maximum number of times that the authentication PAE state machine will retransmit an EAP Request packet to the supplicant. Its default value is 2 and can be any integer number among 1 to 10.</p> <p><i>reauth_period</i> - It's a nonzero number of seconds, which is used to be the re-authentication timer. The default value is 3600.</p>

config 802.1x auth_parameter

enable_reauth - You can enable or disable the re-authentication mechanism for a specific port.

max_users - Specifies per port maximum number of users.

The range is 1 to 128.

The default value is 16.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the parameters that control the operation of the authenticator associated with a port:

```
DGS-3627:admin# config 802.1x auth_parameter ports 1:1-1:20 direction both
Command: config 802.1x auth_parameter ports 1:1-1:20 direction both
```

Success.

```
DGS-3627:admin#
```

config 802.1x auth_mode

Purpose Used to configure 802.1X authentication mode.

Syntax **config 802.1x auth_mode [port_based | mac_based]**

Description The config 802.1x auth_mode command configures the authentication mode.

Parameters *port_based* - Configure the authentication as port based mode.

mac_based - Configure the authentication as MAC based mode.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the authentication mode:

```
DGS-3627:admin# config 802.1x auth_mode port_based
Command: config 802.1x auth_mode port_based
```

Success.

```
DGS-3627:admin#
```

config 802.1x init

Purpose Used to initialize the authentication state machine of some or all ports.

Syntax **config 802.1x init [port_based ports [< portlist | all >] | mac_based ports [< portlist > | all] { mac_address < macaddr > }]**

Description The config 802.1x init command used to initialize the authentication state machine of some or all.

Parameters *port_based* - Configure the authentication as port based mode.

mac_based - Configure the authentication as MAC based mode.

portlist - Specifies a range of ports to be configured.

all - All ports.

mac_address - MAC address of client.

config 802.1x init

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To initialize the authentication state machine of some or all:

```
DGS-3627:admin# config 802.1x init port_based ports all
Command: config 802.1x init port_based ports all

Success.

DGS-3627:admin#
```

config 802.1x reauth

Purpose	Used to re-authenticate the device connected to the port.
Syntax	config 802.1x reauth [port_based ports [< portlist all >] mac_based ports [< portlist > all] { mac_address < macaddr > }]
Description	The config 802.1x reauth command re-authenticates the device connected to the port. During the re-authentication period, the port status remains authorized until failed re-authentication.
Parameters	<i>port_based</i> - Configure the authentication as port based mode. <i>mac_based</i> - Configure the authentication as MAC based mode. <i>portlist</i> - Specifies a range of ports to be configured. <i>all</i> - All ports. <i>mac_address</i> - MAC address of client.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To re-authenticate the device connected to the port:

```
DGS-3627:admin# config 802.1x reauth port_based ports all
Command: config 802.1x reauth port_based ports all

Success.

DGS-3627:admin#
```

create 802.1x guest_vlan

Purpose	Used to assign a static VLAN to be guest VLAN.
Syntax	create 802.1x guest_vlan { < vlan_name 32 > }
Description	The create 802.1x guest_vlan command will assign a static VLAN to be guest VLAN. The specific VLAN which assigned to guest VLAN must be existed. The specific VLAN which assigned to guest VLAN can't be deleting.
Parameters	<vlan_name 32> - Specify the static VLAN to be guest VLAN.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a VLAN named “guestVLAN” as 802.1X guest VLAN:

```
DGS-3627:admin# create 802.1x guest_vlan guestVLAN
Command: create 802.1x guest_vlan guestVLAN

Success.

DGS-3627:admin#
```

delete 802.1x guest_vlan

Purpose	Used to delete guest VLAN configuration.
Syntax	delete 802.1x guest_vlan { < vlan_name 32 > }
Description	The delete 802.1x guest_vlan command will delete guest VLAN setting, but not delete the static VLAN. All ports which enabled guest VLAN will remove to original VLAN after deleted guest VLAN.
Parameters	<vlan_name 32> - Specify the static VLAN to be guest VLAN.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the guest VLAN named “guestVLAN”:

```
DGS-3627:admin# delete 802.1x guest_vlan guestVLAN
Command: delete 802.1x guest_vlan guestVLAN

Success.

DGS-3627:admin#
```

config 802.1x guest_vlan

Purpose	Used to configure guest VLAN settings.
Syntax	config 802.1x guest_vlan ports [< portlist > all] state [enable disable]
Description	The config 802.1x guest_vlan command configures guest VLAN setting. If the specific port state is changed from enabled state to disable state, this port will move to its original VLAN.
Parameters	<i>ports</i> - A range of ports enable or disable guest VLAN function. <i>state</i> - Specify the guest VLAN port state of the configured ports. <i>enable</i> - join the guest VLAN. <i>disable</i> - remove from guest VLAN.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Enable on port 1 – 8 to configure 802.1X guest VLAN:

```
DGS-3627:admin# config 802.1x guest_vlan ports 1-8 state enable
Command: config 802.1x guest_vlan ports 1-8 state enable

Warning! GVRP of the ports were disabled!

Success.

DGS-3627:admin#
```

show 802.1x guest_vlan

Purpose	Used to show guest VLAN setting.
Syntax	show 802.1x guest_vlan
Description	The show guest_vlan command allows you to show the information of guest VLANs.
Parameters	None.
Restrictions	None.

Example usage:

To show 802.1X guest VLAN on the switch:

```
DGS-3627:admin# show 802.1x guest_vlan
Command: show 802.1x guest_vlan

Guest VLAN Setting
-----
Guest VLAN   : guest
Enable Guest VLAN Ports      : 1-10

DGS-3627:admin#
```

config radius add

Purpose	Use to add a new RADIUS server. The server with lower index has higher authenticative priority.
Syntax	config radius add < server_index 1-3 > [< server_ip > < ipv6addr >] key < passwd 32 > [default { auth_port < udp_port_number 1-65535 > acct_port < udp_port_number 1-65535 > timeout < int 1-255 > retransmit < int 1-20 > } (1)]
Description	The “config radius add” command adds a new RADIUS server.
Parameters	<p><i>server_index</i> - RADIUS server index.</p> <p><i>server_ip</i> - The IP address of the RADIUS server.</p> <p><i>ipv6addr</i> - The IPv6 address of the RADIUS server.</p> <p><i>passwd</i> - The key pre-negotiated between switch and the RADIUS server. It is used to encrypt user’s authentication data before being transmitted over internet. The maximum length of the key is 32.</p> <p><i>default</i> - Sets the authentication UDP port number to 1812 accounting UDP port number to 1813, timeout to 5 seconds and retransmit to 2.</p> <p><i>auth_port</i> - Specifies the UDP port number which is used to transmit RADIUS authentication data between the switch and the RADIUS server. The range is 1 to 65535.</p> <p><i>acct_port</i> - Specifies the UDP port number which is used to transmit RADIUS accounting statistics between the switch and the RADIUS server. The range is 1 to 65535.</p> <p><i>timeout</i> - The time in second for waiting server reply. Default value is 5 seconds.</p> <p><i>retransmit</i> - The count for re-transmitting. Default value is 2.</p>

config radius add

Restrictions	Only Administrator and Operator-level users can issue this command.
--------------	---

Example usage:

To add a new RADIUS server:

```
DGS-3627:admin# config radius add 1 10.48.74.121 key dlink default
Command: config radius add 1 10.48.74.121 key dlink default

Success.

DGS-3627:admin#
```

config radius delete

Purpose	Used to delete a RADIUS server.
Syntax	config radius delete < server_index 1-3 >
Description	The config radius delete command delete a RADIUS server.
Parameters	<i>server_index</i> - RADIUS server index.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete a radius server:

```
DGS-3627:admin# config radius delete 1
Command: config radius delete 1

Success.

DGS-3627:admin#
```

config radius

Purpose	Used to configure a RADIUS server.
Syntax	config radius <server_index 1-3> { ipaddress [<server_ip> <ipv6addr>] key <passwd 32> auth_port [<udp_port_number> default] acct_port [<udp_port_number> default] timeout [<int 1-255> default] retransmit [<int 1-20> default] } (1)
Description	The config radius command configures a RADIUS server.
Parameters	<p><i>server_index</i> - RADIUS server index.</p> <p><i>server_ip</i> - The IP address of the RADIUS server.</p> <p><i>ipv6addr</i> - The IPv6 address of the RADIUS server</p> <p><i>passwd</i> - The key pre-negotiated between switch and RADIUS server. It is used to encrypt user's authentication data before being transmitted over internet. The maximum length of the key is 32.</p> <p><i>auth_port</i> - Specifies the UDP port number which is used to transmit RADIUS authentication data between the switch and the RADIUS server. The range is 1 to 65535. Default value is 1812.</p> <p><i>acct_port</i> - Specifies the UDP port number which is used to transmit RADIUS accounting statistics between the switch and the RADIUS server. The range is 1 to 65535. Default value</p>

config radius

is 1813.

timeout - The time in second for waiting server reply. Default value is 5 seconds.

retransmit - The count for re-transmitting. Default value is 2.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To configure a radius server:

```
DGS-3627:admin# config radius server 1 auth_port 60
```

```
Command: config radius server 1 auth_port 60
```

```
Success.
```

```
DGS-3627:admin#
```

show radius

Purpose

Used to display RADIUS server configurations.

Syntax

show radius

Description

The show radius command displays RADIUS server configurations.

Parameters

None.

Restrictions

None.

Example usage:

To display RADIUS server configurations:

```

DGS-3627:admin# show radius
Command: show radius
Time Out      : 5 seconds
Retransmit    : 2

Server 1
IP Address    : fe80:fec0:56ab:34b0:20b2:6aff:febf:7ec6
Auth-Port     : 1812
Acct-Port     : 5
Timeout       : 2
Retransmit    : 3
Key           : adfdslkfjefiefdkgjdassdwtgjk6y1w

Server 2
IP Address    : 172.18.211.71
Auth-Port     : 1812
Acct-Port     : 1813
Retransmit    : 2
Key           : 1234567

Server 3
IP Address    : 172.18.211.108
Auth-Port     : 1812
Acct-Port     : 1813
Retransmit    : 2
Key           : adfdslkfjefiefdkgjdassdwtgjk6y1w

The total entries: 3

DGS-3627:admin#

```

show auth_statistics

Purpose	Use to display information of authenticator statistics.
Syntax	show auth_statistics {ports [<portlist> all]}
Description	The show auth_statistics command displays information of authenticator statistics.
Parameters	<i>portlist</i> - Specifies a range of ports to be displayed. <i>all</i> – Specifies all ports.
Restrictions	None.

Example usage:

To display authenticator statistics information for port 1:

```

DGS-3627:admin# show auth_statistics ports 1
Command: show auth_statistics ports 1

Port number : 1

EapolFramesRx                0
EapolFramesTx                6
EapolStartFramesRx          0
EapolReqIdFramesTx          6
EapolLogoffFramesRx         0
EapolReqFramesTx            0
EapolRespIdFramesRx         0
EapolRespFramesRx           0
InvalidEapolFramesRx        0
EapLengthErrorFramesRx      0
LastEapolFrameVersion        0
LastEapolFrameSource         00-00-00-00-00-00

DGS-3627:admin#

```

show auth_diagnostics

Purpose	Used to display information of authenticator diagnostics.
Syntax	show auth_diagnostics {ports [<portlist> all]}
Description	The show auth_diagnostics command displays information of authenticator diagnostics.
Parameters	<i>portlist</i> - Specifies a range of ports to be displayed. <i>all</i> – Specifies all ports.
Restrictions	None.

Example usage:

To display authenticator diagnostics information for port 1:

```

DGS-3627:admin# show auth_diagnostics ports 1
Command: show auth_diagnostics ports 1

Port number : 1

EntersConnecting                20
EapLogoffsWhileConnecting      0
EntersAuthenticating           0
SuccessWhileAuthenticating     0
TimeoutsWhileAuthenticating    0
FailWhileAuthenticating        0
ReauthsWhileAuthenticating     0
EapStartsWhileAuthenticating   0
EapLogoffWhileAuthenticating   0
ReauthsWhileAuthenticated      0
EapStartsWhileAuthenticated    0
EapLogoffWhileAuthenticated    0
BackendResponses               0
BackendAccessChallenges        0
BackendOtherRequestsToSupplicant 0
BackendNonNakResponsesFromSupplicant 0
BackendAuthSuccesses           0
BackendAuthFails               0

DGS-3627:admin#

```

show auth_session_statistics

Purpose	Use to display information of authenticator session statistics.
Syntax	show auth_session_statistics {ports [<portlist> all]}
Description	The show auth_session_statistics command displays information of authenticator session statistics.
Parameters	<i>portlist</i> - Specifies a range of ports to be displayed. <i>all</i> – Specifies all ports.
Restrictions	None.

Example usage:

To display authenticator session statistics information for port 1:

```
DGS-3627:admin# show auth_session_statistics ports 1
Command: show auth_session_statistics ports 1

Port number : 1

SessionOctetsRx           0
SessionOctetsTx           0
SessionFramesRx           0
SessionFramesTx           0
SessionId                 0
SessionAuthenticMethod    Remote Authentication Server
SessionTime                0
SessionTerminateCause     SupplicantLogoff
SessionUserName

DGS-3627:admin#
```

show auth_client

Purpose	Use to display information of RADIUS authentication client.
Syntax	show auth_client
Description	The show auth_client command displays information of RADIUS authentication client.
Parameters	None.
Restrictions	None.

Example usage:

To display authentication client information:

```
DGS-3627:admin# show auth_client
Command: show auth_client

radiusAuthClient ==>
radiusAuthClientInvalidServerAddresses    0

radiusAuthServerEntry ==>
radiusAuthServerIndex :1

radiusAuthClientServerPortNumber          2
radiusAuthClientRoundTripTime             0
radiusAuthClientAccessRequests            0
radiusAuthClientAccessRetransmissions     0
radiusAuthClientAccessAccepts             0
radiusAuthClientAccessRejects             0
radiusAuthClientAccessChallenges          0
radiusAuthClientMalformedAccessResponses  0
radiusAuthClientBadAuthenticators         0
radiusAuthClientPendingRequests           0
radiusAuthClientPacketsDropped            0

DGS-3627:admin#
```

show acct_client

Purpose	Used to display information of RADIUS accounting client.
Syntax	show acct_client
Description	The show acct_client command displays information of RADIUS accounting client.
Parameters	None.
Restrictions	None.

Example usage:

To display information of RADIUS accounting client:

```
DGS-3627:admin# show acct_client
Command: show acct_client

radiusAcctClient ==>
radiusAcctClientInvalidServerAddresses      0

radiusAuthServerEntry ==>
radiusAccServerIndex : 1

radiusAccClientServerPortNumber            2
radiusAccClientRetransmissions              0
radiusAccClientMalformedResponses          0
radiusAccClientBadAuthenticators           0
radiusAccClientPendingRequests             0
radiusAccClientPacketsDropped              0

DGS-3627:admin#
```

config accounting service

Purpose	Used to configure the state of the specified RADIUS accounting service.
Syntax	config accounting service [network shell system] state [enable disable]
Description	The config accounting service command is used to enable or disable the specified RADIUS accounting service.
Parameters	<p><i>network</i> - Accounting service for 802.1X port access control. By default, the service is disabled.</p> <p><i>shell</i> - Accounting service for shell events: When user logs on or out the switch (via the console, Telnet, or SSH) and timeout occurs, accounting information will be collected and sent to RADIUS server. By default, the service is disabled.</p> <p><i>system</i> - Accounting service for system events: reset, reboot. By default, the service is disabled.</p> <p><i>enable</i> - Enable the specified accounting service.</p> <p><i>disable</i> - Disable the specified accounting service.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Enable it to configure accounting shell state:

```
DGS-3627:admin# config accounting service shell state enable
Command: config accounting service shell state enable

Success.

DGS-3627:admin#
```

show accounting service

Purpose	Used to show the status of RADIUS accounting services.
Syntax	show accounting service
Description	The show accounting service command displays the state for RADIUS accounting service.
Parameters	<i>portlist</i> - Specifies a range of ports to be configured.
Restrictions	None.

Example usage:

To show information of RADIUS accounting services:

```
DGS-3627:admin# show accounting service
Command: show accounting service

Accounting Service
-----
Network      : Enabled
Shell        : Enabled
System       : Enabled

DGS-3627:admin#
```

ACCESS AUTHENTICATION CONTROL COMMANDS

The TACACS / XTACACS / TACACS+ / RADIUS commands allow users to secure access to the Switch using the TACACS / XTACACS / TACACS+ / RADIUS protocols. When a user logs in to the Switch or tries to access the administrator level privilege, he or she is prompted for a password. If TACACS / XTACACS / TACACS+ / RADIUS authentication is enabled on the Switch, it will contact a TACACS / XTACACS / TACACS+ / RADIUS server to verify the user. If the user is verified, he or she is granted access to the Switch.

There are currently three versions of the TACACS security protocol, each a separate entity. The Switch's software supports the following versions of TACACS:

- a) TACACS (Terminal Access Controller Access Control System) — Provides password checking and authentication, and notification of user actions for security purposes utilizing via one or more centralized TACACS servers, utilizing the UDP protocol for packet transmission.
- b) Extended TACACS (XTACACS) — An extension of the TACACS protocol with the ability to provide more types of authentication requests and more types of response codes than TACACS. This protocol also uses UDP to transmit packets.
- c) TACACS+ (Terminal Access Controller Access Control System plus) — Provides detailed access control for authentication for network devices. TACACS+ is facilitated through Authentication commands via one or more centralized servers. The TACACS+ protocol encrypts all traffic between the Switch and the TACACS+ daemon, using the TCP protocol to ensure reliable delivery.

The Switch also supports the RADIUS protocol for authentication using the Access Authentication Control commands. RADIUS or Remote Authentication Dial In User Server also uses a remote server for authentication and can be responsible for receiving user connection requests, authenticating the user and returning all configuration information necessary for the client to deliver service through the user. RADIUS may be facilitated on this Switch using the commands listed in this section.

In order for the TACACS / XTACACS / TACACS+ / RADIUS security function to work properly, a TACACS / XTACACS / TACACS+ / RADIUS server must be configured on a device other than the Switch, called a server host and it must include usernames and passwords for authentication. When the user is prompted by the Switch to enter usernames and passwords for authentication, the Switch contacts the TACACS / XTACACS / TACACS+ / RADIUS server to verify, and the server will respond with one of three messages:

1. The server verifies the username and password, and the user is granted normal user privileges on the Switch.
2. The server will not accept the username and password and the user is denied access to the Switch.
3. The server doesn't respond to the verification query. At this point, the Switch receives the timeout from the server and then moves to the next method of verification configured in the method list.

The Switch has four built-in server groups, one for each of the TACACS, XTACACS, TACACS+ and RADIUS protocols. These built-in server groups are used to authenticate users trying to access the Switch. The users will set server hosts in a preferable order in the built-in server group and when a user tries to gain access to the Switch, the Switch will ask the first server host for authentication. If no authentication is made, the second server host in the list will be queried, and so on. The built-in server group can only have hosts that are running the specified protocol. For example, the TACACS server group can only have TACACS server hosts.

The administrator for the Switch may set up five different authentication techniques per user-defined method list (TACACS / XTACACS / TACACS+ / RADIUS / local / none) for authentication. These techniques will be listed in an order preferable, and defined by the user for normal user authentication on the Switch, and may contain up to eight authentication techniques. When a user attempts to access the Switch, the Switch will select the first technique listed for authentication. If the first technique goes through its server hosts and no authentication is returned, the Switch will then go to the next technique listed in the server group for authentication, until the authentication has been verified or denied, or the list is exhausted.

Please note that user granted access to the Switch will be granted normal user privileges on the Switch. To gain access to admin level privileges, the user must enter the **enable admin** command and then enter a password, which was previously configured by the administrator of the Switch.



NOTE: TACACS, XTACACS and TACACS+ are separate entities and are not compatible. The Switch and the server must be configured exactly the same, using the same protocol. (For example, if the Switch is set up for TACACS authentication, so must be the host server.)

The Access Authentication Control commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
enable password encryption	
disable password encryption	
create account	[admin operator user] <username 15>
config account	<username> {encrypt [plain_text sha_1] <password>}
show account	
delete account	<username>
enable authen_policy	
disable authen_policy	
show authen_policy	
create authen_login method_list_name	<string 15>
config authen_login	[default method_list_name <string 15>] method {tacacs xtacacs tacacs+ radius server_group <string 15> local none}(1)
delete authen_login method_list_name	<string 15>
show authen_login	[default method_list_name <string 15> all]
create authen_enable method_list_name	<string 15>
config authen_enable	[default method_list_name <string 15>] method {tacacs xtacacs tacacs+ radius server_group <string 15> local _enable none}(1)
delete authen_enable method_list_name	<string 15>
show authen_enable	[default method_list_name <string 15> all]
config authen application	[console telnet ssh http all] [login enable] [default method_list_name <string 15>]
show authen application	
create authen server_group	<string 15>
config authen server_group	[tacacs xtacacs tacacs+ radius <string 15>] [add delete] server_host <ipaddr> protocol [tacacs xtacacs tacacs+ radius]
delete authen server_group	<string 15>
show authen server_group	{<string 15>}
create authen server_host	<ipaddr> protocol [tacacs xtacacs tacacs+ radius] { port <int 1-65535> key [<key_string 254> none] timeout <int 1-255> retransmit <int 1-20> }
config authen server_host	<ipaddr> protocol [tacacs xtacacs tacacs+ radius] { port <int 1-65535> key [<key_string 254> none] timeout <int 1-255> retransmit <int 1-20> }
delete authen server_host	<ipaddr> protocol [tacacs xtacacs tacacs+ radius]
show authen server_host	
config authen parameter response_timeout	<int 0-255>
config authen parameter attempt	<int 1-255>
show authen parameter	
enable admin	

Command	Parameters
config admin local_enable	

Each command is listed, in detail, in the following sections.

enable password encryption

Purpose	This command is used to enable password encryption.
Syntax	enable password encryption
Description	<p>The user account configuration information will be stored in the configuration file, and can be applied to the system later.</p> <p>If password encryption is enabled, the passwords will be in encrypted form.</p> <p>When password encryption is disabled, if the user specifies the password in plain text form, the password will be in plain text form. However, if the user specifies the password in encrypted form, or if the password has been converted to encrypted form by the last enable password encryption command, the password will always be in the encrypted form and can not be reverted back to plaintext.</p>
Parameters	None
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable password encryption:

```
DGS-3627:admin# enable password encryption
Command: enable password encryption

DGS-3627:admin#
```

disable password encryption

Purpose	This command is used to disable password encryption.
Syntax	disable password encryption
Description	<p>The user account configuration information will be stored in the configuration file, and can be applied to the system later.</p> <p>If password encryption is enabled, the passwords will be in encrypted form.</p> <p>When password encryption is disabled, if the user specifies the password in plain text form, the password will be in plain text form. However, if the user specifies the password in encrypted form, or if the password has been converted to encrypted form by the last enable password encryption command, the password will always be in the encrypted form and can not be reverted back to plaintext.</p>
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable password encryption:

```
DGS-3627:admin# disable password encryption
```

```
Command: disable password encryption
```

```
DGS-3627:admin#
```

create account

Purpose	This command is used to create user accounts.
Syntax	create account [admin operator user] <username 15>
Description	The create account command is used to create user accounts. A username can be between 1 and 15 characters. The password is between 0 and 15 characters and is case sensitive. The total number of accounts supported by the Switch (including admin and user level accounts) is 8.
Parameters	<p><i>admin</i> - Specify an administrator level account. The administrator is the highest privilege level in the Switch.</p> <p><i>operator</i> - Specify an operator level account.</p> <p><i>user</i> - Specify a user level account.</p> <p><i><username 15></i> - The user name, which must be a minimum of 1 character and a maximum of 15 characters.</p>
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To create the admin-level user "alpha":

```
DGS-3627:admin# create account admin alpha
```

```
Command: create account admin alpha
```

```
Enter a case-sensitive new password:****
```

```
Enter the new password again for confirmation:****
```

```
Success.
```

```
DGS-3627:admin#
```

config account

Purpose	This command is used to configure user accounts.
Syntax	config account <username> {encrypt [plain_text sha_1] <password>}
Description	<p>When the password information is not specified in the command, the system will prompt the user to input the password interactively. In this case, the user can only input a plain text password.</p> <p>If the user specifies a password in the command, the user can select to input the password in plain text form or in encrypted form. The encryption algorithm is based on SHA-1.</p>
Parameters	<p><i><username></i> - Specify the name of the account. The account must already be defined.</p> <p><i>plain_text</i> - Specify the password in plain text form.</p> <p><i>sha_1</i> - Specify the password in SHA-1 encrypted form.</p> <p><i>password</i> - The password for the user account. The length of a password in plain-text form and encrypted form are different. For a plain-text form password, the password must be a minimum of 0 characters and a maximum of 15 characters. For an encrypted form password, the length is fixed to 35 bytes long. The password is case-sensitive.</p>
Restrictions	Only Administrator level users can issue this command.

Example usage:

To configure the user password of the “alpha” account:

```
DGS-3627:admin# config account alpha
Command: config account alpha

Enter an old password:****
Enter a case-sensitive new password:****
Enter the new password again for confirmation:****

Success.

DGS-3627:admin#
```

show account

Purpose	This command is used to display the user accounts that have been created on the Switch.
Syntax	show account
Description	The show account command displays the user accounts that have been created on the Switch.
Parameters	None
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display the user accounts that have been created on the Switch:

```
DGS-3627:admin# show account
Command: show account

Current Accounts:
Username      Access Level
-----
System       User
dlink        Admin

Total Entries : 2

DGS-3627:admin#
```

delete account

Purpose	This command is used to delete an existing account.
Syntax	delete account <username>
Description	The delete account command deletes an existing account.
Parameters	<username> - Specify the name of the user that will be deleted.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To delete the user account “System”:

```
DGS-3627:admin# delete account System
Command: delete account System

Success.

DGS-3627:admin#
```

enable authen_policy

Purpose	This command is used to enable the system access authentication policy.
Syntax	enable authen_policy
Description	Enable system access authentication policy- When authentication is enabled, the device will adopt the login authentication method list to authenticate the user attempting to log in, and adopt the enable authentication method list to authenticate the enable password for promoting the user's privilege to Admin level.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable the system access authentication policy:

```
DGS-3627:admin# enable authen_policy
Command: enable authen_policy

Success.

DGS-3627:admin#
```

disable authen_policy

Purpose	This command is used to disable the system access authentication policy.
Syntax	disable authen_policy
Description	Disable system access authentication policy- When authentication is disabled, the device will adopt the local user account database to authenticate the user attempting to log in, and adopt the local enable password to authenticate the enable password for promoting the user's privilege to Admin level.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To disable the system access authentication policy:

```
DGS-3627:admin# disable authen_policy
Command: disable authen_policy

Success.

DGS-3627:admin#
```

show authen_policy

Purpose	This command is used to display if the system access authentication policy is enabled or disabled.
Syntax	show authen_policy
Description	Displays if the system access authentication policy is enabled or disabled.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display if the system access authentication policy is enabled or disabled:

```
DGS-3627:admin# show authen_policy
Command: show authen_policy

Authentication Policy : Enabled

DGS-3627:admin#
```

create authen_login method_list_name

Purpose	This command is used to create a user-defined method list of authentication methods for users attempting to log in to the Switch.
Syntax	create authen_login method_list_name <string 15>
Description	Creates a user-defined method list of authentication methods for users attempting to log into the Switch. The maximum number of supported login method lists is 8.
Parameters	<string 15> - The user-defined method list name
Restrictions	Only Administrator level users can issue this command.

Example usage:

To create a user-defined method list called "login_list_1" for users attempting to log in to the Switch:

```
DGS-3627:admin# create authen_login method_list_name login_list_1
Command: create authen_login method_list_name login_list_1

Success.

DGS-3627:admin#
```

config authen_login

Purpose	This command is used to configure a user-defined or default method list of authentication methods for users attempting to log in to the Switch.
Syntax	config authen_login [default method_list_name <string 15>] method {tacacs xtacacs tacacs+ radius server_group <string 15> local none}(1)
Description	Configures a user-defined or default method list of authentication methods for users attempting to log in to the Switch. The method sequence will affect the authentication result. For example, if the user specifies tacacs+ first, then tacacs and local, when the user tries to log in, the authentication request will be sent to the first server host in the tacacs+ built-in server group. If the first server host in the tacacs+ group is missing, the authentication request will be sent to the second server host in the tacacs+ group, and so on. If all server

config authen_login

hosts in the tacacs+ group are missing, the authentication request will be sent to the first server host in the tacacs group. If all server hosts in the tacacs group are missing, the local account database in the device will be used to authenticate the user. When a user logs in to the device successfully, using either the tacacs/xtacacs/tacacs+/radius built-in, user-defined server groups methods, or none, only the “user” privilege level will be assigned. If the user wants to access admin privilege level, the user must use the “enable admin” command to promote the privilege level. However, when the local method is used, the privilege level will depend on the account privilege level stored in the local device.

Parameters

default - Specify the default method list of authentication methods.
method_list_name - Specify the user-defined method list of authentication methods.
tacacs - Specify authentication by the built-in server group “tacacs”.
xtacacs - Specify authentication by the built-in server group “xtacacs”.
tacacs+ - Specify authentication by the built-in server group “tacacs+”.
radius - Specify authentication by the built-in server group “radius”.
server_group - Specify authentication by the user-defined server group.
local - Specify authentication by the local user account database in the device.
none - Specify no authentication.

Restrictions

Only Administrator level users can issue this command.

Example usage:

To configure a user-defined method list called “login_list_1”, that specifies a sequence of the built-in “tacacs+” server group, followed by the “tacacs” server group, and finally the local account database for users attempting to log in to the Switch:

```
DGS-3627:admin# config authen_login method_list_name login_list_1 method tacacs+ tacacs local
Command: config authen_login method_list_name login_list_1 method tacacs+ tacacs local
Success.
DGS-3627:admin#
```

delete authen_login method_list_name

Purpose

This command is used to delete a user-defined method list of authentication methods for users logging into the Switch.

Syntax

delete authen_login method_list_name <string 15>

Description

Deletes a user-defined method list of authentication methods for users attempting to log in to the Switch.

Parameters

<string 15> - The user-defined method list name.

Restrictions

Only Administrator level users can issue this command.

Example usage:

To delete the user-defined method list called “login_list_1” for users attempting to log in to the Switch:


```
DGS-3627:admin# delete authen_login method_list_name login_list_1
Command: delete authen_login method_list_name login_list_1

Success.

DGS-3627:admin#
```

show authen_login

Purpose	This command is used to display the method list of authentication methods that will be used for users attempting to log in to the Switch.
Syntax	show authen_login [default method_list_name <string 15> all]
Description	Displays the method list of authentication methods that will be used for users attempting to log in to the Switch.
Parameters	<i>default</i> - Displays the default user-defined method list for users logging into the Switch. <i>method_list_name</i> - Displays the specific user-defined method list for users logging into the Switch. <i>all</i> - Displays all the method lists for users attempting to log in to the Switch.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display the user-defined method list called "login_list_1" for users attempting to log in to the Switch:

```
DGS-3627:admin# show authen_login method_list_name login_list_1
Command: show authen_login method_list_name login_list_1

Method List Name  Priority  Method Name      Comment
-----
login_list_1     1        tacacs+          Built-in Group
                  2        tacacs           Built-in Group
                  3        mix_1            User-defined Group
                  4        local            Keyword

DGS-3627:admin#
```

create authen_enable method_list_name

Purpose	This command is used to create a user-defined method list of authentication methods for promoting a user's privilege to Admin level.
Syntax	create authen_enable method_list_name <string 15>
Description	Creates a user-defined method list of authentication methods for promoting a user's privilege to Admin level. The maximum number of supported enable method lists is 8.
Parameters	<string 15> - The user-defined method list name
Restrictions	Only Administrator level users can issue this command.

Example usage:

To create a user-defined method list called "enable_list_1" for promoting a user's privilege to Admin level:

```
DGS-3627:admin# create authen_enable method_list_name enable_list_1
Command: create authen_enable method_list_name enable_list_1

Success.

DGS-3627:admin#
```

config authen_enable

Purpose	This command is used to configure a user-defined or default method list of authentication methods for promoting a user's privilege to Admin level.
Syntax	config authen_enable [default method_list_name <string 15>] method {tacacs xtacacs tacacs+ radius server_group <string 15> local_enable none}(1)
Description	Configures a user-defined or default method list of authentication methods for promoting a user's privilege to Admin level. The sequence of methods will affect the authentication result. For example, if the sequence is tacacs+ first, followed by tacacs and local_enable, when a user tries to login, the authentication request will be sent to the first server host in the tacacs+ built-in server group. If the first server host in the tacacs+ group is missing, the authentication request will be sent to the second server host in the tacacs+ group, and so on. If all server hosts in the tacacs+ group are missing, the authentication request will be sent to the first server host in the tacacs group. If all server hosts in the tacacs group are missing, the local enable password in the device will be used to authenticate the user's password. The local enable password in the device can be configured using the "config admin local_password" CLI command.
Parameters	<p><i>default</i> - Specify the default method list of authentication methods.</p> <p><i>method_list_name</i> - Specify the user-defined method list of authentication methods.</p> <p><i>tacacs</i> - Specify authentication by the built-in server group "tacacs".</p> <p><i>xtacacs</i> - Specify authentication by the built-in server group "xtacacs".</p> <p><i>tacacs+</i> - Specify authentication by the built-in server group "tacacs+".</p> <p><i>radius</i> - Specify authentication by the built-in server group "radius".</p> <p><i>server_group</i> - Specify authentication by the user-defined server group.</p> <p><i>local_enable</i> - Specify authentication by the local enable password in the device.</p> <p><i>none</i> - Specify no authentication.</p>
Restrictions	Only Administrator level users can issue this command.

Example usage:

To configure a user-defined method list called "method_list_name" that will be used to promote a user's privilege to Admin level:

```
DGS-3627:admin# config authen_enable method_list_name enable_list_1 method tacacs+ tacacs local_enable
Command: config authen_enable method_list_name enable_list_1 method tacacs+ tacacs local_enable

Success.

DGS-3627:admin#
```

delete authen_enable method_list_name

Purpose	This command is used to delete a user-defined method list of authentication methods for promoting a user's privilege to Admin level.
Syntax	delete authen_enable method_list_name <string 15>

delete authen_enable method_list_name

Description	Deletes a user-defined method list of authentication methods for promoting a user's privilege to Admin level.
Parameters	<string 15> - The user-defined method list name
Restrictions	Only Administrator level users can issue this command.

Example usage:

To delete the user-defined method list called "enable_list_1", that is used to promote a user's privilege to Admin level:

```
DGS-3627:admin# delete authen_enable method_list_name enable_list_1
Command: delete authen_enable method_list_name enable_list_1

Success.

DGS-3627:admin#
```

show authen_enable

Purpose	This command is used to display the method list of authentication methods for promoting a user's privilege to Admin level.
Syntax	show authen_enable [default method_list_name <string 15> all]
Description	Displays the method list of authentication methods used for promoting a user's privilege to Admin level.
Parameters	<i>default</i> - Display the default user-defined method list for promoting a user's privilege to Admin level. <i>method_list_name</i> - Display the specific user-defined method list for promoting a user's privilege to Admin level. <i>all</i> - Display all the method lists for promoting a user's privilege to Admin level.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display all the method lists that are used for promoting a user's privilege to Admin level:

```
DGS-3627:admin# show authen_enable all
Command: show authen_enable all

Method List Name  Priority  Method Name      Comment
-----
enable_list_1    1         tacacs+          Built-in Group
                  2         tacacs           Built-in Group
                  3         mix_1            User-defined Group
                  4         local            Keyword

enable_list_2    1         tacacs+          Built-in Group
                  2         radius           Built-in Group

Total Entries : 2

DGS-3627:admin#
```

config authen application

Purpose	This command is used to configure login or enable method lists for all or the specified applications.
Syntax	config authen application [console telnet ssh http all] [login enable] [default method_list_name <string 15>]
Description	Configures login or enable method lists for all or the specified applications.
Parameters	<p><i>console</i> - Application: Console.</p> <p><i>telnet</i> - Application: Telnet.</p> <p><i>ssh</i> - Application: SSH.</p> <p><i>http</i> - Application: Web.</p> <p><i>all</i> - Application: Console, Telnet, SSH, and Web.</p> <p><i>login</i> - Specify the method list of authentication methods for user's attempting to log in.</p> <p><i>enable</i> - Specify the method list of authentication methods for promoting a user's privilege to Admin level.</p> <p><i>default</i> - Specify the default method list.</p> <p><i>method_list_name</i> - Specify the user-defined method list name.</p>
Restrictions	Only Administrator level users can issue this command.

Example usage:

To configure a login method list for Telnet called "login_list_1":

```
DGS-3627:admin# config authen application telnet login method_list_name login_list_1
Command: config authen application telnet login method_list_name login_list_1

Success.

DGS-3627:admin#
```

show authen application

Purpose	This command is used to display the login/enable method list for all applications.
Syntax	show authen application
Description	Displays the login/enable method list for all applications.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display the login/enable method lists for all applications:

```
DGS-3627:admin# show authen application
Command: show authen application

Application      Login Method List      Enable Method List
-----
Console          default                 default
Telnet           login_list_1           default
HTTP             default                 default

DGS-3627:admin#
```

create authen server_group

Purpose	This command is used to create a user-defined authentication server group.
Syntax	create authen server_group <string 15>
Description	Creates a user-defined authentication server group. The maximum number of supported server groups, including the built-in server groups, is 8. Each group can have a maximum of 8 server hosts..
Parameters	<string 15> - Specify the user-defined server group name.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To create a user-defined authentication server group called "mix_1":

```
DGS-3627:admin# create authen server_group mix_1
Command: create authen server_group mix_1

Success.

DGS-3627:admin#
```

config authen server_group

Purpose	This command is used to add or remove an authentication server host to or from the specified server group.
Syntax	config authen server_group [tacacs xtacacs tacacs+ radius <string 15>] [add delete] server_host <ipaddr> protocol [tacacs xtacacs tacacs+ radius]
Description	Adds or removes an authentication server host to or from the specified server group. The built-in "tacacs", "xtacacs", "tacacs+", and "radius" server groups only accept server hosts with the same protocol, but a user-defined server group can accept server hosts with different protocols. The server host must be created first by using the "create authen server_host" CLI command.
Parameters	<p><i>server_group tacacs</i> - Specify the built-in server group "tacacs".</p> <p><i>server_group xtacacs</i> - Specify the built-in server group "xtacacs".</p> <p><i>server_group tacacs+</i> - Specify the built-in server group "tacacs+".</p> <p><i>server_group radius</i> - Specify the built-in server group "radius".</p> <p><i>server_group</i> - Specify a user-defined server group.</p> <p><i>add</i> - Add a server host to a server group.</p> <p><i>delete</i> - Remove a server host from a server group.</p> <p><i>server_host</i> - Specify the server host's IP address.</p> <p><i>protocol tacacs</i> - Specify TACACS for the server host's authentication protocol</p> <p><i>protocol xtacacs</i> - Specify XTACACS for the server host's authentication protocol</p> <p><i>protocol tacacs+</i> - Specify TACACS+ for the server host's authentication protocol</p> <p><i>protocol radius</i> - Specify RADIUS for the server host's authentication protocol</p>
Restrictions	Only Administrator level users can issue this command.

Example usage:

To add an authentication server host with an IP address of 10.1.1.222 to server group "mix_1", specifying the TACACS+ protocol:

```
DGS-3627:admin# config authen server_group mix_1 add server_host 10.1.1.222 protocol
tacacs+
Command: config authen server_group mix_1 add server_host 10.1.1.222 protocol tacacs+

Success.

DGS-3627:admin#
```

delete authen server_group

Purpose	This command is used to delete a user-defined authentication server group.
Syntax	delete authen server_group <string 15>
Description	Deletes a user-defined authentication server group.
Parameters	<string 15> - Specify the user-defined server group name that will be deleted.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To delete a user-defined authentication server group called "mix_1":

```
DGS-3627:admin# delete authen server_group mix_1
Command: delete authen server_group mix_1

Success.

DGS-3627:admin#
```

show authen server_group

Purpose	This command is used to display the authentication server groups.
Syntax	show authen server_group {<string 15>}
Description	Displays the authentication server groups.
Parameters	<string 15> - Specify the built-in or user-defined server group name to display.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display all authentication server groups:

```
DGS-3627:admin# show authen server_group
```

```
Command: show authen server_group
```

```
Server Group : mix_1
```

Group Name	IP Address	Protocol
-----	-----	-----
mix_1	10.1.1.222	TACACS+
	10.1.1.223	TACACS
radius	10.1.1.224	RADIUS
tacacs	10.1.1.225	TACACS
tacacs+	10.1.1.226	TACACS+
xtacacs	10.1.1.227	XTACACS

```
Total Entries : 5
```

```
DGS-3627:admin#
```

create authen server_host

Purpose	This command is used to create an authentication server host.
Syntax	create authen server_host <ipaddr> protocol [tacacs xtacacs tacacs+ radius] { port <int 1-65535> key [<key_string 254> none] timeout <int 1-255> retransmit <int 1-20> }
Description	Creates an authentication server host. When an authentication server host is created, the IP address and protocol are the index. This means that more than one authentication protocol service can be run on the same physical host. The maximum number of supported server hosts is 16.
Parameters	<p><i>server_host</i> - Specify the server host's IP address.</p> <p><i>protocol tacacs</i> - Specify that the server host's authentication protocol will be TACACS.</p> <p><i>protocol xtacacs</i> - Specify that the server host's authentication protocol will be XTACACS.</p> <p><i>protocol tacacs+</i> - Specify that the server host's authentication protocol will be TACACS+.</p> <p><i>protocol radius</i> - Specify that the server host's authentication protocol will be RADIUS.</p> <p><i>port</i> - The port number of the authentication protocol for the server host. Default value for TACACS/XTACACS/TACACS+ is 49. Default value for RADIUS is 1812.</p> <p><i>key</i> - The key for TACACS+ and RADIUS authentication. If the value is null, no encryption will apply. This value is meaningless for TACACS and XTACACS.</p> <p><i>none</i> - No encryption for TACACS+ and RADIUS authentication. This value is meaningless for TACACS and XTACACS.</p> <p><i>timeout</i> - The time in seconds to wait for the server reply. Default value is 5 seconds.</p> <p><i>retransmit</i> - The count for re-transmissions. This value is meaningless for TACACS+. Default value is 2.</p>
Restrictions	Only Administrator level users can issue this command.

Example usage:

To create a TACACS+ authentication server host, specifying a listening port number of 15555 and a timeout value of 10 seconds:

```
DGS-3627:admin# create authen server_host 10.1.1.222 protocol tacacs+ port 15555 timeout 10
Command: create authen server_host 10.1.1.222 protocol tacacs+ port 15555 timeout 10

Success.

DGS-3627:admin#
```

config authen server_host

Purpose	This command is used to configure an authentication server host.
Syntax	config authen server_host <ipaddr> protocol [tacacs xtacacs tacacs+ radius] { port <int 1-65535> key [<key_string 254> none] timeout <int 1-255> retransmit <int 1-20> }
Description	Configures an authentication server host.
Parameters	<p><i>server_host</i> - Specify the server host's IP address.</p> <p><i>protocol tacacs</i> - Specify that the server host's authentication protocol will be TACACS.</p> <p><i>protocol xtacacs</i> - Specify that the server host's authentication protocol will be XTACACS.</p> <p><i>protocol tacacs+</i> - Specify that the server host's authentication protocol will be TACACS+.</p> <p><i>protocol radius</i> - Specify that the server host's authentication protocol will be RADIUS.</p> <p><i>port</i> - The port number of the authentication protocol for the server host. Default value for TACACS/XTACACS/TACACS+ is 49. Default value for RADIUS is 1812.</p> <p><i>key</i> - The key for TACACS+ and RADIUS authentication. If the value is null, no encryption will apply. This value is meaningless for TACACS and XTACACS.</p> <p><i>none</i> - No encryption for TACACS+ and RADIUS authentication. This value is meaningless for TACACS and XTACACS.</p> <p><i>timeout</i> - The time in seconds for waiting for the server reply. Default value is 5 seconds.</p> <p><i>retransmit</i> - The count for re-transmissions. This value is meaningless for TACACS+. Default value is 2.</p>
Restrictions	Only Administrator level users can issue this command.

Example usage:

To configure the TACACS+ authentication server host with an IP address of 10.1.1.222 to have the key value "This is a secret":

```
DGS-3627:admin# config authen server_host 10.1.1.222 protocol tacacs+ key "This is a secret"
Command: config authen server_host 10.1.1.222 protocol tacacs+ key "This is a secret"

Success.

DGS-3627:admin#
```

delete authen server_host

Purpose	This command is used to delete an authentication server host.
Syntax	delete authen server_host <ipaddr> protocol [tacacs xtacacs tacacs+ radius]
Description	Deletes an authentication server host.
Parameters	<p><i>server_host</i> - Specify the server host's IP address.</p> <p><i>protocol tacacs</i> - Specify that the server host's authentication protocol is TACACS.</p>

delete authen server_host

protocol xtacacs - Specify that the server host's authentication protocol is XTACACS.
protocol tacacs+ - Specify that the server host's authentication protocol is TACACS+.
protocol radius - Specify that the server host's authentication protocol is RADIUS.

Restrictions Only Administrator level users can issue this command.

Example usage:

To delete an authentication server host, with an IP address of 10.1.1.222, that is running the TACACS+ protocol:

```
DGS-3627:admin# delete authen server_host 10.1.1.222 protocol tacacs+
Command: delete authen server_host 10.1.1.222 protocol tacacs+
```

Success.

```
DGS-3627:admin#
```

show authen server_host

Purpose This command is used to display the authentication server hosts.

Syntax **show authen server_host**

Description Displays the authentication server hosts.

Parameters None.

Restrictions Only Administrator level users can issue this command.

Example usage:

To display all authentication server hosts:

```
DGS-3627:admin# show authen server_host
Command: show authen server_host
```

SRV IP Address	Protocol	Port	Timeout	Retransmit	Key
10.1.1.222	TACACS+	15555	10	No Use	

Total Entries : 1

```
DGS-3627:admin#
```

config authen parameter response_timeout

Purpose This command is used to configure the amount of time the Switch will wait for a user to authenticate through a console, Telnet, or SSH application.

Syntax **config authen parameter response_timeout <int 0-255>**

Description Configure the amount of time the Switch will wait for a user to authenticate through a console, Telnet, or SSH application.

Parameters *<int 0-255>* - The amount time the Switch will wait for a user to authenticate through a console, Telnet, or SSH application. 0 means there is no time out. Default value is 30 seconds.

Restrictions Only Administrator level users can issue this command.

Example usage:

To configure the amount of time the Switch will wait for a user to authenticate through a console, Telnet, or SSH application to 60 seconds:

```
DGS-3627:admin# config authen parameter response_timeout 60
Command: config authen parameter response_timeout 60

Success.

DGS-3627:admin#
```

config authen parameter attempt

Purpose	This command is used to configure the maximum number of attempts a user can try to login or promote the privilege on a console, Telnet, or SSH application.
Syntax	config authen parameter attempt <int 1-255>
Description	Used to configure the maximum number of attempts that a user can try to login or promote the privilege on a console, Telnet, or SSH application. If failed login attempts exceeds this number, the connection or access will be locked.
Parameters	<int 1-255> - Specify the maximum number of attempts that a user can try to login or promote the privilege on a console or telnet or SSH application. Default value is 3.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To configure the maximum attempts for user's trying to login or promote the privilege to be 9:

```
DGS-3627:admin# config authen parameter attempt 9
Command: config authen parameter attempt 9

Success.

DGS-3627:admin#
```

show authen parameter

Purpose	This command is used to display the parameters of authentication.
Syntax	show authen parameter
Description	Displays the parameters of authentication.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display the parameters of authentication:

```
DGS-3627:admin# show authen parameter
Command: show authen parameter

Response timeout : 60 seconds
User attempts    : 9

DGS-3627:admin#
```

enable admin

Purpose	This command is used to enter the administrator level privilege
Syntax	enable admin
Description	<p>Promote the "user" privilege level to "admin" level. When the user enters this command, the authentication method tacacs, xtacacs, tacacs+, user-defined server groups, local_enable or none will be used to authenticate the user. Since TACACS, XTACACS and RADIUS do not support the "enable" function by their selves,, if the user wants to use either one of these three protocols to enable authentication, the user must create a special account on the server host first, which has a username of "enable", and then configure its password as the enable password to support the "enable" function.</p> <p>This command can not be used when the authentication policy is disabled.</p> <p>For switches with 3-levels of privilege, this command can be used by users with user level and operator level privileges to access the administrator privilege level.</p>
Parameters	None.
Restrictions	None.

Example usage:

To enable administrator level privileges:

```
DGS-3627:user# enable admin
Password:*****

DGS-3627:user#
```

config admin local_enable

Purpose	This command is used to configure the local enable password of the administrator level privilege.
Syntax	config admin local_enable
Description	<p>Configure the local enable password for the enable command. When the user chooses the "local_enable" method to promote the privilege level, the enable password of the local device is needed.</p> <p>When the password information is not specified in the command, the system will prompt the user to input the password interactively. In this case, the user can only input a plain text password. If the password is present in the command, the user can select to input the password in plain text or encrypted form. The encryption algorithm is based on SHA-1.</p>
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To configure the administrator password:

```
DGS-3627:admin# config admin local_enable
Command: config admin local_enable

Enter the old password:
Enter the case-sensitive new password:*****
Enter the new password again for confirmation:*****
Success.

DGS-3627:admin#
```

ACCESS CONTROL LIST (ACL) COMMANDS

The Switch implements Access Control Lists that enable the Switch to deny network access to specific devices or device groups based on IP settings and MAC address. Access profiles allow you to establish criteria to determine whether or not the Switch will forward packets based on the information contained in each packet's header. These criteria can be specified on a VLAN-by-VLAN basis.

Creating an access profile is divided into two basic parts. First, an access profile must be created using the `create access_profile` command. For example, if you want to deny all traffic to the subnet 10.42.73.0 to 10.42.73.255, you must first create an access profile that instructs the Switch to examine all of the relevant fields of each frame:

```
create access_profile profile_id 1 ip source_ip_mask 255.255.255.0
```

Here we have created an access profile that will examine the IP field of each frame received by the Switch. Each source IP address the Switch finds will be combined with the `source_ip_mask` with a logical AND operation. The `profile_id` parameter is used to give the access profile an identifying number – in this case, 1. The `deny` parameter instructs the Switch to filter any frames that meet the criteria – in this case, when a logical AND operation between an IP address specified in the next step and the `ip_source_mask` match.

The default for an access profile on the Switch is to permit traffic flow. If you want to restrict traffic, you must use the `deny` parameter.

Now that an access profile has been created, you must add the criteria the Switch will use to decide if a given frame should be forwarded or filtered. Here, we want to filter any packets that have an IP source address between 10.42.73.0 and 10.42.73.255:

```
config access_profile profile_id 1 add access_id 1 ip source_ip 10.42.73.1 port 1 deny
```

Here we use the `profile_id 1` which was specified when the access profile was created. The `add` parameter instructs the Switch to add the criteria that follows to the list of rules that are associated with access profile 1. For each rule entered into the access profile, you can assign an `access_id` that both identifies the rule and establishes a priority within the list of rules. A lower `access_id` gives the rule a higher priority. In case of a conflict in the rules entered for an access profile, the rule with the highest priority (lowest `access_id`) will take precedence.

The `ip` parameter instructs the Switch that this new rule will be applied to the IP addresses contained within each frame's header. `source_ip` tells the Switch that this rule will apply to the source IP addresses in each frame's header. Finally, the IP address 10.42.73.1 will be combined with the `source_ip_mask 255.255.255.0` to give the IP address 10.42.73.0 for any source IP address between 10.42.73.0 to 10.42.73.255.

Due to a chipset limitation, the Switch supports a maximum of fourteen access profiles. The rules used to define the access profiles are limited to a total of 1792 rules for the Switch. One rule can support ACL per port or per portmap.

The Access Control List (ACL) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create access_profile	[ethernet {vlan source_mac <macmask 000000000000-ffffffff> destination_mac <macmask 000000000000-ffffffff> 802.1p ethernet_type} ip {vlan source_ip_mask <netmask> destination_ip_mask <netmask> dscp [icmp {type code} igmp {type} tcp {src_port_mask <hex 0x0-0xffff> dst_port_mask <hex 0x0-0xffff> flag_mask [all {urg ack psh rst syn fin}]} udp {src_port_mask <hex 0x0-0xffff> dst_port_mask <hex 0x0-0xffff>} protocol_id_mask <hex 0x0-0xff> {user_define_mask <hex 0x0-0xffffffff>}}] packet_content_mask {offset_chunk_1 <value 0-31> <hex 0x0-0xffffffff> offset_chunk_2 <value 0-31> <hex 0x0-0xffffffff> offset_chunk_3 <value 0-31> <hex 0x0-0xffffffff> offset_chunk_4 <value 0-31> <hex 0x0-0xffffffff>} ipv6 {class flowlabel source_ipv6_mask <ipv6mask> destination_ipv6_mask <ipv6mask> [tcp {src_port_mask <hex 0x0-0xffff> dst_port_mask <hex 0x0-0xffff>} udp {src_port_mask <hex 0x0-0xffff> dst_port_mask <hex 0x0-0xffff>}]}] profile_id <value 1-14>
delete access_profile	[profile_id <value 1-14> all]
config access_profile	profile_id <value 1-14> [add access_id [auto_assign <value 1-128>] [ethernet {vlan <vlan_name 32> source_mac <macaddr 000000000000-ffffffff> destination_mac <macaddr 000000000000-ffffffff> 802.1p <value 0-7> ethernet_type <hex 0x0-0xffff>} port [<portlist> all] [permit {priority <value 0-7> {replace_priority} rx_rate [no_limit <value 1-156249>] replace_dscp <value 0-63> counter [enable disable]} mirror {group_id <value 1-4>} deny} ip {vlan <vlan_name 32> source_ip <ipaddr> destination_ip <ipaddr> dscp <value 0-63> [icmp {type <value 0-255> code <value 0-255>} igmp {type <value 0-255>} tcp {src_port <value 0-65535> dst_port <value 0-65535> urg ack psh rst syn fin} udp {src_port <value 0-65535> dst_port <value 0-65535>} protocol_id <value 0 - 255> {user_define <hex 0x0-0xffffffff>}}] port [<portlist> all] [permit {priority <value 0-7> {replace_priority} rx_rate [no_limit <value 1-156249>] replace_dscp <value 0-63> counter [enable disable]} mirror {group_id <value 1-4>} deny} packet_content {offset_chunk_1 <hex 0x0-0xffffffff> offset_chunk_2 <hex 0x0-0xffffffff> offset_chunk_3 <hex 0x0-0xffffffff> offset_chunk_4 <hex 0x0-0xffffffff>} port [<portlist> all] [permit {priority <value 0-7> {replace_priority} rx_rate [no_limit <value 1-156249>] replace_dscp <value 0-63> counter [enable disable]} mirror {group_id <value 1-4>} deny} ipv6 {class <value 0-255> flowlabel <hex 0x0-0xffff> source_ipv6 <ipv6addr> destination_ipv6 <ipv6addr> [tcp {src_port <value 0-65535> dst_port <value 0-65535>} udp {src_port <value 0-65535> dst_port <value 0-65535>}}] port [<portlist> all] [permit {priority <value 0-7> {replace_priority} rx_rate [no_limit <value 1-156249>] counter [enable disable]} mirror {group_id <value 1-4>} deny}]{time_range <range_name 32>} delete access_id <value 1-128>]
config flow_meter	profile_id <value 1-14> access_id <value 1-128>[[tr_tcm cir <value 0-156249> {cbs <value 0-16384>} pir <value 0-156249> {pbs <value 0-16384>} sr_tcm cir <value 0-156249> cbs <value 0-16384> ebs <value 0-16384>] {conform [permit replace_dscp <value 0-63>] {counter [enable disable]}} exceed [permit replace_dscp <value 0-63> drop] {counter [enable disable]} violate [permit replace_dscp <value 0-63> drop] {counter [enable disable]} delete]
show flow_meter	{profile_id <value 1-14> {access_id <value 1-128>}}
config time_range	<range_name 32> [hours start_time <time hh:mm:ss> end_time <time hh:mm:ss> weekdays <daylist> delete]
show time_range	

Each command is listed, in detail, in the following sections.

create access_profile

Purpose	Used to create access list rules.
Syntax	create access_profile [ethernet {vlan source_mac <macmask 000000000000-ffffffff> destination_mac <macmask 000000000000-ffffffff> 802.1p ethernet_type} ip {vlan source_ip_mask <netmask> destination_ip_mask <netmask> dscp [icmp {type code} igmp {type} tcp {src_port_mask <hex 0x0-0xffff> dst_port_mask <hex 0x0-0xffff> flag_mask [all {urg ack psh rst syn fin}]}] udp {src_port_mask <hex 0x0-0xffff> dst_port_mask <hex 0x0-0xffff>} protocol_id_mask <hex 0x0-0xff> {user_define_mask <hex 0x0-0xffffffff>}}] packet_content_mask { offset_chunk_1 <value 0-31> <hex 0x0-0xffffffff> offset_chunk_2 <value 0-31> <hex 0x0-0xffffffff> offset_chunk_3 <value 0-31> <hex 0x0-0xffffffff> offset_chunk_4 <value 0-31> <hex 0x0-0xffffffff>} ipv6 {class flowlabel source_ipv6_mask <ipv6mask> destination_ipv6_mask <ipv6mask> [tcp {src_port_mask <hex 0x0-0xffff> dst_port_mask <hex 0x0-0xffff>} udp {src_port_mask <hex 0x0-0xffff> dst_port_mask <hex 0x0-0xffff>}}] profile_id <value 1-14>
Description	The create access_profile command creates access list rules.
Parameters	<p><i>vlan</i> - Specifies a vlan mask. Only the last 12 bits of the mask will be considered.</p> <p><i>source_mac</i> - Specifies the source mac mask.</p> <p><i>destination_mac</i> - Specifies the destination mac mask.</p> <p><i>802.1p</i> - Specifies 802.1p priority tag mask.</p> <p><i>ethernet_type</i> - Specifies the ethernet type mask.</p> <p><i>vlan</i> - Specifies a vlan mask. Only the last 12 bits of the mask will be considered.</p> <p><i>source_ip_mask</i> - Specifies an IP source submask.</p> <p><i>destination_ip_mask</i> - Specifies an IP destination submask.</p> <p><i>dscp</i> - Specifies the dscp mask.</p> <p><i>icmp</i> - Specifies that the rule applies to icmp traffic.</p> <p style="padding-left: 2em;"><i>type</i> - Specifies that the rule applies to icmp type traffic.</p> <p style="padding-left: 2em;"><i>code</i> - Specifies that the rule applies to icmp code traffic.</p> <p><i>igmp</i> - Specifies that the rule applies to igmp traffic.</p> <p style="padding-left: 2em;"><i>type</i> - Specifies that the rule applies to igmp type traffic.</p> <p><i>tcp</i> - Specifies that the rule applies to tcp traffic.</p> <p style="padding-left: 2em;"><i>src_port_mask</i> - Specifies the tcp source port mask.</p> <p style="padding-left: 2em;"><i>dst_port_mask</i> - Specifies the tcp destination port mask.</p> <p style="padding-left: 2em;"><i>flag_mask</i> - Specifies the TCP flag field mask.</p> <p><i>udp</i> - Specifies that the rule applies to udp traffic.</p> <p style="padding-left: 2em;"><i>src_port_mask</i> - Specifies theudp source port mask.</p> <p style="padding-left: 2em;"><i>dst_port_mask</i> - Specifies theudp destination port mask.</p> <p><i>protocod_id_mask</i> - Specifies that the rule applies to the ip protocol id traffic.</p> <p style="padding-left: 2em;"><i>user_define_mask</i> - Specifies that the rule applies to the ip protocol id and the mask options behind the IP header length is 20 bytes.</p> <p><i>ipv6</i> - Specifies ipv6 filtering mask. The field is optional by project.</p> <p style="padding-left: 2em;"><i>class</i> - Specifies the ipv6 class.</p> <p style="padding-left: 2em;"><i>flowlabel</i> - Specifies the ipv6 flowlabel.</p> <p style="padding-left: 2em;"><i>source_ipv6_mask</i> - Specifies an IPv6 source submask.</p> <p style="padding-left: 2em;"><i>destination_ipv6_mask</i> - Specifies an IPv6 destination submask.</p> <p style="padding-left: 2em;"><i>src_port_mask</i> - Specifies an IPv6 L4(TCP/UDP) source port submask</p> <p style="padding-left: 2em;"><i>des_port_mask</i> - Specifies an IPv6 L4(TCP/UDP) destination port submask</p> <p><i>profile_id</i> - Specifies the index of access list profile. The range is depend on project..</p> <p><i>offset_chunk_1</i>, <i>offset_chunk_2</i>, <i>offset_chunk_3</i>, <i>offset_chunk_4</i> - Specifies the frame content offset and mask. Up to 4 trunk offset and masks in maximum could be configured. A trunk mask presents 4 bytes.</p>

create access_profile

Restrictions	Only Administrator and Operator-level users can issue this command.
--------------	---

Example usage:

To create an Ethernet access profile:

```
DGS-3627:admin# create access_profile ethernet vlan source_mac 00-00-00-00-00-01
destination_mac 00-00-00-00-00-02 802.1p ethernet_type profile_id 1
Command: create access_profile ethernet vlan source_mac 00-00-00-00-00-01 destination_mac
00-00-00-00-00-02 802.1p ethernet_type profile_id 1

Success.

DGS-3627:admin#
```

To create an option 2 packet content mask access profile:

```
DGS-3627:admin# create access_profile packet_content_mask offset_chunk_1 0 0xFFFFFFFF
offset_chunk_2 1 0xFFFFFFFF offset_chunk_3 2 0xFFFFFFFF offset_chunk_4 3 0xFFFFFFFF
profile_id 3
Command: create access_profile packet_content_mask offset_chunk_1 0 0xFFFFFFFF
offset_chunk_2 1 0xFFFFFFFF offset_chunk_3 2 0xFFFFFFFF offset_chunk_4 3 0xFFFFFFFF
profile_id 3

Success.

DGS-3627:admin#
```

delete access_profile

Purpose	Used to delete access list rules.
Syntax	delete access_profile [profile_id <value 1-14> all]
Description	The delete access_profile command deletes access list rules. Delete access_profile command can only delete the profile which is created by ACL module.
Parameters	<i>profile_id</i> - Specifies the index of access list profile. The range is depend on project.. <i>all</i> - Specifies the whole access list profile to delete.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete access list rules:

```
DGS-3627:admin#delete access_profile profile_id 10
Command: delete access_profile profile_id 10

Success.

DGS-3627:admin#
```

config access_profile

Purpose	Used to configure access list entry.
---------	--------------------------------------

config access_profile

Syntax	<pre>config access_profile profile_id <value 1-14> [add access_id [auto_assign <value 1-128>] [ethernet {vlan <vlan_name 32> source_mac <macaddr 000000000000-ffffffff> destination_mac <macaddr 000000000000-ffffffff> 802.1p <value 0-7> ethernet_type <hex 0x0-0xffff>} port [<portlist> all] [permit {priority <value 0-7> {replace_priority} rx_rate [no_limit <value 1-156249>] replace_dscp <value 0-63> counter [enable disable]} mirror {group_id <value 1-4>} deny] ip {vlan <vlan_name 32> source_ip <ipaddr> destination_ip <ipaddr> dscp <value 0-63> [icmp {type <value 0-255> code <value 0-255>} igmp {type <value 0-255>} tcp {src_port <value 0-65535> dst_port <value 0-65535> urg ack psh rst syn fin} udp {src_port <value 0-65535> dst_port <value 0-65535>} protocol_id <value 0 - 255> {user_define <hex 0x0-0xffffffff>}}] port [<portlist> all] [permit {priority <value 0-7> {replace_priority} rx_rate [no_limit <value 1-156249>] replace_dscp <value 0-63> counter [enable disable]} mirror {group_id <value 1-4>} deny] packet_content {offset_chunk_1 <hex 0x0-0xffffffff> offset_chunk_2 <hex 0x0-0xffffffff> offset_chunk_3 <hex 0x0-0xffffffff> offset_chunk_4 <hex 0x0-0xffffffff>} port [<portlist> all] [permit {priority <value 0-7> {replace_priority} rx_rate [no_limit <value 1-156249>] replace_dscp <value 0-63> counter [enable disable]} mirror {group_id <value 1-4>} deny] ipv6 {class <value 0-255> flowlabel <hex 0x0-0xffff> source_ipv6 <ipv6addr> destination_ipv6 <ipv6addr> [tcp {src_port <value 0-65535> dst_port <value 0-65535>} udp {src_port <value 0-65535> dst_port <value 0-65535>}}] port [<portlist> all] [permit {priority <value 0-7> {replace_priority} rx_rate [no_limit <value 1-156249>] counter [enable disable]} mirror {group_id <value 1-4>} deny]}{time_range <range_name 32>} delete access_id <value 1-128>]</pre>
Description	<p>The config access_profile command configures access list entry.</p> <p>ACL mirror function will be worked after mirror enabled and mirror port has been configured by mirror command.</p> <p>When apply a access rule to a target, if the target is VLAN, then the setting for value the VLAN field will not take effect.</p>
Parameters	<p><i>profile_id</i> - Specifies the index of access list profile. The range is depend on project.</p> <p><i>access_id</i> - Specifies the index of access list entry. The range of this value is 1-65535, but the supported max entry number is depend on project.</p> <p><i>auto_assign</i> - while add to multiple ports , the access id will be auto assigned.</p> <p><i>vlan</i> - Specifies a vlan name</p> <p><i>source_mac</i> - Specifies the source mac</p> <p><i>destination_mac</i> - Specifies the destination mac</p> <p><i>802.1p</i> - Specifies the value of 802.1p priority tag, the vaule can be configured between 1 to 7</p> <p><i>ethernet_type</i> - Specifies the Ethernet type</p> <p><i>vlan</i> - Specifies a vlan name</p> <p><i>source_ip</i> - Specifies an IP source address</p> <p><i>destination_ip</i> - Specifies an IP destination address</p> <p><i>dscp</i> - Specifies the value of dscp, the value can be configured 0 to 63</p> <p><i>icmp</i> – See below:</p> <p><i>type</i> - Specifies that the rule applies to the value of icmp type traffic</p> <p><i>code</i> - Specifies that the rule applies to the value of icmp code traffic</p> <p><i>igmp</i> – See below:</p> <p><i>type</i> - Specifies that the rule applies to the value of igmp type traffic</p> <p><i>tcp</i> – See below:</p> <p><i>src_port</i> - Specifies that the rule applies the range of tcp source port</p> <p><i>dst_port</i> - Specifies the range of tcp destination port range</p> <p><i>flag</i> - Specifies the TCP flag fields .</p> <p><i>udp</i> – See below:</p> <p><i>src_port</i> - Specifies the range of tcp source port range</p>

config access_profile

dst_port - Specifies the range of tcp destination port mask

protocod_id - Specifies that the rule applies to the value of ip protocol id traffic

user_define - Specifies that the rule applies to the ip protocol id and the mask options behind the IP header length is 20 bytes.

packet_content - Specifies the packet content for the user defined mask.

ipv6 - Specifies the rule applies to ipv6 fields . The field is optional by project.

class - Specifies the value of ipv6 class.

flowlabel - Specifies the value of ipv6 flowlabel.

source_ipv6 - Specifies the value of ipv6 source address.

destination_ipv6 - Specifies the value of ipv6 destination address.

src_port - Specifies the value of ipv6 L4(TCP/UDP) source port

dst_port - Specifies the value of ipv6 L4(TCP/UDP) destination port

port - Specifies a list of port to apply the rule.

permit - Specifies the packets that match the access profile are permit by the switch

priority - Specifies that priority of the packet will be changed if the packet match the access rule.

replace_priority - Specifies 802.1p priority of the outgoing packet will be marked too.

replace_dscp - Specifies that DSCP of the outgoing packet will be marked by the new value.

counter - Specifies whether counter feature will be enabled / disabled. If the rule is binded with *flow_meter*, then "counter" here will be overridden.

deny - Specifies the packets that match the access profile are filtered by the switch

mirror - Specifies the packets that match the access profile are sent the copied one to the mirror port.

time_range - Specifies name of this time range entry.

offset_chunk_1, offset_chunk_2, offset_chunk_3, offset_chunk_4 - Specifies the content of the trunk to be monitored.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To configure an access list rule entry:

```
DGS-3627:admin# config access_profile profile_id 1 add access_id 1 ip vlan default
source_ip 20.2.2.3 destination_ip 10.1.1.252 dscp 3 icmp type 11 code 32 port 1 mirror
group_id 1 time_range testdaily
```

```
Command: config access_profile profile_id 1 add access_id 1 ip vlan default source_ip
20.2.2.3 destination_ip 10.1.1.252 dscp 3 icmp type 11 code 32 port 1 mirror group_id 1
time_range testdaily
```

Mirror function must be enabled and mirror port must be configured.

Success.

```
DGS-3627:admin#
```

To configure a rule entry for packet content mask profile:

```
DGS-3627:admin# config access_profile profile_id 5 add access_id auto_assign
packet_content offset_chunk_1 0xAAAAAAAA offset_chunk_2 0xBBBBBBBB offset_chunk_3
0xFFFFFFFF offset_chunk_4 0xEEEEEEEE port all permit
Command: config access_profile profile_id 5 add access_id auto_assign packet_content
offset_chunk_1 0xAAAAAAAA offset_chunk_2 0xBBBBBBBB offset_chunk_3 0xFFFFFFFF
offset_chunk_4 0xEEEEEEEE port all permit
```

Success.

DGS-3627:admin#

show access_profile

Purpose	Used to display current access list table.
Syntax	show access_profile {profile_id <value 1-14>}
Description	The show access_profile command displays current access list table.
Parameters	<i>profile_id</i> - Specifies the index of access list profile. The range is depend on project.
Restrictions	None.

Example usage:

To display current access list table:

```
DGS-3627:admin# show access_profile
Command: show access_profile

Access Profile Table

Total Unused Rule Entries: 1769
Total Used Rule Entries : 3

Access Profile ID: 1                                TYPE : Packet Content
=====
Owner          : ACL
MASK Option :
-----
Offset_chunk_1: 1      value:FFFFFFFF
Offset_chunk_2: 2      value:EEEEEEEE
Offset_chunk_3: 3      value:DDDDDDDD
Offset_chunk_4: 4      value:CCCCCCC

Access ID : 1                Mode: Permit                priority: 3
Port: 1:1
-----
Offset_chunk_1: 1      value:11111111
Offset_chunk_2: 2      value:22222222
Offset_chunk_3: 3      value:11111111
Offset_chunk_4: 4      value:44444444
=====
Unused rule entries: 127

DGS-3627:admin#
```

config flow_meter profile_id

Purpose	To configure packet flow-based metering based on an access profile and rule.
Syntax	config flow_meter profile_id <value 1-14> access_id <value 1-128> [[tr_tcm cir <value 0-156249> {cbs <value 0-16384>} pir <value 0-156249> {pbs <value 0-16384>} sr_tcm cir <value 0-156249> cbs <value 0-16384> ebs <value 0-16384>] {conform [permit replace_dscp <value 0-63>] {counter [enable disable]}} exceed [permit replace_dscp <value 0-63> drop] {counter [enable disable]} violate [permit replace_dscp <value 0-63> drop] {counter [enable disable]} delete]
Description	<p>This command is used to configure the flow-based metering function. The metering function support three modes, single rate two colors, single rate three color, and two rate three color. The access rule must first be created before the parameters of this function can be applied.</p> <p>For the single rate two color mode, users may set the preferred bandwidth for this rule, in Kbps and once the bandwidth has been exceeded, overflow packets will be either dropped or be set to a drop precedence, depending on user configuration. The drop precedence will be used by RED. With RED, the packet with higher drop precedence will be dropped with higher probability.</p> <p>For the single rate three color mode, users need to specify the committed rate in Kbps, the committed burst size and the excess burst size.</p> <p>For the two rate three color mode, users need to specify the committed rate in Kbps, the committed burst size, the peak rate and the peak burst size.</p> <p>There can be two cases to map the color of packet, color blind mode and color aware mode. In the color-blind case, the determination for the color of packet is based on metering result. In the color-aware case, the determination for the color of packet is based metering result and the ingress DSCP.</p> <p>When the color blind or color aware is not specified, color blind is the default mode.</p> <p>The green color packet will be treated the conforming action, the yellow color packet will be treated the exceeding action, and the red color packet will be treated the violating action.</p>
Parameters	<p><i>profile_id</i> - Specifies the profile_ID.</p> <p><i>access_id</i> - Specifies the access_ID.</p> <p><i>tr_tcm</i> - Specify the “two rate three color mode”.</p> <p><i>cir</i> - Specify the “committed information rate”.</p> <p>The unit is 64Kbps.</p> <p>The max rate 156249*64Kbps</p> <p><i>cbs</i> - Specify the “committed burst size”.</p> <p>The unit is Kbytes. That is to say, 1 means 1Kbytes.</p> <p>This parameter is an optional parameter. The default value is 4*1024.</p> <p>The max set value is 16*1024.</p> <p><i>pir</i> - Specify the “Peak Information Rate”.</p> <p>The unit is 64Kbits.</p> <p>The max rate is 156249*64Kbps</p> <p><i>pbs</i> - Specify the “peak burst size”.</p> <p>The unit is Kbytes.</p> <p>This parameter is an optional parameter.The default value is 4*1024.</p> <p>The max set value is 16*1024.</p> <p><i>sr_tcm</i> - Specify the “single rate three color mode”.</p> <p><i>cir</i> - Specify the “committed information rate”.</p> <p>The unit is 64Kbps.</p> <p>The max rate is 156249*64Kbps</p> <p><i>cbs</i> - Specify the “committed burst size”.</p> <p>The unit is Kbytes.</p> <p>The max set value is 16*1024.</p> <p><i>ebs</i> - Specify the “Excess Burst Size”.</p>

config flow_meter profile_id

The unit is Kbytes.
 The max set value is 16*1024.
conform - Specify the action when packet is in “green color”.
permit - Permit the packet.
replace_dscp - Change the dscp of packet.
exceed - Specify the action when packet is in “yellow color”.
permit - Permit the packet.
replace_dscp - Change the dscp of packet.
drop - Drop the packet.
violate - Specify the action when packet is in “red color”.
permit - Permit the packet.
replace_dscp - Change the dscp of packet.
counter - Specify the counter.
 This is optional. The default is “disable”.
 The resource may be limited such that counter can not be turned on. The limitation is project dependent.
counter will be cleared when the function is disabled.
delete - Delete the specified flow_meter.
 Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To configure a two rates thress color flow meter:

```
DGS-3627:admin# config flow_meter profile_id 1 access_id 1 tr_tcm cir 1000 cbs 200 pir
2000 pbs 200 exceed replace_dscp 21 violate drop
Command: config flow_meter profile_id 1 access_id 1 tr_tcm cir 1000 cbs 200 pir 2000 pbs
200 exceed replace_dscp 21 violate drop

Success.
DGS-3627:admin#
```

show flow_meter

Purpose	To configure packet flow-based metering based on an access profile and rule.
Syntax	show flow_meter {profile_id <value 1-14> {access_id <value 1-128>}}
Description	This command displays the flow meter configuration.
Parameters	<i>profile_id</i> - Specifies the profile_ID. <i>access_id</i> - Specifies the access_ID.
Restrictions	None.

Example usage:

To display the flow meter configuration:

```
DGS-3627:admin# show flow_meter
Command: show flow_meter

Flow Meter Information
-----
Profile ID:4      Access ID:1      Mode : trTCM
CIR:1000(64Kbps) CBS:200(Kbyte)  PIR:2000(64Kbps)  PBS:200(Kbyte)
Action:
  Conform : Permit           Counter: Disabled
  Exceed  : Permit           Replace DSCP: 21   Counter: Disabled
  Violate : Drop             Counter: Disabled

Total Entries: 1

DGS-3627:admin#
```

config time_range

Purpose	Used to configure the range of time to activate a function on the switch.
Syntax	config time_range <range_name 32> [hours start_time <time hh:mm:ss> end_time <time hh:mm:ss> weekdays <daylist> delete]
Description	This command defines a specific range of time to activate a function on the Switch by specifying which time range in a day and which days in a week are covered in the time range. Note that the specified time range is based on SNTP time or configured time. If this time is not available, then the time range will not be met.
Parameters	<p><i><range_name 32></i> - Specifies the name of the time range settings.</p> <p><i>start_time</i> - Specifies the starting time in a day. (24-hr time) For example, 19:00 means 7PM. 19 is also acceptable. start_time must be smaller than end_time.</p> <p><i>end_time</i> - Specifies the ending time in a day. (24-hr time)</p> <p><i>weekdays</i> - Specify the list of days contained in the time range. Use a dash to define a period of days. Use a comma to separate specific days. For example, mon-fri (Monday to Friday), sun, mon, fri (Sunday, Monday and Friday)</p> <p><i>delete</i> - Deletes a time range profile. When a time_range profile has been associated with ACL entries, the delete of this time_range profile will fail.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the range of time to activate a function on the switch.

```
DGS-3627:admin# config time_range weekend hours start_time 0:0:0 end_time 23:59:5
9 weekdays sun,sat
Command: config time_range weekend hours start_time 0:0:0 end_time 23:59:59 week
days sun,sat

Success.

DGS-3627:admin#
```

show time_range

Purpose	Used to display time range information.
Syntax	show time_range
Description	The show time_range command displays current time range setting.

show time_range

Parameters	None.
Restrictions	None.

Example usage:

To display current time range setting:

```
DGS-3627:admin#show time_range
```

```
Command: show time_range
```

```
Time Range Information
```

```
-----  
Range Name      : weekend  
Weekdays       : Sun,Sat  
Start Time      : 00:00:00  
End Time        : 23:59:59
```

```
Total Entries :1
```

```
DGS-3627:admin#
```

ACL FLOW METERING COMMANDS

Before configuring the ACL Flow Meter, here is a list of acronyms and terms users will need to know.

trTCM – Two Rate Three Color Marker. This, along with the srTCM, are two methods available on the switch for metering and marking packet flow. The trTCM meters and IP flow and marks it as a color based on the flow's surpassing of two rates, the CIR and the PIR.

- **CIR** – Committed Information Rate. Common to both the trTCM and the srTCM, the CIR is measured in bytes of IP packets. IP packet bytes are measured by taking the size of the IP header but not the link specific headers. For the trTCM, the packet flow is marked green if it doesn't exceed the CIR and yellow if it does. The configured rate of the CIR must not exceed that of the PIR. The CIR can also be configured for unexpected packet bursts using the CBS and PBS fields.
- **CBS** – Committed Burst Size. Measured in bytes, the CBS is associated with the CIR and is used to identify packets that exceed the normal boundaries of packet size. The CBS should be configured to accept the biggest IP packet that is expected in the IP flow.
- **PIR** – Peak Information Rate. This rate is measured in bytes of IP packets. IP packet bytes are measured by taking the size of the IP header but not the link specific headers. If the packet flow exceeds the PIR, that packet flow is marked red. The PIR must be configured to be equal or more than that of the CIR.
- **PBS** – Peak Burst Size. Measured in bytes, the PBS is associated with the PIR and is used to identify packets that exceed the normal boundaries of packet size. The PBS should be configured to accept the biggest IP packet that is expected in the IP flow.

srTCM – Single Rate Three Color Marker. This, along with the trTCM, are two methods available on the switch for metering and marking packet flow. The srTCM marks its IP packet flow based on the configured CBS and EBS. A packet flow that does not reach the CBS is marked green, if it exceeds the CBS but not the EBS its marked yellow, and if it exceeds the EBS its marked red.

- **CBS** – Committed Burst Size. Measured in bytes, the CBS is associated with the CIR and is used to identify packets that exceed the normal boundaries of packet size. The CBS should be configured to accept the biggest IP packet that is expected in the IP flow.
- **EBS** – Excess Burst Size. Measured in bytes, the EBS is associated with the CIR and is used to identify packets that exceed the boundaries of the CBS packet size. The EBS is to be configured for an equal or larger rate than the CBS.

DSCP – Differentiated Services Code Point. The part of the packet header where the color will be added. Users may change the DSCP field of incoming packets.

The ACL Flow Meter function will allow users to color code IP packet flows based on the rate of incoming packets. Users have two types of Flow metering to choose from, trTCM and srTCM, as explained previously. When a packet flow is placed in a color code, the user can choose what to do with packets that have exceeded that color-coded rate.

Green – When an IP flow is in the green mode, its configurable parameters can be set in the Conform field, where the packets can have their DSCP field changed. This is an acceptable flow rate for the ACL Flow Meter function.

Yellow – When an IP flow is in the yellow mode, its configurable parameters can be set in the Exceed field. Users may choose to either **Permit** or **Drop** exceeded packets. Users may also choose to change the DSCP field of the packets.

Red – When an IP flow is in the red mode, its configurable parameters can be set in the Exceed field. Users may choose to either **Permit** or **Drop** exceeded packets. Users may also choose to change the DSCP field of the packets.

Users may also choose to count exceeded packets by clicking the **Counter** check box. If the counter is enabled, the counter setting in the access profile will be disabled.

The ACL Flow Meter commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config flow_meter profile_id	<value 1-14> access_id <value 1-128> [[tr_tcm cir <value 0-156249> {cbs <value 0-16384>} pir <value 0-156249> {pbs <value 0-16384>} sr_tcm cir <value 0-156249> cbs <value 0-16384> ebs <value 0-16384> } {conform [permit replace_dscp <value 0-63>] {counter [enable disable]}} exceed [permit replace_dscp <value 0-63> drop] {counter [enable disable]} violate [permit replace_dscp <value 0-63> drop] {counter [enable disable]} delete]
show flow_meter	{profile_id <value 1-14> {access_id <value 1-128>}}

Each command is listed, in detail, in the following sections.

config flow_meter profile_id

Purpose	Used to configure the flow metering function for ACL..
Syntax	config flow_meter profile_id <value 1-14> access_id <value 1-128> [[tr_tcm cir <value 0-156249> {cbs <value 0-16384>} pir <value 0-156249> {pbs <value 0-16384>} sr_tcm cir <value 0-156249> cbs <value 0-16384> ebs <value 0-16384>] {conform [permit replace_dscp <value 0-63>} {counter [enable disable]}} exceed [permit replace_dscp <value 0-63> drop] {counter [enable disable]} violate [permit replace_dscp <value 0-63> drop] {counter [enable disable]} delete]
Description	This command is used to configure the parameters for the flow metering function for ACL entries created on the switch.
Parameters	<p><i>profile_id</i> <value 1-14> – Enter the pre-configured Profile ID for which to configure the ACL Flow Metering parameters.</p> <p><i>access_id</i> <value 1-128> – Enter the pre-configured Access ID for which to configure the ACL Flow Metering parameters.</p> <p><i>tr_tcm</i> - Choosing this field will allow users to employ the Two Rate Three Color Mode and set the following parameters to determine the color rate of the IP packet flow.</p> <ul style="list-style-type: none"> • <i>cir</i> <value 0-156249> – The Committed Information Rate can be set between 0 and 156249. IP flow rates at or below this level will be considered <i>green</i>. IP flow rates that exceed this rate but not the PIR rate are considered <i>yellow</i>. • <i>cbs</i> <value 0-16384> – The Committed Burst Size. Used to gauge packets that are larger than the normal IP packets. This field does not have to be set for this feature to function properly but is to be used in conjunction with the CIR setting. The CBS should be configured to accept the biggest IP packet that is expected in the IP flow. • <i>pir</i> <value 0-16384> – The Peak information Rate. IP flow rates that exceed this setting will be considered as <i>red</i>. This field must be set at an equal or higher value than the CIR. • <i>pbs</i> <value 0-16384> – The Peak Burst Size. This optional field is to be used in conjunction with the PIR. The PBS should be configured to accept the biggest IP packet that is expected in the IP flow. <p><i>sr_tcm</i> – Choosing this field will allow users to employ the Single Rate Three Color Mode and set the following parameters to determine the color rate of the IP packet flow.</p> <ul style="list-style-type: none"> • <i>cir</i> <value 0-156249> – The Committed Information Rate can be set between 0-156249. The color rates are based on the following two fields which are used in conjunction with the CIR. • <i>cbs</i> <value 0-16384> – Committed Burst Size. Measured in bytes, the CBS is associated with the CIR and is used to identify packets that exceed the normal boundaries of packet size. The CBS should be configured to accept the biggest IP packet that is expected in the IP flow. Packet flows which are lower than this configured value are marked green. Packet flows which exceed this value but are less than the EBS value are marked yellow. • <i>ebs</i> <value 0-16384> – Excess Burst Size. Measured in bytes, the EBS is associated with the CIR and is used to identify packets that exceed the boundaries of the CBS packet size. The EBS is to be configured for an equal or larger rate than the CBS. Packet flows that exceed this value are marked as red. <p><i>conform</i> – This field denotes the <i>green</i> packet flow. Green packet flows may have their DSCP field rewritten to a value stated in this field. Users may also choose to count green packets by checking the Counter check box.</p> <ul style="list-style-type: none"> • <i>permit</i> – Enter this parameter to allow packet flows that are in the green flow. • <i>replace_dscp</i> <value 0-63> – Packets that are in the green flow may have their DSCP field rewritten using this parameter and entering the DSCP value to replace. • <i>counter [enable disable]</i> – Use this parameter to enable or disable the packet counter for the specified ACL entry in the green flow. <p><i>exceed</i> – This field denotes the <i>yellow</i> packet flow. Yellow packet flows may have excess packets permitted through or dropped. Users may replace the DSCP field of these packets by checking its radio button and entering a new DSCP value in the allotted field.</p> <ul style="list-style-type: none"> • <i>permit</i> – Enter this parameter to allow packet flows that are in the yellow flow. • <i>replace_dscp</i> <value 0-63> – Packets that are in the yellow flow may have their DSCP

config flow_meter profile_id

field rewritten using this parameter and entering the DSCP value to replace.

- *drop* – Enter this parameter to drop packets that are in the yellow flow.
- *counter [enable | disable]* – Use this parameter to enable or disable the packet counter for the specified ACL entry in the yellow flow.

violate – This field denotes the *red* packet flow. Red packet flows may have excess packets permitted through or dropped. Users may replace the DSCP field of these packets by checking its radio button and entering a new DSCP value in the allotted field.

- *permit* – Enter this parameter to allow packet flows that are in the red flow.
- *replace_dscp <value 0-63>* – Packets that are in the red flow may have their DSCP field rewritten using this parameter and entering the DSCP value to replace.
- *drop* – Enter this parameter to drop packets that are in the red flow.
- *counter [enable | disable]* – Use this parameter to enable or disable the packet counter for the specified ACL entry in the red flow.
- *delete* – Use this parameter to delete the specified flow meter.

Restrictions

Only Administrator and Operator-level users can issue this command. Only two counters may be enabled at any given time.

Example usage:

To enable the sFlow function:

```
DGS-3627:admin# config flow_meter profile_id 1 access_id 1 tr_tcm cir 1000 cbs 200 pir
2000 pbs 200 exceed replace_dscp 21 violate drop
Command: config flow_meter profile_id 1 access_id 1 tr_tcm cir 1000 cbs 200 pir 2000 pbs
200 exceed replace_dscp 21 violate drop
```

Success.

```
DGS-3627:admin#
```

show flow_meter

Purpose	Used to display the ACL flow meter parameters set on the switch.
Syntax	show flow_meter {profile_id <value 1-14> {access_id <value 1-128>}}
Description	This command will display the flow meter parameters set on the switch.
Parameters	<i>profile_id <value 1-14></i> – Enter the profile ID of the ACL entry to be viewed for flow metering. <i>access_id <value 1-128></i> – Enter the access ID corresponding to the ACL entry to be viewed.
Restrictions	None.

Example usage:

To enable the sFlow function:

```
DGS-3627:admin# show flow_meter profile_id 1 access_id 1
Command: show flow_meter profile_id 1 access_id 1

Profile ID : 1          Access ID : 1          Mode: trTCM
CIR: 1000(64kbps)     CBS: 200(Kbyte)       PIR: 2000(64kbps)    PBS : 200(Kbyte)
Action:
Conform : Permit                               Counter : Disabled
Exceed  : Permit   Replace DSCP: 21             Counter : Disabled
Violate : Drop                                   Counter : Disabled

Total Entries : 1

DGS-3627:admin#
```

ADDRESS RESOLUTION PROTOCOL (ARP) COMMANDS

The Address Resolution Protocol (ARP) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create arpentry	<ipaddr> <macaddr>
delete arpentry	[<ipaddr> all]
config arpentry	<ipaddr> <macaddr>
config arp_aging time	<min 0-65535>
clear arptable	
show arpentry	{ipif <ipif_name 12> ipaddress <ipaddr> static mac_address <macaddr>}

Each command is listed, in detail, in the following sections.

create arpentry

Purpose	Used to create a static entry in the ARP table.
Syntax	create arpentry <ipaddr> <macaddr>
Description	This command is used to enter a static ARP entry into the switch's ARP table.
Parameters	<i>ipaddr</i> - The IP address of the end node or station. <i>macaddr</i> - The MAC address corresponding to the IP address above.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a static ARP entry for the IP address 10.48.74.121 and MAC address 00-50-BA-00-07-36:

```
DGS-3627:admin# create arpentry 10.48.74.121 00-50-BA-00-07-36
Command: create arpentry 10.48.74.121 00-50-BA-00-07-36

Success.

DGS-3627:admin#
```

delete arpentry

Purpose	Used to delete a static entry from the ARP table.
Syntax	delete arpentry [<ipaddr> all]
Description	This command is used to delete an ARP entry, by specifying either the IP address of the entry or all. Specifying 'all' clears the switch's ARP table.
Parameters	<i>ipaddr</i> - The IP address of the end node or station. <i>all</i> - Delete all ARP entries.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an entry of IP address 10.48.74.121 from the ARP table:

```
DGS-3627:admin# delete arpentry 10.48.74.121
Command: create arpentry 10.48.74.121

Success.

DGS-3627:admin#
```

config arpentry

Purpose	Used to configure a static entry's MAC address in the ARP table.
Syntax	config arpentry <ipaddr> <macaddr>
Description	This command configures a static entry's MAC address in the ARP table. Specify the IP address and MAC address of the entry.
Parameters	<i>ipaddr</i> - The IP address of the end node or station. <i>macaddr</i> - The MAC address corresponding to the IP address above.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure a static ARP entry with IP address 10.48.74.121 to have a MAC address of 00-50-BA-00-07-37:

```
DGS-3627:admin# config arpentry 10.48.74.121 00-50-BA-00-07-37
Command: config arpentry 10.48.74.121 00-50-BA-00-07-37

Success.

DGS-3627:admin#
```

config arp_aging time

Purpose	Used to configure the aging out time for an ARP entry.
Syntax	config arp_aging time <min 0-65535>
Description	This command sets the maximum amount of time, in minutes, that a dynamic ARP entry can remain in the switch's ARP table, without being accessed, before it is dropped from the table.
Parameters	<i>min</i> - The ARP age-out time, in minutes. The default is 20. The range is 0 to 65535.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure an ARP aging time of 30 minutes:

```
DGS-3627:admin# config arp_aging time 30
Command: config arp_aging time 30

Success.

DGS-3627:admin#
```

clear arptable

Purpose	Used to clear all the dynamic ARP entries from the ARP table.
Syntax	clear arptable
Description	This command is used to clear all the dynamic entries from ARP table.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To clear the ARP table:

```
DGS-3627:admin# clear arptable
Command: clear arptable

Success.

DGS-3627:admin#
```

show arprentry

Purpose	Used to display the ARP table.
Syntax	show arprentry {ipif <ipif_name 12> ipaddress <ipaddr> static mac_address <macaddr> }
Description	This command is used to displays the ARP table. You can filter the display by IP address, interface name, static entries, or MAC address.
Parameters	<i>ipif_name</i> - The name of the IP interface the end node or station for which the ARP table entry was made, resides on. <i>ipaddr</i> - The IP address of the end node or station. <i>static</i> - Display the static entries in the ARP table. <i>macaddr</i> - Displays the ARP entry by MAC address.
Restrictions	Only Administrator, Operator, and User level users can issue this command.

Example usage:

To display the ARP table:

```
DGS-3627:admin# show arpentry
```

```
Command: show arpentry
```

```
ARP Aging Time : 20
```

Interface	IP Address	MAC Address	Type
System	10.0.0.0	FF-FF-FF-FF-FF-FF	Local/Broadcast
System	10.1.1.1	00-02-03-04-05-06	Static
System	10.1.1.2	00-02-03-04-05-06	Dynamic
System	10.1.1.3	00-02-03-04-05-06	Static
System	10.90.90.90	00-01-02-03-04-00	Local
System	10.255.255.255	FF-FF-FF-FF-FF-FF	Local/Broadcast

```
Total Entries: 6
```

```
DGS-3627:admin#
```


ARP SPOOFING PREVENTION COMMANDS

The ARP Spoofing Prevention commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config arp_spoofing_prevention	[add gateway_ip <ipaddr> gateway_mac <macaddr> ports [<portlist> all] delete gateway_ip <ipaddr>]
show arp_spoofing_prevention	

Each command is listed, in detail, in the following sections.

config arp_spoofing_prevention

Purpose	The user can configure the spoofing prevention entry to prevent spoofing of MAC for the protected gateway.
Syntax	config arp_spoofing_prevention [add gateway_ip <ipaddr> gateway_mac <macaddr> ports [<portlist> all] delete gateway_ip <ipaddr>]
Description	The user can configure the spoofing prevention entry to prevent spoofing of MAC for the protected gateway. When an entry is created, those ARP packets whose sender IP matches the gateway IP of an entry, but either its sender MAC field or source MAC field does not match the gateway MAC of the entry will be dropped by the system.
Parameters	<p><i>add</i> - Specifies to add an ARP spoofing prevention entry.</p> <p><i>gateway_ip</i> - Specifies a gateway IP address to be configured.</p> <p><i><ipaddr></i> - Enter the IP address used for this configuration here.</p> <p><i>gateway_mac</i> - Specifies a gateway MAC address to be configured.</p> <p><i><macaddr></i> - Enter the MAC address used for this configuration here.</p> <p><i>ports</i> - Specifies a range of ports to be configured.</p> <p><i><portlist></i> - Enter a list of ports used for the configuration here.</p> <p><i>all</i> - Specifies all of ports to be configured.</p> <p><i>delete</i> - Specifies to delete an ARP spoofing prevention entry.</p> <p><i>gateway_ip</i> - Specifies a gateway ip to be configured.</p> <p><i><ipaddr></i> - Enter the IP address used for this configuration here.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the ARP spoofing prevention entry:

```
DGS-3627:admin# config arp_spoofing_prevention add gateway_ip 10.254.254.251 gateway_mac 00-00-00-11-11-11 ports 1-2
Command: config arp_spoofing_prevention add gateway_ip 10.254.254.251 gateway_mac 00-00-00-11-11-11 ports 1-2
```

Success.

```
DGS-3627:admin#
```

show arp_spoofing_prevention

Purpose	This command is used to show the ARP spoofing prevention entry.
Syntax	show arp_spoofing_prevention
Description	This command is used to show the ARP spoofing prevention entry.
Parameters	None.
Restrictions	None.

Example usage:

To display the ARP spoofing prevention entries:

```
DGS-3627:admin# show arp_spoofing_prevention
Command: show arp_spoofing_prevention

ARP Spoofing Prevention Table
Gateway IP Address Gateway MAC Address Port
-----
10.254.254.251      00-00-00-11-11-11  1-2

Total Entries : 1

DGS-3627:admin#
```

BORDER GATEWAY PROTOCOL (BGP) DEBUG COMMANDS

BGP is a UNICAST Routing protocol. It can be used on any Layer 3 Ethernet switch supporting the IP routing function.

The Border Gateway Protocol (BGP) debug commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
debug error_log	[dump clear upload_toTFTP <ipaddr> <path_filename 64>]
debug buffer	[utilization dump clear upload_toTFTP <ipaddr> <path_filename 64>]
debug output	[module <module_list> all] [buffer console]
debug bgp show flag	
debug bgp all flag	[enable disable]
debug bgp fsm_event	[enable disable]
debug bgp packet	[{open update keepalive notify refresh capability } (1) all] [in out] [enable disable]
debug bgp error state	[enable disable]
debug bgp show global_info	
debug bgp show peer	
debug bgp show peer_group	
debug bgp show network	
debug bgp show aggregate	
debug bgp show damp	
debug bgp show interface_info	
debug bgp show bgp_timer	
debug bgp show redist_list	
debug bgp show as_path_access_list	
debug bgp show community_list	
debug bgp route_map	[enable disable]
debug bgp access_list	[enable disable]
debug bgp prefix_list	[enable disable]

Each command is listed, in detail, in the following sections.

debug error_log

Purpose	This command is used to dump, clear, or upload the software error log to the TFTP server
Syntax	debug error_log [dump clear upload_toTFTP <ipaddr> <path_filename 64>]
Description	This command is used to dump, clear, or upload the software error log to the TFTP server.

debug error_log

	The "error_log" here refers to the software error log stored in NVRAM. For more information on this command, please refer to the UIS-Debug topic
Parameters	<p><i>dump</i> - Displays debug messages occurring in the debug log.</p> <p><i>clear</i> - Clears the debug log.</p> <p><i>upload_toTFTP</i> - Uploads the debug log to the TFTP server that is specified by its IP address.</p> <p><i><ipaddr></i> - IP version 4 address</p> <p><i><path_filename 64></i> - Uploads the debug log to the TFTP server and names it to the string <i><path_filename 64></i>.</p>
Restrictions	Only Administrator level users can issue this command.

Example usage:

To dump the error log:

```
DGS-3627:admin# debug error_log dump
Command: debug error_log dump

*****
# debug log: 1
# level: fatal
# clock: 1000ms
# time : 2010/03/11 13:00:00

===== SOFTWARE FATAL ERROR =====
Invalid mutex handle : 806D6480

Current TASK : bcmARL.0

----- TASK STACKTRACE -----
->802ACE98
->8018C814
->8028FF44
->8028352C
->801D703C
->8013B8A4
->802AE754
->802A5E0C
->802A5D6C

-----
TASK  NAME  StackTop  CurStkSP  StackSize  SchCnt  PRIO(I)  STATUS
8069E7D0  FWD-ETH  823E9798  823E95C4  1K/ 32K   2      160/160  Q:IP_PKT
806A3E70  SysLogTask  80BD040C  80BD0298  1K/ 16K   3      180/180
          E:SysLogEvent

Output truncated...
```

debug buffer

Purpose	This command is used to show the debug buffer's state, dump clear, or upload the debug buffer to the TFTP server
Syntax	debug buffer [utilization dump clear upload_toTFTP <ipaddr> <path_filename 64>]
Description	This command is used to show the debug buffer's state or dump, clear, or upload the debug

debug buffer

	buffer to the TFTP server. The “buffer” here refers to the module debug messages stored in the RAM. For more information on this command, please refer to the UIS-Debug topic
Parameters	<p><i>utilization</i> - Displays the debug buffer’s state</p> <p><i>dump</i> - Displays the debug messages in the debug buffer.</p> <p><i>clear</i> - Clears the debug buffer</p> <p><i>upload_toTFTP</i> - Uploads the debug buffer to the TFTP server that is specified by its IP address</p> <p><i><ipaddr></i> - IP version 4 address</p> <p><i><path_filename 64></i> - Uploads the debug buffer to the TFTP server and names it to the string <i><path_filename 64></i>.</p>
Restrictions	Only Administrator level users can issue this command.

Example usage:

To show the debug buffer’s state:

```
DGS-3627:admin# debug buffer utilization
Command: debug buffer utilization

Allocate from      :      System memory
Total size       :      2 MB
Utilization rate  :      30%

DGS-3627:admin#
```

debug output

Purpose	This command is used to set the specified module’s debug message output to the debug buffer or console
Syntax	debug output [module <module_list> all] [buffer console]
Description	This command is used to set the specified module’s debug message output to the debug buffer or console. For more information on this command, please refer to the UIS-Debug topic.
Parameters	<p><i><module_list></i> - This is the controlling module list. For BGP debug, use BGP as the parameter.</p> <p><i>all</i> - Control output method of all modules.</p> <p><i>buffer</i> - Let debug messages of the module output to the debug buffer.(default)</p> <p><i>console</i> - Let debug messages of the module output to the console.</p>
Restrictions	Only Administrator level users can issue this command.

Example usage:

To set all modules’ debug message output to console:

```
DGS-3627:admin# debug output all console
Command: debug output all console

Success.

DGS-3627:admin#
```

debug bgp show flag

Purpose	This command is used to display the current BGP debugging flags' setting
Syntax	debug bgp show flag
Description	This command is used to display the current BGP debugging flags' setting
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

This example shows the BGP debug flag:

```
DGS-3627:admin# debug bgp show flag
```

```
Command: debug bgp show flag
```

```
Current BGP flags setting:
```

```

Peer FSM Event           Disable
OPEN Packet Receive     Disable
OPEN Packet Send        Disable
UPDATE Packet Receive    Disable
UPDATE Packet Send       Disable
KEEPALIVE Packet Receive Disable
KEEPALIVE Packet Send    Disable
NOTIFY Packet Receive    Disable
NOTIFY Packet Send       Disable
REFRESH Packet Receive   Disable
REFRESH Packet Send      Disable
CAPABILITY Packet Receive Disable
CAPABILITY Packet Send   Disable
Filter Info              Disable
Route MAP                Disable
Access List              Disable
Prefix List              Disable
ERROR Information        Disable
Zebros Debug Info        Disable
Other Normal Information. Disable
    
```

```
DGS-3627:admin#
```

debug bgp all flag

Purpose	This command is used to set all BGP debugging flags to be disabled or enabled
Syntax	debug bgp all flag [enable disable]
Description	This command is used to set all BGP debugging flags to be disabled or enabled
Parameters	<i>enable</i> - Enable the BGP debug function <i>disable</i> - Disable the BGP debug function
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure all BGP debug flags' state to be enabled:

```
DGS-3627:admin# debug bgp all flag enable
Command: debug bgp all flag enable

Success.

DGS-3627:admin#
```

debug bgp fsm_event

Purpose	This command is used to set the flag of debugged information related to the peer FSM Event
Syntax	debug bgp fsm_event [enable disable]
Description	This command is used to set the flag of debugged information related to the peer FSM Event
Parameters	<i>enable</i> - Enable the BGP debug function <i>disable</i> - Disable the BGP debug function
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure BGP peer FSM event debug flag to be enabled:

```
DGS-3627:admin# debug bgp fsm_event enable
Command: debug bgp fsm_event enable

Success.

DGS-3627:admin#
```

After the BGP peer FSM event debug flag is set to enable, it may print following information:

```
BGP: 10.1.1.1-10.2.2.2, [FSM] State Change: Idle -> Connect.
BGP: 10.1.1.1-10.2.2.2, [FSM] Hold-Timer Expiry.
BGP: 10.1.1.1-10.2.2.2, [FSM] State: Open, Event: 3.
```

debug bgp packet

Purpose	This command is used to set the flag of debugged information related to the different type of BGP packets, receiving and sending.
Syntax	debug bgp packet [{open update keepalive notify refresh capability } (1) all] [in out] [enable disable]
Description	This command is used to set the flag of debugged information related to the different type of BGP packets, receiving and sending. When a packet is sent or received and the updated packet's NLRI prefix is more than 5, the debugged information will only show the number five in the NLRI prefix followed by three dots to the end.
Parameters	<i>packet</i> - Packet type for debug information to display: open update keepalive notify refresh capability all

debug bgp packet

	Direction of packet: in out
	<i>enable</i> - Enable the BGP debug function <i>disable</i> - Disable the BGP debug function
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure BGP to display debugging information after it received update packets:

```
DGS-3627:admin# debug bgp packet all in enable
Command: debug bgp packet all in enable

Success.

DGS-3627:admin#
```

After the BGP peer FSM event debug flag is enabled, it may print following information:

```
BGP:Peer:<10.1.1.10> RCV OPEN, version:<4>,remote-as:<40>, HoldTime:<180>,RID:<16.0.0.1>
BGP:Peer:<10.1.1.10> RCV KEEPALIVE.
BGP:Peer:<10.1.1.10> RCV UPDATE, withdraw: <21.0.0.0/8>,<22.0.0.0/8>,<23.0.0.0/8>,<24.0.0.0/8>,<25.0.0.0/8>...
BGP:Peer:<10.1.1.10> RCV UPDATE,attr:<Orign:i,As-path:10,Next-hop:10.1.1.10,Med:5>, NLRI:<21.0.0.0/8>,<22.0.0.0/8>
BGP:Peer:<10.1.1.10> RCV NOTIFCATION,Code:<OPEN Message Error.>,SubCode:<Bad Peer AS.>
BGP:Peer:<10.1.1.10> RCV REFRESH,afi:<1>,safi:<1>
BGP:Peer:<10.1.1.10> RCV Capability Action:Set,Code: GRST ,Length:2
```

debug bgp error

Purpose	This command is used to set the flag of debugging information related to BGP errors, to not send BGP notifications
Syntax	debug bgp error state [enable disable]
Description	This command is used to set the flag of debugging information related to BGP errors, to not send BGP notifications
Parameters	<i>enable</i> - Enable the BGP debug function <i>disable</i> - Disable the BGP debug function
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure BGP to enable the error debug flag:

```
DGS-3627:admin# debug bgp error state enable
Command: debug bgp error state enable

Success.

DGS-3627:admin#
```


After configuring BGP to enable the error debug flag, it may print following information when an error happens:

```
BGP: 10.1.1.1-10.2.2.2, NHop Validate: Invalid NHop address 250.3.0.0/8 received.
BGP: Hold-Timer: Invalid Peer.
```

debug bgp show global_info

Purpose	This command is used to display global information of the current BGP instance.
Syntax	debug bgp show global_info
Description	This command is used to display global information of the current BGP instance.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure BGP to show global information:

```
DGS-3627:admin# debug bgp show global_info
Command: debug bgp show global_info

Following is the information for global debugging:
-----

AS Number                : 10000
Router ID                 : 192.168.60.105
Cluster ID                : 0.0.0.0
Confed ID                 : 0
Confederation peers      :
Fast External Fallover   : Enabled
Graceful Restart         : Disabled
Restart Time              : 120 Seconds
Stalepath Time           : 360 Seconds
Update Delay Time        : 120 Seconds
Dampening ability        : Disabled
Client to Client ability : Enable
Cluster peers are:

Aggregate Next_Hop_Check : Disabled
Default Local Preference : 100
Default Holdtime         : 180
Default Keepalive        : 60
Scan Time                 : 60

BGP active flag:

BGP active af-flag is:
BGP_AF_CFLAG_NETWORK_SYNC
note: address family is IPv4 Unicast

BGP active Redist-Flags:
note: The address family is IPv4

BGP Trap                  : None

DGS-3627:admin#
```

debug bgp show peer

Purpose	This command is used to display information of all the peers in the BGP protocol database.
Syntax	debug bgp show peer
Description	This command is used to display information of all the peers in the BGP protocol database.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure BGP to show all the peers' information:

```

DGS-3627:admin# debug bgp show peer
Command: debug bgp show peer

BGP neighbor: 10.10.10.2 (Internal Peer)
-----
Session State: Enabled
Session Activity: Enabled
Peer Group: NULL
Remote AS: 1
Local AS:10
Remote Router ID:192.168.252.252
BGP State: Established ( UP for 00:24:25)
Hold Time (Configured): 180 Seconds
Hold Time(Current Used): 180 Seconds
Keepalive Interval (Configured): 60 Seconds
Keepalive Interval(Current Used): 60 Seconds
Advertisement Interval(Configured): 5 Seconds
Advertisement Interval (Current Used) : 5 Seconds
AS Origination Interval (Configured) : 0 Seconds
AS Origination Interval (Current Used) : 15 Seconds
Connect Retry Interval (Configured) : 0 Seconds
Connect Retry Interval (Current Used) : 120 Seconds
EBGP Multihop: 2
Weight: 100
Next Hop Self: Disabled
Remove Private AS: Disabled
Allowas In: Disabled
Graceful Restart : Disabled
Address Family IPv4 Unicast
IPv4 Unicast: Advertised and Received
Soft Reconfiguration Inbound: Enabled
Community Sent to this Neighbor: Both Standard and Extended
Default Originate: Enabled
Incoming Update Prefix List: prelist1
Incoming Update Filter List: ASlist1
Route Map for Outgoing Routes: routemap1
Unsuppress Route Map: us_routmpl
Outbound Route Filter (ORF) type (64) Prefix-list:
Send Mode: Enabled
Receive Mode: Disabled
IP Route Prefix List orf_prelist1: 1 entries
seq 5 permit 30.0.0.0/8
Prefix Count: 1560
Send Prefix Count: 860
Prefix Max Count: 12000
Prefix warning threshold: 75
Prefix Max Warning: Disabled

DGS-3627:admin#
    
```

debug bgp show peer group

Purpose	This command is used to display the current peer group's configuration in the BGP protocol stack
Syntax	debug bgp show peer_group
Description	This command is used to display the current peer group's configuration in the BGP protocol stack

debug bgp show peer group

Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure BGP to show the peer group's configuration:

```
DGS-3627:admin# :5#debug bgp show peer_group
Command: debug bgp show peer_group
```

```
BGP Peer Group :local1
```

```
-----
Session State : Enabled
Session Activity : Enabled
Members : 192.168.6.102
Remote AS : Not Set
Holdtime Interval : 180 seconds
Keepalive Interval : 60 seconds
Advertisement Interval : 0 seconds
AS Origination Interval : 0 Seconds
Connect Retry Interval : 0 Seconds
EBGP Multihop : 1
Weight : 0
Next Hop Self : Disabled
Remove Private As : Disabled
Allows In : Disabled
Graceful Restart : Disabled
Soft Reconfiguration Inbound : Disabled
Community Sent to this Neighbor : None
Default Originate : Disabled
Capability Orf Prefix List : None
Prefix max count: 12000
Prefix warning threshold: 75
Prefix max warning: Disabled
```

```
DGS-3627:admin#
```

debug bgp show network

Purpose	This command is used to display the current network's configuration in the BGP protocol stack.
Syntax	debug bgp show network
Description	This command is used to display the current network's configuration in the BGP protocol stack.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure BGP to show the current network information:

```
DGS-3627:admin# debug bgp show network
```

```
Command: debug bgp show network
```

Network	Route Map
-----	-----
192.168.0.0/8	NULL
172.16.0.0/16	map1

```
Total Entries :2
```

```
DGS-3627:admin#
```

debug bgp show aggregate

Purpose	This command is used to display the current aggregate's configuration in the BGP protocol stack.
Syntax	debug bgp show aggregate
Description	This command is used to display the current aggregate's configuration in the BGP protocol stack.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure BGP to show the current aggregate's information:

```
DGS-3627:admin# debug bgp show aggregate
```

```
Command: debug bgp show aggregate
```

Network	Summary Only	AS Set	Suppress Count
-----	-----	-----	-----
192.168.0.0/8	YES	NO	0
172.16.0.0/16	NO	NO	0

```
Total Entries :2
```

```
DGS-3627:admin#
```

debug bgp show damp

Purpose	This command is used to display the current dampening configuration and corresponding dynamic information in the BGP protocol stack.
Syntax	debug bgp show damp
Description	This command is used to display the current dampening configuration and corresponding dynamic information in the BGP protocol stack
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure BGP to show the current dampening information:

```

DGS-3627:admin# debug bgp show damp
Command: debug bgp show damp

Route Map                : NULL
Reach Half Life Time is  : 900 seconds
Reuse Value              : 750
Suppress Value           : 2000
Max Suppress Time        : 3600 seconds
Unreach Half Life Time is : 900 seconds
Reuse Index Size         : 1024
Reuse List Size          : 512
Reuse Offset             : 0

Current dampened routes:

  Damp Reuse List Info:
reuse_index index  ptr penalty   flap  start_time  t_updated   suppress_time
  evt

show BGP Damp no reuse list info: 0
index ptr penalty flap  start_time  t_updated   suppress_time evt

BGP Damp Decay List Info:
decay array size is 90.
Index  value
-----
1      1
2      0.969663
3      0.940247
4      0.911722
5      0.884064
6      0.857244
7      0.831238
8      0.806021
9      0.781569
10     0.757858
Output truncated...

DGS-3627:admin#

```

debug bgp show interface_info

Purpose	This command is used to display the current interface information in the BGP protocol stack.
Syntax	debug bgp show interface_info
Description	This command is used to display the current interface information in the BGP protocol stack.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure BGP to show the current interface information:

```
DGS-3627:admin# debug bgp show interface_info
```

```
Command: debug bgp show interface_info
```

```
Interface Information:
```

Name	Index	Network	Flags	Status
-----	-----	-----	-----	-----
System	0001	30.30.30.30/8	0	Up

```
DGS-3627:admin#
```

debug bgp show bgp_timer

Purpose	This command is used to display the current BGP timer chain information in the BGP protocol stack.
Syntax	debug bgp show bgp_timer
Description	This command is used to display the current BGP timer chain information in the BGP protocol stack.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure BGP to show the current BGP timer chain information:

```
DGS-3627:admin# debug bgp show bgp_timer
```

```
Command: debug bgp show bgp_timer
```

```
BGP timer Link:
node      time      func
-----
08B108D0  0001     00675AF4
08B1AC70  0016     0065F4F4
08B1ACA8  0017     0065F5CC
08B37DCC  0029     0065F4F4
08B37E04  0030     0065F5CC
032821BC  0035     00662840
08B1AC54  0135     0065F40C
08B37DB0  0148     0065F40C
```

```
DGS-3627:admin#
```

debug bgp show redistrib_list

Purpose	This command is used to display the current BGP redistribution information.
Syntax	debug bgp show redistrib_list
Description	This command is used to display the current BGP redistribution information.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure BGP to show the current BGP redistribution information:

```
DGS-3627:admin# debug bgp show redist_list
Command: debug bgp show redist_list

Last redistribution count summary:
Type      Route_count_rib  total_count      Time(msec)
-----
OSPF      0                 0                 0
RIP       0                 0                 0
STATIC    0                 0                 0
LOCAL     0                 0                 0

Redistributed routes summary:
Network          Type  Route_map  Metric  Next_hop
-----
Total entry: 0

Redist list information:
No redist list exist!

DGS-3627:admin#
```

debug bgp show as_path_access_list

Purpose	This command is used to display the current BGP path access list configuration in the BGP protocol stack.
Syntax	debug bgp show as_path_access_list
Description	This command is used to display the current BGP path access list configuration in the BGP protocol stack.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure BGP to show the current BGP path access list information:

```
DGS-3627:admin# debug bgp show as_path_access_list
Command: debug bgp show as_path_access_list

BGP AS Path Access List 1
deny (_64[6-9][0-9][0-9]_|_65[0-9][0-9][0-9]_)
permit 33

Total entry: 1

DGS-3627:admin#
```

debug bgp show community_list

Purpose	This command is used to display the current community list configuration in the BGP protocol stack.
Syntax	debug bgp show community_list
Description	This command is used to display the current community list configuration in the BGP protocol stack.

debug bgp show community_list

Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure BGP to show the current community list information:

```
DGS-3627:admin# debug bgp show community_list
Command: debug bgp show community_list

Community list:1 standard
    permit internet

DGS-3627:admin#
```

debug bgp route_map

Purpose	This command is used to set the route map debugging flags to disabled or enabled. If this flag is enabled, the route map permit or deny values in the BGP module will be displayed.
Syntax	debug bgp route_map [enable disable]
Description	This command is used to set the route map debugging flags to be disabled or enabled.
Parameters	<i>enable</i> - Enable the route_map debug function. <i>disable</i> - Disable the route_map debug function.
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure the route map debugging flags' state to be enabled:

```
DGS-3627:admin# debug bgp router_map enable
Command: debug bgp router_map enable

Success.
```

After configuring BGP to enable the route map debug flag, it may print the following information when the route map is applied:

```
route_map:<map1>,apply bgp neighbor:<13.0.0.1> MATCH.
route_map:<map1>,apply bgp static route:<32.0.0.0/8> Not MATCH.
```

debug bgp access_list

Purpose	This command is used to set the access list debugging flags to be disabled or enabled. If this flag is enabled, the access list will display the values permit or deny in BGP module.
Syntax	debug bgp access_list [enable disable]
Description	This command is used to set the access list debugging flags to be disabled or enabled.
Parameters	<i>enable</i> - Enable the access_list debug function <i>disable</i> - Disable the access_list debug function
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure the access list debug flags' state to be enabled:

```
DGS-3627:admin# debug bgp access_list enable
Command: debug bgp access_list enable

Success.
```

After configuring BGP to enable the access list debug flag, it may print following information when the access list is applied:

```
access_list:<acl>,apply bgp neighbor:<19.0.0.1> MATCH.
```

debug bgp prefix_list

Purpose	This command is used to set the prefix list debugging flags to be disabled or enabled. If this flag is enabled, the prefix list will display the values permit or deny in BGP module.
Syntax	debug bgp prefix_list [enable disable]
Description	This command is used to set the prefix list debugging flags to be disabled or enabled.
Parameters	<i>enable</i> - Enable the prefix_list debug function <i>disable</i> - Disable the prefix_list debug function
Restrictions	Only Administrator level users can issue this command.

Example usage:

Configure the prefix list debug flags' state to be enabled:

```
DGS-3627:admin# debug bgp prefix_list enable
Command: debug bgp prefix_list enable

Success.
```

After configuring BGP to enable the prefix list debug flag, it may print the following information when the prefix list is applied:

```
Prefix_list:<list1>,apply bgp neighbor:<15.0.0.1> MATCH.
```

BORDER GATEWAY PROTOCOL (BGP) COMMANDS

The Border Gateway Protocol (BGP) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
enable bgp	
disable bgp	
create bgp	<as_number 1-65535>
delete bgp	<as_number 1-65535>
config bgp router_id	<ipaddr>
config bgp synchronization	[enable disable]
config bgp enforce_first_as	[enable disable]
create bgp aggregate_address	<network_address> {summary_only as_set}
delete bgp aggregate_address	[<network_address> all]
show bgp aggregate_address	{<network_address>}
create bgp network	<network_address> {route_map <map_name 16>}
config bgp network	<network_address> [route_map <map_name 16> clear_routemap]
delete bgp network	[<network_address> all]
show bgp network	{<network_address>}
config bgp timer	holdtime <sec 0-65535> keepalive <sec 0-65535>
config bgp	{ always_compare_med [enable disable] deterministic_med [enable disable] default_local_preference <uint 0-4294967295> bestpath { as_path_ignore [enable disable] compare_routerid [enable disable] med_confed [enable disable] med_missing_as_worst [enable disable] compare_confed_aspath [enable disable] }(1)}(1)
config bgp dampening	[route_map <map_name 16> clear_routemap { state [enable disable] half_life <min 1-45 > reuse<value 1-20000> suppress <value 1-20000> max_suppress_time <min 1-255 > un_reachability_half_life <min 1-45>}(1)]
show bgp dampening	
config bgp peer_group	<peer_group_name 16> [add delete] <ipaddr>
config bgp peer_group	<peer_group_name 16> remote_as <as_number 0-65535>
create bgp neighbor	[<ipaddr> [remote_as <as_number 1-65535>] peer_group <peer_group_name 16>] peer_group <peer_group_name 16>]
delete bgp neighbor	[<ipaddr> peer_group <peer_group_name 16> all]
config bgp neighbor description	[<ipaddr> peer_group <peer_group_name 16>] [description <desc 80> clear_description]
config bgp neighbor session	[<ipaddr> peer_group <peer_group_name 16>] state [enable disable]
config bgp neighbor session	[<ipaddr> peer_group <peer_group_name 16>] activity [enable disable]

config bgp neighbor general	[<ipaddr> peer_group <peer_group_name 16>] { ebgp_multihop <value 1-255> weight [<value 0-65535> default] update_source [add delete] ipif <ipif_name 12> send_community [standard none] next_hop_self [enable disable] soft_reconfiguration_inbound [enable disable] remove_private_as [enable disable] allowas_in [enable {<value 1-10>} disable] default_originate [enable {route_map <map_name 16>} disable] }(1)
config bgp neighbor timer	[<ipaddr> peer_group <peer_group_name 16>] { advertisement_interval [<sec 0-600> default] [keepalive <sec 0-65535> holdtime <sec 0-65535> default_keepalive_holdtime] as_Origination_interval [<sec 1-600> default] connect [<sec 1-65535> default]}(1)
config bgp neighbor route_reflector_client	[<ipaddr> peer_group <peer_group_name 16>] state [enable disable]
config bgp neighbor map	[<ipaddr> peer_group <peer_group_name 16>] { unsuppress_map [add delete] <map_name 16> route_map [in out] [add delete] <map_name 16>}(1)
config bgp neighbor filter	[<ipaddr> peer_group <peer_group_name 16>] { filter_list [in out] [add delete] <list_name 16> prefix_list [in out] [add delete] <list_name 16> capability_orf_prefix_list [receive send both none]}(1)
show bgp peer_group	{<peer_group_name 16>}
config bgp route_reflector cluster_id	<ipaddr>
config bgp client_to_client_reflection	[enable disable]
config bgp confederation identifier	<as_number 0-65535>
config bgp confederation peers	[add delete] <aspath_list>
clear bgp	[all ipaddr <ipaddr> as <as_number 1-65535> peer_group <peer_group_name 16> external] {soft {[in { prefix_filter} out]}}
clear bgp dampening	{[<ipaddr> <network_address>]}
create bgp as_path access_list	<list_name 16>
config bgp as_path access_list	<list_name 16> [add delete] <regexp_str 80> [deny permit]
delete bgp as_path access_list	[list_name <list_name 16> all]
show bgp as_path access_list	{<list_name 16>}
create bgp community_list	[standard expanded] <list_name 16>
config bgp community_list	[standard <list_name 16> [add delete] {internet local_as no_advertise no_export community_set <community_set 80>} [deny permit] expanded <list_name 16> [add delete] <regexp_str 80> [deny permit]]
delete bgp community_list	[list_name <list_name 16> all]
show bgp community_list	{<list_name 16>}
show bgp route	{[regexp <desc 80> inconsistent_as cidr_only filter_list <list_name 16> route_map <map_name 16> community {community_set <community_set 80> local_as no_advertise no_export internet}{exact_match} community_list <list_name 16> {exact_match} ipaddress <ipaddr> network <network_address> {longer_prefixes} prefix_list <list_name 16>]}
show bgp neighbors	{<ipaddr> {[advertised_routes received_routes routes received_prefix_filter statistics]}}
show bgp dampened_routes	
show bgp flap_statistics	
show bgp	{summary}
show bgp reflection	

show bgp confederation	
config bgp trap	[peer_established peer_idle all] [enable disable]
show bgp trap_state	
config bgp scan_timer	[<sec 5-60> default]
config bgp aggregate_next_hop_check	[enable disable]
config bgp fast_external_fallover	[enable disable]
config bgp neighbor maximum_prefix	[<ipaddr> peer_group <peer_group_name 16>] <value 1-12000> {<value 1-100>} {warning_only}
clear bgp flap_statistics	{[<ipaddr> <network_address>]}

Each command is listed, in detail, in the following sections.

enable bgp

Purpose	This command is used to enable the BGP protocol.
Syntax	enable bgp
Description	By enabling the BGP protocol, all the previous configurations will be applied to the protocol kernel and start. By default, BGP is disabled.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable BGP protocol:

```
DGS-3627:admin# enable bgp
Command: enable bgp

Success.

DGS-3627:admin#
```

disable bgp

Purpose	This command is used to disable the BGP protocol.
Syntax	disable bgp
Description	By disabling the BGP protocol, all peers will be disconnected and dynamic routes will be deleted. All the static configurations however will be reserved. If BGP is enabled again, the previous configurations can be re-applied.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable BGP protocol:

```
DGS-3627:admin# disable bgp
Command: disable bgp

Success.

DGS-3627:admin#
```

create bgp

Purpose	This command is used to create a BGP process. It's AS number must be set.
Syntax	create bgp <as_number 1-65535>
Description	When the BGP protocol starts, it must belong to a single AS. The user must set the AS number before configuring any of the other attributes.
Parameters	<as_number> - Specifies the BGP AS number. The valid value is from 1 to 65535.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a BGP process:

```
DGS-3627:admin# create bgp 100
Command: create bgp 100

Success.

DGS-3627:admin#
```

delete bgp

Purpose	This command is used to delete the BGP process.
Syntax	delete bgp <as_number 1-65535>
Description	This command is used to delete the BGP process. The AS number must be specified. When the BGP process is deleted, all peer and route information from BGP will be deleted. Route entries redistributed from BGP must also be canceled.
Parameters	<as_number> - Specifies the BGP AS number. The valid value is from 1 to 65535.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete a BGP process:

```
DGS-3627:admin# delete bgp 100
Command: delete bgp 100

Success.

DGS-3627:admin#
```

config bgp router_id

Purpose	This command is used to configure the BGP process's router ID
Syntax	config bgp router_id <ipaddr>

config bgp router_id

Description	<p>The address of a loopback interface is preferred to an IP address on a physical interface because the loopback interface is more effective than a fixed interface as an identifier because there is no physical link to go down.</p> <p>The user must specify a unique router ID within the network.</p> <p>This command will reset all active BGP peering sessions.</p> <p>When a router ID is not configured, the router ID is selected by the following rules:</p> <p>If a loopback interface is configured, the router ID is set to the IP address of the loopback.</p> <p>If multiple loopback interfaces are configured, the loopback with the highest IP address is used.</p> <p>If no loopback interface is configured, the router ID is set to the highest IP address on a physical interface.</p> <p>Note: One newly created interface whose address may be preferred to be the router ID according to the rules above, but, it will not be chosen to be router ID immediately. Only when the router ID is set to zero or when recreating a BGP instance, the new interface may be selected as the BGP router ID.</p>
Parameters	<ipaddr> - An ID to identify a BGP router. If it is set to zero the router ID will be automatically determined. The default value is the highest IP address on a physical interface.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the BGP process's router ID:

```
DGS-3627:admin# config bgp router_id 10.10.10.1
Command: config bgp router_id 10.10.10.1

Success
DGS-3627:admin#
```

config bgp synchronization

Purpose	This command is used to configure the BGP synchronization ability.
Syntax	config bgp synchronization [enable disable]
Description	Usually, a BGP speaker does not advertise a route to an external neighbor unless that route is local or exists in the IGP. By default, synchronization between BGP and the IGP is turned off to allow the BGP to advertise a network route without waiting for route validation from the IGP. This feature allows routers and access servers within an Autonomous System to have the route before BGP makes it available to other autonomous systems.
Parameters	<p><i>enable</i> - Specifies to enable synchronization..</p> <p><i>disable</i> - Specifies to disable synchronization. By default, this setting is disabled.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the BGP process' synchronization ability:

```
DGS-3627:admin# config bgp synchronization enable
Command: config bgp synchronization enable

Success
DGS-3627:admin#
```

config bgp enforce_first_as

Purpose	This command is used to enforce the neighbor's AS as the first AS in the AS list.
Syntax	config bgp enforce_first_as [enable disable]
Description	This command is used to enforce the neighbor's AS as the first AS in the AS list. When the setting is enabled, any updates received from an external neighbor, that does not have the neighbor's configured Autonomous System (AS) at the beginning of the AS_PATH in the received update, will be denied. Enabling this feature adds to the security of the BGP network by not allowing traffic from unauthorized systems.
Parameters	<i>enforce_first_as</i> - Enable or disable the enforce_first_as setting. The default setting is disabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the BGP process's enforce_first_as ability:

```
DGS-3627:admin# config bgp enforce_first_as enable
Command: config bgp enforce_first_as enable

Success
DGS-3627:admin#
```

create bgp aggregate_address

Purpose	This command is used to create an aggregate entry in the Border Gateway Protocol (BGP) database.
Syntax	create bgp aggregate_address <network_address> {summary_only as_set}
Description	Using the aggregate_address command with no keywords will create an aggregate entry in the BGP routing table, if any more specific BGP routes are available that fall within the specified range. The aggregate route will be advertised as coming from your Autonomous System and will have the atomic aggregate attribute set to indicate that information might be missing. That is, the original AS path associated with more specific routes will be lost. The atomic aggregate attribute is set unless you specify the as_set keyword. Using the as_set keyword will create an aggregate entry, but the path advertised for this route will include an AS set consisting of all ASs that are contained in all paths that are being summarized. Do not use continually withdrawn and updated as autonomous system path reachability information for the summarized routes changes. Using the summary_only keyword will create an aggregate route but suppresses advertisements of more specific routes to all neighbors. If you want to suppress only advertisements to certain neighbors, you may use the neighbor prefix_list command.
Parameters	<i><network_address></i> - The IP network address aggregated. <i>as_set</i> - Generates Autonomous System set path information. The default setting is not set. <i>summary_only</i> - More specific routes will not be advertised. The default setting is not set.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create an aggregate route of which the network address is 10.0.0.0/8, suppress more-specific routes:


```
DGS-3627:admin# create bgp aggregate_address 10.0.0.0/8 summary_only
Command: create bgp aggregate_address 10.0.0.0/8 summary_only

Success.

DGS-3627:admin#
```

delete bgp aggregate_address

Purpose	This command is used to delete an aggregate entry in a Border Gateway Protocol (BGP) database.
Syntax	delete bgp aggregate_address [<network_address> all]
Description	This command is used to delete an aggregate entry in a Border Gateway Protocol (BGP) database.
Parameters	<network_address> - The IP aggregated network to be deleted. all - Used to delete all IP aggregated networks.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an aggregate route for which the network address is 10.0.0.0/8:

```
DGS-3627:admin# delete bgp aggregate_address 10.0.0.0/8
Command: delete bgp aggregate_address 10.0.0.0/8

Success.

DGS-3627:admin#
```

show bgp aggregate_address

Purpose	This command is used to show an aggregate entry in the Border Gateway Protocol (BGP) database.
Syntax	show bgp aggregate_address {<network_address>}
Description	This command displays the aggregate network address.
Parameters	<network_address> - The IP aggregated network address. If a specific network address is not specified, all aggregated addresses will be displayed.
Restrictions	None.

Example usage:

To display an aggregate route of 10.0.0.0/8:

```
DGS-3627:admin# show bgp aggregate_address 10.0.0.0/8
Command: show bgp aggregate_address 10.0.0.0/8
Network Address      Options
-----
10.0.0.0/8          summary_only, as_set

Total Aggregate Address Number: 1

DGS-3627:admin#
```

create bgp network

Purpose	This command is used to specify the network advertised by the Border Gateway Protocol (BGP).
Syntax	create bgp network <network_address> {route_map <map_name 16>}
Description	BGP networks can be learned from connected routes, from dynamic routing, and from static route sources.
Parameters	<i><network_address></i> - Represents the local network that BGP will advertise. <i>route_map</i> - Specifies the route map to be applied to the advertised networks. If not specified, all networks are advertised.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To setup network 10.108.0.0/16 to be included in the BGP updates:

```
DGS-3627:admin# create bgp network 10.108.0.0/16
Command: create bgp network 10.108.0.0/16

Success.

DGS-3627:admin#
```

config bgp network

Purpose	This command is used to configure the attributes associated with the network advertised by the Border Gateway Protocol (BGP).
Syntax	config bgp network <network_address> [route_map <map_name 16> clear_routemap]
Description	This command changes the BGP attributes associated with the network.
Parameters	<i><network_address></i> - Represents the local network that BGP will advertise. <i><map_name 16></i> - Specifies the route map applied to the advertised networks. <i>clear_routemap</i> - Removes the route map applied to the network if specified this parameter.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To change the network 10.108.0.0/16 to clear a route map:

```
DGS-3627:admin# config bgp network 10.108.0.0/16 clear_routemap
Command: config bgp network 10.108.0.0/16 clear_routemap

Success.

DGS-3627:admin#
```

delete bgp network

Purpose	This command is used to delete the networks advertised by the Border Gateway Protocol (BGP).
Syntax	delete bgp network [<network_address> all]
Description	This command is used to delete the networks advertised.

delete bgp network

Parameters	<i><network_address></i> - Represents the local network that BGP will advertise. <i>all</i> - Deletes all BGP networks.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete network 10.108.0.0/16 to be advertised in the BGP updates:

```
DGS-3627:admin# delete bgp network 10.108.0.0/16
Command: delete bgp network 10.108.0.0/16

Success.

DGS-3627:admin#
```

show bgp network

Purpose	This command is used to show the networks advertised by the Border Gateway Protocol (BGP).
Syntax	show bgp network {<network_address>}
Description	This command used to show the networks advertised by BGP.
Parameters	<i><network_address></i> - Represents the local network that BGP will advertise. If a specific network address is not specified, all network addresses will be displayed.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show network 10.108.0.0/16 advertised in the BGP updates:

```
DGS-3627:admin# show bgp network 10.108.0.0/16
Command: show bgp network 10.108.0.0/16

Network Address      Route Map
-----
10.108.0.0/16       -

Total Network Number: 1

DGS-3627:admin#
```

config bgp timer

Purpose	This command is used to configure the BGP protocol timer.
Syntax	config bgp timer holdtime <sec 0-65535> keepalive <sec 0-65535>
Description	This command is used to configure the BGP protocol timer. The hold time needs to be at least three times that of the keepalive time. If the timer is specified for specific neighbors, then the neighbor specific timer will take effect.
Parameters	<i>holdtime</i> - The valid values are from 0 to 65535. The system will declare a peer as dead if a keepalive message is received that is more than the hold time.

config bgp timer

The default value is 180 seconds.

If the holdtime is set to zero, then the holdtime will never expire.

If the two routers that build a BGP connection have a different hold time, then the smaller hold time will be used.

If the timer is specified for specific neighbors, then the neighbor specific timer will take effect.

The hold time needs to be at least three times that of the keepalive timer.

keepalive - The valid values are from 0 to 65535.

This specifies the interval at which keepalive messages are sent to its peer.

If the keepalive value is set to zero, then the keepalive message will not be sent out.

The default value is 60 seconds.

If the two routers that build a BGP connection have a different keepalive timer, then the smaller keepalive timer will be used.

If the timer is specified for specific neighbors, then the neighbor specific timer will take effect.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the BGP hold and keepalive timer:

```
DGS-3627:admin# config bgp timer holdtime 360 keepalive 120
Command:4# config bgp timer holdtime 360 keepalive 120
```

Success.

```
DGS-3627:admin#
```

config bgp bestpath

Purpose This command is used to configure the BGP best path selection related setting.

Syntax `config bgp { always_compare_med [enable | disable] | deterministic_med [enable | disable] | default_local_preference <uint 0-4294967295> | bestpath { as_path_ignore [enable | disable] | compare_routerid [enable | disable] | med_confed [enable | disable] | med_missing_as_worst [enable | disable] | compare_confed_aspath [enable | disable] }(1)}(1)`

Description MED is a metric assigned to tell the external router how to choose a route. By default, MED is used to determine the route that is advertised by the same AS.

The BGP deterministic med command can be configured to enforce a deterministic comparison of the MED values between all the paths received from within the same Autonomous System

Default local preference

By default, a BGP router will send the default local preference with the routes. It can be overwritten if the local preference is set by the route map. For the received route, the local preference received with the route will be used in the best path selection. This local preference will be overwrite if the local preference is ingress set by the route map.

For the local routes, the default local preference will be used for them in the best path selection

Best path selection process

The following is the steps that the BGP will use to select the best path among BGP routes:

Prefer the path that has the largest weight.

config bgp bestpath

If the routes have the same weight, use the route with the highest local preference.

If the routes have the same local preference, prefer the route that was originated by BGP on this router. Originated from network command > from redistribute command> from aggregate command.

If no route was originated, prefer the route with the shortest AS path.

If all paths are of the same AS length, prefer the route with lowest origin code (IGP < EGP < INCOMPLETE).

If the origin codes are the same, prefer the path with the lowest Multi Exit Discriminator.

If the MEDs are the same, prefer external paths over internal paths. EBGP>IBGP.

Prefer the path through the closest IGP neighbor.

Prefer the path that was received first (the oldest one).

Prefer the path with the lowest BGP Router ID.

Prefer the routes advertised by the BGP speaker with a lower BGP identifier value.

Prefer the routes advertised by the BGP speaker with a lower peer address.

Parameters

always_compare_med - Enable or disable the comparison of the Multi Exit Discriminator (MED) for paths from the neighbors in different Autonomous Systems. By default this setting is disabled.

deterministic_med - Enable or disable to enforce the deterministic comparison of the Multi Exit Discriminator (MED) for paths received from the neighbors within the same Autonomous System By default this setting is disabled.

default_local_preference - The default value is 100

as_path_ignore - If enabled, the BGP process will ignore the AS path in the path selection process. By default this value is disabled.

compare_routerid - If enabled, the BGP process will include the router ID in the path selection process. Similar routes are compared and the route with the lowest router ID is selected. By default this value is disabled.

med_confed - If enabled, the BGP process will compare the MED for the routes that are received from confederation peers. For routes that have an external AS in the path, the comparison does not occur. By default this value is disabled.

med_missing_as_worst - If enabled, the BGP process will assign a value of infinity to routes that are missing the Multi Exit Discriminator (MED) attribute. If disabled, the BGP process will assign a value of zero to routes that are missing the Multi Exit Discriminator (MED) attribute, causing this route to be chosen as the best path. By default this value is disabled.

compare_confed_aspath - If enabled, the BGP process will compare the confederation AS path length of the routes received. The shorter the confederation AS path length, the better the route is. By default this value is disabled.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the comparison of the Multi Exit Discriminator (MED):

```
DGS-3627:admin# config bgp always_compare_med disable
Command:4# config bgp always_compare_med disable

Success.
DGS-3627:admin# config bgp bestpath compare_confed_aspath enable
Command:4# config bgp bestpath compare_confed_aspath enable

Success.
```

config bgp dampening

Purpose	This command is used to configure BGP process's dampening configurations
Syntax	config bgp dampening [route_map <map_name 16> clear_routemap { state [enable disable] half_life <min 1-45 > reuse<value 1-20000> suppress <value 1-20000> max_suppress_time <min 1-255 > un_reachability_half_life <min 1-45>}(1)]
Description	<p>The purpose of this command is to eliminate the dampening of routes and thus to avoid unstable networks caused by flapping routes. The following describes the way it is achieved. If a prefix is removed or is added, BGP will add a penalty on the route of 1000; if an attribute of received route changes, BGP will add a penalty on the route of: 500.</p> <p>Suppose that the half-life is configured to be 15min, the re-use value will be 800, and the suppress value will be 1500.</p> <p>When a route flaps (from up to down), add the penalty by 1000. Since the penalty is smaller than the suppress value, BGP will work normally. It will send a withdraw message (an update message) to the neighbors.</p> <p>The penalty of the route will decrease as time elapses. Here we assume that if it passes 7.5 minutes, then the penalty of the route is $1000 - 500 * 7.5 / 15 = 750$.</p> <p>If another flap occurs (the route changes from down to up) then the penalty of the route will be 1750, which is larger than the suppress value, and the route will be dampened. BGP will not send an update message for this status change.</p> <p>When the penalty of the route decreases and becomes smaller than the re-use value (800), the route will not be dampened and the update message will be sent again.</p> <p>Lastly, the max-suppress-time is the longest time the route may be suppressed. So, it decides the maximum penalty a route may suffer regardless of the number of times that the prefix is dampened. Here is the formula: $\text{Maximum-penalty} = \text{reuse-value} * 2 \text{max-suppress-time} / \text{half-life}$</p> <p>NOTE: If the dampening ability is enabled and there are one or more dampened routes, the dampened routes will be released to be the normal state immediately after we disable the dampening function.</p>
Parameters	<p><i>state</i> - Specifies the BGP dampening function's state.</p> <p><i>half_life</i> - Specifies the time (in minutes) after which the penalty of the reachable routes will be down, by half. The default setting is 15 minutes.</p> <p><i>reuse</i> - If the penalty for a flapping route decreases enough to fall below this value, the route is unsuppressed. The default setting is 750.</p> <p><i>suppress</i> - A route is suppressed when its penalty exceeds this limit. The default setting is 2000.</p> <p><i>max_suppress_time</i> - The maximum time (in minutes) a route can be suppressed. The default setting is 60 minutes</p> <p><i>un_reachability_half_life</i> - Specifies the time (in minutes) after which the penalty of the unreachable routes will be down, by half. The default setting is 15 minutes.</p> <p><i>route_map</i> - This is to set the dampening running configuration..</p> <p><i>clear_routemap</i> - This option will withdraw the route map configuration.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the dampening function:

```
DGS-3427:5#config bgp dampening state disable
Command: config bgp dampening state disable

Success.
DGS-3627:admin#
```

show bgp dampening

Purpose	This command is used to show the BGP dampening configurations.
Syntax	show bgp dampening
Description	The purpose of this command is to show the BGP dampening configurations.
Parameters	None.
Restrictions	None.

Example usage:

To display the BGP dampening configurations:

```
DGS-3627:admin# show bgp dampening
Command:4# show bgp dampening

BGP Dampening State           :Enabled

BGP Dampening Route Map       :dmp1
Half-life Time                 :15 mins
Reuse Value                    :750
Suppress Value                 :2000
MAX Suppress Time              :45 mins
Unreachable route's Half-life :15 mins

DGS-3627:admin#
```

config bgp peer_group

Purpose	This command is used to configure the BGP peer group.
Syntax	config bgp peer_group <peer_group_name 16> [add delete] <ipaddr>
Description	<p>The purpose of the neighbor peer group is to simplify the BGP neighbor configuration. The command is used to add an IP or to delete an IP from a BGP peer group. The peer group must be created using the “create neighbor peer group” command. The members must all be internal or external. If all the members of the BGP peer group are external, they are allowed to have different AS numbers. There are two kinds of the peer groups.</p> <p>For the first kind of peer group, the remote AS is not set; members must be created as neighbors before it can be added to the peer group. When we configure the peer group’s remote AS behind this, the member’s remote AS will not change.</p> <p>For the second kind of peer group, the peer group has set a remote AS number. A member can be added to the peer group even if the member didn’t exist before. In this situation, the system will create a neighbor for the peer group’s remote AS automatically. The member’s remote AS will change to the configured peer group’s remote AS, but the others’ will not change, which is created as a neighbor before added to the peer group.</p> <p>If a BGP peer belongs to a peer group, some attributes or actions can only be configured</p>

config bgp peer_group

from the peer group. The following is a list of them:

- capability_orf_prefix_list
- next_hop_self
- route_reflector_client
- send_community
- soft_reconfiguration_inbound
- remove_private_as
- allowas_in
- holdtime
- keepalive
- unsuppress_map
- filter_list for out direction
- route_map for out direction
- prefix_list for out direction
- AS Originate timer
- Connect timer

On the contrary, some attributes or actions are allowed to be configured from both the peer group and the member. If they are configured from the member, the setting will overwrite the setting configured from the peer group.

Other attributes that can be set from an individual peer are as follows:

- description,
- filter_list for in direction,
- route_map for in direction,
- prefix_list for in direction,
- ebgp_multihop,
- session state,
- session activity,
- weight.
- default_originate.
- update_source.

As for the above attributes, setting the attribute of a peer group will automatically affect the setting for individual peers in the peer group.

If Users configure the peer group's session state to disable, all the peer group members session state can't be set to enable. Users can't set the peer group's session activity to disable.

As for the description attribute, setting the peer group will not affect the setting for an individual peer.

Parameters	<i><peer_group_name></i> - This is the name of the BGP peer group. The length is up to 16 bytes. <i><ipaddr></i> - The IP address to be added or deleted.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete a member from the peer group named "local":


```
DGS-3627:admin# config bgp peer_group local delete 10.2.2.2
Command: config bgp peer_group local delete 10.2.2.2

Success.

DGS-3627:admin#
```

config bgp peer_group remote_as

Purpose	This command is used to configure the BGP peer group's remote AS number.
Syntax	config bgp peer_group <peer_group_name 16> remote_as <as_number 0-65535>
Description	The command is used to configure the AS number of a BGP peer group. After this command is executed, all peers belonging to this peer group, which are generated with no indicated AS number, will change their AS number to the same value as the peer group's stop and restarted values. If the peer group remote AS has a value of zero, it means "no remote_as", and members that are generated with no indicated AS number will be deleted. The default AS number is 0.
Parameters	<peer_group_name> - The name of the BGP peer group. The length is up to 16 bytes. <as_number 0-65535> - The number of autonomous systems to which the peer group belongs to. The range is from 0 to 65535.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set a peer group named local remote_as to 50:

```
DGS-3627:admin# config bgp peer_group local remote_as 50
Command: config bgp peer_group local remote_as 50

Success.

DGS-3627:admin#
```

create bgp neighbor

Purpose	This command is used to create a BGP neighbor.
Syntax	create bgp neighbor [<ipaddr> [remote_as <as_number 1-65535>] peer_group <peer_group_name 16>] peer_group <peer_group_name 16>]
Description	The command is used to create a BGP neighbor. Either a single router or a peer group can be a neighbor. If the created neighbor has a single IP address, the remote AS must be specified. A peer group must be specified for which this BGP speaking neighbor belongs to, and in this condition, a remote AS must be specified to the peer group first. If the created neighbor is a peer group, then the remote AS cannot be specified here. The remote AS must be specified by using the config peer_group remote_as command.
Parameters	<ipaddr> - The IP address of the BGP speaking neighbor. <peer_group_name> - Specifies the peer group to be created and added as a neighbor. <as_number> - The number of Autonomous Systems to which the neighbor belongs. The range is from 0 to 65535.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a neighbor peer whose address is 10.10.10.2:

```
DGS-3627:admin# create bgp neighbor 10.10.10.2 remote_as 10
Command: create bgp neighbor 10.10.10.2 remote_as 10

Success.

DGS-3627:admin#
```

delete bgp neighbor

Purpose	This command is used to delete the BGP neighbor.
Syntax	delete bgp neighbor [<i><ipaddr></i> peer_group <i><peer_group_name 16></i> all]
Description	The command is used to delete a BGP neighbor.
Parameters	<i><ipaddr></i> - Specifies the IP address of the neighbor that will be deleted. <i><peer_group_name></i> - Specifies the peer group that will be deleted as a neighbor. <i>all</i> - Delete all BGP neighbors, including individual peers and peer groups.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete a neighbor whose address is 10.10.10.2:

```
DGS-3627:admin# delete bgp neighbor 10.10.10.2
Command: delete bgp neighbor 10.10.10.2

Success.

DGS-3627:admin#
```

config bgp neighbor description

Purpose	This command is used to configure the BGP neighbor's description attribute.
Syntax	config bgp neighbor [<i><ipaddr></i> peer_group <i><peer_group_name 16></i>] [description <i><desc 80></i> clear_description]
Description	The command is used to configure the description for a BGP neighbor.
Parameters	<i><ipaddr></i> - Specifies the IP address of the neighbor to be configured. <i><peer_group_name></i> - Specifies the peer group to be configured. <i>description</i> - Associate a description with a neighbor. By default, the description is not specified. <i>clear_description</i> - Removes the neighbor's description.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure a neighbor's description:

```
DGS-3627:admin# config bgp neighbor 10.10.10.2 description EBGP-neighbor
Command: config bgp neighbor 10.10.10.2 description EBGP-neighbor

Success.

DGS-3627:admin#
```

config bgp neighbor session

Purpose	This command is used to configure the BGP neighbor's session attribute.
Syntax	config bgp neighbor session [<ipaddr> peer_group <peer_group_name 16>] state [enable disable]
Description	The command is used to configure the state for a BGP neighbor. If a neighbor is specified to be in the disabled state, it is equivalent to the case that the neighbor is deleted except when the neighbor configuration is kept.
Parameters	<ipaddr> - Specifies the IP address of the neighbor to be configured. <peer_group_name> - Specifies the peer group to be configured. state - If state is changed from enabled to disabled, the session with the neighbor peer will be terminated.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To shut down all the neighbors that are contained in the peer group "Campus":

```
DGS-3627:admin# config bgp neighbor session peer_group Campus state disable
Command: config bgp neighbor session peer_group Campus state disable

Success.

DGS-3627:admin#
```

config bgp neighbor session activity

Purpose	This command is used to configure the BGP neighbor's session activity for an individual address family.
Syntax	config bgp neighbor session [<ipaddr> peer_group <peer_group_name 16>] activity [enable disable]
Description	This command can be used to configure the activity state for an individual address family. For now, only the address family "IPv4" is supported:
Parameters	<ipaddr> - Specifies the IP address of the neighbor to be configured. <peer_group_name> - Specifies the peer group to be configured. activity - Specify the state for an individual address family. By default, the setting is enabled for IPv4 address families.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To shut down all the neighbors' activity states that are contained in the peer group "Campus":

```
DGS-3627:admin# config bgp neighbor session 10.1.1.1 activity disable
```

```
Command: config bgp neighbor session 10.1.1.1 activity disable
```

```
Success.
```

```
DGS-3627:admin#
```

config bgp neighbor general

Purpose	This command is used to configure the BGP neighbor's general setting.
Syntax	config bgp neighbor general [<ipaddr> peer_group <peer_group_name 16>] { ebgp_multihop <value 1-255> weight [<value 0-65535> default] update_source [add delete] ipif <ipif_name 12> send_community [standard none] next_hop_self [enable disable] soft_reconfiguration_inbound [enable disable] remove_private_as [enable disable] allowas_in [enable {<value 1-10>} disable] default_originate [enable {route_map <map_name 16>} disable] }(1)
Description	<p>ebgp_multihop: This specifies the TTL of the BGP packet sent to the neighbor. If it is specified as 1, it will have a restriction that the neighbor must be directly connected to it.</p> <p>weight: This specifies the weight that will be associated to the routes learned from the specified neighbor. The route with highest weight will be chosen as the preferred route. If the route map sets weight to a route, then this route map specified weight will override the weight specified by the BGP neighbor's command. Weight is an attribute which is specified in the ingress direction, and is not an attribute to be advertised with the route. It is used to specify preference for routes received from a neighbor over another neighbor.</p> <p>update_source: This parameter allows BGP sessions to use any operational interface for TCP connections.</p> <p>soft_reconfiguration_inbound: If the setting is enabled, the route updates sent from the specified neighbor will be stored. This storage is required for inbound soft reconfiguration. When a soft reset is requested for inbound sessions, the session will not be torn down, but the inbound routing table will be cleared. It needs to be rebuilt. If the soft reconfiguration inbound is enabled, then the routing table can be rebuilt based on the stored route update information. If the soft reconfiguration inbound is disabled, then the local router will send the route refresh requests to the neighbor to ask for the route refresh.</p> <p>next_hop_self: If the next_hop_self option is enabled, the router will set the next hop to itself when it advertises the routes to the specific neighbor. If the next_hop_self option is disabled, the next hop attributes will not be changed. The behavior described here will be overridden by the set next hop statement if route map is applied to the neighbor in the out direction.</p> <p>remove_private_as: The private Autonomous System numbers are from 64512 to 65535. If this setting is set to enable, the private AS number in the AS path attribute of the BGP update packets will be dropped.</p> <p>allowas_in: The BGP router will do AS path loop checks for the received BGP update packet. If the BGP router's self AS appears in the AS path, it is identified as a loop and the packet will be discarded. If the allow-as setting is enabled, the BGP router's self AS is allowed in the AS path list.</p> <p>default_originate: If this setting is enabled, it will allow a BGP speaker (the local router) to send the default route 0.0.0.0/0 to a neighbor to use as the default route. If route map is specified, the default route will be injected if the route map contains a match IP address statement. If this setting is disabled, no default route will be sent to the neighbor. The default setting is disabled.</p>

config bgp neighbor general

Parameters	<p><i><ipaddr></i> - Specifies the IP address of the neighbor to be configured.</p> <p><i><peer_group_name></i> - Specifies the peer group to be configured.</p> <p><i>ebgp_multihop</i> - Specifies the TTL of the BGP packet sent to the neighbor. For an EBGp neighbor the default setting is 1. This means only direct connected neighbors are allowed.</p> <p><i>weight</i> - The valid range is from 0 to 65535.</p> <p>If this is not specified, the routes learned through another BGP peer will have a default weight of 0.</p> <p>Routes sourced by the local router have a weight of 32768. It cannot be changed.</p> <p><i>update_source</i> - Specifies an interface to be used by BGP sessions for TCP connection. By default, this parameter is not set.</p> <p><i>send_community</i> - This specifies the communities attribute to be sent to the BGP neighbor.</p> <p style="padding-left: 20px;"><i>standard</i> - Only standard communities will be sent.</p> <p style="padding-left: 20px;"><i>none</i> - No communities will be sent. The default value is none.</p> <p><i>remove_private_as</i> - If this setting is set to enable, the private AS number in the AS path attribute of the BGP update packets will be dropped. By default, the setting is disabled.</p> <p><i>allowas_in</i> - If the allowas_in setting is enabled, the BGP router's self AS is allowed in the AS path list. By default, the allowas_in setting is disabled. If no number is supplied, the default value of three times is used.</p> <p><i>next_hop_self</i> - Enable or disable the next hop self attribute. By default, this setting is disabled.</p> <p><i>soft_reconfiguration_inbound</i> - Specifies to enable or disable the inbound soft reconfiguration function. By default, this setting is disabled.</p> <p><i>default_originate</i> - Specifies to enable or disable the default originate function. By default, this setting is disabled.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the EBGp multi-hop to 2:

```
DGS-3627:admin# config bgp neighbor general 10.100.200.1 ebgp_multihop 2
Command: config bgp neighbor general 10.100.200.1 ebgp_multihop 2

Success.

DGS-3627:admin#
```

config bgp neighbor timer

Purpose	This command is used to configure the BGP neighbor's timer attribute.
Syntax	config bgp neighbor timer [<i><ipaddr></i> peer_group <i><peer_group_name 16></i>] { advertisement_interval [<i><sec 0-600></i> default] [keepalive <i><sec 0-65535></i> holdtime <i><sec 0-65535></i> default_keepalive_holdtime] as_origination_interval [<i><sec 1-600></i> default] connect [<i><sec 1-65535></i> default]}(1)
Description	advertisement_interval: If an advertised route is flapping, this usually occurs when an interface is unstable. As a result, a lot of UPDATE and WITHDRAWN messages will be sent. One method to control the flooding of these messages is to set a minimum advertisement interval.
Parameters	<p><i><ipaddr></i> - Specifies the IP address of the neighbor to be configured.</p> <p><i><peer_group_name></i> - Specifies the peer group to be configured.</p> <p><i>advertisement_interval</i> - It specifies the interval at which the BGP process sends update</p>

config bgp neighbor timer

messages to its peer.

The valid value is from 0 to 65535.

If this value is set to zero, the update or withdrawn message will be sent immediately.

The default value for IBGP peers is 5 seconds and for EBGP peers it is 30 seconds.

When specified to default, the neighbor specific advertisement interval setting will be returned to the default setting.

holdtime - The system will declare a peer as dead if not receiving a keepalive message until the hold time.

If two routers, that built a BGP connection, have different hold times, the smaller hold time will be used.

The valid value is from 0 to 65535.

If the holdtime is zero, then the holdtime will never expire.

It is recommended that the holdtime value is three times that of the keepalive timer. By default, the timer is not specified. This neighbor specific setting will follow the global setting.

keepalive - This specifies the interval at which a keepalive message is sent to its peers.

If the two routers, that build a BGP connection, have different keepalive timers, the smaller keepalive timer will be unset. The valid value is from 0 to 65535.

If the keepalive is set to zero, then the keepalive message will not be sent out. By default, the timer is not specified. This neighbor specific setting will follow the global setting.

default_keepalive_holdtime - Clear the specification of the neighbor specific holdtime and keepalive setting.

as_origination_interval - The minimum interval between the sending AS origination routing updates. The valid value is from 1 to 600. The default setting is 15 seconds.

connect - The minimum interval BGP sends TCP connect requests to the peer after a TCP connection fail happens. The valid value is from 1 to 65535. The default setting is 120 seconds.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the advertisement interval to 20 seconds:

```
DGS-3627:admin# config bgp neighbor timer peer_group Campus advertisement_interval 20
Command: config bgp neighbor timer peer_group Campus advertisement_interval 20
```

Success.

```
DGS-3627:admin#
```

config bgp neighbor route_reflector_client

Purpose

This command is used to configure the BGP's neighbor of the route reflector client.

Syntax

config bgp neighbor route_reflector_client [<ipaddr> | peer_group <peer_group_name 16>] state [enable | disable]

Description

When the route reflector client is defined and the router reflection is enabled, the BGP router will act as the route reflector. The reflector and its client form a cluster. In a cluster, all the members must be an iBGP connection with the reflector and vice versa. The reflector is the representative of the cluster. For the reflector, the iBGP connection is established by the create bgp neighbor command and the corresponding neighbor must be specified as the client by this command. For the client, the iBGP connection is established by the create bgp

config bgp neighbor route_reflector_client

	neighbor command. When the router is in reflection mode, the router will exchange information with client neighbors in the reflection way and with the remaining neighbors in the ordinary way. When the router is in non-reflection mode, the router will exchange information with all the neighbors in the non-reflection way. An AS can have multiple clusters, and a cluster can have more than one reflector for redundancy purposes.
Parameters	<i><ipaddr></i> - Specifies the IP address of the neighbor to be configured. <i><peer_group_name></i> - Specifies the peer group to be configured. <i>state</i> - Enable: The specified neighbor will become the router reflector client. By default, this state is disabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To add a neighbor as the route reflector client:

```
DGS-3627:admin# config bgp neighbor route_reflector_client 10.10.10.2 state enable
Command: config bgp neighbor route_reflector_client 10.10.10.2 state enable
```

Success.

```
DGS-3627:admin#
```

config bgp neighbor map

Purpose	This command is used to configure the BGP neighbor route map related setting.
Syntax	config bgp neighbor map [<i><ipaddr></i> peer_group <i><peer_group_name 16></i>] { unsuppress_map [add delete] <i><map_name 16></i> route_map [in out] [add delete] <i><map_name 16></i>}(1)
Description	The command is used to configure the route map related setting for a BGP neighbor. When a route map is applied by the route_map command, it enforces the route policy. When it is applied by the unsuppress_map command, the suppressed route which matches the permit rule will be unsuppressed. It provides a manipulation of routers per neighbor. If a route map is configured relating to a BGP neighbor but the route map doesn't exist, it means deny any. If the route map exists but has no filter entry defined, it will permit all.
Parameters	<i><ipaddr></i> - Specifies the IP address of the neighbor to be configured. <i><peer_group_name></i> - Specifies the peer group to be configured. <i>unsuppress_map <map_name 16></i> - The name of a route map used to selectively advertise routers previously suppressed by the aggregate_address command. <i>route_map</i> - Specify the route map to be applied to the incoming or outgoing routes. <i>in</i> - Specifies the incoming routes from the neighbor. <i>out</i> - Specifies the outgoing routes sent to the peer.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the unsuppressed map of peer group "Campus" to Profile1:

```
DGS-3627:admin# config bgp neighbor map peer_group Campus unsuppress_map add Profile1
Command: config bgp neighbor map peer_group Campus unsuppress_map add Profile1

Success.

DGS-3627:admin#
```

config bgp neighbor filter

Purpose	This command is used to configure the BGP neighbor's filter related setting.
Syntax	config bgp neighbor filter [<i>ipaddr</i>] <i>peer_group</i> < <i>peer_group_name 16</i> >] { <i>filter_list</i> [<i>in</i> <i>out</i>] [<i>add</i> <i>delete</i>] < <i>list_name 16</i> > <i>prefix_list</i> [<i>in</i> <i>out</i>] [<i>add</i> <i>delete</i>] < <i>list_name 16</i> > <i>capability_orf_prefix_list</i> [<i>receive</i> <i>send</i> <i>both</i> <i>none</i>]}(1)
Description	The command is used to configure the filter related setting for a BGP neighbor. filter_list : If the filter list doesn't exist, it will permit all. Or if the filter list does exist but has no filter entry, it means deny any. prefix_list : If the prefix list doesn't exist or the prefix list does exist but has no filter entry defined, it will permit all. capability_orf_prefix_list : The BGP Outbound Route Filter Capability allows one BGP router to install its configured inbound prefix list filter on to the remote BGP router. This is used for reducing the amount of unwanted routing updates from the remote peer.
Parameters	<i>ipaddr</i> - Specifies the IP address of the neighbor to be configured. <i>peer_group_name</i> - Specifies the peer group to be configured. <i>filter_list</i> - Specifies the name of an as_path access_list to be applied as a filter. The filtering can be applied to incoming routes or outgoing routes. <i>prefix_list</i> - Specifies the name of a prefix_list to be applied as a filter. The filtering can be applied to incoming routes or outgoing routes. <i>in</i> - Specify to apply inbound traffic. <i>out</i> - Specify to apply outbound traffic. <i>capability_orf_prefix_list</i> - Used to configure an outbound route filter prefix list capability. It can be sent with the following values: <i>receive</i> - Enables the ORF prefix list capability in the receiving direction. The local router will install the prefix filter list notified by the remote router. <i>send</i> - Enables the ORF prefix list capability in the sending direction. The local router will notify the remote router for the ORF prefix list capability. <i>both</i> - Enables the ORF prefix list capability in both received and send directions. <i>none</i> - Disable the ORF prefix list capability in both received and send directions.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the BGP neighbor ingress filter list for the peer group "Campus" to List1:

```
DGS-3627:admin# config bgp neighbor filter peer_group Campus filter_list in add List1
Command: config bgp neighbor filter peer_group Campus filter_list in add List1

Success.

DGS-3627:admin#
```

show bgp peer_group

Purpose	The command is used to show the information of the BGP peer group.
---------	--

show bgp peer_group

Syntax	show bgp peer_group {<peer_group_name 16>}
Description	To display the BGP peer group's information.
Parameters	<peer_group_name> - The name of the BGP peer group. The length is up to 16 bytes. This means to display all the BGP peer groups' information that doesn't specify the peer group name.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show the information of the BGP peer group local1:

```

DGS-3627:admin# create bgp neighbor peer_group local1
Command:4#create bgp neighbor peer_group local1

Success.

DGS-3627:admin# create bgp neighbor 10.2.2.2 remote_as 10
Command:4#create bgp neighbor 10.2.2.2 remote_as 10

Success.

DGS-3627:admin# config bgp peer_group local1 add 10.2.2.2
Command:4#config bgp peer_group local1 add 10.2.2.2

Success.

DGS-3627:admin# show bgp peer_group local1
Command:4#show bgp peer_group local1

BGP Peer Group :local1
-----
Description                :
Session State               : Enabled
Session Activity           : Enabled
Members                     : 10.2.2.2
Remote AS                   : Not Set
Advertisement Interval      : 30 seconds
Keepalive Interval         : 60 seconds.
Holdtime Interval          : 180 seconds.
AS Origination Interval    : 15 seconds
Connect Retry Interval     : 120 seconds
EBGP Multihop              : 1
Weight                     : 0
Update Source               : ipif1
Next Hop Self               : Disabled
Route Reflector Client     : Disabled
Send Community              : None
Remove Private As          : Disabled
AllowAS In                 : Disabled
Soft Reconfiguration Inbound :Disabled
Unsuppressed Map           : usmap1
Default Originate           : Disabled
Incoming Update Prefix List : prelist1
Incoming Update Filter List : ASlist1
Route Map for outgoing Routes : routemap1
Outbound Route Filter (ORF) type (64) Prefix-list:
Send Mode                   : Enabled
Receive Mode                 : Disabled
Prefix Max Count            : 12000
Prefix Warning Threshold    : 75
Prefix Warning Only         : Disabled

DGS-3627:admin#

```

config bgp route_reflector cluster_id

Purpose	This command is used to configure the BGP process's global attribute.
Syntax	config bgp route_reflector cluster_id <ipaddr>

config bgp route_reflector cluster_id

Description	<p>The route reflector and its clients together form a cluster. When a single route reflector is deployed in a cluster, the cluster is identified by the router ID of the route reflector.</p> <p>When the cluster ID is 0.0.0.0, the cluster is identified by the router ID. Otherwise, the cluster is identified by the cluster ID.</p> <p>The BGP cluster_id command is used to assign a cluster ID to a route reflector when the cluster has one or more route reflectors. Multiple route reflectors are deployed in a cluster to increase redundancy and to avoid a single point of failure. When multiple route reflectors are configured in a cluster, they must be configured with the same cluster ID. This allows all route reflectors in the cluster to recognize updates from peers in the same cluster and reduces the number of updates that needs to be stored in BGP routing tables.</p> <p>This command is only required for the reflector and not the client.</p>
Parameters	<ipaddr> - Specifies the IP address of the cluster ID. Setting the cluster ID to 0.0.0.0 will remove specifications of the cluster ID. The default value is 0.0.0.0.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the cluster ID:

```
DGS-3627:admin# config bgp route_reflector cluster_id 10.100.200.1
Command: config bgp route_reflector cluster_id 10.100.200.1

Success.

DGS-3627:admin#
```

config bgp client_to_client_reflection

Purpose	This command is used to configure the BGP client to the client reflection setting.
Syntax	config bgp client_to_client_reflection [enable disable]
Description	<p>The command is only required for the reflector.</p> <p>If the reflection is disabled, then the router will not reflect routes from the route reflect client to other route reflect clients, but it will still send routes received from a non-reflecting client to a reflecting client.</p>
Parameters	<p><i>enable</i> - The reflector will operate in reflector mode.</p> <p><i>disable</i> - The reflector will operate in non-reflector mode.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the client to client reflection:

```
DGS-3627:admin# config bgp client_to_client_reflection disable
Command: config bgp client_to_client_reflection disable

Success.

DGS-3627:admin#
```

config bgp confederation identifier

Purpose	This command is used to configure the BGP confederation.
---------	--

config bgp confederation identifier

Syntax	config bgp confederation identifier <as_number 0-65535>
Description	<p>A confederation, which is represented by an AS, is a group of the sub AS.</p> <p>A confederation can be used to reduce the internal BGP (iBGP) mesh by dividing a large single AS into multihop sub AS. External peers interact with the confederation as if it is a single AS.</p> <p>Each sub AS is fully meshed within itself and it has connections to other sub ASs within the confederation. The next hop, Multi Exit Discriminator (MED), and local preference information is preserved throughout the confederation, allowing users to retain a single Interior Gateway Protocol (IGP) for all the autonomous systems.</p>
Parameters	<p><as_number> - as_number: 0-65535, Autonomous System numbers which we use to specify a BGP confederation.</p> <p>If it is set to zero, the BGP confederation number is deleted. By default, this setting is zero.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a confederation in which the AS number is 20:

```
DGS-3627:admin# config bgp confederation identifier 20
Command: config bgp confederation identifier 20

Success.

DGS-3627:admin#
```

config bgp confederation peers

Purpose	This command is used to add or delete BGP confederation peers.
Syntax	config bgp confederation peers [add delete] <aspath_list>
Description	The command is used to configure multiple adjacent Autonomous Systems in a confederation. The Autonomous Systems specified in this command are visible internally to the confederation. Each Autonomous System is fully meshed within itself or configures route reflector.
Parameters	<p><aspath_list> - Can be one or multiple AS number partitions, each separated by a comma.</p> <p>AS number: 1-65535, Autonomous System numbers for BGP peers that will belong to the confederation.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To add two confederation peers in which the AS numbers are 50000 and 50001:

```
DGS-3627:admin# config bgp confederation peers add 50000, 50001
Command: config bgp confederation peers add 50000, 50001

Success.

DGS-3627:admin#
```

clear bgp

Purpose	This command is used to reset the Border Gateway Protocol (BGP) connections using hard or soft reconfigurations.
Syntax	clear bgp [all ipaddr <ipaddr> as <as_number 1-65535> peer_group <peer_group_name 16> external] {soft {[in { prefix_filter} out]}}
Description	<p>This command is used to initiate a hard reset or a soft reset for a connection.</p> <p>If a hard reset is applied to the inbound session, the inbound session will be torn down and the local inbound routing table and the remote outbound routing table will be cleared.</p> <p>If a soft reset is applied to the inbound session, the session will not be rebuilt but the local inbound routing table will be cleared and needs to be rebuilt.</p> <p>If a soft reconfiguration inbound is enabled, then the routing table can be rebuilt based on the stored route updates information. If a soft reconfiguration inbound is disabled, then the local router will send the route refresh request to the neighbor to ask for the route refresh.</p> <p>When the inbound session is soft reset with the prefix filter option, and the capability_orf_prefix_list is enabled in the send direction, then the local BGP will send 'clear the routing table', and notify the remote neighbor for the prefix filter.</p> <p>This is a way to notify the neighbor of the prefix filter whenever a change is made to the prefix filter.</p>
Parameters	<p><i>all</i> - Specifies that all current BGP sessions will be reset.</p> <p><i><as_number></i> - Specifies to reset sessions with BGP peers in the specified Autonomous System.</p> <p><i>peer_group</i> - Specifies to reset a peer group.</p> <p><i>ipaddr</i> - Specifies to reset the session with the specified neighbor.</p> <p><i>external</i> - All eBGP sessions will be reset.</p> <p><i>soft</i> - Initiates a soft reset. Does not tear down the session.</p> <p><i>in</i> - Initiates inbound reconfiguration. If neither in nor out keywords are specified, both inbound and outbound sessions are reset.</p> <p><i>prefix_filter</i> - The local site configured prefix filter will be notified to the remote neighbor when inbound soft reset is applied.</p> <p><i>out</i> - Initiates outbound reconfiguration.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To reset all Border Gateway Protocol (BGP) connections:

```
DGS-3627:admin# clear bgp all
Command: clear bgp all

Success.

DGS-3627:admin# clear bgp ipaddr 10.10.1.2 soft in
Command: clear bgp ipaddr 10.10.1.2 soft in

Success.

DGS-3627:admin#
```

clear bgp dampening

Purpose	This command is used to clear the BGP route dampening information and to unsuppressed suppressed routes.
Syntax	clear bgp dampening {[<ipaddr> <network_address>]}

clear bgp dampening

Description	This command clears the route dampening information stored in the routing table. If no parameters are specified, the dampening information for the entire routing table will be cleared.
Parameters	<ipaddr> - Specifies an IPv4 address to clear the dampening information. <network_address> - Specifies an IPv4 network to clear the dampening information.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To clear route dampening information from network 192.168.10.0/24 and free suppressed routes:

```
DGS-3627:admin# clear bgp dampening 192.168.10.0/24
Command: clear bgp dampening 192.168.10.0/24

Success.

DGS-3627:admin#
```

create bgp as_path access_list

Purpose	This command is used to configure an Autonomous System path access list.
Syntax	create bgp as_path access_list <list_name 16>
Description	The command is used configure an Autonomous System path access list. You can apply an Autonomous System path access list to both inbound and outbound routes exchanged by a BGP peer session.
Parameters	<list_name 16> - AS path access list name.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create an Autonomous System path access list:

```
DGS-3627:admin# create bgp as_path access_list test
Command: create bgp as_path access_list test

Success.

DGS-3627:admin#
```

config bgp as_path access_list

Purpose	This command is used to configure matching rules for an Autonomous System path access list using regular expressions.
Syntax	config bgp as_path access_list <list_name 16> [add delete] <regexp_str 80> [deny permit]
Description	This command configures the match rules for the AS list. Each rule is defined by a regular expression.
Parameters	<list_name 16> - AS path access list name. add - Add a matching rule. delete - Delete a matching rule.

config bgp as_path access_list

<regexp_str 80> - Regular expression that defines the as_path filter.
permit - Permits advertisement based on matching conditions.
deny - Denies advertisement based on matching conditions.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

This example configures a matching rule for an AS path access list:

```
DGS-3627:admin# create bgp as_path access_list test
Command: create bgp as_path access_list test

Success.

DGS-3627:admin# config bgp as_path access_list test add (_64[6-9][0-9][0-9]_|_65[0-9][0-9][0-9]_) deny
Command:4# config bgp as_path access_list test add (_64[6-9][0-9][0-9]_|_65[0-9][0-9][0-9]_) deny

Success.

DGS-3627:admin# config bgp as_path access_list test add .* permit
Command: config bgp as_path access_list test add .* permit

Success.

DGS-3627:admin#
```

delete bgp as_path access_list

Purpose	This command is used to delete an Autonomous System path access list.
Syntax	delete bgp as_path access_list [list_name <list_name 16> all]
Description	This command is used to delete an Autonomous System path access list.
Parameters	<i><list_name 16></i> - AS path access list name.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configures a matching rule for an AS path access list:

```
DGS-3627:admin# delete bgp as_path access_list list_name test
Command: delete bgp as_path access_list list_name test

Success.

DGS-3627:admin#
```

show bgp as_path access_list

Purpose	This command is used to display the Autonomous System path access list.
Syntax	show bgp as_path access_list {<list_name 16>}

show bgp as_path access_list

Description	This command displays the Autonomous System path's access list. If a specific access list is not specified, all AS path access lists will be displayed.
Parameters	<list_name 16> - AS path access list name.
Restrictions	None.

Example usage:

To display an AS path access list:

```
DGS-3627:admin# show bgp as_path access_list 1
Command: show bgp as_path access_list 1

BGP AS Path Access List: 1
deny (_64[6-9][0-9][0-9]_|_65[0-9][0-9][0-9]_)
permit 33

Total Filter Entries: 2

Total AS Path Access List Number: 1

DGS-3627:admin#
```

create bgp community_list

Purpose	This command is used to create a BGP community list.
Syntax	create bgp community_list [standard expanded] <list_name 16>
Description	This command is used to create a BGP community list.
Parameters	<i>standard</i> - Configures a standard named community list. <i>expanded</i> - Configures an expanded named community list. <list_name 16> - This is the name of the community list that will be created. The string size is 16 bytes.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a standard BGP community list:

```
DGS-3627:admin# create bgp community_list standard list1
Command: create bgp community_list standard list1

Success.

DGS-3627:admin#
```

config bgp community_list

Purpose	The command is used to configure the matching rules for a BGP community list.
Syntax	config bgp community_list [standard <list_name 16> [add delete] {internet local_as no_advertise no_export community_set <community_set 80>} [deny permit] expanded <list_name 16> [add delete] <regexp_str 80> [deny permit]]
Description	This command is used to configure the matching rule for the community access list.

config bgp community_list

Multiple rules can be defined for a community list.
 Each rule is either in the permit form or in the deny form.
 Each rule in the standard community list contains one community.
 A community string, which contains multiple communities, can be defined for a rule.
 A Route can be associated with a community string. To match a rule, two community strings must exactly match.
 The built-in community strings including *internet*, *local_as*, *no_advertise*, and *no_export*.
 The user-defined community is 4-bytes long, with the leading two bytes representing the AS number and the trailing two bytes representing a user defined number.
 BGP community attributes exchanged between BGP peers are controlled by the neighbor *send-community* command.
 The community string associated with routes can be controlled by the route map. By default, the community string "internet" will be sent. If the route map sets a community string, this community string will be added to the existing community string associated with the route.
 If permit rules exist in an access list, then routes with community that does not match any rule in the list will be denied.
 If there are no rules or only deny rules configured for the community list, all routes will be denied.

Parameters

standard - Configures a standard community list.
expanded - Configures an expanded community list.
 <*list_name* 16> - Name of community list to be configured.
deny - Denies the routes if the rule is matched.
permit - Permits the routes if the rule is matched.
add - Adds a rule to the community list.
delete - Deletes a rule from the community list.
internet - Routes with this community will be sent to all peers either internal or external.
local_as - Routes with this community will be sent to peers in the same AS, but will not be sent to peers in another sub AS in the same confederation and to the external peers.
no_advertise - Routes with this community will not be advertised to any peer either internal or external.
no_export - Routes with this community will be sent to peers in the same AS or in other sub Autonomous Systems within a confederation, but will not be sent to an external BGP (eBGP) peer.
 <*community_set*> - A community is 4 bytes long, including the 2 bytes' for the Autonomous System's number and 2 bytes for the network number This value is configured with two 2-byte numbers separated by a colon. The valid range of both numbers is from 1 to 65535.
 A community set can be formed by multiple communities, separated by a comma.
 An example of a community string is 200:1024, 300:1025,400:1026

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To create a standard community list and configure permit routes from the network 10 in the Autonomous System 50000:10

```
DGS-3627:admin# create bgp community_list standard list1
```

```
Command: create bgp community_list standard list1
```

```
Success.
```

```
DGS-3627:admin# config bgp community_list standard list1 add community_set 50000:10 permit
```

```
Command: config bgp community_list standard list1 add community_set 50000:10 permit
```

```
Success.
```

```
DGS-3627:admin#
```

delete bgp community_list

Purpose	This command is used to delete a BGP community list.
Syntax	delete bgp community_list [list_name <list_name 16> all]
Description	This command is used to delete a BGP community list.
Parameters	<list_name 16> - The name of the community list to be deleted.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the community list named "list1":

```
DGS-3627:admin# delete bgp community_list list_name list1
```

```
Command:4# delete bgp community_list list_name list1
```

```
Success.
```

```
DGS-3627:admin#
```

show bgp community_list

Purpose	This command is used to show a BGP community list.
Syntax	show bgp community_list {<list_name 16>}
Description	This command is used to show a BGP community list.
Parameters	<list_name 16> - Name of community list to be displayed.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To display the community list named "list1":

```
DGS-3627:admin# create bgp community_list standard list1
Command: create bgp community_list standard list1

Success.

DGS-3627:admin# config bgp community_list standard list1 add community_set 50000:10
permit
Command: config bgp community_list standard list1 add community_set 50000:10 permit

Success.

DGS-3627:admin# show bgp community_list list1
Command:4# show bgp community_list list1

Community List Name: list1
-----
Type                : standard

permit:             50000:100

DGS-3627:admin#
```

show bgp route

Purpose	This command is used to display route entries in the Border Gateway Protocol (BGP) routing table
Syntax	show bgp route {[regexp <desc 80> inconsistent_as cidr_only filter_list <list_name 16> route_map <map_name 16> community {community_set <community_set 80> local_as no_advertise no_export internet}{exact_match} community_list <list_name 16> {exact_match} ipaddress <ipaddr> network <network_address> {longer_prefixes} prefix_list <list_name 16>]}
Description	This command is used to show BGP routes.
Parameters	<p><i>regexp</i> - Displays routes matching the AS path regular expression</p> <p><i><regexp_str 80></i> - This is a regular expression to match the BGP AS paths. You must enclose this in quotes. Blank spaces are permitted. Detail rule please see reference doc.</p> <p><i>cidr_only</i> - Displays only routes with non-natural network masks</p> <p><i>prefix_list</i> - Displays routes conforming to the prefix list</p> <p><i>filter_list</i> - Displays routes conforming to the filter list</p> <p><i>route_map</i> - Displays routes matching the route map</p> <p><i><map_name 16></i> - Specifies the name for the specified route map.</p> <p><i><list_name 16></i> - Specifies the list name for the specified prefix list, IP access list, or route map.</p> <p><i><ipaddr></i> - Displays the host route that matches the specified IP address.</p> <p><i><network_address></i> - Displays the route that matches the specified network address. The format of network is (xxx.xxx.xxx/xx). It specifies an IP address and length of network mask.</p> <p><i>longer_prefixes</i> - If specified, more specific routes will also be displayed.</p> <p><i>community</i> - Displays routes matching the communities</p> <p><i>community_set <community_set 80></i> - A community is in the form of <as_number> : <udn_number>. A community string can be formed by multiple communities, separated by a comma. An example of a community string is 200:1024, 300:1025, 400:1026.</p> <p><i>local_as</i> - Do not send outside local AS (well-known community)</p>

show bgp route

no_advertise - Do not advertise to any peer (well-known community)

no_export - Do not export to next AS (well-known community)

exact_match - If specified, communities need to match exactly.

If not specified, then there are two cases:

If internet is contained in the community list, then all routes will match.

If not, then the community needs to be a subset of route's community to match.

inconsistent_as - Displays the routes if they have the same prefix and different AS path origins.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To show how to get the BGP route information:

DGS-3627:admin# show bgp route

Command: show bgp route

BGP local router ID is 10.0.40.1

Status codes: s suppressed, d damped, h history, * valid, > best, i - internal

Origin codes: i - IGP, e - EGP, ? - incomplete

IP Address/Netmask	Gateway	Metric	LocPrf	Weight	Path
*> 10.10.10.0/24	172.16.10.1	0	0	300	10 i
*> 10.10.20.0/24	172.16.10.1	0	0	300	10 i
* 10.20.10.0/24	172.16.10.1	0	0	300	10 i
*dh 30.10.1.1/24	172.3.3.2	100	50	200	20 i

Total Entries: 4

DGS-3627:admin# show bgp route cidr_only

Command: show bgp route cidr_only

BGP local router ID is 172.16.73.131

Status codes: s suppressed, d damped, h history, * valid, > best, i - internal

Origin codes: i - IGP, e - EGP, ? - incomplete

IP Address/Netmask	Gateway	Metric	LocPrf	Weight	Path
*> 192.168.0.0/8	172.16.72.24	0	1878	200	?
*> 172.16.0.0/24	172.16.72.30	0	108	200	?

Total Entries: 2

DGS-3627:admin# show bgp route community_list communitylist1

Command: show bgp route community_list communitylist1

BGP local router ID is 192.168.32.1

Status codes: s suppressed, d damped, h history, * valid, > best, i - internal

Origin codes: i - IGP, e - EGP, ? - incomplete

IP Address/Netmask	Gateway	Metric	LocPrf	Weight	Path
* i10.3.0.0	10.0.22.1	0	100	1800	1239 ?
*>i10.3.0.0	10.0.16.1	0	100	1800	1239 ?
* i10.6.0.0	10.0.22.1	0	100	1800	690 568 ?

Total Entries: 3

DGS-3627:admin# show bgp route filter_list filter_list_one

Command: show bgp route filter_list filter_list_one

BGP local router ID is 172.16.72.24

Status codes: s suppressed, d damped, h history, * valid, > best, i - internal

Origin codes: i - IGP, e - EGP, ? - incomplete

IP Address/Netmask	Gateway	Metric	LocPrf	Weight	Path
* 172.16.0.0	172.16.72.30			0	109 108 ?
* 172.16.1.0	172.16.72.30			0	109 108 ?
* 172.16.11.0	172.16.72.30			0	109 108 ?
* 172.16.14.0	172.16.72.30			0	109 108 ?
* 172.16.15.0	172.16.72.30			0	109 108 ?
* 172.16.16.0	172.16.72.30			0	109 108 ?

Total Entries: 6

DGS-3627:admin# show bgp route regexp "108\$"

Command: show bgp route regexp "108\$"

BGP local router ID is 172.16.72.24

Status codes: s suppressed, d damped, h history, * valid, > best, i - internal

Origin codes: i - IGP, e - EGP, ? - incomplete

IP Address/Netmask	Gateway	Metric	LocPrf	Weight	Path
s 172.16.0.0	172.16.72.30			0	109 108 ?
s 172.16.0.0	172.16.72.31			0	109 108 ?
* 172.16.1.0	172.16.72.30			0	109 108 ?
* 172.16.11.0	172.16.72.30			0	109 108 ?
* 172.16.14.0	172.16.72.30			0	109 108 ?
* 172.16.15.0	172.16.72.30			0	109 108 ?
* 172.16.16.0	172.16.72.30			0	109 108 ?

Total Entries: 7

DGS-3627:admin# show bgp route inconsistent_as

Command: show bgp route inconsistent_as

BGP local router ID is 172.16.72.24

Status codes: s suppressed, d damped, h history, * valid, > best, i - internal

Origin codes: i - IGP, e - EGP, ? - incomplete

IP Address/Netmask	Gateway	Metric	LocPrf	Weight	Path
* 172.16.1.0	172.16.72.30			0	109 108 i
	172.16.72.21			0	110 101 i
* 172.16.11.0	172.16.72.30			0	109 108 i
	172.16.72.10			0	104 105 i
	172.16.72.10			0	104 103 i

Total Entries: 2

```
DGS-3627:admin# show bgp route network 2.2.2.0/24
```

```
Command: show bgp route network 2.2.2.0/24
```

```
BGP routing table entry for 2.2.2.0/24
```

```
Paths:(1 available, best #1, table: Default_IP_Routing_Table, not advertised to any peer.)
```

```
Not advertised to any peer.
```

```
AS path is: Local
```

```
Next hop is: 0.0.0.0 ,from 0.0.0.0 (local router_id is:192.168.1.1)
```

```
Origin IGP, metric 100, localpref 0, weight 32768, sourced, best
```

```
Community: no_advertise
```

show bgp neighbors

Purpose	This command is used to display BGP and TCP connections with the BGP neighbor or routing table entries containing a BGP neighbor.
Syntax	show bgp neighbors {<ipaddr> [{ advertised_routes received_routes routes received_prefix_filter statistics]}}
Description	To display BGP and TCP connection information for neighbor sessions, or routing table entries with BGP neighbors. For BGP, this includes detailed neighbor attributes, capability, path, and prefix information. For TCP, this includes statistics related to BGP neighbor session establishment and maintenance.
Parameters	<p><i>neighbors</i> - Detailed information about TCP and BGP neighbor connections.</p> <p><i>advertised_routes</i> - Displays the routes advertised to a BGP neighbor.</p> <p><i>received_routes</i> - Displays the routes received from this neighbor.</p> <p><i>received_prefix_filter</i> - Displays the prefix filter information that is received from a BGP neighbor.</p> <p><i>routes</i> - Displays routes in the routing table learned from the neighbor.</p>
Restrictions	None.

Example usage:

To display BGP neighbors:

```
DGS-3627:admin# show bgp neighbors 10.10.10.2
Command: show bgp neighbors 10.10.10.2

BGP neighbor: 10.10.10.2 (Internal Peer)
-----
Session State           : Enabled
Session Activity       : Enabled
Remote AS               : 1
Remote Router ID       :192.168.252.252
BGP State               : Established ( UP for 00:24:25)
Hold Time               : 180 Seconds
Keepalive Interval     : 60 Seconds
Advertisement Interval  : 5 Seconds
AS Origination Interval : 15 seconds
Connect Retry Interval : 120 seconds
EBGP Multihop          : 2
Weight                 : 100
Next Hop Self          : Disabled
Remove Private As      : Disabled
Allows In               : Enabled (Num: 3)
Graceful Restart       : Disabled
Address Family IPv4 Unicast
IPv4 Unicast           : Advertised and Received
Soft Reconfiguration Inbound : Enabled
Community Sent to this Neighbor : Both Standard and Extended
Default Originate      : Enabled
Incoming Update Prefix List : prelist1
Incoming Update Filter List : ASlist1
Outgoing Update Distribute List : AccessList1
Route Map for outgoing Routes : routemap1
Unsuppress Route Map   : us_routmp1
Outbound Route Filter (ORF) type (64) Prefix-list:
Send Mode              : Enabled
Receive Mode           : Disable
Prefix Max Count       : 12000
Prefix Warning Threshold : 75
Prefix Warning Only    : Disabled

DGS-3627:admin#
```

```
DGS-3627:admin# show bgp neighbors 172.16.232.178 advertised_routes
Command: show bgp neighbors 172.16.232.178 advertised_routes

BGP local router ID is 172.16.232.181
Status codes: s suppressed, d damped, h history, * valid, > best, i - internal
Origin codes: i - IGP, e - EGP, ? - incomplete
IP Address/Netmask   Gateway           Metric  LocPrf  Weight  Path
-----
*>i10.0.0.0         172.16.232.179   0       100     0       ?
*> 10.20.2.0        0.0.0.0          0       32768   i

Total Entries :2

DGS-3627:admin#
```



```
DGS-3627:admin# show bgp neighbors 172.16.232.178 received_routes
Command: show bgp neighbors 172.16.232.178 received_routes

BGP local router ID is 172.16.232.181
Status codes: s suppressed, d damped, h history, * valid, > best, i - internal
Origin codes: i - IGP, e - EGP, ? - incomplete
IP Address/Netmask   Gateway           Metric  LocPrf  Weight  Path
-----
*>i10.0.0.0         172.16.232.179   0       100     0       ?
*> 10.20.2.0        0.0.0.0          0       32768   0       i

Total Entries :2

DGS-3627:admin# show bgp neighbors 172.16.232.178 received_prefix_filter
Command: show bgp neighbors 172.16.232.178 received_prefix_filter

  Ip prefix-list 172.16.232.181: 1 entries
  Seq 5 deny 10.0.0.0/8 le 32

Total Entries :1

DGS-3627:admin#
```

```
DGS-3627:admin# show bgp neighbors 192.168.6.102 routes
Command: show bgp neighbors 192.168.6.102 routes

BGP local router ID is 10.0.40.1
Status codes: s suppressed, d damped, h history, * valid, > best, i - internal
Origin codes: i - IGP, e - EGP, ? - incomplete
IP Address/Netmask   Gateway           Metric  LocPrf  Weight  Path
-----
*> 10.10.10.0/24     172.16.10.1      0       0       300     10 i
*> 10.10.20.0/24     172.16.10.1      0       0       300     10 i
* 10.20.10.0/24      172.16.10.1      0       0       300     10 i
*dh 30.10.1.1/24     172.3.3.2        100     50      200     20 i

Total Entries :4

DGS-3627:admin#
```

show bgp dampened_routes

Purpose	This command is used to display dampened entries in the Border Gateway Protocol (BGP) routing table.
Syntax	show bgp dampened_routes
Description	The command is used to show dampened routes.
Parameters	<i>dampened_routes</i> - Displays the dampened routes
Restrictions	None.

Example usage:

To show the BGP dampened route information:

```
DGS-3627:admin# show bgp dampened_routes
```

```
Command: show bgp dampened_routes
```

```
BGP local router ID is 172.29.232.182
```

```
Status codes: s suppressed, d damped, h history, * valid, > best, i -internal
```

```
Origin codes: i - IGP, e - EGP, ? - incomplete
```

Network	From	Reuse	Path
*d 10.0.0.0/8	172.16.232.177	00:18:4	100 ?
*d 10.2.0.0/16	172.16.232.177	00:28:5	100 ?

```
Total Entries: 2
```

show bgp flap_statistics

Purpose	This command is used to display flap entries in the Border Gateway Protocol's (BGP) routing table
Syntax	show bgp flap_statistics
Description	The command is used to show BGP flap routes.
Parameters	None.
Restrictions	None.

Example usage:

To show flap BGP route information:

```
DGS-3627:admin# show bgp flap_statistics
```

```
Command:show bgp flap_statistics
```

```
BGP local router ID is 172.29.232.182
```

```
Status codes: s suppressed, d damped, h history, * valid, > best, i -internal
```

```
Origin codes: i - IGP, e - EGP, ? - incomplete
```

Network	From	Flaps	Duration	Reuse	Path
*d 10.0.0.0/8	172.29.232.177	4	00:13:31	00:18:10	100i
*d 10.2.0.0/16	172.29.232.177	4	00:02:45	00:28:20	100i

```
Total Entries: 2
```

show bgp

Purpose	This command is used to display BGP configuration and summary of the BGP status.
Syntax	show bgp {summary}
Description	This command is used to display BGP configuration and summary of the BGP status.
Parameters	None.
Restrictions	None.

Example usage:

To display the BGP setting:

```
DGS-3627:admin# show bgp
Command: show bgp
BGP Global State           : Enabled
Version                    : 4
BGP Router Identifier      : 172.16.1.1
Synchronization           : Enabled
Enforce First AS          : Enabled
Local AS number           : 100
Scan Time                  : 60 Seconds
Hold Time                  : 300 Seconds
Keep Alive Time           : 100 Seconds
Dampening                  : Enabled
Always Compare MED        : Disabled
Deterministics MED        : Disabled
Med Confed                 : Disabled
Default Local Preference  : 200
AS Path Ignore            : Disabled
Compare Router ID         : Enabled
MED Missing as Worst     : Disabled
Compare Confederation Path : Disabled
Fast External Fallover    : Disabled
Aggregate Next Hop Check  : Disabled
BGP Trap                  : None

DGS-3627:admin#
```

To display the BGP summary:

```
DGS-3627:admin# show bgp summary
Command: show bgp summary
BGP Router Identifier      : 172.16.1.1,
Local AS Number           : 100
Dampening                  : Enabled
BGP AS Path Entries       : 10
BGP Community Entries     : 7
Neighbor      Ver      AS      MsgRcvd  MsgSent  Up/Down  State/PfxRcvd
-----
10.100.1.1    4      200    26       22       00:14:23  23
10.200.1.1    4      300    21       51       00:13:40  0
10.200.1.5    4      300    21       5        00:10:05  Idle

Total Number of Neighbors: 3

DGS-3627:admin#
```

show bgp reflection

Purpose	This command is used to display the route reflection configuration of BGP.
Syntax	show bgp reflection
Description	This command displays the BGP route reflection configuration.
Parameters	None.
Restrictions	None.

Example usage:

To display the BGP reflection setting:

```
DGS-3627:admin# show bgp reflection
Command: show bgp reflection

Client to Client Reflection State : Disabled
Cluster ID                        : 0.0.0.0

Router Reflector Client:
 10.1.1.20
 10.1.1.30

DGS-3627:admin#
```

show bgp confederation

Purpose	This command is used to display the confederation configuration of BGP.
Syntax	show bgp confederation
Description	This command displays the BGP confederation configuration.
Parameters	None.
Restrictions	None.

Example usage:

To display the BGP confederation setting:

```
DGS-3627:admin# show bgp confederation
Command: show bgp confederation

BGP AS Number           : 65501.
Confederation Identifier : 10
Confederation Peer      : 65502,65503
Neighbor List:
IP Address              Remote AS Number
-----
192.168.1.1            65502
192.168.1.2            65503
192.168.1.3            65501

DGS-3627:admin#
```

config bgp trap

Purpose	This command is used to configure the BGP trap state.
Syntax	config bgp trap [peer_established peer_idle all] [enable disable]
Description	This command controls the sending of BGP traps.
Parameters	<p><i>peer_established</i> - Enables or disables the sending of the peer established trap. The default value is disabled.</p> <p><i>peer_idle</i> - Enables or disables the sending of the peer idle trap. The default value is disabled.</p> <p><i>all</i> - Enables or disables the sending of both the peer idle and established trap. The default value is disabled.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the BGP peer idle trap state:

```
DGS-3627:admin# config bgp trap peer_idle disable
Command: config bgp trap peer_idle disable

Success.

DGS-3627:admin#
```

show bgp trap

Purpose	This command is used to show the BGP trap state.
Syntax	show bgp trap_state
Description	This command displays the BGP trap state.
Parameters	None.
Restrictions	None.

Example usage:

To display the BGP trap state:

```
DGS-3627:admin# show bgp trap_state
Command: show bgp trap_state

BGP Trap State:
BGP Peer Established: Enabled.
BGP Peer Idle: Enabled

DGS-3627:admin#
```

config bgp scan_timer

Purpose	This command is used to configure the BGP scan timer value. BGP will check the next hop whether it is reachable from the BGP route before the timer expires.
Syntax	config bgp scan_timer [<sec 5-60> default]
Description	This command configures the BGP scan timer value.
Parameters	<i><sec 5-60></i> - Set the BGP scan timer value from 5 to 60 seconds. The default value is 60 seconds <i>default</i> - Set the BGP scan timer to the default value.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the BGP scan timer to 30 seconds:

```
DGS-3627:admin# config bgp scan_timer 30
Command: config bgp scan_timer 30

Success.

DGS-3627:admin#
```

config bgp aggregate_next_hop_check

Purpose	This command is used to configure the BGP aggregated routes' next hop check. Only the routes with the same next hop attribute can be aggregated if the BGP aggregate next hop check is enabled.
Syntax	config bgp aggregate_next_hop_check [enable disable]
Description	This command configures the BGP aggregate next hop check state.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the BGP aggregate next hop check state:

```
DGS-3627:admin# config bgp aggregate_next_hop_check enable
Command: config bgp aggregate_next_hop_check enable

Success.

DGS-3627:admin#
```

config bgp fast_external_fallover

Purpose	This command is used to configure the BGP fast external fallover.
Syntax	config bgp fast_external_fallover [enable disable]
Description	This commands configures a Border Gateway Protocol (BGP) routing process to immediately reset its external BGP peer sessions if the link used to reach these peers goes down,
Parameters	<i>enable</i> - Enables BGP fast external fallover flag. The default value is enabled. <i>disable</i> - Disables BGP fast external fallover.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable BGP fast external fallover:

```
DGS-3627:admin# config bgp fast_external_fallover disable
Command: config bgp fast_external_fallover disable

Success.

DGS-3627:admin#
```

config bgp neighbor maximum_prefix

Purpose	This command is used to configure the BGP neighbor maximum prefix.
Syntax	config bgp neighbor maximum_prefix [<ipaddr> peer_group <peer_group_name 16>] <value 1-12000> {<value 1-100>} {warning_only}
Description	This command is used to control how many prefixes can be received from a neighbor.
Parameters	<ipaddr> - Specifies the IP address of the neighbor to be configured. <peer_group_name 16> - Specifies the peer group to be configured. <value 1-12000> - The maximum number of prefixes allowed from the specified neighbor.

config bgp neighbor maximum_prefix

The default is 12000.

<value 1-100> - An integer specifying at what percentage the maximum prefix limit on the router starts to generate a warning message. The range is from 1 to 100. The default is 75.

warning_only - Allows the router to generate a log message when the maximum prefix limit is exceeded, instead of terminating the peering session.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To set the maximum number of prefixes that will be accepted from the neighbor 192.168.1.1 to 5000, when 50 percent of the maximum prefix limit has been reached. This will display a warning message.

```
DGS-3627:admin# config bgp neighbor maximum_prefix 192.168.1.1 5000 50
```

```
Command: config bgp neighbor maximum_prefix 192.168.1.1 5000 50
```

```
Success.
```

```
DGS-3627:admin#
```

clear bgp flap_statistics

Purpose

This command is used to clear the BGP route dampening flap statistics.

Syntax

```
clear bgp flap_statistics {[<ipaddr> | <network_address>]}
```

Description

The command is used to clear the accumulated penalties for routes that have been received on a router that has BGP dampening enabled. If no arguments or keywords are specified, flap statistics are cleared for all routes.

Parameters

<ipaddr> - Specifies an IPv4 address to clear the dampening flap statistics.

<network_address> - Specifies an IPv4 network to clear the dampening flap statistics.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To clear the route dampening flap statistics of network 192.168.1.0/24:

```
DGS-3627:admin# clear bgp flap_statistics 192.168.1.0/24
```

```
Command: clear bgp flap_statistics 192.168.1.0/24
```

```
Success.
```

```
DGS-3627:admin#
```

BPDU ATTACK PROTECTION COMMANDS

In a network, customers do not want all the ports of the device to receive STP packets, because some ports that receive STP BPDU packets will waste system resources.

If the ports are not expected to receive BPDU packets, BPDU attack protection will prevent some ports from receiving them. The port where BPDU attack protection function is enabled will enter protection state (drop/block/disable) when it receives a STP BPDU packet.

The BPDU Attack Protection commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config bpdu_protection ports	[<portlist> all] {state [enable disable] mode [drop block shutdown] } (1)
config bpdu_protection recovery_timer	[<sec 60-1000000> infinite]
config bpdu_protection	[trap log] [none attack_detected attack_cleared both]
enable bpdu_protection	
disable bpdu_protection	
show bpdu_protection	{ports {<portlist>}}

Each command is listed, in detail, in the following sections.

config bpdu_protection ports

Purpose	Used to configure bpdu_protection state and mode.
Syntax	config bpdu_protection ports [<portlist> all] {state [enable disable] mode [drop block shutdown] } (1)
Description	<p>The config bpdu_protection ports command is used to configure the BPDP protection function for the ports on the switch. In generally, there are two states in BPDU protection function. One is normal state, and another is under attack state. The under attack state have three modes: drop, block, and shutdown. A BPDU protection enabled port will enter under attack state when it receives one STP BPDU packet. And it will take action based on the configuration. Thus, BPDU protection can only be enabled on STP-disabled port.</p> <p>BPDU protection has high priority than fbpdu setting configured by configure STP command in determination of BPDU handling. That is, when fbpdu is configured to forward STP BPDU but BPDU protection is enabled, then the port will not forward STP BPDU.</p> <p>BPDU protection also has high priority than BPDU tunnel port setting in determination of BPDU handling.</p> <p>That is, when a port is configured as BPDU tunnel port for STP, it will forward STP BPDU. But if the port is BPDU protection enabled. Then the port will not forward STP BPDU</p>
Parameters	<p><i>portlist</i> - Specified a range of ports to be configured (port number).</p> <p><i>all</i> - For set all ports in the system, you may use "all" parameter.</p> <p><i>state</i> - Specified the bpdu_protection state. The default state is disable</p> <p><i>enable</i> - Enable bpdu_protection</p> <p><i>disable</i> - Disable bpdu_protection</p> <p><i>mode</i> - Specified the bpdu_protection mode. The default mode is shutdown</p> <p><i>drop</i> - Drop all received BPDU packets when the port enters under_attack state.</p> <p><i>block</i> - Drop all packets (include BPDU and normal packets) when the port enters under_attack state.</p>

config bpdu_protection ports

	<i>shutdown</i> - Shut down the port when the port enters under_attack state.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set the port state enable and drop mode:

```
DGS-3627:admin# config bpdu_protection ports 1 state enable mode drop
Commands: config bpdu_protection ports 1 state enable mode drop

Success.

DGS-3627:admin#
```

config bpdu_protection recovery_interval

Purpose	Used to configure bpdu_protection recovery timer.
Syntax	config bpdu_protection recovery_timer [<sec 60-1000000> infinite]
Description	When a port enters under attack state, it can be disabled or blocked based on the configuration. The state can be recovered manually or by the auto recovery mechanism. This command is used to configure the auto-recovery timer. To manually recover the port, the user needs to disable and re-enable the port.
Parameters	<i>recovery_timer</i> - Specified the bpdu_protection Auto-Recovery recovery_timer. The default value of recovery_timer is 60. <i>infinite</i> - The port will not be auto recovered. <sec 60 –1000000> - The timer (in seconds) used by the Auto-Recovery mechanism to recover the port. The valid range is 60 to 1000000.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the bpdu_protection recovery_timer to 120 seconds for the entire switch:

```
DGS-3627:admin# config bpdu_protection recovery_timer 120
Commands: config bpdu_protection recovery_timer 120

Success.

DGS-3627:admin#
```

config bpdu_protection

Purpose	Used to configure bpdu_protection trap state or log state.
Syntax	config bpdu_protection [trap log] [none attack_detected attack_cleared both]
Description	The config bpdu_protection trap command is used to configure the bpdu_protection trap state or state for the entire switch.
Parameters	<i>trap</i> - To specify the trap state. <i>log</i> - To specify the log state. <i>none</i> - Neither attack_detected nor attack_cleared is trapped or logged. <i>attack_detected</i> - Events will be logged or trapped when the BPDU attacks is detected.

config bpdu_protection

attack_cleared - Events will be logged or trapped when the BPDU attacks is cleared.

both - The events of *attack_detected* and *attack_cleared* shall be trapped or logged.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To config the bpdu_protection trap state as both for the entire switch:

```
DGS-3627:admin# config bpdu_protection trap both
```

```
Commands: config bpdu_protection trap both
```

```
Success.
```

```
DGS-3627:admin#
```

enable bpdu_protection

Purpose Used to enable bpdu_protection globally.

Syntax **enable bpdu_protection**

Description The enable bpdu_protection command is used to enable bpdu_protection function globally for the entire switch.

Parameters None.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To enable bpdu_protection function globally for the entire switch:

```
DGS-3627:admin# enable bpdu_protection
```

```
Commands: enable bpdu_protection
```

```
Success.
```

```
DGS-3627:admin#
```

disable bpdu_protection

Purpose Used to disalbe bpdu_protection globally.

Syntax **disable bpdu_protection**

Description The disable bpdu_protection command is used to disable bpdu_protection function globally for the entire switch.

Parameters None.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To disable bpdu_protection function globally for the entire switch:

```
DGS-3627:admin# disable bpdu_protection
```

```
Commands: disable bpdu_protection
```

```
Success.
```

```
DGS-3627:admin#
```

show bpdu_protection

Purpose	Used to show bpdu_protection status.
Syntax	show bpdu_protection {ports {<portlist>}}
Description	The show bpdu_protection command is used to display bpdu_protection global configuration or per port configuration and current status.
Parameters	<i>portlist</i> - Specified a range of ports to be configured.
Restrictions	None.

Example usage:

To show the bpdu_protection for the entire switch:

```
DGS-3627:admin# show bpdu_protection
```

```
Commands: show bpdu_protection
```

```
BPDU Protection Global Settings
```

```
-----
BPDU Protection status      : Enabled
BPDU Protection Recovery Time : 60 seconds
BPDU Protection Trap State   : None
BPDU Protection Log State    : None
```

```
DGS-3627:admin#
```

To show the bpdu_protection status ports 1-12:

```
DGS-3627:admin# show bpdu_protection ports 1-12
```

```
Commands: show bpdu_protection ports 1-12
```

Port	State	Mode	Status
1	Enabled	shutdown	Normal
2	Enabled	shutdown	Normal
3	Enabled	shutdown	Normal
4	Enabled	shutdown	Normal
5	Enabled	shutdown	Under Attack
6	Enabled	shutdown	Normal
7	Enabled	shutdown	Normal
8	Enabled	shutdown	Normal
9	Enabled	shutdown	Normal
10	Enabled	Block	Normal
11	Disabled	shutdown	Normal
12	Disabled	shutdown	Normal

```
DGS-3627:admin#
```

CABLE DIAGNOSTICS COMMAND LIST

The Cable Diagnostics commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
cable_diag ports	[<portlist> all]

Each command is listed, in detail, in the following sections.

cable_diag ports

Purpose	This command is used to configure the cable diagnostics.
Syntax	cable_diag ports [<portlist> all]
Description	<p>For FE port, two pairs of cable will be diagnosed. For GE port, four pairs of cable will be diagnosed. The type of cable error can be open, short, or crosstalk.</p> <p>Open means that the cable in the error pair does not have a connection at the specified position.</p> <p>Short means that the cables in the error pair has a short problem at the specified position, Crosstalk means that the cable in the error pair has a crosstalk problem at the specified position.</p> <p>When a port is in link-up status, the test will obtain the distance of the cable. Since the status is link-up, the cable will not have the short or open problem. But the test may still detect the crosstalk problem.</p> <p>When a port is in link-down status, the link-down may be caused by many factors.</p> <ol style="list-style-type: none"> 1. When the port has a normal cable connection, but the remote partner is powered off, the cable diagnosis can still diagnose the health of the cable as if the remote partner is powered on. 2. When the port does not have any cable connection, the result of the test will indicate no cable. 3. The test will detect the type of error and the position where the error occurs. <p>Note that this test will consume a low number of packets. Since this test is for copper cable, the port with fiber cable will be skipped from the test. For combo port, the test will always be applied to the copper media only.</p>
Parameters	<p><i><portlist></i> - Enter a list of ports used for the configuration here.</p> <p><i>all</i> - Specifies that all the ports will be used for this test.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Test the cable on port 1-2:

```
DGS-3627:admin# cable_diag ports 1-2
```

```
Command: cable_diag ports 1-2
```

```
Perform Cable Diagnostics ...
```

Port	Type	Link Status	Test Result	Cable Length(M)
1	GE	Link up	OK	2
2	GE	Link down	Pair 1 Open at 1M Pair 2 Open at 1M Pair 3 Short at 2M Pair 4 Open at 2M	

```
DGS-3627:admin#
```

COMMAND HISTORY LIST

The switch history commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
?	{<command>}
config command_history	<value 1-40>
show command_history	

Each command is listed, in detail, in the following sections.

?	
Purpose	Used to display all commands in the Command Line Interface (CLI).
Syntax	? {<command>}
Description	This command will display all of the commands available through the Command Line Interface (CLI).
Parameters	{<command>} – Entering the question mark with an appropriate command will list all the corresponding parameters for the specified command, along with a brief description of the commands function and similar commands having the same words in the command.
Restrictions	None.

Example usage:

To display all of the commands in the CLI:

```
DGS-3627:admin# ?
..
?
cd
clear
clear address_binding dhcp_snoop binding_entry ports
clear arptable
clear attack_log
clear counters
clear dhcp_binding
clear fdb
clear log
clear mac_based_access_control auth_mac
clear port_security_entry port
config 802.1p default_priority
config 802.1p user_priority
config 802.1x auth_mode
config 802.1x auth_parameter ports
config 802.1x auth_protocol
config 802.1x capability ports
config 802.1x guest_vlan ports
config 802.1x init
CTRL+C ESC q Quit SPACE n Next Page Enter Next Entry a All
```

To display the parameters for a specific command:

```
DGS-3627:admin# ? config stp
Command:? config stp

Command: config stp
Usage: {maxage <value 6-40>|maxhops <value 1-20> |hellotime <value 1-10>| forwa
rdldelay <value 4-30>|txholdcount <value 1-10>|fbpdu [enable|disable]|lbd [enable
|disable] |lbd_recover_timer [<value 0> | <value 60-1000000>]}
Description: Used to update the STP Global Configuration.
config stp instance_id
config stp mst_config_id
config stp mst_ports
config stp ports
config stp priority
config stp version

DGS-3627:admin#
```

config command_history

Purpose	Used to configure the command history.
Syntax	config command_history <value 1-40>
Description	This command is used to configure the command history.
Parameters	<value 1-40> – The number of previously executed commands maintained in the buffer. Up to 40 of the latest executed commands may be viewed.
Restrictions	None.

Example usage

To configure the command history:

```
DGS-3627:admin# config command_history 20
Command: config command_history 20

Success.

DGS-3627:admin#
```

show command_history

Purpose	Used to display the command history.
Syntax	show command_history
Description	This command will display the command history.
Parameters	None.
Restrictions	None.

Example usage

To display the command history:

```
DGS-3627:admin# show command_history
Command: show command_history

?
? show
show vlan
show command history

DGS-3627:admin#
```


COMMAND LOGGING COMMANDS

The command logging function is used to log the commands that have successfully been configured to the switch via the command line interface. The requirement is to log the command itself, along with information about the user account that entered the command into the system log and the informational severity level. Commands that do not cause a change in the switch configuration or operation (such as show) will not be logged. A save command will change the configuration file hence it will be logged.

The Command Logging commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
enable command logging	
disable command logging	
show command logging	

Each command is listed, in detail, in the following sections.

enable command logging

Purpose	Used to enable command logging.
Syntax	enable command logging
Description	The enable command logging command is used to enable the command logging function. Note: When the switch is under the booting procedure, all configuration commands will not be logged. When the user has logged in using AAA authentication, the user name should not be changed if the user has used the “enable admin” command to replace its privilege.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the command logging function:

```
DGS-3627:admin# enable command logging
Command: enable command logging

Success.

DGS-3627:admin#
```

disable command logging

Purpose	Used to disable the command logging function.
Syntax	disable command logging
Description	The disable command logging command is used to disable the command logging function.

disable command logging

Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the command logging function:

```
DGS-3627:admin# disable command logging
Command: disable command logging

Success.

DGS-3627:admin#
```

show command logging

Purpose	This command displays the switch's general command logging configuration status
Syntax	show command logging
Description	Use this command to show the command logging configuration status.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show the command logging configuration status:

```
DGS-3627:admin# show command logging
Command: show command logging

Command Logging State : Disabled

DGS-3627:admin#
```

COMPOUND AUTHENTICATION COMMANDS

The Compound Authentication UI specification describes the Common feature for access control functionalities and specifications.

The Compound Authentication commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create authentication guest_vlan	[vlan <vlan_name 32> vlanid <vlanid 1-4094>]
delete authentication guest_vlan	[vlan <vlan_name 32> vlanid <vlanid 1-4094>]
config authentication guest_vlan	[vlan <vlan_name 32> vlanid <vlanid 1-4094>] [add delete] ports [<portlist> all]
config authentication ports	[<portlist> all] {auth_mode [port_based host_based { vlanid <vidlist> state [enable disable] }] multi_authen_methods[none any dot1x_impb impb_jwac]} (1)
show authentication guest_vlan	
show authentication ports	{<portlist>}
enable authorization attributes	
disable authorization attributes	
show authorization	
config authentication server failover	[local permit block]
show authentication	

Each command is listed, in detail, in the following sections.

create authentication guest_vlan

Purpose	Used to assign a static VLAN to be guest VLAN.
Syntax	create authentication guest_vlan [vlan <vlan_name 32> vlanid <vlanid 1-4094>]
Description	The create guest_vlan command will assign a static VLAN to be guest VLAN. The specific VLAN which assigned to guest VLAN must be existed. The specific VLAN which assigned to guest VLAN can't be deleted. For further description of this command please see description for config authentication guest_vlan ports.
Parameters	<vlan_name 32> - Specify the guest VLAN by VLAN name. vlanid - Specify the guest VLAN by VLAN ID.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create an authentication guest VLAN:

```
DGS-3627:admin# create authentication guest_vlan vlan guestVLAN
Command: create authentication guest_vlan vlan guestVLAN

Success.

DGS-3627:admin#
```

delete authentication guest_vlan

Purpose	Used to delete guest VLAN configuration.
Syntax	delete authentication guest_vlan [vlan <vlan_name 32> vlanid <vlanid 1-4094>]
Description	The delete guest_vlan command will delete guest VLAN setting, but won't delete the static VLAN. All ports which enable guest VLAN will move to original VLAN after deleting guest VLAN. For further description of this command please see description for config authentication guest_vlan ports.
Parameters	<i><vlan_name 32></i> - Specify the guest VLAN by VLAN name. <i>vlanid</i> - Specify the guest VLAN by VLAN ID.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an authentication guest VLAN:

```
DGS-3627:admin# delete authentication guest_vlan vlan guestVLAN
Command: delete authentication guest_vlan vlan guestVLAN

Success.

DGS-3627:admin#
```

config authentication guest_vlan ports

Purpose	Used to configure security port(s) as specified guest VLAN member.
Syntax	config authentication guest_vlan [vlan <vlan_name 32> vlanid <vlanid 1-4094>] [add delete] ports [<portlist> all]
Description	Used to configure security port(s) as specified guest VLAN member.
Parameters	<i>vlan_name</i> - Assigned a VLAN as guest VLAN. The VLAN must be an existed static VLAN. <i>vlanid</i> - Assigned a VLAN as guest VLAN. The VLAN must be an existed static VLAN. <i>add</i> - Specifies to add port list to the guest VLAN. <i>delete</i> - Specifies to delete port list from the guest VLAN. <i>portlist</i> - Specify the configured port(s).
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure an authentication guest VLAN:

```
DGS-3627:admin# config authentication guest_vlan vlan gv add ports all
Command: config authentication guest_vlan vlan gv add ports all

Success.

DGS-3627:admin#
```

config authentication ports

Purpose	Used to configure security port(s).
Syntax	config authentication ports [<portlist> all] {auth_mode [port_based host_based {vlanid <vidlist> state [enable disable] }]} multi_authen_methods[none any dot1x_impb impb_jwac]} (1)
Description	The user can use this command to configure authorization mode and authentication method on ports.
Parameters	<p><i>portlist</i> - Specify port(s) to configure.</p> <p><i>auth_mode</i> - <i>port_based</i> - If one of the attached hosts passes the authentication, all hosts on the same port will be granted to access network. If the user fails to authorize, this port will keep trying the next authentication</p> <p><i>host_based</i> - Every user can be authenticated individually. V2.01 and later, can authenticate client on specific authentication VLAN(s).</p> <p><i>vlanid</i> - Specific authentication VLAN(s).</p> <p><i>enable</i> - Assign the specified VID list as authentication VLAN(s).</p> <p><i>disable</i> - Remove the specified VID list from authentication VLAN(s).</p> <p>If "vlanid" is not specified, or all VLANs is disabled, means do not care which VLAN the client comes from, the client will be authenticated if the client's MAC (not care the VLAN) is not authenticated. After the client is authenticated, the client will not be re-authenticated when received from other VLANs.</p> <p>All VLANs are disabled by default.</p> <p>NOTE: When port's authorization mode is changed to port based, previously authentication VLAN(s) on this port will be clear.</p> <p><i>multi_authen_methods</i> - Specifies the method for compound authentication.</p> <p><i>none</i> - Compound authentication is not enabled,</p> <p>For project that support single authentication mode, the authentication method is defined by individual authentication module.</p> <p>For project that does not support single authentication mode, access authentication is disabled on the port.</p> <p><i>any</i> - If any one of the authentication method (802.1X, MAC-based Access Control, WAC and JWAC) passes, then pass.</p> <p><i>dot1x_impb</i> - 802.1X will be verified first, and then IMPB will be verified. Both authentication need to be passed.</p> <p><i>impb_jwac</i> - JWAC will be verified first, and then IMPB will be verified. Both authentication need to be passed.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

The following example sets authorization mode and authentication VLAN for all port:

```
DGS-3627:admin# config authentication ports all auth_mode host_based vlanid 1-3 state enable
Command: config authentication ports all auth_mode host_based vlanid 1-3 state enable

Success.

DGS-3627:admin#
```

show authentication guest_vlan

Purpose	Used to show guest VLAN setting.
Syntax	show authentication guest_vlan
Description	The show guest VLAN command allows you to show the information of guest VLAN.
Parameters	None.
Restrictions	None.

Example usage:

This example displays the guest VLAN setting:

```
DGS-3627:admin# show authentication guest_vlan
Command: show authentication guest_vlan

Guest VLAN VID          : 1
Guest VLAN Member Ports : 4

Guest VLAN VID          : 3
Guest VLAN Member Ports : 1,8

Total Entries: 2

DGS-3627:admin#
```

show authentication ports

Purpose	Used to display authentication setting on port(s).
Syntax	show authentication ports {<portlist>}
Description	User can use this command to display authentication method and authorization mode on ports.
Parameters	<i>portlist</i> - Display compound authentication on specify port(s). If not specify the port, displays compound authentication setting of all ports.
Restrictions	None.

Example usage:

This example displays authentication setting for all ports:

```
DGS-3627:admin# show authentication ports
```

```
Command: show authentication ports
```

Port	Methods	Auth Mode	Authentication VLAN(s)
1	None	Host based	1,3,5,9,11,88,16 18,56
2	Any	Port based	
3	802.1X_IMP	Host based	
4	None	Host based	2000,2005
5	IMPB_JWAC	Port based	
6	None	Host based	
7	None	Host based	1-20
8	802.1X_IMP	Host based	
9	None	Host based	

```
DGS-3627:admin#
```

enable authorization

Purpose	The enable authorization command will enable authorization.
Syntax	enable authorization attributes
Description	Used to enable authorization attributes. When the authorization for attributes is enabled, whether the authorized attributes (for example VLAN, 802.1p default priority assigned by the RADIUS server or local database will be accepted which depends on the individual module's setting. Authorization for attributes is enabled by default.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

This example sets authorization global state enabled:

```
DGS-3627:admin# enable authorization attributes
```

```
Command: enable authorization attributes
```

```
Success.
```

```
DGS-3627:admin#
```

disable authorization

Purpose	The disable authorization command will disable authorization.
Syntax	disable authorization attributes
Description	Used to disable authorization attributes. When the authorization for attributes is disabled, the authorized attributes (for example VLAN, 802.1p default priority assigned by the RADIUS server or local database will be ignored even if the individual module's setting is enabled. Authorization for attributes is enabled by default.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

This example sets authorization global state disabled:

```
DGS-3627:admin# disable authorization attributes
Command: disable authorization attributes

Success.

DGS-3627:admin#
```

show authorization

Purpose	Used to show authorization status.
Syntax	show authorization
Description	Used to show authorization status.
Parameters	None.
Restrictions	None.

Example usage:

This example displays authorization status:

```
DGS-3627:admin# show authorization
Command: show authorization

Authorization for Attributes: Enabled.

DGS-3627:admin#
```

config authentication server failover

Purpose	Used to configure authentication server failover function.
Syntax	config authentication server failover [local permit block]
Description	<p>Description</p> <p>When authentication server fails, administrator can configure to:</p> <p>Use local DB to authenticate the client</p> <p>The switch will resort to using local database to authenticate the client. If the client fails on local authentication, the client is regarded as un-authenticated, otherwise, it authenticated.</p> <p>Pass authentication</p> <p>The client is always regarded as authenticated. If guest VLAN enabled, client will stay at guest VLAN, otherwise, it will stay at original VLAN.</p> <p>Block the client (default setting)</p> <p>The client is always regarded as un-authenticated.</p>
Parameters	<p><i>local</i> - Use local DB to authenticate the client.</p> <p><i>permit</i> - The client is always regarded as authenticated.</p> <p><i>block</i> - Block the client (Default setting)</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Set authentication server auth fail over state:

```
DGS-3627:admin# config authentication server failover local
Command: config authentication server failover local

Success.

DGS-3627:admin#
```

show authentication

Purpose	Used to show authentication global configuration.
Syntax	show authentication
Description	Used to show authentication global configuration.
Parameters	None.
Restrictions	None.

Example usage:

To show authentication:

```
DGS-3627:admin# show authentication
Command: show authentication

Authentication Server Failover: Block.

DGS-3627:admin# show authentication
Command: show authentication

Authentication Server Failover: Permit.

DGS-3627:admin# show authentication
Command: show authentication

Authentication Server Failover: Local.

DGS-3627:admin#
```

CONFIGURATION COMMANDS

Configuration function is used to conserve several configuration files in switch. With configuration function, user could conserve several same configurations in switch, one for currently use, other for back up, and user could conserve several different configurations in switch for different condition use.

The Configuration commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
download cfg_fromTFTP	[<ipaddr> <ipv6addr> <domain_name 255>] src_file <path_filename 64> {[increment dest_file {<drive_id> <pathname 64>}]}
upload cfg_toTFTP	[<ipaddr> <ipv6addr> <domain_name 255>] dest_file <path_filename 64> {src_file {<drive_id> <pathname 64>} { [include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>} } { [include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>} } { [include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>}}}}}
show config	[active boot_up {<drive_id> <pathname 64>} { [include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>} } { [include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>} } { [include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>}}}}}
config configuration	{<drive_id> <pathname 64> {delete boot_up active}}
save config	{<drive_id> <pathname 64>}

Each command is listed, in detail, in the following sections.

download cfg_fromTFTP

Purpose	Used to down load a switch configuration file from TFTP server
Syntax	download cfg_fromTFTP [<ipaddr> <ipv6addr> <domain_name 255>] src_file <path_filename 64> {[increment dest_file {<drive_id> <pathname 64>}]}
Description	This command is used to download a config file from a TFTP server. For projects that support file system, the stored file name must be specified, for projects that support multiple configurations, the configuration ID can be specified. If the configuration ID is not specified, the boot up configuration is implied.
Parameters	<p><i>ipaddr</i> - The IPv4 address of the TFTP server.</p> <p><i>ipv6addr</i> - The IPv6 address of the TFTP server.</p> <p><i>domain_name</i> - The domain name of the host.</p> <p><i>src_file</i> - The pathname specifies the DOS pathname on the TFTP server. It can be a relative pathname or an absolute pathname.</p> <p><i>dest_file</i> - The pathname specifies an absolute pathname on the device. If pathname is not specified, it refers to the boot up configuration file.</p> <p><i><drive_id></i> - Specify the drive ID here.</p> <p><i>increment</i> - If increment is specified, then the existing configuration will not be cleared before applying of the new configuration. If it is not specified, then the existing configuration will be cleared before applying of the new configuration.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To download the configuration file “desxxx.cfg” from TFTP server at IP address 10.54.71.1:

```
DGS-3627:admin# download cfg_fromTFTP 10.54.71.1 src_file desxxxx.cfg
Command: download cfg_fromTFTP 10.54.71.1 src_file desxxxx.cfg

Connecting to server..... Done.
Download configuration..... Done.

DGS-3627:admin#
```

To download configuration file from TFTP server tftp.cfgmngmt.com:

```
DGS-3627:admin# download cfg_fromTFTP tftp.cfgmngmt.com src_file desxxxx.cfg
Command: download cfg_fromTFTP tftp.cfgmngmt.com src_file desxxxx.cfg

Connecting to server..... Done.
Download configuration..... Done.

DGS-3627:admin#
```

upload cfg_toTFTP

Purpose	Used to upload a configuration file from device to TFTP server.
Syntax	upload cfg_toTFTP [<ipaddr> <ipv6addr> <domain_name 255>] dest_file <path_filename 64> {src_file {<drive_id> <pathname 64>} { [include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>} } { [include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>} } { [include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>}}}}}
Description	<p>Used to upload a configuration file from the device to the TFTP server. Note that, for stacking system, only the master’s configuration file is allowed to be uploaded.</p> <p>The output stream of the configuration data can be filtered by the expression specified at the end of the command. The expression can contain up to three multiple filter evaluations. A filter evaluation begins with a filter type (include, exclude, and begin), followed by up to three filter strings (ex: “stp”). A filter string is enclosed by symbol “. The following describes the meaning of the each filter type.</p> <p>include: includes lines that contain the specified filter string. exclude: excludes lines that contain the specified filter string begin: The first line that contains the specified filter string will be the first line of the output.</p> <p>The relationship of multiple filter strings following the same filter type is OR. That is, one line is qualified if one of specified filter strings is matched. If more than one filter evaluation is specified; the output of filtered by the former evaluation will be used as the input of the latter evaluation.</p> <p>For example, if the following expression is specified include “stp” exclude “port” The result of the above example is all lines that include the “stp” string but exclude the “port” string.</p>
Parameters	<p><i>ipaddr</i> - The IPv4 address of the TFTP server. <i>ipv6addr</i> - The IPv6 address of the TFTP server. <i>domain_name</i> - The domain name of the host. <i>dest_file</i> - The pathname specifies the DOS pathname on the TFTP server. It can be a relative pathname or an absolute pathname.</p>

upload cfg_toTFTP

<drive_id> - Specify the drive ID here.

src_file - The pathname specifies an absolute pathname on the device file system. If pathname is not specified, it refers to the boot up configuration file.

filter_string - A filter string is enclosed by symbol ". Thus, the filter string itself cannot contain the "character. The filter string is case sensitive.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To upload the boot up configuration file to TFTP server and save as "cfg":

```
DGS-3627:admin# upload cfg_toTFTP 10.48.74.121 dest_file c:\cfg\DGS-3627S\cfg
```

```
Command: upload cfg_toTFTP 10.48.74.121 dest_file c:\cfg\DGS-3627S\cfg
```

```
Connecting to server... Done.
```

```
Upload Configuration... Done.
```

```
DGS-3627:admin#
```

In case that the designated file does not exist:

```
DGS-3627:admin# upload cfg_toTFTP 10.48.74.121 dest_file c:\cfg\DGS-3627S\cfg
```

```
Command: upload cfg_toTFTP 10.48.74.121 dest_file c:\cfg\DGS-3627S\cfg
```

```
The designated file does not exist.
```

```
Abort.
```

```
DGS-3627:admin#
```

show config

Purpose Display the content of the current configuration, the configuration to be used in next boot, or the configuration file specified by the command.

Syntax **show config** [active | boot_up | {<drive_id> <pathname 64>} { [include | exclude | begin] <filter_string 80> {<filter_string 80> {<filter_string 80>} } { [include | exclude | begin] <filter_string 80> {<filter_string 80> {<filter_string 80>} } { [include | exclude | begin] <filter_string 80> {<filter_string 80> {<filter_string 80>}}}}}

Description Display the content of the current configuration, the configuration to be used in next boot, or the configuration file specified by the command.

The output stream of the configuration data can be filtered by the expression specified at the end of the command. The expression can contain up to three multiple filter evaluations. A filter evaluation begins with a filter type (include, exclude, and begin), followed by up to three filter strings (ex: "stp"). A filter string is enclosed by symbol ". The following describes the meaning of the each filter type.

include: includes lines that contain the specified filter string.

exclude: excludes lines that contain the specified filter string

begin: The first line that contains the specified filter string will be the first line of the output.

The relationship of multiple filter strings following the same filter type is OR. That is, one line is qualified if one of specified filter strings is matched.

If more than one filter evaluation is specified; the output of filtered by the former evaluation will be used as the input of the latter evaluation.

show config

For example, if the following expression is specified, Include “stp” exclude “port”
The result of the above example is all lines that include the “stp” string but exclude the “port” string.

Parameters	<p><i>active</i> – Specify to display the active configuration.</p> <p><i>boot_up</i> – Specify to display the boot-up configuration.</p> <p><i><drive_id></i> - Specify the drive ID here</p> <p><i>pathname</i> - The pathname specifies an absolute pathname on the device file system. If pathname is not specified, the boot up configuration is implied.</p> <p><i>filter_string</i> - A filter string is enclosed by symbol ". Thus, the filter string itself cannot contain the "character. The filter string is case sensitive.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

The following example illustrates how the special filters account affect the configuration display:

```
DGS-3627:admin# show config active include "account"
Command: show config active include "account"
config accounting service network state disable
config accounting service shell state disable
config accounting service system state disable

DGS-3627:admin#
```

config configuration

Purpose	Used to select a configuration file as the next boot up configuration or to apply a specific configuration to the system. This command is required when multiple configuration files are supported.
Syntax	config configuration {<drive_id>} <pathname 64> {delete boot_up active}
Description	Used to select a configuration file as the next boot up configuration or to apply a specific configuration to the system. This command is required when multiple configuration files are supported.
Parameters	<p><i><drive_id></i> - Specify the drive ID here.</p> <p><i>pathname</i> - Specifies a configuration file on the device file system.</p> <p><i>boot_up</i> - Specifies it as a boot up file.</p> <p><i>active</i> - Specifies to apply the configuration.</p> <p><i>delete</i> - Specifies to delete the configuration.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure configuration as boot-up 1:

```
DGS-3627:admin#config configuration 1 boot_up
Command: config configuration 1 boot_up

Success.

DGS-3627:admin#
```

save config

Purpose	Used to save the current configuration to a file.
Syntax	save config {<drive_id>} <pathname 64>
Description	Used to save the current configuration to a file. This command is required to be supported regardless of whether file system is supported or whether multiple configuration files are supported. The configuration will only save to the master unit.
Parameters	<i><drive_id></i> - Specify the drive ID here. <i>pathname</i> - The pathname specifies the absolute pathname on the device file system. If pathname is not specified, it refers to the boot up configuration file.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To save the configuration:

```
DGS-3627:admin#save config 123
Command: save config 123

Saving all configurations to NV-RAM..... Done.

DGS-3627:admin#
```

COUNTER COMMANDS

The Counter commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
show packet ports	<portlist>
show error ports	<portlist>
show utilization ports	
clear counters	{ports <portlist>}

Each command is listed, in detail, in the following sections.

show packet ports

Purpose	Used to show statistics about the packets which were sent and received by the switch.
Syntax	show packet ports <portlist>
Description	The show packet ports command shows statistics about the packets which were sent and received by the switch.
Parameters	<i>portlist</i> - Specifies a range of ports to be displayed. (Unit ID: port number).
Restrictions	None.

Example usage:

To display the packets analysis for port 7 of unit 2:

```
DGS-3627:admin# show packet ports 2:7
```

```
Command: show packet ports 2:7
```

```
Port number : 2:7
```

Frame Size/Type	Frame Counts	Frames/sec
-----	-----	-----
64	30284	3
65-127	5998	0
128-255	11985	1
256-511	1004	0
512-1023	1363	0
1024-1518	15	0
1519-1522	0	0
1519-2047	0	0
2048-4095	0	0
4096-9216	0	0
Unicast RX	1	0
Multicast RX	0	0
Broadcast RX	5	0
Frame Type	Total	Total/sec
-----	-----	-----
RX Bytes	384	0
RX Frames	6	0
TX Bytes	5619310	340
TX Frames	50673	4

show error ports

Purpose	Use to show error statistics information for a range of ports.
Syntax	show error ports <portlist>
Description	The show error ports command shows error statistics for a range of ports.
Parameters	<i>portlist</i> - Specifies a range of ports to be displayed. (Unit ID: port number).
Restrictions	None.

Example usage:

To display the errors of the port 3 of unit 1:

```
DGS-3627:admin# show error ports 1:3
```

```
Command: show error ports 1:3
```

```
Port number : 1:3
```

RX Frames		TX Frames	
-----		-----	
CRC Error	0	Excessive Deferral	0
Undersize	0	CRC Error	0
Oversize	0	Late Collision	0
Fragment	0	Excessive Collision	0
Jabber	0	Single Collision	0
Drop Pkts	0	Collision	0
Buffer Full Drop	0		
ACL Drop	0		
Multicast Drop	0		
VLAN Ingress Drop	0		

show utilization

Purpose	Use to show real-time port utilization statistics.
Syntax	show utilization ports {<portlist>}
Description	The show utilization command displays real-time port utilization statistics.
Parameters	<i>portlist</i> - Specifies a range of ports to be displayed. (Unit ID: port number).
Restrictions	None.

Example usage:

To show the ports utilization:

```
DGS-3627:admin# show utilization ports
Command: show utilization ports
```

Port	TX/sec	RX/sec	Util	Port	TX/sec	RX/sec	Util
1:1	0	0	0	1:22	0	0	0
1:2	0	0	0	1:23	0	0	0
1:3	0	0	0	1:24	0	0	0
1:4	0	0	0	1:25	0	0	0
1:5	0	0	0	1:26	19	49	1
1:6	0	0	0	2:1	0	0	0
1:7	0	0	0	2:2	0	0	0
1:8	0	0	0	2:3	0	0	0
1:9	0	0	0	2:4	0	0	0
1:10	0	0	0	2:5	0	0	0
1:11	0	0	0	2:6	0	0	0
1:12	0	0	0	2:7	0	30	1
1:13	0	0	0	2:8	0	0	0
1:14	0	0	0	2:9	30	0	1
1:15	0	0	0	2:10	0	0	0
1:16	0	0	0	2:11	0	0	0
1:17	0	0	0	2:12	0	0	0
1:18	0	0	0	2:13	0	0	0
1:19	0	0	0	2:14	0	0	0
1:20	0	0	0	2:15	0	0	0
1:21	0	0	0	2:16	0	0	0

clear counter

Purpose	Used to clear the switch's statistics counters.
Syntax	clear counters {ports <portlist>}
Description	The clear counters command clears the switch's statistics counters.
Parameters	<i>portlist</i> - Specifies a range of ports to be configured. The port list is specified by listing the lowest switch number and the beginning port number on that switch, separated by a colon. Then highest switch number, and the highest port number of the range (also separated by a colon) are specified. The beginning and the end of the port list range are separated by a dash.

For example:

1:3 would specify unit 1, port 3;

2:4 specifies unit 2, port 4;

1:3-2:4 specifies all of the ports between unit 1, port 3 and unit 2, port 4 – in numerical order.

clear counter

If no parameter is specified, system will counter all of the ports.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To clear the switch's statistics counters:

```
DGS-3627:admin# clear counters ports 2:7-2:9
```

```
Command: clear counters ports 2:7-2:9
```

```
Success.
```

```
DGS-3627:admin#
```

DEBUG COMMANDS

Software Debug is used to define the common behavior of each module's debug function and collect and save basic OS information when exceptions happen.

The Debug commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
debug error_log	[dump clear upload_toTFTP <ipaddr> <path_filename 64>]
debug buffer	[utilization dump clear upload_toTFTP <ipaddr> <path_filename 64>]
debug output	[module <module_list> all] [buffer console]
debug config ipv6route_preference	[local static ripng ospf6] <value 1-999>
debug config error_reboot	[enable disable]
debug show status	{ module <module_list> }
debug config state	[enable disable]
debug show error_reboot state	

Each command is listed, in detail, in the following sections.

debug error_log

Purpose	Use this command to dump, clear or upload the software error log to a TFTP server.
Syntax	debug error_log [dump clear upload_toTFTP <ipaddr> <path_filename 64>]
Description	Dump, clear or upload the debug log to a TFTP server. The "error log" here refers to the software error log stored in NVRAM.
Parameters	<p><i>dump</i> - Display the debug message of the debug log.</p> <p><i>clear</i> - Clear the debug log.</p> <p><i>upload_toTFTP</i> - Upload the debug log to a TFTP server specified by IP address.</p> <p><i><ipaddr></i> - Specifies the IPv4 address of the TFTP server.</p> <p><i><path_filename 64></i> - The pathname specifies the DOS pathname on the TFTP server. It can be a relative pathname or an absolute pathname.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To dump the error log:

```
DGS-3627:admin# debug error_log dump
Command: debug error_log dump

*****
# debug log: 1
# level: fatal
# clock: 10000ms
# time : 2010/03/11 13:00:00

===== SOFTWARE FATAL ERROR =====
Invalid mutex handle : 806D6480

Current TASK : bcmARL.0

----- TASK STACKTRACE -----
->802ACE98
->8018C814
->8028FF44
->8028352C
->801D703C
->8013B8A4
->802AE754
->802A5E0C
->802A5D6C

-----
TASK  NAME  StackTop  CurStkSP  StackSize  SchCnt  PRIO(I)  STATUS
8069E7D0  FWD-ETH  823E9798  823E95C4  1K/ 32K   2    160/160  Q:IP_PKT
806A3E70  SysLogTask  80BD040C  80BD0298  1K/ 16K   3    180/180
          E:SysLogEvent
806A4340  PktStorm  80BF3188  80BF2DAC  2K/ 16K   807E4  190/190
          Q:ST_Storm
```

To clear the error log:

```
DGS-3627:admin# debug error_log clear
Command: debug error_log clear

Success.

DGS-3627:admin#
```

To upload the error log to TFTP server:

```
DGS-3627:admin# debug error_log upload_toTFTP 10.0.0.90 debug-log.txt
Command: debug error_log upload_toTFTP 10.0.0.90 debug-log.txt

Connecting to server..... Done.
Upload error log      ..... Done.

DGS-3627:admin#
```

debug buffer

Purpose	Use this command to show the debug buffer's state, or dump, clear, or upload the debug buffer to a TFTP server.
Syntax	debug buffer [utilization dump clear upload_toTFTP <ipaddr> <path_filename 64>]
Description	Show the debug buffer's state or dump, clear or upload the debug buffer to TFTP server. The "buffer" here refers to the module debug message stored in RAM.
Parameters	<p><i>utilization</i> - Display the debug buffer's state.</p> <p><i>dump</i> - Display the debug message in the debug buffer.</p> <p><i>clear</i> - Clear the debug buffer.</p> <p><i>upload_toTFTP</i> - Upload the debug buffer to a TFTP server specified by IP address.</p> <p><i><ipaddr></i> - Specifies the IPv4 address of the TFTP server.</p> <p><i><path_filename 64></i> - The pathname specifies the DOS pathname on the TFTP server. It can be a relative pathname or an absolute pathname.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show the debug buffer's state:

```
DGS-3627:admin# debug buffer utilization
Command: debug buffer utilization

Allocate from      :      System memory
Total size       :      2 MB
Utilization rate  :      30%

DGS-3627:admin#
```

To clear the debug buffer:

```
DGS-3627:admin# debug buffer clear
Command: debug buffer clear

Success.

DGS-3627:admin#
```

To upload the messages stored in debug buffer to TFTP server:

```
DGS-3627:admin# debug buffer upload_toTFTP 10.0.0.90 debugcontent.txt
Command: debug buffer upload_toTFTP 10.0.0.90 debugcontent.txt

Connecting to server..... Done.
Upload debug file      ..... Done.

DGS-3627:admin#
```

debug output

Purpose	Use the command to set a specified module's debug message output to debug buffer or local console. If the user uses the command in a Telnet session, the error message also is output to the local console.
Syntax	debug output [module <module_list> all] [buffer console]

debug output

Description	Set specified module's debug message output to debug buffer or local console.
Parameters	<p><i><module_list></i> - The module list.</p> <p><i>all</i> - Control output method of all modules.</p> <p><i>buffer</i> - Direct the debug message of the module output to debug buffer(default).</p> <p><i>console</i> - Direct the debug message of the module output to local console.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set all module debug message outputs to local console:

```
DGS-3627:admin# debug output all console
Command: debug output all console

Success.

DGS-3627:admin#
```

debug config ipv6route_preference

Purpose	Use the command to debug the IPv6 route preference.
Syntax	debug config ipv6route_preference [local static ripng ospf6] <value 1-999>
Description	Use the command to debug the IPv6 route preference.
Parameters	<p><i>local</i> - Debug configure local preference.</p> <p><i>static</i> - Debug configure staticl preference.</p> <p><i>ripng</i> - Debug configure ripng preference.</p> <p><i>ospf6</i> - Debug configure ospf6 preference.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set the local preference to 1:

```
DGS-3627:admin# debug config ipv6route_preference local 1
Command: debug config ipv6route_preference local 1

Success.

DGS-3627:admin#
```

debug config error_reboot

Purpose	This command is used to set if the switch needs to be rebooted when a fatal error occurs. When the error occurs, the watchdog timer will be disabled by the system first, and then all debug information will be saved in NVRAM. If the error_reboot is enabled, the watchdog shall be enabled after all information is stored into NVRAM.
Syntax	debug config error_reboot [enable disable]
Description	Set if the switch needs to be rebooted when a fatal error occurs.
Parameters	<i>enable</i> - Need reboot switch when fatal error happens.(if the project do not define the default setting, enable for default)

debug config error_reboot

disable - Do not need reboot switch when fatal error happens, system will hang-up for debug and enter the debug shell mode for debug..

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To set the switch to not need a reboot when a fatal error occurs:

```
DGS-3627:admin# debug config error_reboot disable
Command: debug config error_reboot disable
```

Success.

```
DGS-3627:admin#
```

debug show status

Purpose Use the command to show the specified module's debug status.

Syntax **debug show status { module <module_list> }**

Description Show the debug handler state and the specified module's debug status.
If the input module list is empty, the states of all registered modules which support debug module will be shown.

Parameters <module_list> - The module list.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To show the specified module's debug state:

```
DGS-3627:admin# debug show status module MSTP
Command: debug show status module MSTP
```

Debug Global State: Enabled

MSTP : Enabled

```
DGS-3627:admin#
```

To show the debug state:

```
DGS-3627:admin# debug show status
Command: debug show status
```

Debug Global State: Enabled

MSTP : Disabled

DHCPV6_CLIENT : Disabled

DHCPV6_RELAY : Disabled

DHCPV6_SERVER : Disabled

VRRP : Disabled

RIPNG : Disabled

```
DGS-3627:admin#
```

debug config state

Purpose	Use the command to set the state of the debug.
Syntax	debug config state [enable disable]
Description	Use the command to set the state of the debug.
Parameters	<i>enable</i> - Enable the debug state. <i>disable</i> - Disable the debug state.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set the debug state to disabled:

```
DGS-3627:admin# debug config state disable
Command: debug config state disable

Success.

DGS-3627:admin#
```

debug show error_reboot state

Purpose	Use the command to show the error reboot status.
Syntax	debug show error_reboot state
Description	Show the error reboot status.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show the error reboot status.

```
DGS-3627:admin# debug show error_reboot state
Command: debug show error_reboot state

Error Reboot: Enabled

DGS-3627:admin#
```


DHCP LOCAL RELAY COMMANDS

The DHCP Local Relay commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config dhcp_local_relay vlan	<vlan_name 32> state [enable disable]
enable dhcp_local_relay	
disable dhcp_local_relay	
show dhcp_local_relay	

Each command is listed, in detail, in the following sections.

config dhcp_local_relay

Purpose	Used to enable or disable DHCP local relay function to vlan.
Syntax	config dhcp_local_relay vlan <vlan_name 32> state [enable disable]
Description	The config dhcp_local_relay vlan command is used to enable /disable DHCP local relay function for specified vlan. When DHCP local relay is enabled for the VLAN, the DHCP packet will be relayed in broadcast way without change of the source MAC address and gateway address. DHCP option 82 will be automatically added.
Parameters	<i>vlan_name</i> - The name of the VLAN to be enabled DHCP local relay. <i>state</i> - Enable or disable DHCP local relay for specified vlan.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable DHCP local relay for default vlan:

```
DGS-3627:admin# config dhcp_local_relay vlan default state enable
Command: config dhcp_local_relay vlan default state enable

Success.

DGS-3627:admin#
```

enable dhcp_local_relay

Purpose	Used to enable the DHCP local relay function on the switch.
Syntax	enable dhcp_local_relay
Description	The enable dhcp_local_relay command globally enables the DHCP local relay function on the switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the DHCP local relay function:

```
DGS-3627:admin# enable dhcp_local_relay
Command: enable dhcp_local_relay

Success.

DGS-3627:admin#
```

disable dhcp_local_relay

Purpose	Used to disable the DHCP local relay function on the switch.
Syntax	disable dhcp_local_relay
Description	The disable dhcp_local_relay command globally disables the DHCP local relay function on the switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the DHCP local relay function:

```
DGS-3627:admin# disable dhcp_local_relay
Command: disable dhcp_local_relay

Success.

DGS-3627:admin#
```

show dhcp_local_relay

Purpose	Used to display the current DHCP local relay configuration.
Syntax	show dhcp_local_relay
Description	The show dhcp_local_relay command displays the current DHCP local relay configuration.
Parameters	None.
Restrictions	None.

Example usage:

To display local dhcp relay status:

```
DGS-3627:admin# show dhcp_local_relay
Command: show dhcp_local_relay

DHCP/BOOTP Local Relay Status      : Disabled
DHCP/BOOTP Local Relay VID List    : 1,3-4

DGS-3627:admin#
```

DHCP RELAY COMMANDS

The DHCP Relay commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config dhcp_relay	{hops <value 1-16> time <sec 0-65535>}
config dhcp_relay add	ipif <ipif_name 12> <ipaddr>
config dhcp_relay delete	ipif <ipif_name 12> <ipaddr>
config dhcp_relay option_82	{state [enable disable] check [enable disable] policy [replace drop keep]}
enable dhcp_relay	
disable dhcp_relay	
show dhcp_relay	{ipif <ipif_name 12>}
config dhcp_relay option_60 state	[enable disable]
config dhcp_relay option_60 add	string <mutiword 255> relay <ipaddr> [exact-match partial-match]
config dhcp_relay option_60 default	[relay <ipaddr> mode [relay drop]]
config dhcp_relay option_60 delete	[string <mutiword 255> {relay <ipaddr>}] ipaddress <ipaddr> all default {<ipaddr>}
show dhcp_relay option_60	{[string <mutiword 255> ipaddress < ipaddr> default]}
config dhcp_relay option_61 state	[enable disable]
config dhcp_relay option_61 add	[mac_address <macaddr> string <mutiword 255>] [relay <ipaddr> drop]
config dhcp_relay option_61 default	[relay <ipaddr> drop]
config dhcp_relay option_61 delete	[mac_address <macaddr> string <mutiword 255> all]
show dhcp_relay option_61	

Each command is listed, in detail, in the following sections.

config dhcp_relay

Purpose	Used to configure the DHCP relay feature of the switch.
Syntax	config dhcp_relay { hops <value 1-16> time <sec 0-65535>}
Description	The config dhcp_relay command configures the DHCP relay feature of the switch.
Parameters	<p><i>hops</i> - Specifies the maximum number of relay hops that the DHCP/BOOTP packets can cross. The range is 1 to 16. The default value is 4. The DHCP packet will be dropped when the relay hop count in the received packet is equal to or greater than this setting.</p> <p><i>time</i> - The secs field in the DHCP packet must be equal to or greater than this setting to be relayed by the router. The default value is 0.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure DHCP relay status:

```
DGS-3627:admin# config dhcp_relay hops 4 time 2
Command: config dhcp_relay hops 4 time 2

Success.

DGS-3627:admin#
```

config dhcp_relay add

Purpose	Used to add an IP destination address to the switch's DHCP relay table. Used to configure a DHCP server for relay of packets.
Syntax	config dhcp_relay add ipif <ipif_name 12> <ipaddr>
Description	The config dhcp_relay add command adds an IP address as a destination to forward (relay) DHCP/BOOTP packets. This server IP can either have the same network address as the network address of this ipif or not. If the network address is different, the system will automatically route the relayed packet.
Parameters	<i>ipif</i> - The name of the IP interface which contains the IP address below. < <i>ipaddr</i> > - The DHCP/BOOTP server IP address.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To add a DHCP/BOOTP server to the relay table:

```
DGS-3627:admin# config dhcp_relay add ipif System 10.43.21.12
Command: config dhcp_relay add ipif System 10.43.21.12

Success.

DGS-3627:admin#
```

config dhcp_relay delete

Purpose	Used to delete one or all IP destination addresses from the switch's DHCP relay table.
Syntax	config dhcp_relay delete ipif <ipif_name 12> <ipaddr>
Description	The config dhcp_relay delete command is used to delete one or all of the IP destination addresses in the switch's relay table.
Parameters	<i>ipif</i> - The name of the IP interface which contains the IP address below. < <i>ipaddr</i> > - The DHCP/BOOTP server IP address.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete a DHCP/BOOTP server to the relay table:

```
DGS-3627:admin# config dhcp_relay delete ipif System 10.43.21.12
Command: config dhcp_relay delete ipif System 10.43.21.12

Success.

DGS-3627:admin#
```

config dhcp_relay option_82

Purpose	Used to configure the processing of DHCP 82 option for the DHCP relay function.
Syntax	config dhcp_relay option_82 { state [enable disable] check [enable disable] policy [replace drop keep]}
Description	Configures the processing of DHCP 82 option for the DHCP relay function. When DHCP 82 option is enabled, the DHCP packet received from the client will be inserted with option 82 field before being relayed to the server. The DHCP 82 option contained 2 suboptions which is circuit ID suboption and remote ID suboption. The formats for the circuit ID suboption and the remote ID suboption are as following. For the circuit ID suboption of a standalone switch, the module field is always zero.
Parameters	<p><i>state</i> - When the state is enabled, the DHCP packet will be inserted with the option 82 field before being relayed to server. The DHCP packet will be processed based on the behaviour defined in check and policy setting. When the state is disabled, the DHCP packet will be relayed directly to server without further check and processing on the packet. The default setting is disabled.</p> <p><i>check</i> - When the state is enabled; For packet come from client side, the packet should not have the option 82's field. If the packet has this option field, it will be dropped. For packets come from the server side, the packet should have the option 82's field. If the packet does not have option field and does not have correct option fields, the packet will be dropped. The default setting is disabled.</p> <p><i>policy</i> - Specifies the way to process the packet come from the client side which has the 82 option field, and it is not dropped since the check function is disabled.</p> <p><i>replace</i> - Replace the exiting option 82 field in the packet.</p> <p><i>drop</i> - Discard if the packet has the option 82 field.</p> <p><i>keep</i> - Retain the existing option 82 field in the packet. The default setting is replace.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure dhcp_relay option 82:

```
DGS-3627:admin# config dhcp_relay option_82 state enable
Command: config dhcp_relay option_82 state enable

Success.

DGS-3627:admin# config dhcp_relay option_82 check disable
Command: config dhcp_relay option_82 check disable

Success.

DGS-3627:admin# config dhcp_relay option_82 policy replace
Command: config dhcp_relay option_82 policy replace

Success.

DGS-3627:admin#
```

enable dhcp_relay

Purpose	Used to enable the DHCP relay function on the switch.
Syntax	enable dhcp_relay
Description	The enable dhcp_relay command enables the DHCP relay function on the switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the DHCP relay function:

```
DGS-3627:admin# enable dhcp_relay
Command: enable dhcp_relay

Success.

DGS-3627:admin#
```

disable dhcp_relay

Purpose	Used to disable DHCP relay function on the switch.
Syntax	disable dhcp_relay
Description	The disable dhcp_relay command disables the DHCP relay function on the switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the DHCP relay function:

```
DGS-3627:admin# disable dhcp_relay
Command: disable dhcp_relay

Success.

DGS-3627:admin#
```

show dhcp_relay

Purpose	Used to display the current DHCP relay configuration.
Syntax	show dhcp_relay {ipif <ipif_name 12>}
Description	The show dhcp_relay command displays the current DHCP relay configuration.
Parameters	<i>ipif</i> - IP interface name. If no parameter specified, the system will display all dhcp relay configuration.
Restrictions	None.

Example usage:

To display dhcp relay status:

```
DGS-3627:admin# show dhcp_relay ipif System
Command: show dhcp_relay ipif System

DHCP/BOOTP Relay Status      : Disabled
DHCP/BOOTP Hops Count Limit  : 4
DHCP/BOOTP Relay Time Threshold : 0 second(s)
DHCP Vendor Class Identifier Option 60 State: Disabled
DHCP Client Identifier Option 61 State: Disabled
DHCP Relay Agent Information Option 82 State : Disabled
DHCP Relay Agent Information Option 82 Check : Disabled
DHCP Relay Agent Information Option 82 Policy : Replace
```

Interface	Server 1	Server 2	Server 3	Server 4
System	10.48.74.122	10.23.12.34	10.12.34.12	10.48.75.121

```
DGS-3627:admin#
```

config dhcp_relay option_60 state

Purpose	Used to config dhcp_relay option_60 state.
Syntax	config dhcp_relay option_60 state [enable disable]
Description	<p>This decides whether dhcp_relay will process the DHCP option 60 or not.</p> <p>When option_60 is enabled, if the packet does not have option 60, then the relay servers cannot be determined based on option 60. The relay servers will be determined based on either option 61 or per IPIF configured servers.</p> <p>If the relay servers are determined based on option 60 or option 61, then per IPIF configured servers will be ignored.</p> <p>If the relay servers are not determined either by option 60 or option 61, then per IPIF configured servers will be used to determine the relay servers.</p>
Parameters	<p><i>state</i> - See below:</p> <p><i>enable</i> - Enables the function dhcp_relay use option_60 rules to relay dhcp packet.</p> <p><i>disable</i> - Disables the function dhcp_relay use option_60 rules to relay dhcp packet.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the state of dhcp_relay option 60:

```
DGS-3627:admin# config dhcp_relay option_60 state enable
Command: config dhcp_relay option_60 state enable
```

Success

```
DGS-3627:admin#
```

config dhcp_relay option_60 add

Purpose	Used to add a entry for DHCP Relay option 60.
Syntax	config dhcp_relay option_60 add string <mutiword 255> relay <ipaddr> [exact-match partial-match]
Description	This command configures the option 60 relay rules. Note that different string can be specified with the same relay server, and the same string can be specified with multiple relay servers.

config dhcp_relay option_60 add

	The system will relay the packet to all the matching servers.
Parameters	<p><i>string</i> - The specified string.</p> <p><i>relay</i> - Specify a relay server IP address.</p> <p><i>exact-match</i> - The option 60 string in the packet must full match with the specified string.</p> <p><i>partial-match</i> - The option 60 string in the packet only need partial match with the specified string.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To add a entry for DHCP Relay option 60:

```
DGS-3627:admin# config dhcp_relay option_60 add string "abc" relay 10.90.90.1 exact-match
Command: config dhcp_relay option_60 add string "abc" relay 10.90.90.1 exact-match

Success

DGS-3627:admin#
```

config dhcp_relay option_60 default

Purpose	This command is used to configure the DHCP Relay option 60 as the default Relay Server.
Syntax	config dhcp_relay option_60 default [relay <ipaddr>] mode [relay drop]
Description	<p>When there are no match servers found for the packet based on option 60, the relay servers will be determined by the default relay server setting.</p> <p>When there is no matching found for the packet, the relay servers will be determined based on the default relay servers.</p> <p>When drop is specified, the packet with no matching rules found will be dropped without further process.</p> <p>If the setting is no- drop, then the packet will be processed further based on option 61. The final relay servers will be the union of option 60 default relay servers and the relay servers determined by option 61.</p>
Parameters	<p><i>relay</i> - The specified IP address for dhcp_relay forward. Specify a relay server IP for the packet that has mathcing option 60 rules.</p> <p><i>drop</i> - Specify to drop the packet that has no matching option 60 rules.</p> <p><i>relay</i> - The packet will be relayed based on the relay rules.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the DHCP Relay option 60 as the default Relay Server:

```
DGS-3627:admin# config dhcp_relay option_60 default mode drop
Command: config dhcp_relay option_60 default mode drop

Success

DGS-3627:admin#
```


config dhcp_relay option_60 delete

Purpose	This command is used to delete the DHCP Relay option 60 entry.
Syntax	config dhcp_relay option_60 delete [string <mutiword 255> {relay <ipaddr>} ipaddress <ipaddr> all default {< ipaddr>}]
Description	This can delete the entry by user specified. When all is specified, all rules excluding the default rules are deleted.
Parameters	<i>string</i> - Delete all the entry whose string is equal to the string of specified if ipaddress is not specified <i>relay <ipaddr></i> - Delete one entry, whose string and IP address are equal to the string and IP address specified by the user. <i>all</i> - Delete all the entry. Default relay servers are excluded. <i>ipaddress</i> - Delete all the entry whose ipaddress is equal to the specified ipaddress. <i>default</i> - Delete the default relay ipaddress that is specified by the user.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the DHCP Relay option 60 entry:

```
DGS-3627:admin# config dhcp_relay option_60 delete string "abc" relay 10.90.90.1
Command: config dhcp_relay option_60 delete string "abc" relay 10.90.90.1
```

Success

```
DGS-3627:admin#
```

show dhcp_relay option_60

Purpose	This command is used to show the DHCP Relay option 60 entry.
Syntax	show dhcp_relay option_60 {[string <mutiword 255> ipaddress < ipaddr> default]}
Description	This show dhcp_relay option_60 entry by the user specified.
Parameters	<i>string</i> - Show the entry which's string equal the string of specified. <i>ipaddress</i> - Show the entry whose ipaddress equal the specified ipaddress. <i>default</i> - Show the default behaviour of dhcp_relay option60.
Restrictions	None.

Example usage:

To show the DHCP Relay option 60 entry:

```
DGS-3627:admin# show dhcp_relay option_60
```

```
Command: show dhcp_relay option_60
```

```
Default processing Mode: drop
```

```
Default Servers:
```

```
10.90.90.100
```

```
10.90.90.101
```

```
10.90.90.102
```

```
Matching Rules:
```

String	Match Type	IP Address
-----	-----	-----
abc	exact match	10.90.90.1
abcde	partial match	10.90.90.2
abcdefg	exact match	10.90.90.3

```
Total Entries : 3
```

```
DGS-3627:admin#
```

config dhcp_relay option_61 state

Purpose	This command is used to configure the DHCP Relay option 61 state.
Syntax	config dhcp_relay option_61 state [enable disable]
Description	<p>This decides whether dhcp_relay will process the DHCP option 61 or not.</p> <p>When option_61 is enabled, if the packet does not have option 61, then the relay servers cannot be determined based on option 61.</p> <p>If the relay servers are determined based on option 60 or option 61, then per IPIF configured servers will be ignored.</p> <p>If the relay servers are not determined either by option 60 or option 61, then per IPIF configured servers will be used to determine the relay servers.</p>
Parameters	<p><i>state</i> - See below:</p> <p><i>enable</i> - Enable the function dhcp_relay use option_61 ruler to relay dhcp packet.</p> <p><i>disable</i> - Disable the function dhcp_relay use option_61 ruler to relay dhcp packet.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the state of dhcp_relay option 61:

```
DGS-3627:admin# config dhcp_relay option_61 state enable
```

```
Command: config dhcp_relay option_61 state enable
```

```
Success
```

```
DGS-3627:admin#
```

config dhcp_relay option_61 add

Purpose	This command is used to add a rule for DHCP Relay option 61.
Syntax	config dhcp_relay option_61 add [mac_address <macaddr> string <mutiword 255>] [relay <ipaddr> drop]

config dhcp_relay option_61 add

Description	This command adds a rule to determine the relay server based on option 61. The match rule can base on either MAC address or a user-specified string. Only one relay server can be specified for a MAC-address or a string, If relay servers are determined based on option 60, and one relay server is determined based on option 61, the final relay servers will be the union of these two sets of the servers.
Parameters	<i>mac_address</i> - The client's client-ID which is the hardware address of client. <i>string</i> - The client's client-ID, which is specified by administrator. <i>relay</i> - Specify to relay the packet to a IP address. <i>drop</i> - Specify to drop the packet.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To add a rule for DHCP Relay option 61:

```
DGS-3627:admin# config dhcp_relay option_61 add mac_address 00-11-22-33-44-55 drop
Command: config dhcp_relay option_61 add mac_address 00-11-22-33-44-55 drop

Success

DGS-3627:admin#
```

config dhcp_relay option_61 default

Purpose	This command is used to configure the default ruler for option 61.
Syntax	config dhcp_relay option_61 default [relay <ipaddr> drop]
Description	Up to default server IP address can be specified. This setting will be used to determine the rule to process those packets that have no option 61 matching rules. The default default-rule is drop.
Parameters	<i>relay</i> - Specify to relay the packet that has no option matching 61 matching rules to an IP address. <i>drop</i> - Specify to drop the packet that have no option 61 matching rules.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the default ruler for option 61:

```
DGS-3627:admin# config dhcp_relay option_61 default drop
Command: config dhcp_relay option_61 default drop

Success

DGS-3627:admin#
```

config dhcp_relay option_61 delete

Purpose	This command is used to delete an option 61 rule.
Syntax	config dhcp_relay option_61 delete [mac_address <macaddr> string <mutiword 255> all]

config dhcp_relay option_61 delete

Description	This command is used to delete an option 61 rule.
Parameters	<i>mac_address</i> - The entry with the specified MAC address will be deleted. <i>string</i> - The entry with the specified string will be deleted. <i>all</i> - All rules excluding the default rule will be deleted.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an option 61 rule:

```
DGS-3627:admin# config dhcp_relay option_61 delete mac_address 00-11-22-33-44-55
Command: config dhcp_relay option_61 delete mac_address 00-11-22-33-44-55
```

Success

```
DGS-3627:admin#
```

show dhcp_relay option_61

Purpose	This command is used to show all rulers for option 61.
Syntax	show dhcp_relay option_61
Description	This command is used to show all rulers for option 61.
Parameters	None.
Restrictions	None,

Example usage:

To show all rulers for option 61:

```
DGS-3627:admin# show dhcp_relay option_61
Command: show dhcp_relay option_61

Default Relay Rule:drop

Matching Rules:

Client-ID                               Type                               Relay rule
-----                               -
00-01-02-03-04-05                     MAC Address                       10.1.1.1

Total Entries : 1

DGS-3627:admin#
```

DHCP SERVER SCREENING COMMANDS

The DHCP Server Screening Commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

The DHCP Server Screening commands allow you not only to restrict all DHCP Server packets but also to receive any specified DHCP server packets by any specified DHCP client, it is useful when one or more than one DHCP servers are present on the network and both provide DHCP services to different distinct groups of clients. Enabling the DHCP filter for the first time will create both an access profile and access rule per port, following this other access rules can be created. These rules are used to block all DHCP server packets. Similarly, the addition of a permit DHCP entry will create one access profile and one access rule the first time the DHCP client MAC address is the client MAC address, and the Source IP address is the same as the DHCP server's IP address (UDP port number 67). These rules are used to permit the DHCP server packets with specific fileds, which the user configures.

When the DHCP Server filter function is enabled, all DHCP Server packets will be filtered from a specific port. Also, you are allowed to create entries for specific port-based Server IP address and Client MAC address binding entries. Be aware that the DHCP Server filter function must be enabled first. Once all settings are complete, all DHCP Server packets will be filtered from a specific port except those that meet the Server IP Address and Client MAC Address binding.

Command	Parameters
config filter dhcp_server	[add permit server_ip <ipaddr> {client_mac <macaddr>} ports [<portlist> all] delete permit server_ip <ipaddr> {client_mac <macaddr>} ports [<portlist> all] ports [<portlist> all] state [enable disable]]
show filter dhcp_server	
config filter dhcp_server trap_log	[enable disable]
config filter dhcp_server illegal_server_log_suppress_duration	[1min 5min 30min]

Each command is listed in detail in the following sections.

config filter dhcp_server

Purpose	DHCP server packets except those that have been IP/client MAC bound will be filtered. This command is used to configure the state of the function for filtering of DHCP server packet and to add/delete the DHCP server/client binding entry.
Syntax	config filter dhcp_server [add permit server_ip <ipaddr> {client_mac <macaddr>} ports [<portlist> all] delete permit server_ip <ipaddr> {client_mac <macaddr>} ports [<portlist> all] ports [<portlist> all] state [enable disable]]
Description	This command has two purposes: to filter all DHCP server packets on the specified port(s) and to allow some DHCP server packets to be forwarded if they are on the pre-defined server IP address/MAC address binding list. Thus the DHCP server can be restricted to service a specified DHCP client. This is useful when there are two or more DHCP servers present on a network.
Parameters	<i>ipaddr</i> – The IP address of the DHCP server to be filtered. <i>macaddr</i> – The MAC address of the DHCP client.

config filter dhcp_server

Restrictions	<p><i>state</i> – To Enable/disable the filter DHCP server state.</p> <p><i>portlist</i> – The port list of filter DHCP server.</p> <p>Only Administrator and Operator level users can issue this command.</p> <p>Enabling the DHCP filter will create one access profile and create one access rule per port (UDP port 67).</p> <p>Addition of a DHCP filter permit entry will create one access profile and create one access rule (DA = client MAC address, SA = source IP address and UDP port 67).</p>
--------------	---

Example usage:

To add an entry from the DHCP server/client filter list in the switch's database:

```
DGS-3627:admin# config filter dhcp_server add permit server_ip 10.1.1.1 client_mac 00-00-00-00-00-01 ports 1:1-1:3
Command: config filter dhcp_server add permit server_ip 10.1.1.1 client_mac 00-00-00-00-00-01 ports 1:1-1:3

Success.

DGS-3627:admin#
```

To configure the filter DHCP server state:

```
DGS-3627:admin# config filter dhcp_server ports 1:1-1:3 state enable
Command: config filter dhcp_server ports 1:1-1:3 state enable

Success.

DGS-3627:admin#
```

show filter dhcp_server

Purpose	Used to display current DHCP server/client filter list created on the switch.
Syntax	Show filter dhcp_server
Description	This command is used to display DHCP server/client filter list created on the switch. The log ceasing unauthorized duration and the log/trap state.
Parameters	None.
Restrictions	None.

Example usage:

To display the DHCP server/client filter list created on the switch the log ceasing unauthorized duration and the log/trap state:

```
DGS-3627:admin# show filter dhcp_server
Command: show filter dhcp_server

Filter DHCP Server Trap_Log State: Disabled

Enabled Ports: 1:1-1:3

Illegal Server Log Suppress Duration:5 minutes
Filter DHCP Server/Client Table
Server IP Address Client MAC Address Port
-----
10.1.1.1          00-00-00-00-00-01 1:1-1:3

Total Entries: 1

DGS-3627:admin#
```

config filter dhcp_server trap_log

Purpose	Used to configure the trap and log related to the DHCP server filter.
Syntax	config filter dhcp_server trap_log [enable disable]
Description	Used to enable/disable trap/log related to DHCP server filter.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable log and trap for the DHCP server filter event:

```
DGS-3627:admin# config filter dhcp_server trap_log disable
Command: config filter dhcp_server trap_log disable

Success.

DGS-3627:admin#
```

config filter dhcp_server illegal_server_log_suppress_duration

Purpose	This function is used to configure the illegal server log suppress duration.
Syntax	config filter dhcp_server illegal_server_log_suppress_duration [1min 5min 30min]
Description	The DHCP server filtering function filters any illegal DHCP server packets. The DHCP server who sends the illegal packets will be logged. This command is used to suppress the logging of DHCP servers who continue to send illegal DHCP packets. The same illegal DHCP server IP address that is detected will be logged only once regardless of how many illegal packets are sent.
Parameters	<i>illegal_server_log_suppress_duration</i> – The log can be suppressed by 1 minute, 5 minutes or 30 minutes. The default value is 5 minutes.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the illegal_server_log_suppress_duration for 30 minutes:

```
DGS-3627:admin# config filter dhcp_server illegal_server_log_suppress_duration 30min
Command: config filter dhcp_server illegal_server_log_suppress_duration 30min

Success.

DGS-3627:admin#
```


DHCP SERVER COMMANDS

For this release, the Switch now has the capability to act as a DHCP server to devices within its locally attached network. DHCP, or Dynamic Host Configuration Protocol, allows the switch to delegate IP addresses, subnet masks, default gateways and other IP parameters to devices that request this information. This occurs when a DHCP enabled device is booted on or attached to the locally attached network. This device is known as the DHCP client and when enabled, it will emit query messages on the network before any IP parameters are set. When the DHCP server receives this request, it returns a response to the client, containing the previously mentioned IP information that the DHCP client then utilizes and sets on its local configurations.

The user can configure many DHCP related parameters that it will utilize on its locally attached network, to control and limit the IP settings of clients desiring an automatic IP configuration, such as the lease time of the allotted IP address, the range of IP addresses that will be allowed in its DHCP pool, the ability to exclude various IP addresses within the pool as not to make identical entries on its network, or to assign the IP address of an important device (such as a DNS server or the IP address of the default route) to another device on the network.

Users also have the ability to bind IP addresses within the DHCP pool to specific MAC addresses in order to keep consistent the IP addresses of devices that may be important to the upkeep of the network that require a static IP address.

The DHCP Server commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create dhcp pool	<pool_name 12>
delete dhcp pool	[<pool_name 12> all]
create dhcp pool manual_binding	<pool_name 12> <ipaddr> hardware_address <macaddr> {type [Ethernet IEEE802]}
delete dhcp pool manual_binding	<pool_name 12> [<ipaddr> all]
show dhcp pool manual_binding	{<pool_name 12>}
show dhcp_binding	{<pool_name 12>}
clear dhcp_binding	{<pool_name 12>}
config dhcp ping_packets	<number 2-10>
config dhcp ping_timeout	<millisecond 500-2000>
config dhcp pool boot_file	<pool_name 12> <file_name 64>
config dhcp pool default_router	<pool_name 12> <ipaddr> {<ipaddr>} {<ipaddr>}
config dhcp pool dns_server_address	<pool_name 12> <ipaddr> {<ipaddr>} {<ipaddr>}
config dhcp pool domain_name	<pool_name 12> <domain_name 64>
config dhcp pool lease	<pool_name 12> [<day 0-365> <hour 0-23> <minute 0-59> infinite]
config dhcp pool netbios_name_server	<pool_name 12> <ipaddr> {<ipaddr>} {<ipaddr>}
config dhcp pool netbios_node_type	<pool_name 12> [broadcast peer_to_peer mixed hybrid]
config dhcp pool network_addr	<pool_name 12> <network_address>
config dhcp pool next_server	<pool_name 12> <ipaddr>
enable dhcp_server	
disable dhcp_server	
show dhcp_server	
create dhcp excluded_address begin_address	<ipaddr> end_address <ipaddr>
delete dhcp excluded_address	[begin_address <ipaddr> end_address <ipaddr> all]
show dhcp excluded_address	
show dhcp pool	{ <pool_name 12> }

Each command is listed in detail in the following sections.

create dhcp pool

Purpose	Used to create a DHCP pool.
Syntax	create dhcp pool <pool_name 12>
Description	This command will create a DHCP pool for the DHCP server. Once created, this pool may be modified for accepting DHCP clients into this pool.
Parameters	<pool_name 12> – Enter an name of up to 12 alphanumeric characters to identify the pool to be created with this command.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create the DHCP pool Floor2:

```
DGS-3627:admin# create dhcp pool Floor2
Command:create dhcp pool Floor2
```

Success.

```
DGS-3627:admin#
```

delete dhcp pool

Purpose	Used to delete a DHCP pool.
Syntax	delete dhcp pool [<pool_name 12> all]
Description	This command will delete a DHCP pool that was created with the create dhcp pool command.
Parameters	<pool_name 12> – Enter an name of up to 12 alphanumeric characters to identify the pool to be deleted with this command. all – Enter this command to delete all created DHCP pool.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the DHCP pool Floor2:

```
DGS-3627:admin# delete dhcp pool Floor2
Command:delete dhcp pool Floor2
```

Success.

```
DGS-3627:admin#
```

create dhcp pool manual_binding

Purpose	Used to create a DHCP pool manual binding entry.
Syntax	create dhcp pool manual_binding <pool_name 12> <ipaddr> hardware_address <macaddr> {type [Ethernet IEEE802]}
Description	This command will create a DHCP manual pool binding entry for a previously created pool. When a MAC address is entered in this command, it will be bound to a IP address from the given pool either by the user, or automatically by the Switch.
Parameters	<p><i><pool_name 12></i> – Enter the name of the previously created pool that will contain the manual binding entry.</p> <p><i><ipaddr></i> – Enter the IP address to be statically bound to a device within the local network that will be specified by entering the Hardware Address in the following field.</p> <p><i>hardware_address <macaddr></i> – Enter the MAC address of the device to be statically bound to the IP address entered in the previous field.</p> <p><i>type [Ethernet IEEE802]</i> – This field is used to specify the type of connection for which this manually bound entry will be set. <i>Ethernet</i> will denote that the manually bound device is connected directly to the Switch, while the <i>IEEE802</i> denotes that the manually bound device is outside the local network of the Switch.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a manual binding DHCP entry:

```
DGS-3627:admin# create dhcp pool manual_binding engineering 10.10.10.1 hardware_address
02.02.02.02.02 type Ethernet
Command: create dhcp pool manual_binding engineering 10.10.10.1 hardware_address
02.02.02.02.02 type Ethernet

Success.

DGS-3627:admin#
```

delete dhcp pool manual_binding

Purpose	Used to delete a previously created DHCP manual binding entry.
Syntax	delete dhcp pool manual_binding <pool_name 12> [<ipaddr> all]
Description	This command will delete a DHCP manual binding entry created with the create dhcp pool manual_binding command.
Parameters	<p><i><pool_name 12></i> – Enter the previously created pool name from which to delete a manual binding DHCP entry.</p> <p><i><ipaddr></i> – Enter the IP address of the manual binding entry to be deleted.</p> <p><i>all</i> – Enter this command to delete all manual binding entries for the given pool.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete a manual binding DHCP entry:

```
DGS-3627:admin# delete dhcp pool manual_binding Floor2 10.10.10.1
Command: delete dhcp pool manual_binding Floor2 10.10.10.1

Success.

DGS-3627:admin#
```

show dhcp pool manual_binding

Purpose	Used to display the manual binding settings for a DHCP pool.
Syntax	show dhcp pool manual_binding {<pool_name 12>}
Description	This command will display the manual binding entries for the selected DHCP pool.
Parameters	<pool_name 12> – Enter the name of the DHCP pool for which to view manual binding entries. Entering this command without the pool name will display all manual binding entries of the DHCP server.
Restrictions	None.

Example usage:

To display the manual binding entries of the DHCP pool accounting:

```
DGS-3627:admin# show dhcp pool manual_binding accounting
Command: show dhcp pool manual_binding accounting

Pool Name      IP Address      Identifier(Hardware_Address)  Type
-----
accounting     192.168.0.1     01-22-b7-35-ce-99            Ethernet
accounting     192.168.0.2     0a-52-f7-34-ce-88            Ethernet

Total Entries : 2

DGS-3627:admin#
```

show dhcp_binding

Purpose	Used to show the DHCP binding information.
Syntax	show dhcp_binding {<pool_name 12>}
Description	This command is used to display the DHCP binding information by created pool. Entering the command without the pool name will display all information regarding DHCP binding on the switch.
Parameters	<pool_name 12> – Enter the name of the DHCP pool for which to view binding information.
Restrictions	None.

Example usage:

To display the DHCP binding information on the Switch:

```
DGS-3627:admin# show dhcp_binding
```

```
Command:show dhcp_binding
```

Pool Name	IP Address	Hardware Address	Type	Status	Life Time (secs)
engineering	192.168.0.1	01-22-b7-35-ce-99	Ethernet	Manual	864000

```
Total Entries : 1
```

```
DGS-3627:admin#
```

clear dhcp_binding

Purpose	Used to clear the DHCP binding information.
Syntax	clear dhcp_binding {<pool_name 12>}
Description	This command is used to clear the DHCP binding settings for a particular created DHCP pool.
Parameters	<pool_name 12> – Enter the name of the DHCP pool for which to clear the binding information.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To display the DHCP binding information on the Switch:

```
DGS-3627:admin# clear dhcp_binding
```

```
Command:clear dhcp_binding
```

```
Success.
```

```
DGS-3627:admin#
```

config dhcp ping_packets

Purpose	Used to set the number of ping packets that will be sent out to find if an IP address is available.
Syntax	config dhcp ping_packets <number 2-10>
Description	This command will set the number of ping packets that will be sent out to find if an IP address is available to be allocated as a valid DHCP IP address.
Parameters	<number 2-10> – Enter a number between 2 and 10 to denote the number of ping packets that the Switch will send out on the network containing the IP address to be allotted. If the ping request is not returned, the IP address is considered unique to the local network and then allotted to the requesting client. The default setting is 2 packets.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the number of ping packets to be used for DHCP:

```
DGS-3627:admin# config dhcp ping_packets 2
Command: config dhcp ping_packets 2

Success.

DGS-3627:admin#
```

config dhcp ping_timeout

Purpose	Used to set the time the Switch will wait before timing out a ping packet.
Syntax	config dhcp ping_timeout <millisecond 500-2000>
Description	This command is used set the time the Switch will wait before timing out a ping packet. If no answer is received, the IP address is considered unused and may be allocated to a requesting client.
Parameters	<millisecond 500-2000> – The user may set a time between 500 and 2000 milliseconds that the Switch will wait before timing out a ping packet. The default setting is 500 milliseconds.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the Ping timeout:

```
DGS-3627:admin# config dhcp ping_timeout 500
Command: config dhcp ping_timeout 500

Success.

DGS-3627:admin#
```

config dhcp pool boot_file

Purpose	Used to specify the Boot File that will be used as the boot image of the DHCP client
Syntax	config dhcp pool boot_file <pool_name 12> <file_name 64>
Description	This command is used to specify the Boot File that will be used as the boot image of the DHCP client. This image is usually the operating system that the client uses to load its IP parameters.
Parameters	<pool_name 12> – Enter the previously created pool name from which the boot file will be set. <file_name 64> – Enter the name of the boot file that will be used for DHCP clients.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set the boot file:

```
DGS-3627:admin# config dhcp pool boot_file accounting boot.had
Command: config dhcp pool boot_file accounting boot.had

Success.

DGS-3627:admin#
```

config dhcp pool default_router

Purpose	Used to configure the default router for the DHCP client.
Syntax	config dhcp pool default_router <pool_name 12> <ipaddr> {<ipaddr>} {<ipaddr>}
Description	This command is used to configure the default router for DHCP clients requesting DHCP information for the switch. Users may add up to three IP addresses to identify the router, but must specify at least one.
Parameters	<i><pool_name 12></i> – Enter the previously created pool name for which to add a default router. <i><ipaddr></i> – Enter the IP address for the default router for this pool. Users may specify up to three default routers but users must add at least one.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the default router:

```
DGS-3627:admin# config dhcp pool default_router accounting 10.245.32.1
Command: config dhcp pool default_router accounting 10.245.32.1
```

Success.

```
DGS-3627:admin#
```

config dhcp pool dns_server_address

Purpose	Used to configure the IP addresses of DNS servers for a specific DHCP pool.
Syntax	config dhcp pool dns_server_address <pool_name 12> <ipaddr> {<ipaddr>} {<ipaddr>}
Description	This command is used to configure the DNS server IP addresses for a specific DHCP pool for the switch. The DNS Server correlates IP addresses to host names when queried. Users may add up to three DNS Server addresses.
Parameters	<i><pool_name 12></i> – Enter the previously created pool name for which to add a DNS address. <i><ipaddr></i> – Enter the IP address for the DNS server for this pool. Users may specify up to three DNS servers.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the DNS server address for a DHCP pool:

```
DGS-3627:admin# config dhcp pool dns_server_address accounting 10.245.32.1
Command: config dhcp pool dns_server_address accounting 10.245.32.1
```

Success.

```
DGS-3627:admin#
```


config dhcp pool domain_name

Purpose	Used to configure the domain name for the DHCP pool of the Switch.
Syntax	config dhcp pool domain_name <pool_name 12> <domain_name 64>
Description	This command is used to configure the domain name for the DHCP pool of the Switch. This domain name represents a general group of networks that collectively make up the domain.
Parameters	<pool_name 12> – Enter the previously created pool name for which to add a default router. <domain_name 64> – The Domain Name may be an alphanumeric string of up to 64 characters.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the domain name for a DHCP pool:

```
DGS-3627:admin# config dhcp pool domain_name accounting d_link.com
Command: config dhcp pool domain_name accounting d_link.com
```

Success.

```
DGS-3627:admin#
```

config dhcp pool lease

Purpose	Used to configure the lease time of DHCP clients within a DHCP pool.
Syntax	config dhcp pool lease <pool_name 12> [<day 0-365> <hour 0-23> <minute 0-59> infinite]
Description	Using this command, the user can specify the lease time for the DHCP client. This time represents the amount of time that the allotted address is valid on the local network.
Parameters	<pool_name 12> – Enter the previously created pool name for which to set the lease time for accepted DHCP clients. day 0-365 – Enter the amount of days for the lease. The default setting is one day. hour 0-23 – Enter the number of hours for the lease. minute 0-59 – Enter the number of minutes for the lease. infinite – Enter this parameter to set the allotted IP address to never be timed out of its lease.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the lease time for the DHCP pool:

```
DGS-3627:admin# config dhcp pool lease accounting infinite
Command: config dhcp pool lease accounting infinite
```

Success.

```
DGS-3627:admin#
```

config dhcp pool netbios_name_server

Purpose	Used to configure the IP address(es) for the Net BIOS name server,
Syntax	config dhcp pool netbios_name_server <pool_name 12> <ipaddr> {<ipaddr>}
{<ipaddr>}
Description	This command is used to enter the IP address of a Net BIOS Name Server that will be available to a Microsoft DHCP Client. This Net BIOS Name Server is actually a WINS (Windows Internet Naming Service) Server that allows Microsoft DHCP clients to correlate host names to IP addresses within a general grouping of networks. The user may establish up to three Net BIOS Name Servers.
Parameters	<pool_name 12> – Enter the previously created pool name for which to set the Net BIOS name server for DHCP clients. <ipaddr> – Enter the IP address for the Net BIOS name server for this pool. Users may specify up to three Net BIOS name servers.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the Net BIOS name server for the DHCP pool:

```
DGS-3627:admin# config dhcp pool netbios_name_server accounting 10.98.254.2
Command: config dhcp pool netbios_name_server accounting 10.98.254.2

Success.

DGS-3627:admin#
```

config dhcp pool netbios_node_type

Purpose	Used to set the Net BIOS node type for the DHCP server.
Syntax	config dhcp pool netbios_node_type <pool_name 12> [broadcast peer_to_peer mixed hybrid]
Description	This command is used to allow users to set the type of node server for the previously configured Net BIOS Name server. The user has four choices for node types which are <i>Broadcast</i> , <i>Peer to Peer</i> , <i>Mixed</i> and <i>Hybrid</i> .
Parameters	<pool_name 12> – Enter the previously created pool name for which to set the Net BIOS node type for DHCP clients. [broadcast peer_to_peer mixed hybrid] – Users may choose the node type for the Net BIOS from one of the four listed.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the Net BIOS node type for the DHCP pool:

```
DGS-3627:admin# config dhcp pool netbios_node_type accounting hybrid
Command: config dhcp pool netbios_node_type accounting hybrid

Success.

DGS-3627:admin#
```

config dhcp pool network_addr

Purpose	Used to configure the network address and corresponding subnet mask for the DHCP pool.
Syntax	config dhcp pool network_addr <pool_name 12> <network_address>
Description	This command will allow users to enter the IP address pool to be assigned to requesting DHCP Clients. This address will not be chosen but the first 3 sets of numbers in the IP address will be used for the IP address of requesting DHCP Clients. (ex. If this entry is given the IP address 10.10.10.2, then assigned addresses to DHCP Clients will resemble 10.10.10.x, where x is a number between 1 and 255 but does not include the assigned 10.10.10.2)
Parameters	<p><pool_name 12> – Enter the previously created pool name for which to set the network address.</p> <p><network_address> – IP address and netmask that is the address of this DHCP pool. The address and mask information can be specified using the traditional format (for example, 10.1.2.3/255.0.0.0 or in CIDR format, 10.1.2.3/8).</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the network address for the DHCP pool:

```
DGS-3627:admin# config dhcp pool network_addr accounting 10.1.1.1/8
Command:config dhcp pool network_addr accounting 10.1.1.1/8

Success.

DGS-3627:admin#
```

config dhcp pool next_server

Purpose	Used to configure the IP address of the server that has the boot file for the DHCP pool.
Syntax	config dhcp pool next_server <pool_name 12> <ipaddr>
Description	This command is used to configure the IP address of the server that has the boot file for the DHCP pool.
Parameters	<p><pool_name 12> – Enter the previously created pool name for which to set the next server.</p> <p><ipaddr> – Enter the IP address of the next server which has the boot file.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the IP address of the next server:

```
DGS-3627:admin# config dhcp pool next_server accounting 10.99.88.77
Command: config dhcp pool next_server accounting 10.99.88.77

Success.

DGS-3627:admin#
```

enable dhcp_server

Purpose	Used to enable the DHCP function on the switch.
Syntax	enable dhcp_server
Description	This command, along with the disable dhcp_server will enable and disable the DHCP server function without affecting configurations.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable DHCP server:

```
DGS-3627:admin# enable dhcp_server
Command: enable dhcp_server

Success.

DGS-3627:admin#
```

disable dhcp_server

Purpose	Used to disable the DHCP function on the switch.
Syntax	disable dhcp_server
Description	This command, along with the enable dhcp_server will enable and disable the DHCP server function without affecting configurations.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the DHCP server:

```
DGS-3627:admin# disable dhcp_server
Command: disable dhcp_server

Success.

DGS-3627:admin#
```

show dhcp_server

Purpose	Used to display the DHCP server settings.
Syntax	show dhcp_server
Description	This command will display the DHCP server settings for its Global state, ping packet count and ping timeout.
Parameters	None.
Restrictions	None.

Example usage:

To display the DHCP server settings:

```
DGS-3627:admin# show dhcp_server
Command:show dhcp_server

DHCP Server Global State: Disable
Ping Packet Number      : 2
Ping Timeout            : 500 ms

DGS-3627:admin#
```

create dhcp excluded_address begin_address

Purpose	Used to configure IP addresses that will be excluded from the DHCP Server pool of addresses.
Syntax	create dhcp excluded_address begin_address <ipaddr> end_address <ipaddr>
Description	This command will allow the user to set an IP address, or a range of IP addresses that are NOT to be included in the range of IP addresses that the Switch will allot to clients requesting DHCP service.
Parameters	<i>begin_address <ipaddr></i> – Enter the beginning IP address of the range of IP addresses to be excluded from the DHCP pool. <i>end_address <ipaddr></i> – Enter the ending IP address of the range of IP addresses to be excluded from the DHCP pool.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure IP an address that will be excluded from the DHCP server pool of addresses:

```
DGS-3627:admin# create dhcp excluded_address begin_address 10.10.10.1 end_address
10.10.10.10
Command: create dhcp excluded_address begin_address 10.10.10.1 end_address 10.10.10.10

Success.

DGS-3627:admin#
```

delete dhcp excluded_address

Purpose	Used to delete IP addresses that have been configured as excluded from the DHCP Server pool of addresses.
Syntax	delete dhcp excluded_address [begin_address <ipaddr> end_address <ipaddr> all]
Description	This command will allow the user to delete a previously set IP address, or a range of IP addresses that are NOT to be included in the range of IP addresses that the Switch will allot to clients requesting DHCP service.
Parameters	<p><i>begin_address <ipaddr></i> – Enter the beginning IP address of the range of IP addresses to be deleted from the excluded IP address list, from the DHCP pool.</p> <p><i>end_address <ipaddr></i> – Enter the ending IP address of the range of IP addresses to be deleted from the excluded IP address list, from the DHCP pool.</p> <p>all – Enter this command to delete all excluded IP addresses, from the DHCP pool.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete IP addresses that have been configured as excluded from the DHCP server pool of addresses:

```
DGS-3627:admin# delete dhcp excluded_address begin_address 10.10.10.1 end_address
10.10.10.10
Command: delete dhcp excluded_address begin_address 10.10.10.1 end_address 10.10.10.10

Success.

DGS-3627:admin#
```

show dhcp excluded_address

Purpose	Used to display the excluded IP addresses of the DHCP server function.
Syntax	show dhcp excluded_address
Description	This command is used to display the excluded IP addresses of the DHCP server function.
Parameters	None.
Restrictions	None.

Example usage:

To display the DHCP server settings:

```
DGS-3627:admin# show dhcp excluded_address
Command: show dhcp excluded_address

Index          Begin_Address      End_Address
-----          -
1              192.168.0.1        192.168.0.100
2              10.10.10.10        10.10.10.10

Total Entries : 2

DGS-3627:admin#
```

show dhcp pool

Purpose	Used to show the DHCP pool information.
Syntax	show dhcp pool {<pool_name 12>}
Description	This command is used to display the DHCP pool information. Entering the command without the pool name will display all DHCP pool information on the switch.
Parameters	<pool_name 12> – Enter the name of the DHCP pool for which to view DHCP pool information.
Restrictions	None.

Example usage:

To display the DHCP pool information:

```
DGS-3627:admin# show dhcp pool Floor2
Command: show dhcp pool Floor2

Pool Name           :Floor2
Network Address     :10.0.0.0/8
Domain Name         :
DNS Server Address  :0.0.0.0
NetBIOS Name Server :0.0.0.0
NetBIOS Node Type   :Broadcast
Default Router      :0.0.0.0
Pool Lease          :1 Days, 0 Hours, 0 Minutes
Boot File           :
Next Server         :0.0.0.0

Total Pool Entry: 1

DGS-3627:admin#
```

DHCPV6 CLIENT COMMANDS

The DHCPv6 Client commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config ipif	<ipif_name 12> [{ ipaddress <network_address> vlan <vlan_name 32> state [enable disable] proxy_arp [enable disable] {local [enable disable]}} (1) bootp dhcp ipv6 ipv6address <ipv6networkaddr> dhcpv6_client [enable disable]]
debug dhcpv6_client state	[enable disable]
debug dhcpv6_client output	[buffer console]
debug dhcpv6_client packet	{all receiving sending} state [enable disable]

Each command is listed, in detail, in the following sections.

config ipif

Purpose	Use this command to configure the DHCPv6 client state for the interface.
Syntax	config ipif <ipif_name 12> [{ ipaddress <network_address> vlan <vlan_name 32> state [enable disable] proxy_arp [enable disable] {local [enable disable]}} (1) bootp dhcp ipv6 ipv6address <ipv6networkaddr> dhcpv6_client [enable disable]]
Description	The command is used to configure the DHCPv6 client state for one interface.
Parameters	<p><i>ipif <ipif_name 12></i> - The name of the IP interface.</p> <p><i>ipaddress <network_address></i> - Configures a network on an IP interface. The address should specify a host address and length of network mask. Since an IP interface can have only one IPv4 address, the newly configured address will overwrite the original one.</p> <p><i>vlan <vlan_name 32></i> - Name of the VLAN where the IPIF is operated.</p> <p><i>proxy_arp</i> - Enable or disable the proxy ARP function. This is for the IPv4 function. Default: Disabled.</p> <p><i>local</i> - This setting controls whether the system provides the proxy reply for the ARP packets destined for an IP address located in the same interface as the received interface. When proxy ARP is enabled for an interface, the system will do the proxy reply for the ARP packets destined for an IP address located in a different interface. For ARP packets destined for an IP address located in the same interface, the system will check this setting to determine whether to reply. Default: Disabled.</p> <p><i>state</i> - Enable or disable the state of the IP interface.</p> <p><i>bootp</i> - Use BOOTP to obtain the IPv4 address.</p> <p><i>dhcp</i> - Use DHCP to obtain the IPv4 address.</p> <p><i>ipv6 ipv6address</i> - IPv6 network address: The address should specify a host address and length of network prefix. There can be multiple V6 addresses defined on an interface. Thus, as a new address is defined, it is added on this IP interface.</p> <p><i>dhcpv6_client</i> - See below:</p> <ul style="list-style-type: none"> <i>enable</i> - Enable the DHCPv6 client state of the interface. <i>disable</i> - Disable the DHCPv6 client state of the interface.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the DHCPv6 client state of the System interface to enabled:

```
DGS-3627:admin# config ipif System dhcpv6_client state enable
Command : config ipif System dhcpv6_client state enable

success

DGS-3627:admin#
```

To display IP interface settings:

```
DGS-3627:admin# show ipif System
Command: show ipif System

IP Interface           : System
VLAN Name              : default
Interface Admin state  : Enabled
DHCPv6 Client State    : Enabled
IPv4 Address           : 10.90.90.90/8 (Manual) Primary
Proxy ARP              : Disabled (Local : Disabled)
IPv6 Link-Local Address : FE80::219:5BFF:FEF5:26C0/128
IPv6 Global Unicast Address : 2000::2/64 (Manual)
IPv6 Global Unicast Address : 3000::3/64 (DHCPv6)
IP MTU                 : 1580

DGS-3627:admin#
```

debug dhcpv6_client state

Purpose	Enable or disable the DHCPv6 client debug function.
Syntax	debug dhcpv6_client state [enable disable]
Description	Use this command to enable or disable the DHCPv6 client debug function.
Parameters	<i>state</i> - See below: <i>enable</i> - Enable the DHCPv6 client debug function. <i>disable</i> - Disable the DHCPv6 client debug function.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enabled the DHCPv6 client debug function:

```
DGS-3627:admin# debug dhcpv6_client state enable
Command:  debug dhcpv6_client state enable

Success.

DGS-3627:admin#
```

debug dhcpv6_client output

Purpose	Used to set the debug message to output to buffer or console.
Syntax	debug dhcpv6_client output [buffer console]

debug dhcpv6_client output

Description	Set message output to buffer or console.
Parameters	<i>buffer</i> - Let the debug message output to buffer. <i>console</i> - Let the debug message output to console.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set debug information to output to console:

```
DGS-3627:admin# debug dhcpv6_client output console
Command: debug dhcpv6_client output console
```

Success.

```
DGS-3627:admin#
```

debug dhcpv6_client packet

Purpose	Used to enable or disable the debug information flag for DHCPv6 client packets, including packet receiving and sending.
Syntax	debug dhcpv6_client packet {all receiving sending} state [enable disable]
Description	Enable or disable the debug information flag for DHCPv6 client packets, including packet receiving and sending.
Parameters	<i>all</i> - Set packet receiving and sending debug flags. <i>receiving</i> - Set packet receiving debug flag. <i>sending</i> - Set packet sending debug flag. <i>enable</i> - Enable the designated flags. <i>disable</i> - Disable the designated flags.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable DHCPv6client packet sending debug flags:

```
DGS-3627:admin# debug dhcpv6_client packet sending state enable
Command: debug dhcpv6_client packet sending state enable
```

Success.

```
DGS-3627:admin#
```

DHCPV6 RELAY COMMANDS

The DHCPv6 Relay commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config dhcpv6_relay hop_count	<value 1-32>
config dhcpv6_relay	[add delete] ipif <ipif_name 12> <ipv6addr>
config dhcpv6_relay ipif	[<ipif_name 12> all] state [enable disable]
show dhcpv6_relay	{ipif <ipif_name 12>}
enable dhcpv6_relay	
disable dhcpv6_relay	
debug dhcpv6_relay state	[enable disable]
debug dhcpv6_relay output	[buffer console]
debug dhcpv6_relay packet	{all receiving sending} state [enable disable]
debug dhcpv6_relay hop_count state	[enable disable]

Each command is listed, in detail, in the following sections.

config dhcpv6_relay hop_count

Purpose	This command is used to configure the DHCPv6 relay hop count of the switch.
Syntax	config dhcpv6_relay hop_count <value 1-32>
Description	This command is used to configure the DHCPv6 relay hop count of the switch.
Parameters	<i>hop_count</i> - The hop count is the number of relay agents that have to be relayed in this message. The range is 1 to 32. The default value is 4.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the maximum hops of a DHCPv6 relay packet that can be transferred to 4:

```
DGS-3627:admin# config dhcpv6_relay hop_count 4
Command: config dhcpv6_relay hop_count 4

Success.

DGS-3627:admin#
```

config dhcpv6_relay

Purpose	This command is used to add or delete a destination IP address to or from the switch's DHCPv6 relay table.
Syntax	config dhcpv6_relay [add delete] ipif <ipif_name 12> <ipv6addr>

config dhcpv6_relay

Description	This command can add or delete an IPv6 destination address to forward (relay) DHCPv6 packets.
Parameters	<i>add</i> - Add an IPv6 destination to the DHCPv6 relay table. <i>delete</i> - Delete an IPv6 destination from the DHCPv6 relay table <i>ipif_name</i> - The name of the IP interface in which DHCPv6 relay is to be enabled. <i>ipv6addr</i> - The DHCPv6 server IP address.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To add a DHCPv6 server to the relay table:

```
DGS-3627:admin# config dhcpv6_relay add ipif System 2001:DB8:1234:0:218:FEFF:FEFB:CC0E
Command: config dhcpv6_relay add ipif System 2001:DB8:1234:0:218:FEFF:FEFB:CC0E
Success.
DGS-3627:admin#
```

config dhcpv6_relay ipif

Purpose	This command is used to configure the DHCPv6 relay state of one or all of the specified interfaces.
Syntax	config dhcpv6_relay ipif [<ipif_name 12> all] state [enable disable]
Description	This command is used to configure the DHCPv6 relay state of one or all of the specified interfaces.
Parameters	<i>ipif_name</i> - The name of the IP interface. The value all indicates all configured IP interfaces. <i>state</i> - See below: <i>enable</i> - Choose this parameter to enable the DHCPv6 relay state of the interface. <i>disable</i> - Choose this parameter to disable the DHCPv6 relay state of the interface.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the DHCPv6 relay state of the System interface to enable:

```
DGS-3627:admin# config dhcpv6_relay ipif System state enable
Command: config dhcpv6_relay ipif System state enable
Success.
DGS-3627:admin#
```

show dhcpv6_relay

Purpose	This command displays the current DHCPv6 relay configuration.
Syntax	show dhcpv6_relay {ipif <ipif_name 12>}
Description	This command will display the current DHCPv6 relay configuration of all interfaces, or if an IP interface name is specified, the DHCPv6 relay configuration for that IP interface.

show dhcpv6_relay

Parameters	<i>ipif_name</i> - The name of the IP interface that will be displayed in the current DHCPv6 relay configuration. If no IP interface is specified, all configured DHCPv6 relay interfaces will be displayed.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

This is an example to show the DHCPv6 relay configuration of all interfaces:

```
DGS-3627:admin# show dhcpv6_relay
Command: show dhcpv6_relay

DHCPv6 Hops Count Limit      : 4
DHCPv6 Global State          : Disabled
-----
System Interface:
DHCPv6 Relay Status          : Disabled
Server Address                : 2001:DB8:1234:0:218:FEFF:FEFB:1
Server Address                : 3ffe::500
Server Address                : 3ffe::600
Server Address                : ff05::1:3%Ipif1

Ipif_1 Interface:
DHCPv6 Relay Status          : Enabled
Server Address                : 2001:DB8:1234:1:218:FEFF:FEFB:2

Ipif_2 Interface:
DHCPv6 Relay Status          : Disabled

Total Entries : 3

DGS-3627:admin#
```

To show the DHCPv6 relay configuration of the System interface:

```
DGS-3627:admin# show dhcpv6_relay ipif System
Command: show dhcpv6_relay ipif System

DHCPv6 Hops Count Limit      : 4
DHCPv6 Global State          : Disabled
-----
System Interface:
DHCPv6 Relay Status          : Disabled
Server Address                : 2001:DB8:1234:0:218:FEFF:FEFB:1
Server Address                : 3ffe::500
Server Address                : 3ffe::600
Server Address                : ff05::1:3%Ipif1

DGS-3627:admin#
```

enable dhcpv6_relay

Purpose	Used to enable the DHCPv6 relay function on the Switch.
---------	---

enable dhcpv6_relay

Syntax	enable dhcpv6_relay
Description	This command is used to enable the DHCPv6 relay global state on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the DHCPv6 relay global state to enable:

```
DGS-3627:admin# enable dhcpv6_relay
Command: enable dhcpv6_relay
```

Success.

```
DGS-3627:admin#
```

disable dhcpv6_relay

Purpose	Used to disable the DHCPv6 relay function on the Switch
Syntax	disable dhcpv6_relay
Description	This command is used to disable the DHCPv6 relay global state on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the DHCPv6 relay global state to disable:

```
DGS-3627:admin# disable dhcpv6_relay
Command: disable dhcpv6_relay
```

Success.

```
DGS-3627:admin#
```

debug dhcpv6_relay state

Purpose	This command is used to enable or disable DHCPv6 relay debug functions.
Syntax	debug dhcpv6_relay state [enable disable]
Description	This command is used to enable or disable DHCPv6 relay debug functions.
Parameters	<i>state</i> - See below: <i>enable</i> - Enable the DHCPv6 relay debug function <i>disable</i> - Disable the DHCPv6 relay debug function
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enabled the DHCPv6 relay debug function:

```
DGS-3627:admin# debug dhcpv6_relay state enable
Command:  debug dhcpv6_relay state enable

Success.

DGS-3627:admin#
```

debug dhcpv6_relay output

Purpose	This command is used to set the debug message to output to a buffer or a console.
Syntax	debug dhcpv6_relay output [buffer console]
Description	This command is used to set the debug message to output to a buffer or a console.
Parameters	<i>output</i> - See below: <i>buffer</i> - Let the debug message output to buffer. <i>console</i> - Let the debug message output to console.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set debug information to output to a console:

```
DGS-3627:admin# debug dhcpv6_relay output console
Command:  debug dhcpv6_relay output console

Success.

DGS-3627:admin#
```

debug dhcpv6_relay packet

Purpose	This command is used to enable or disable the debug information flag of the DHCPv6 relay packet, including packets receiving and sending.
Syntax	debug dhcpv6_relay packet {all receiving sending} state [enable disable]
Description	This command is used to enable or disable the debug information flag of the DHCPv6 relay packet, including packets receiving and sending.
Parameters	<i>all</i> - Set packet receiving and sending debug flags. <i>receiving</i> - Set packet receiving debug flag. <i>sending</i> - Set packet sending debug flag. <i>enable</i> - Enable the designated flags. <i>disable</i> - Disable the designated flags.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enabled the DHCPv6 relay packet sending debug:

```
DGS-3627:admin# debug dhcpv6_relay packet sending state enable
Command: debug dhcpv6_relay packet sending state enable

Success.

DGS-3627:admin#
```

debug dhcpv6_relay hop_count state

Purpose	This command is used to enable or disable debug information flag about the hop count.
Syntax	debug dhcpv6_relay hop_count state [enable disable]
Description	This command is used to enable or disable debug information flag about the hop count.
Parameters	<p><i>hop_count</i> - The hop count is the number of relay agents that have to be relayed in this message. The range is 1 to 32. The default value is 4.</p> <p><i>enable</i> - Enable the hop_count state.</p> <p><i>disable</i> - Disable the hop_count state.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable debug information flag about the hop count:

```
DGS-3627:admin# debug dhcpv6_relay hop_count state enable
Command: debug dhcpv6_relay hop_count state enable

Success.

DGS-3627:admin#
```


DHCPV6 SERVER COMMANDS

The DHCPv6 Server commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create dhcpv6 pool	<pool_name 12>
delete dhcpv6 pool	[<pool_name 12> all]
show dhcpv6 pool	{<pool_name 12>}
config dhcpv6 pool ipv6network_addr	<pool_name 12> begin < ipv6networkaddr> end <ipv6networkaddr>
config dhcpv6 pool domain_name	<pool_name 12> <domain_name 255>
config dhcpv6 pool dns_server	<pool_name 12> <ipv6addr> {<ipv6addr>}
config dhcpv6 pool lifetime	<pool_name 12> preferred_lifetime <sec 60-4294967295> valid_lifetime <sec 60-4294967295>
config dhcpv6 pool manual_binding	<pool_name 12> [add <ipv6addr > client_ duid <string 28> delete [<ipv6addr > all]]
show dhcpv6 manual_binding	{<pool_name 12>}
show dhcpv6 binding	{<pool_name 12>}
clear dhcpv6 binding	{<pool_name 12>}
enable dhcpv6_server	
disable dhcpv6_server	
show dhcpv6_server	
config dhcpv6 pool excluded_address	<pool_name 12> [add begin < ipv6addr> end < ipv6addr > delete [begin < ipv6addr> end < ipv6addr> all]]
show dhcpv6 excluded_address	{<pool_name 12>}
config dhcpv6_server ipif	<ipif_name 12> state [enable disable]
debug dhcpv6_server state	[enable disable]
debug dhcpv6_server packet	{all receiving sending} state [enable disable]

Each command is listed, in detail, in the following sections.

create dhcpv6 pool

Purpose	This command is used to create a DHCPv6 pool.
Syntax	create dhcpv6 pool <pool_name 12>
Description	This command is used to create a DHCPv6 pool for the DHCPv6 server.
Parameters	<pool_name 12> - Enter a name of up to 12 alphanumeric characters to identify the pool to be created with this command.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a DHCPv6 pool pool1:

```
DGS-3627:admin# create dhcpv6 pool pool1
Command : create dhcpv6 pool pool1

success

DGS-3627:admin#
```

delete dhcpv6 pool

Purpose	This command is used to delete one or all DHCPv6 pools.
Syntax	delete dhcpv6 pool [<pool_name 12> all]
Description	This command will delete a DHCPv6 pool that was created with the create dhcpv6 pool command.
Parameters	<i>pool <pool_name 12></i> - Enter a name of up to 12 alphanumeric characters to identify the pool to be deleted with this command. <i>all</i> - If specify this parameter, all DHCPv6 pools on the Switch will be deleted.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the DHCPv6 pool by specifying the pool name pool1:

```
DGS-3627:admin# delete dhcpv6 pool pool1
Command: delete dhcpv6 pool pool1

Success.

DGS-3627:admin#
```

show dhcpv6 pool

Purpose	This command is used to display one or all DHCPv6 pools configuration.
Syntax	show dhcpv6 pool {<pool_name 12>}
Description	This command will show one or all DHCPv6 pools configuration that were created with the create dhcpv6 pool command.
Parameters	<i>pool <pool_name 12></i> - Enter the name of the DHCPv6 pool for which to view the pool information. Entering this command without the pool name will display all pools information of the DHCPv6 server.
Restrictions	None.

Example usage:

To show the DHCPv6 pool by specifying the pool name pool1:

```
DGS-3627:admin# show dhcpv6 pool pool1
```

```
Command: show dhcpv6 pool pool1
```

```
Pool Name           : pool1
Begin Network Address : 2000::1/64
End Network Address  : 2000::200/64
Domain Name          : domain.com
DNS Server Address   : 2000::ff
                    : 2000::fe
Preferred Lifetime   : 604800 (sec)
Valid Lifetime       : 2592000 (sec)
```

```
Total Pool Entry: 1
```

```
DGS-3627:admin#
```

config dhcpv6 pool ipv6networkaddr

Purpose	This command is used to configure the range of ipv6network address for the DHCPv6 pool
Syntax	config dhcpv6 pool ipv6network_addr <pool_name 12> begin < ipv6networkaddr> end <ipv6networkaddr>
Description	<p>Specify the range of ipv6network address for the DHCPv6 pool. The IPv6 addresses in the range are free to be assigned to the DHCPv6 client.</p> <p>When the DHCPv6 server receives a request from the client, the server will automatically find an available pool to allocate an IPv6 address.</p> <p>The begin_networkaddr and end_networkaddr must observe some rules as followed:</p> <p>The prefix of the begin_networkaddr and end_networkaddr must be in consistence, otherwise, the switch will print an error message: The prefix of begin_networkaddr and end_networkaddr must be consistence.(e.g.: the begin_networkaddr is 2000::1/64, and the end_networkaddr is 3000::100/64)</p> <p>The begin address must not be large than end address, otherwise, the switch will print an error message: The begin IPv6 address must be lower than or equal to the end IPv6 address.(e.g.: the begin_networkaddr is 2000::200/64, and the end_networkaddr is 2000::100/64)</p> <p>There must not be overlapping between the IPv6 address ranges of two pools, otherwise, the Switch will print an error message: The IP range of the pool is overlapping. (e.g.: pool1: 2000::1/64 --- 2000::100/64, pool2: 2000::50/64 --- 2000::200/64)</p> <p>The IPv6 network address can't be Link-local address and Multicast address, otherwise, the Switch will print an error message: "The IPv6 network address can't be Link-local address or Multicast address." (e.g.: pool1: FE80::1/64 --- FE80::100/64, pool2: FE80::200/64 --- FE80::300/64)</p>
Parameters	<p><i>pool <pool_name 12></i> - Enter the previously created pool name for which to set the network address.</p> <p><i>begin <ipv6networkaddr></i> - The begin IPv6network address of the DHCPv6 pool.</p> <p><i>end < ipv6networkaddr></i> - The end IPv6 network address of the DHCPv6 pool.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the range of ipv6network address for the DHCPv6 pool pool1:

```
DGS-3627:admin# config dhcpv6 pool ipv6networkaddr pool1 begin 2000::1/64 end 2000::32/64
Command: config dhcpv6 pool ipv6networkaddr pool1 begin 2000::1/64 end 2000::32/64

success

DGS-3627:admin#
```

config dhcpv6 pool domain_name

Purpose	This command is used to configure the domain name for the DHCPv6 pool of the Switch.
Syntax	config dhcpv6 pool domain_name <pool_name 12> <domain_name 255>
Description	The domain name configured here will be used as the default domain name by the client. By default, the domain name is empty. If domain name is empty, the domain name information will not be provided to the client.
Parameters	<i>pool <pool_name 12></i> - Enter the pool name for which to set the domain name. <i>domain_name <domain_name 255></i> - The domain name is used by client when resolving hostnames with DNS.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the domain name for the DHCPv6 pool pool1:

```
DGS-3627:admin# config dhcpv6 pool domain_name pool1 d_link.com
Command: config dhcpv6 pool domain_name pool1 d_link.com

Success.

DGS-3627:admin#
```

config dhcpv6 pool dns_server

Purpose	This command is used to configure the DNS server's IPv6 addresses for a specific DHCPv6 pool.
Syntax	config dhcpv6 pool dns_server <pool_name 12> <ipv6addr> {<ipv6addr>}
Description	This command is used to configure the DNS server IPv6 addresses for a specific DHCPv6 pool. Users may add up to two DNS Server addresses. If DNS server is not specified, the DNS server information will not be provided to the client. Users could delete a DNS server address in the method of setting the DNS server address to zero. For example, users first add two DNS server address: 2000::200, 2000::201, and then delete the DNS server address 2000::200. The procedure is as followed: Command: config dhcpv6 pool dns_server pool1 2000::200 2000::201 config dhcpv6 pool dns_server pool1 ::
Parameters	<i><pool_name 12></i> - Enter the pool name for which to add one or two DNS server addresses. <i><ipv6addr></i> - Enter the DNS server IPv6 address for this pool. Users may specify up to two DNS server addresses.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the DNS server address for a DHCPv6 pool:

```
DGS-3627:admin# config dhcpv6 pool dns_server pool1 2000::200 2000::201
Command: config dhcpv6 pool dns_server pool1 2000::200 2000::201

Success.

DGS-3627:admin#
```

config dhcpv6 pool lifetime

Purpose	This command is used to configure the preferred-lifetime and valid-lifetime of IPv6 address within a DHCPv6 pool.
Syntax	config dhcpv6 pool lifetime <pool_name 12> preferred_lifetime <sec 60-4294967295> valid_lifetime <sec 60-4294967295>
Description	within a DHCPv6 pool. preferred lifetime - the length of time that a valid address is preferred (i.e., the time until deprecation). When the preferred lifetime expires, the address becomes deprecated. valid lifetime - the length of time an address remains in the valid state (i.e., the time until invalidation). When the valid lifetime expires, the address becomes invalid. The valid lifetime must be greater than or equal to the preferred lifetime.
Parameters	<i>pool <pool_name 12></i> - Enter the previously created pool name for which to set the preferred-lifetime and valid-lifetime of IPv6 address. <i>preferred_lifetime <sec 60-4294967295></i> - The amount of time (in seconds) that the IPv6 address, based on the specified pool, remains in preferred state. <i>valid_lifetime <sec 60-4294967295></i> - The amount of time (in seconds) that the IPv6 address, based on the specified pool, remains in valid state.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the preferred-lifetime and valid-lifetime for the DHCPv6 pool:

```
DGS-3627:admin# config dhcpv6 pool lifetime pool1 preferred_lifetime 80 valid_lifetime 100
Command: config dhcpv6 pool lifetime pool1 preferred_lifetime 80 valid_lifetime 100

Success.

DGS-3627:admin#
```

config dhcpv6 pool manual_binding

Purpose	This command is used to configure a DHCPv6 pool manual binding entry.
Syntax	config dhcpv6 pool manual_binding <pool_name 12> [add <ipv6addr > client_aid <string 28> delete [<ipv6addr > all]]
Description	An address binding is a mapping between the IPv6 address and DUID (A DHCPv6 Unique Identifier for a DHCPv6 participant) of a client. The IPv6 address specified in the manual binding entry must be in the range of the DHCPv6 pool. If the user specifies a conflict IPv6 address, error message will be returned.
Parameters	<i>pool <pool_name 12></i> - Enter the name of the previously created pool that will contain the manual binding entry.

config dhcpv6 pool manual_binding

add <ipv6addr> - Enter the IPv6 address to be statically bound to a device.
client_ duid <string 28> - Enter the DUID of the device to be statically bound to the IPv6 address entered in the previous field. The DUID string must be '0--9', 'a--f' or 'A--F'.
delete - To delete the manual binding entry.
 <ipv6addr> - Enter the IPv6 address of the manual binding entry to be deleted.
all - Enter this command to delete all manual binding entries for the given pool.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To add a manual binding DHCPv6 entry:

```
DGS-3627:admin# create dhcpv6 pool manual_binding pool1 add 2000::3 client_ duid
00010006124dd5840021918d4d9f
Command: create dhcpv6 pool manual_binding pool1 add 2000::3 client_ duid
00010006124dd5840021918d4d9f
```

success

```
DGS-3627:admin#
```

show dhcpv6 manual_binding

Purpose	This command is used to display the manual binding settings.
Syntax	show dhcpv6 manual_binding {<pool_name 12>}
Description	This command will display the manual binding entries for the selected or all DHCPv6 pools.
Parameters	<i>pool</i> <pool_name 12> - Enter the name of the DHCPv6 pool for which to view manual binding entries. Entering this command without the pool name will display all manual binding entries of the DHCPv6 server.
Restrictions	None.

Example usage:

To display the manual binding entries of the DHCPv6 pool pool1:

```
DGS-3627:admin# show dhcpv6 manual_binding
Command: show dhcpv6 manual_binding

Pool Name: pool1
Entry 1
  IPv6 Address : 3000::21
  DUID         : 00010006124dd584002191454d33

Entry 2
  IPv6 Address : 3000::28
  DUID         : 000300060022d7e50900

Pool Name: pool2
Entry 1
  IPv6 Address : 8000:1000:1000:1000:1000:1000:1000:2000
  DUID         : 00010006124dd584002191454d37

Total Entries: 3

DGS-3627:admin#
```

show dhcpv6 binding

Purpose	This command is used to show the DHCPv6 dynamic binding information.
Syntax	show dhcpv6 binding {<pool_name 12>}
Description	This command is used to display the DHCPv6 dynamic binding information. Entering the command without the pool name will display all information regarding DHCPv6 dynamic binding on the switch. This command only displays the dynamic binding information, not including manual binding information.
Parameters	<pool_name 12> - Enter the name of the DHCPv6 pool for which to view dynamic binding information. Entering this command without the pool name will display all dynamic binding entries of the DHCPv6 server.
Restrictions	None.

Example usage:

To display the DHCPv6 dynamic binding information on the Switch:

```
DGS-3627:admin# show dhcpv6 binding
Command: show dhcpv6 binding

Pool Name: pool1      Ipv6 Address : 2000::3
                    DUID         : 00010006124dd5840021918d4d9f
                    Preferred(s) : 604800           Valid(s): 2592000

Pool Name: pool1      Ipv6 Address : 2000::1
                    DUID         : 00010006124dd5840021918d8865
                    Preferred(s) : 620              Valid(s): 800

Total Entries : 2

DGS-3627:admin#
```

clear dhcpv6 binding

Purpose	This command is used to clear the DHCPv6 dynamic binding information.
Syntax	clear dhcpv6 binding {<pool_name 12>}
Description	This command is used to clear the DHCPv6 dynamic binding information, not including manual binding information. Users could use command (4-1-8) to delete the manual binding information.
Parameters	<pool_name 12> - Enter the name of the DHCPv6 pool for which to clear the dynamic binding information. If not specify the parameter, it will delete all dynamic binding entries of the DHCPv6 server.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To clear the DHCPv6 dynamic binding information on the Switch:

```
DGS-3627:admin# clear dhcpv6 binding
Command: clear dhcpv6 binding

Success.

DGS-3627:admin#
```

enable dhcpv6_server

Purpose	This command is used to enable the DHCPv6 server function on the Switch.
Syntax	enable dhcpv6_server
Description	This command is used to enable the DHCPv6 server global state on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the DHCPv6 server global state to enable:

```
DGS-3627:admin# enable dhcpv6_server
Command: enable dhcpv6_server

Success.

DGS-3627:admin#
```

disable dhcpv6_server

Purpose	This command is used to disable the DHCPv6 server function on the Switch.
Syntax	disable dhcpv6_server
Description	This command is used to disable the DHCPv6 server global state on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the DHCPv6 server global state to disable:

```
DGS-3627:admin# disable dhcpv6_server
Command: disable dhcpv6_server

Success.

DGS-3627:admin#
```

show dhcpv6_server

Purpose	This command is used to display the DHCPv6 server setting.
Syntax	show dhcpv6_server
Description	This command will display the DHCPv6 server settings.
Parameters	None.
Restrictions	None.

Example usage:

To display the DHCPv6 server setting:

```
DGS-3627:admin# show dhcpv6_server
Command: show dhcpv6_server

DHCPv6 Server Global State: Disabled
-----
IP Interface           : System
DHCPv6 Server State   : Enabled

IP Interface           : ipif1
DHCPv6 Server State   : Enabled

Total Entries         : 2

DGS-3627:admin#
```

config dhcpv6 pool excluded_address

Purpose	This command is used to configure the reserved IPv6 addresses on the DHCPv6 server
Syntax	config dhcpv6 pool excluded_address <pool_name 12> [add begin < ipv6addr> end < ipv6addr > delete [begin < ipv6addr> end < ipv6addr> all]]
Description	This command will configure the IPv6 addresses range that the DHCPv6 server should not assign to DHCPv6 client. The excluded address range must be the subset of the specified pool.
Parameters	<p><i>pool <pool_name 12></i> - Enter the name of the DHCPv6 pool for which to add/delete the excluded address information.</p> <p><i>add</i> - Add an excluded address range for a specified pool.</p> <p><i>delete</i> - Delete one or all excluded address ranges of a specified pool.</p> <p><i>begin <ipv6addr></i> - Enter the beginning IPv6 address of the range of IPv6 addresses to be excluded from the DHCPv6 pool.</p> <p><i>end <ipv6addr></i> - Enter the ending IPv6 address of the range of IPv6 addresses to be excluded from the DHCPv6 pool.</p>

config dhcpv6 pool excluded_address

all - Delete all excluded address ranges of a specified pool.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To add the IPv6 addresses range that DHCPv6 server should not assign to clients:

```
DGS-3627:admin# config dhcpv6 pool excluded_address pool1 add begin 2000::3 end 2000::8
Command: config dhcpv6 pool excluded_address pool1 add begin 2000::3 end 2000::8
```

Success.

```
DGS-3627:admin#
```

show dhcpv6 excluded_address

Purpose	This command is used to display the groups of IPv6 addresses which are excluded from the legal assigned IPv6 address
Syntax	show dhcpv6 excluded_address {<pool_name 12>}
Description	This command will display the groups of IPv6 addresses which are excluded from the legal assigned IPv6 address.
Parameters	<pool_name 12> - Enter the name of the DHCPv6 pool for which to display the excluded address information. If not specify the pool name, It will display all pool's excluded address information.
Restrictions	None.

Example usage:

To display the excluded address information:

```
DGS-3627:admin# show dhcpv6 excluded_address
```

```
Command: show dhcpv6 excluded_address
```

```
Pool name: Pool1
```

```
Range 1
```

```
Begin Address: 2000::2
```

```
End Address   : 2000::5
```

```
Range 2
```

```
Begin Address: 2000::8
```

```
End Address   : 2000::8
```

```
Pool name: Pool2
```

```
Range 1
```

```
Begin Address: 3000::2
```

```
End Address   : 3000::5
```

```
Range 2
```

```
Begin Address: 3000::8
```

```
End Address   : 3000::8
```

```
Range 3
```

```
Begin Address: 3000::18
```

```
End Address   : 3000::20
```

```
Total Entries : 5
```

```
DGS-3627:admin#
```

config dhcpv6_server ipif

Purpose	This command is used to configure the DHCPv6 Server state per interface
Syntax	config dhcpv6_server ipif <ipif_name 12> state [enable disable]
Description	This command configures the DHCPv6 Server state on the IP interface.
Parameters	<i>ipif <ipif_name 12></i> - The name of the IP interface. <i>state</i> - See below: <i>enable</i> - Enable the dhcpv6 server state for a specified interface. <i>disable</i> - Disable the dhcpv6 server state for a specified interface.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the DHCPv6 Server state of System Interface to enable:

```
DGS-3627:admin# config dhcpv6_server ipif System state enable
```

```
Command: config dhcpv6_server ipif System state enable
```

```
Success.
```

```
DGS-3627:admin#
```

debug dhcpv6_server state

Purpose	This command is used to enable or disable DHCPv6 server debug functions.
Syntax	debug dhcpv6_server state [enable disable]
Description	This command is used to enable or disable DHCPv6 server debug functions.

debug dhcpv6_server state

Parameters	<i>state</i> - See below: <i>enable</i> - Enable the DHCPv6 server debug function <i>disable</i> - Disable the DHCPv6 server debug function
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enabled the DHCPv6 server debug function:

```
DGS-3627:admin# debug dhcpv6_server state enable
Command:  debug dhcpv6_server state enable

Success.

DGS-3627:admin#
```

debug dhcpv6_server packet

Purpose	This command is used to enable or disable the debug information flag of the DHCPv6 server packet, including packets receiving and sending.
Syntax	debug dhcpv6_server packet {all receiving sending} state [enable disable]
Description	This command is used to enable or disable the debug information flag of the DHCPv6 server packet, including packets receiving and sending.
Parameters	<i>all</i> - Set packet receiving and sending debug flags. <i>receiving</i> - Set packet receiving debug flag. <i>sending</i> - Set packet sending debug flag. <i>enable</i> - Enable the designated flags. <i>disable</i> - Disable the designated flags.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enabled the DHCPv6 server packet sending debug:

```
DGS-3627:admin# debug dhcpv6_server packet sending state enable
Command:  debug dhcpv6_server packet sending state enable

Success.

DGS-3627:admin#
```

D-LINK SINGLE IP MANAGEMENT COMMANDS

Simply put, D-Link Single IP Management is a concept that will stack switches together over Ethernet instead of using stacking ports or modules. Switches using D-Link Single IP Management (labeled here as SIM) must conform to the following rules:

SIM is an optional feature on the Switch and can easily be enabled or disabled. SIM grouping has no effect on the normal operation of the Switch in the user's network.

There are three classifications for switches using SIM. The Commander Switch(CS), which is the master switch of the group, Member Switch(MS), which is a switch that is recognized by the CS as a member of a SIM group, and a Candidate Switch (CaS), which is a switch that has a physical link to the SIM group but has not been recognized by the CS as a member of the SIM group.

A SIM group can only have one Commander Switch(CS). All switches in a particular SIM group must be in the same IP subnet (broadcast domain). Members of a SIM group cannot cross a router. A SIM group accepts up to 33 switches (numbered 0-32), including the Commander Switch (numbered 0). There is no limit to the number of SIM groups in the same IP subnet (broadcast domain), however a single switch can only belong to one group. If multiple VLANs are configured, the SIM group will only utilize the management VLAN on any switch. SIM allows intermediate devices that do not support SIM. This enables the user to manage a switch that are more than one hop away from the CS.

The SIM group is a group of switches that are managed as a single entity. The DGS-3600 Series may take on three different roles:

- **Commander Switch (CS)** – This is a switch that has been manually configured as the controlling device for a group, and takes on the following characteristics:
 - It has an IP Address.
 - It is not a Commander Switch or Member Switch of another Single IP group.
 - It is connected to the Member Switches through its management VLAN.
- **Member Switch (MS)** – This is a switch that has joined a single IP group and is accessible from the CS, and it takes on the following characteristics:
 - It is not a CS or MS of another IP group.
 - It is connected to the CS through the CS management VLAN.
- **Candidate Switch (CaS)** – This is a switch that is ready to join a SIM group but is not yet a member of the SIM group. The Candidate Switch may join the SIM group through an automatic function of the DGS-3600, or by manually configuring it to be a MS of a SIM group. A switch configured as a CaS is not a member of a SIM group and will take on the following characteristics:
 - It is not a CS or MS of another Single IP group.
 - It is connected to the CS through the CS management VLAN.

The following rules also apply to the above roles:

1. Each device begins in the Candidate state.
2. CS's must change their role to CaS and then to MS, to become a MS of a SIM group. Thus the CS cannot directly be converted to a MS.
3. The user can manually configure a CS to become a CaS.
4. A MS can become a CaS by:
 - a. Being configured as a CaS through the CS.
 - b. If report packets from the CS to the MS time out.
5. The user can manually configure a CaS to become a CS

6. The CaS can be configured through the CS to become a MS.

After configuring one switch to operate as the CS of a SIM group, additional xStack® DGS-3600 series switches may join the group by either an automatic method or by manually configuring the Switch to be a MS. The CS will then serve as the in band entry point for access to the MS. The CS's IP address will become the path to all MS's of the group and the CS's Administrator's password, and/or authentication will control access to all MS's of the SIM group.

With SIM enabled, the applications in the CS will redirect the packet instead of executing the packets. The applications will decode the packet from the administrator, modify some data, then send it to the MS. After execution, the CS may receive a response packet from the MS, which it will encode and send back to the administrator.

When a CS becomes a MS, it automatically becomes a member of the first SNMP community (include read/write and read only) to which the CS belongs. However if a MS has its own IP address, it can belong to SNMP communities to which other switches in the group, including the CS, do not belong.

The Upgrade to v1.6

To better improve SIM management, the xStack® DGS-3600 Series switches have been upgraded to version 1.6 in this release. Many improvements have been made, including:

The Commander Switch (CS) now has the capability to automatically rediscover member switches that have left the SIM group, either through a reboot or web malfunction. This feature is accomplished through the use of Discover packets and Maintain packets that previously set SIM members will emit after a reboot. Once a MS has had its MAC address and password saved to the CS's database, if a reboot occurs in the MS, the CS will keep this MS information in its database and when a MS has been rediscovered, it will add the MS back into the SIM tree automatically. No configuration will be necessary to rediscover these switches. There are some instances where pre-saved MS switches cannot be rediscovered. For example, if the Switch is still powered down, if it has become the member of another group, or if it has been configured to be a Commander Switch, the rediscovery process cannot occur.

This version will support multiple switch upload and downloads for firmware, configuration files and log files, as follows:

- Firmware – The switch now supports MS firmware downloads from a TFTP server.
- Configuration Files – This switch now supports downloading and uploading of configuration files both to (for configuration restoration) and from (for configuration backup) MS's, using a TFTP server..
- Log – The switch now supports uploading MS log files to a TFTP server.



NOTE: For more details regarding improvements made in SIMv1.6, please refer to the Single IP Management White Paper located on the D-Link website.

The SIM commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
enable sim	
disable sim	
show sim	{[candidates {<candidate_id 1-100>} members {<member_id 1-32>} group {commander_mac <macaddr>} neighbor]}
reconfig	{member_id <value 1-32> exit}
config sim_group	[add <candidate_id 1-100> {<password>} delete <member_id 1-32>]
config sim	[[commander {group_name <groupname 64>} candidate] dp_interval <sec 30-90> hold_time <sec 100-255>]
download sim_ms	[firmware_from_tftp configuration_from_tftp] <ipaddr> <path_filename> {[members <mclist 1-32> all]}
upload sim_ms	[configuration_to_tftp log_to_tftp] <ipaddr> <path_filename> {[members <mclist> all]}

Each command is listed, in detail, in the following sections.

enable sim

Purpose	Used to enable Single IP Management (SIM) on the Switch
Syntax	enable sim
Description	This command will enable SIM globally on the Switch. SIM features and functions will not function properly unless this function is enabled.
Parameters	None.
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To enable SIM on the Switch:

```
DGS-3627:admin# enable sim
Command: enable sim
```

Success.

```
DGS-3627:admin#
```

disable sim

Purpose	Used to disable Single IP Management (SIM) on the Switch.
Syntax	disable sim
Description	This command will disable SIM globally on the Switch.
Parameters	None.
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To disable SIM on the Switch:

```
DGS-3627:admin# disable sim
Command: disable sim

Success.

DGS-3627:admin#
```

show sim

Purpose	Used to view the current information regarding the SIM group on the Switch.
Syntax	show sim {[candidates {<candidate_id 1-100>} members {<member_id 1-32>} group { commander_mac <macaddr>} neighbor]}
Description	<p>This command will display the current information regarding the SIM group on the Switch, including the following:</p> <p>SIM Version – Displays the current Single IP Management version on the Switch.</p> <p>Firmware Version – Displays the current Firmware version on the Switch.</p> <p>Device Name – Displays the user-defined device name on the Switch.</p> <p>MAC Address – Displays the MAC Address of the Switch.</p> <p>Capabilities – Displays the type of switch, be it Layer 2 (L2) or Layer 3 (L3).</p> <p>Platform – Switch Description including name and model number.</p> <p>SIM State – Displays the current Single IP Management State of the Switch, whether it be enabled or disabled.</p> <p>Role State – Displays the current role the Switch is taking, including Commander, Member or Candidate. A Stand-alone switch will always have the commander role.</p> <p>Discovery Interval – Time in seconds the Switch will send discovery packets out over the network.</p> <p>Hold time – Displays the time in seconds the Switch will hold discovery results before dropping it or utilizing it.</p>
Parameters	<p><i>candidates</i> <candidate_id 1-100> – Entering this parameter will display information concerning candidates of the SIM group. To view a specific candidate, include that candidate's ID number, listed from 1 to 100.</p> <p><i>members</i> <member_id 1-32> – Entering this parameter will display information concerning members of the SIM group. To view a specific member, include that member's id number, listed from 1 to 32.</p> <p><i>group</i> {<i>commander_mac</i> <macaddr>} – Entering this parameter will display information concerning the SIM group. To view a specific group, include the commander's MAC address of the group.</p> <p><i>neighbor</i> – Entering this parameter will display neighboring devices of the Switch. A SIM neighbor is defined as a switch that is physically connected to the Switch but is not part of the SIM group. This screen will produce the following results:</p> <ul style="list-style-type: none"> • Port – Displays the physical port number of the commander switch where the uplink to the neighbor switch is located. • MAC Address – Displays the MAC Address of the neighbor switch. • Role – Displays the role (CS, CaS, MS) of the neighbor switch.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show the SIM information in detail:


```
DGS-3627:admin# show sim
Command: show sim

SIM Version      : VER-1.61
Firmware Version : 2.80.B31
Device Name      :
MAC Address      : 00-19-5B-F5-26-C0
Capabilities     : L3
Platform        : DGS-3627 L3 Switch
SIM State       : Disabled
Role State      : Candidate
Discovery Interval : 30 sec
Holdtime        : 100 sec

DGS-3627:admin#
```

To show the candidate information in summary, if the candidate ID is specified:

```
DGS-3627:admin# show sim candidates
Command: show sim candidates

ID   MAC Address           Platform /           Hold   Firmware   Device Name
   -----             -----             -----   -----   -----
  2   00-55-55-00-55-00   DGS-3627 L3 Switch  140     2.80.B31   default master

Total Entries: 2

DGS-3627:admin#
```

To show the member information in summary, if the member ID is specified:

```
DGS-3627:admin# show sim member 1
Command: show sim member 1

ID   MAC Address           Platform /           Hold   Firmware   Device Name
   -----             -----             -----   -----   -----
  1   00-01-02-03-04-00   DGS-3627 L3 Switch  40     2.80.B31   The Man

Total Entries: 2

DGS-3627:admin#
```

To show other groups information in summary:

```
DGS-3627:admin# show sim group
```

```
Command: show sim group
```

```
SIM Group Name : default
```

ID	MAC Address	Platform / Capability	Hold Time	Firmware Version	Device Name
*1	00-01-02-03-04-00	DGS-3627 L3 Switch	40	2.80.B31	Tiberius

```
SIM Group Name : SIM2
```

ID	MAC Address	Platform / Capability	Hold Time	Firmware Version	Device Name
*1	00-01-02-03-04-00	DGS-3627 L3 Switch	40	2.80.B31	Neo

```
`*' means commander switch.
```

```
DGS-3627:admin#
```

Example usage:

To view SIM neighbors:

```
DGS-3627:admin# show sim neighbor
```

```
Command: show sim neighbor
```

```
Neighbor Info Table
```

Port	MAC Address	Role
23	00-35-26-00-11-99	Commander
23	00-35-26-00-11-91	Member
24	00-35-26-00-11-90	Candidate

```
Total Entries: 3
```

```
DGS-3627:admin#
```

reconfig

Purpose	Used to connect to a member switch, through the commander switch, using telnet.
Syntax	reconfig {member_id <value 1-32> exit}
Description	This command is used to reconnect to a member switch using Telnet.
Parameters	<i>member_id</i> <value 1-32> – Select the ID number of the member switch the user desires to configure. <i>exit</i> – This command is used to exit from managing the member switch and will return to managing the commander switch.
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To connect to the MS, with member ID 2, through the CS, using the command line interface:

```
DGS-3627:admin# reconfig member_id 2
Command: reconfig member_id 2

DGS-3627:admin#
Login:
```

config sim_group

Purpose	Used to add candidates and delete members from the SIM group.
Syntax	config sim [add <candidate_id 1-100> {<password>} delete <member_id 1-32>]
Description	This command is used to add candidates and delete members from the SIM group by ID number.
Parameters	<p><i>add <candidate_id 1-100> <password></i> – Use this parameter to change a candidate switch (CaS) to a member switch (MS) of a SIM group. The CaS may be defined by its ID number and a password (if necessary).</p> <p><i>delete <member_id 1-32></i> – Use this parameter to delete a member switch of a SIM group. The member switch should be defined by ID number.</p>
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To add a member:

```
DGS-3627:admin# config sim_group add 2
Command: config sim_group add 2

Please wait for ACK!!!
SIM Config Success !!!

Success.

DGS-3627:admin#
```

To delete a member:

```
DGS-3627:admin# config sim_group delete 1
Command: config sim_group delete 1

Please wait for ACK!!!
SIM Config Success!!!

Success.

DGS-3627:admin#
```

config sim

Purpose	Used to configure role parameters for the SIM protocol on the Switch.
Syntax	config sim [[commander {group_name <groupname 64>} candidate] dp_interval <sec 30-90> hold_time <sec 100-255>]}
Description	This command is used to configure parameters of switches of the SIM.
Parameters	<i>commander</i> – Use this parameter to configure the commander switch(CS) for the following parameters:

config sim

- *group_name <groupname 64>* – Used to update the name of the group. Enter an alphanumeric string of up to 64 characters to rename the SIM group.
 - *dp_interval <30-90>* – The user may set the discovery protocol interval, in seconds that the Switch will send out discovery packets. Returning information to the CS will include information about other switches connected to it. (Ex. MS, CaS). The user may set the *dp_interval* from 30 to 90 seconds.
 - *hold time <sec 100-255>* – Using this parameter, the user may set the time, in seconds, the CS will hold information sent to it from other switches, utilizing the discovery interval protocol. The user may set the hold time from 100 to 255 seconds.
- candidate* – Used to change the role of a CS (commander) to a CaS (candidate).
- *dp_interval <30-90>* – The user may set the discovery protocol interval, in seconds that the Switch will send out discovery packets. Returning information to the CS will include information about other switches connected to it. (Ex. MS, CaS). The user may set the *dp_interval* from 30 to 90 seconds.
 - *hold time <100-255>* – Using this parameter, the user may set the time, in seconds, the Switch will hold information sent to it from other switches, utilizing the discovery interval protocol. The user may set the hold time from 100 to 255 seconds.

Restrictions

Only Administrator-level users can issue this command.

To change the time interval of the discovery protocol:

```
DGS-3627:admin# config sim commander dp_interval 40
Command: config sim commander dp_interval 40
```

Success.

```
DGS-3627:admin#
```

To change the hold time of the discovery protocol:

```
DGS-3627:admin# config sim hold_time 120
Command: config sim hold_time 120
```

Success.

```
DGS-3627:admin#
```

To transfer the CS (commander) to be a CaS (candidate):

```
DGS-3627:admin# config sim candidate
Command: config sim candidate
```

Success.

```
DGS-3627:admin#
```

To transfer the Switch to be a CS:

```
DGS-3627:admin# config sim commander
Command: config sim commander

Success.

DGS-3627:admin#
```

To update the name of a group:

```
DGS-3627:admin# config sim commander group_name Demetrius
Command: config sim commander group_name Demetrius

Success.

DGS-3627:admin#
```

download sim_ms

Purpose	Used to download firmware or configuration file to an indicated device.
Syntax	download sim_ms [firmware_from_tftp configuration_from_tftp] <ipaddr> <path_filename> {[members <mslist 1-32> all]}
Description	This command will download a firmware file or configuration file to a specified device from a TFTP server.
Parameters	<p><i>firmware_from_tftp</i> – Specify this parameter to download firmware to members of a SIM group.</p> <p><i>configuration_from_tftp</i> – Specify this parameter to download a switch configuration to members of a SIM group.</p> <p><i><ipaddr></i> – Enter the IP address of the TFTP server.</p> <p><i><path_filename></i> – Enter the path and the filename of the firmware or switch on the TFTP server.</p> <p><i>members</i> – Enter this parameter to specify the members the user prefers to download firmware or switch configuration files to. The user may specify a member or members by adding one of the following:</p> <ul style="list-style-type: none"> • <i><mslist 1-32></i> – Enter a value, or values to specify which members of the SIM group will receive the firmware or switch configuration. • <i>all</i> – Add this parameter to specify all members of the SIM group will receive the firmware or switch configuration.
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To download firmware:

```
DGS-3627:admin# download sim_ms firmware_from_tftp 10.53.13.94 c:/dgs3627.had all
Command: download sim_ms firmware_from_tftp 10.53.13.94 c:/dgs3627.had all
```

This device is updating firmware. Please wait...

Download Status :

ID	MAC Address	Result
1	00-01-02-03-04-00	Success
2	00-07-06-05-04-03	Success
3	00-07-06-05-04-03	Success

```
DGS-3627:admin#
```

To download configuration files:

```
DGS-3627:admin# download sim_ms configuration_from_tftp 10.53.13.94 c:/dgs3627.txt all
Command: download sim_ms configuration_from_tftp 10.53.13.94 c:/dgs3627.txt all
```

This device is updating configuration. Please wait...

Download Status :

ID	MAC Address	Result
1	00-01-02-03-04-00	Success
2	00-07-06-05-04-03	Success
3	00-07-06-05-04-03	Success

```
DGS-3627:admin#
```

upload sim_ms

Purpose	User to upload a configuration file to a TFTP server from a specified member of a SIM group.
Syntax	upload sim_ms [configuration_to_tftp log_to_tftp] <ipaddr> <path_filename> {[members <mslist> all]}
Description	This command will upload a configuration file to a TFTP server from a specified member of a SIM group.
Parameters	<p><i>configuration_to_tftp</i> – Specify this parameter if the user wishes to upload a switch configuration to members of a SIM group.</p> <p><i>log_to_tftp</i> – Specify this parameter to download a switch log to members of a SIM group.</p> <p><i><ipaddr></i> – Enter the IP address of the TFTP server to upload a configuration file to.</p> <p><i><path_filename></i> – Enter a user-defined path and file name on the TFTP server to which to upload configuration files.</p> <p><i>members</i> – Enter this parameter to specify the members the user prefers to upload switch configuration or log files to. The user may specify a member or members by adding one of the following:</p> <ul style="list-style-type: none"> <i><mslist></i> – Enter a value, or values to specify which members of the SIM group will receive the switch configuration or log files. <i>all</i> – Add this parameter to specify all members of the SIM group will receive the switch configuration or log files.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To upload configuration files to a TFTP server:

```
DGS-3627:admin# upload sim_ms configuration 10.55.47.1 D:\configuration.txt 1  
Command: upload sim_ms configuration 10.55.47.1 D:\configuration.txt 1
```

Success.

```
DGS-3627:admin#
```

D-LINK UNIDIRECTIONAL LINK DETECTION (DULD) COMMANDS

The unidirectional link detection referred in this document provides a mechanism that can be used to detect unidirectional link for Ethernet switches. This function is established based on OAM, so OAM should be enabled before starting detection.

The D-Link Unidirectional Link Detection (DULD) Resolver commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config duld ports	[<portlist> all] {state [enable disable] mode [shutdown normal] discovery_time <sec 5-65535>}(1)
show duld ports	{<portlist>}

Each command is listed, in detail, in the following sections.

config duld ports

Purpose	Used to configure unidirectional link detection on port
Syntax	config duld ports [<portlist> all] {state [enable disable] mode [shutdown normal] discovery_time <sec 5-65535>}(1)
Description	The command used to configure unidirectional link detection on ports. Unidirectional link detection provides discovery mechanism based on 802.3ah to discovery its neighbor. If the OAM discovery can complete in configured discovery time, it concludes the link is bidirectional. Otherwise, it starts detecting task to detect the link status.
Parameters	<p><portlist> - Specify a range of ports.</p> <p>state - Specifies these ports unidirectional link detection status. The default state is disabled.</p> <p>mode - See below:</p> <ul style="list-style-type: none"> shutdown - If any unidirectional link is detected, disable the port and log an event. normal - Only log an event when a unidirectional link is detected. <p>discovery_time - Specifies these ports neighbor discovery time. If the discovery is timeout, the unidirectional link detection will start. The default discovery time is 5 seconds.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable unidirectional link detection on port 1:

```
DGS-3627:admin# config duld ports 1 state enable
Commands: config duld ports 1 state enable

Success

DGS-3627:admin#
```


show duld

Purpose	Used to show unidirectional link detection information
Syntax	show duld ports {<portlist>}
Description	<p>The command used to show ports unidirectional link information including:</p> <p>Admin state: port's unidirectional link detection configuration state.</p> <p>Discovery Time: the neighbor discovery timer.</p> <p>Link Status: port's link detection result. It maybe</p> <p>Unknown: either local or remote do not support OAM or unidirectional detection.</p> <p>Bidirectional</p> <p>TX Fault</p> <p>RX Fault</p> <p>Link Down</p> <p>Oper Status: indicates the detection is operational or not.</p> <p>Enabled: the port supports OAM and unidirectional detection and discover remote peer supporting this detection capability.</p> <p>Disabled: either local or remote do not support OAM or unidirectional detection.</p> <p>So we should enable OAM when we need to detect the unidirectional link.</p>
Parameters	<p><portlist> - Specify a range of ports to display.</p> <p>If no port specified, all ports will be displayed.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show ports 1-4 unidirectional link detection information:

```
DGS-3627:admin# config duld ports 1,2,4 state enable
Commands: config duld ports 1,2,4 state enable

Success

DGS-3627:admin# show duld ports 1-4
Commands: show duld ports 1-4
```

port	Admin State	Oper Status	Mode	Link Status	Discovery Time(Sec)
1	Enabled	Enabled	Shutdown	Bidirectional	5
2	Enabled	Enabled	Normal	RX Fault	5
3	Enabled	Enabled	Normal	TX Fault	5
4	Disabled	Disabled	Normal	Unknown	5
5	Enabled	Enabled	Normal	Link Down	5

```
DGS-3627:admin#
```

DOMAIN NAME SERVER (DNS) RELAY COMMANDS

The Domain Name Server (DNS) relay commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config dnsr	[[primary secondary] nameserver <ipaddr> [add delete] static <domain_name 32> <ipaddr>]
enable dnsr	{[cache static]}
disable dnsr	{[cache static]}
show dnsr	{static}

Each command is listed, in detail, in the following sections.

config dnsr

Purpose	Used to configure the DNS relay function.
Syntax	config dnsr [[primary secondary] nameserver <ipaddr> [add delete] static <domain_name 32> <ipaddr>]
Description	This command is used to configure the DNS relay function on the Switch.
Parameters	<p><i>primary</i> – Indicates that the IP address below is the address of the primary DNS server.</p> <p><i>secondary</i> – Indicates that the IP address below is the address of the secondary DNS server.</p> <p><i>nameserver <ipaddr></i> – The IP address of the DNS nameserver.</p> <p><i>[add delete]</i> – Indicates whether to add or delete the DNS relay function.</p> <p><i><domain_name 32></i> – The domain name of the entry.</p> <p><i><ipaddr></i> – The IP address of the entry.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set IP address 10.43.21.12 of primary.

```
DGS-3627:admin# config dnsr primary nameserver 10.43.21.12
Command: config dnsr primary nameserver 10.43.21.12
```

Success

```
DGS-3627:admin#
```

Example usage:

To add an entry domain name dns1, IP address 10.43.21.12 to DNS static table:

```
DGS-3627:admin# config dnsr add static dns1 10.43.21.12
Command: config dnsr add static dns1 10.43.21.12

Success.

DGS-3627:admin#
```

Example usage:

To delete an entry domain name dns1, IP address 10.43.21.12 from DNS static table.

```
DGS-3627:admin# config dnsr delete static dns1 10.43.21.12
Command: config dnsr delete static dns1 10.43.21.12

Success.

DGS-3627:admin#
```

enable dnsr

Purpose	Used to enable DNS relay.
Syntax	enable dnsr {[cache static]}
Description	This command is used, in combination with the disable dnsr command below, to enable and disable DNS Relay on the Switch.
Parameters	<i>cache</i> – This parameter will allow the user to enable the cache lookup for the DNS rely on the Switch. <i>static</i> – This parameter will allow the user to enable the static table lookup for the DNS rely on the Switch.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable status of DNS relay:

```
DGS-3627:admin# enable dnsr
Command: enable dnsr

Success.

DGS-3627:admin#
```

Example usage:

To enable cache lookup for DNS relay.

```
DGS-3627:admin# enable dnsr cache
Command: enable dnsr cache

Success.

DGS-3627:admin#
```

Example usage:

To enable static table lookup for DNS relay.

```
DGS-3627:admin# enable dnsr static
Command: enable dnsr static

Success.

DGS-3627:admin#
```

disable dnsr

Purpose	Used to disable DNS relay on the Switch.
Syntax	disable dnsr {[cache static]}
Description	This command is used, in combination with the enable dnsr command above, to enable and disable DNS Relay on the Switch.
Parameters	<i>cache</i> – This parameter will allow the user to disable the cache lookup for the DNS relay on the Switch. <i>static</i> – This parameter will allow the user to disable the static table lookup for the DNS relay on the Switch.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable status of DNS relay.

```
DGS-3627:admin# disable dnsr
Command: disable dnsr

Success.

DGS-3627:admin#
```

Example usage:

To disable cache lookup for DNS relay.

```
DGS-3627:admin# disable dnsr cache
Command: disable dnsr cache

Success.

DGS-3627:admin#
```

Example usage:

To disable static table lookup for DNS relay.

```
DGS-3627:admin# disable dnsr static
Command: disable dnsr static

Success.

DGS-3627:admin#
```

show dnsr

Purpose	Used to display the current DNS relay status.
Syntax	show dnsr {static}
Description	This command is used to display the current DNS relay status.
Parameters	<i>static</i> – Allows the display of only the static entries into the DNS relay table. If this parameter is omitted, the entire DNS relay table will be displayed.
Restrictions	None.

Example usage:

To display DNS relay status:

```
DGS-3627:admin# show dnsr
Command: show dnsr
DNSR Status           : Disabled
Primary Name Server   : 0.0.0.0
Secondary Name Server : 0.0.0.0
DNSR Cache Status     : Disabled
DNSR Static Table Status : Disabled

DNS Relay Static Table

Domain Name           IP Address
-----
www.123.com.tw       10.12.12.123

Total Entries: 1

DGS-3627:admin#
```

DOMAIN NAME SYSTEM (DNS) RESOLVER COMMANDS

The DNS Resolver provides a solution to translate the domain name to IP address for the application on the switch itself.

The Domain Name System (DNS) Resolver commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config name_server	[[add delete] <ipaddr> {primary} timeout <second 1-60>]
show name_server	
create host_name	<name 255> <ipaddr>
delete host_name	[<name 255> all]
show host_name	{static dynamic}
enable dns_resolver	
disable dns_resolver	

Each command is listed, in detail, in the following sections.

config name_server

Purpose	Used to configure the DNS Resolver name server of the switch.
Syntax	config name_server [[add delete] <ipaddr> {primary} timeout <second 1-60>]
Description	<p>The config name_server command is used to configure the DNS Resolver name server of the switch. Note that only when add a name server, the parameter “primary” will be resolved. Other conditions won’t resolve the parameter “primary”. It means that when delete a name server, just check the IP address. If the IP address is the same to the name server’s, the name server will be deleted, don’t check the priority parameter.</p> <p>When adding a name server, if one primary name server exists in the static name server table, then add a new primary name server, the existing primary name server will be changed to a normal name server. If the added primary name server’s IP address is the same to an existed normal name server’s IP address, the existing normal name server will be changed to a primary name server, but won’t add new name server. When no primary name server is specified, the first configured name server will auto change to primary name server.. If the deleted name server’s IP address equals to one of the existing name servers’ IP addresses, regardless whether a normal name server or primary name server, the name server will be deleted.</p>
Parameters	<p><i>add</i> - Add DNS Resolver name server</p> <p><i>delete</i> - Delete DNS Resolver name server</p> <p><i>ipaddr</i> - The DNS Resolver name server IP address</p> <p><i>timeout</i> - The maximum time waiting for a response from a specified name server.</p> <p><i>primary</i> - Specify the name server is a primary name server.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To add DNS Resolver primary name server 10.10.10.10:

```
DGS-3627:admin# config name_server add 10.10.10.10 primary
Command: config name_server add 10.10.10.10 primary

Success.

DGS-3627:admin#
```

To delete DNS Resolver name server 10.10.10.1:

```
DGS-3627:admin# config name_server delete 10.10.10.10
Command: config name_server delete 10.10.10.10

Success.

DGS-3627:admin#
```

To configure DNS Resolver name server time out to 10 seconds:

```
DGS-3627:admin# config name_server timeout 10
Command: config name_server timeout 10

Success.

DGS-3627:admin#
```

show name_server

Purpose	Used to display the current DNS Resolver name servers and name server time out on the switch.
Syntax	show name_server
Description	The show name_server command is used to display the current DNS Resolver name servers and name server time out on the switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the current DNS Resolver name servers and name server time out:

```
DGS-3627:admin# show name_server
```

```
Command: show name_server
```

```
Name Server Timeout: 3 seconds
```

```
Static Name Server Table:
```

```
Server IP Address      Priority
-----
20.20.20.20           Secondary
10.1.1.1              Primary
```

```
Dynamic Name Server Table:
```

```
Server IP Address      Priority
-----
10.48.74.122         Primary
```

```
DGS-3627:admin#
```

create host_name

Purpose	Used to create the static host name entry of the switch.
Syntax	create host_name <name 255> <ipaddr>
Description	The create host name command is used to create the static host name entry of the switch. If the created host name entry exists in the dynamic host name table, the existing dynamic host name entry will be deleted, and then add the created host name entry is added into the static host name table and a log for duplicate is recorded.
Parameters	<name 255> - The host's host name <ipaddr> - The host's IP address
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create static host name "www.example.com":

```
DGS-3627:admin# create host_name www.example.com 10.10.10.10
```

```
Command: create host_name www.example.com 10.10.10.10
```

```
Success.
```

```
DGS-3627:admin#
```

delete host_name

Purpose	Used to delete the static or dynamic host name entries of the switch.
Syntax	delete host_name [<name 255> all]
Description	The delete host_name command is used to delete the static or dynamic host name entries of the switch.
Parameters	<name 255> - The host's host name. all - All of the static and dynamic host name entries.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the static host name entry “www.example.com”:

```
DGS-3627:admin# delete host_name www.example.com
Command: delete host_name www.example.com

Success.

DGS-3627:admin#
```

show host_name

Purpose	Used to display the current host name.
Syntax	show host_name {static dynamic}
Description	The show host_name command is used to display the current host name entries. If the parameters for “static” and “dynamic” are not specified, both static and dynamic host name entries will be displayed.
Parameters	<i>static</i> - Display the static host name entries <i>dynamic</i> - Display the dynamic host name entries
Restrictions	None.

Example usage:

To display the static and dynamic host name entries:

```
DGS-3627:admin# show host_name
Command: show host_name

Static Host Name Table
Host Name                IP Address
-----
www.example.com          10.10.10.10
www.exampla.com          20.20.20.20

Total Static Entries: 2

Dynamic Host Name Table
Host Name                IP Address      TTL
-----
www.examplc.com          30.30.30.30     60 minutes
www.exampld.com          40.40.40.40     10 minutes

Total Dynamic Entries: 2

DGS-3627:admin#
```

enable dns_resolver

Purpose	Used to configure the DNS Resolver state of the switch to enabled.
Syntax	enable dns_resolver
Description	The enable dns_resolver command is used to configure the switch’s DNS Resolver state.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the DNS Resolver state to enabled:

```
DGS-3627:admin# enable dns_resolver
Command: enable dns_resolver

Success.

DGS-3627:admin#
```

disable dns_resolver

Purpose	Used to configure the DNS Resolver state of the switch to disabled.
Syntax	disable dns_resolver
Description	The disable dns_resolver command is used to configure the switch's DNS Resolver state to disabled.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the DNS Resolver state to disabled:

```
DGS-3627:admin# disable dns_resolver
Command: disable dns_resolver

Success.

DGS-3627:admin#
```

DVMRP COMMANDS

The DVMRP commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

DVMRP is a distance-vector multicast routing protocol designed to support the forwarding of multicast datagrams through an inter-network. DVMRP can be summarized as a "broadcast & prune" multicast routing protocol. It builds per-source broadcast trees based upon routing exchanges, then dynamically creates per-source-group multicast delivery trees by pruning the source's truncated broadcast tree. It performs Reverse Path Forwarding checks to determine when multicast traffic should be forwarded to downstream interfaces. In this way, source-rooted shortest path trees can be formed to reach all group members from each source network of multicast traffic.

Command	Parameters
config dvmrp	[ipif <ipif_name 12> all] {metric <value 1-31> probe <sec 1-65535> neighbor_timeout <sec 1-65535> state [enable disable]}
enable dvmrp	
disable dvmrp	
show dvmrp neighbor	{ipif <ipif_name 12> ipaddress <network_address>}
show dvmrp nexthop	{ipaddress <network_address> ipif <ipif_name 12>}
show dvmrp routing_table	{ipaddress <network_address>}
show dvmrp	{ipif <ipif_name 12>}

Each command is listed, in detail, in the following sections.

config dvmrp

Purpose	Used to configure DVMRP on the Switch.
Syntax	config dvmrp [ipif <ipif_name 12> all] {metric <value 1-31> probe <sec 1-65535> neighbor_timeout <sec 1-65535> state [enable disable]}
Description	This command is used to configure DVMRP on the Switch.
Parameters	<p><i>ipif <ipif_name 12></i> – The name of the IP interface for which DVMRP is to be configured.</p> <p><i>all</i> – Specifies that DVMRP is to be configured for all IP interfaces on the Switch.</p> <p><i>metric <value 1-31></i> – Allows the assignment of a DVMRP route cost to the above IP interface. A DVMRP route cost is a relative number that represents the real cost of using this route in the construction of a multicast delivery tree. It is similar to, but not defined as, the hop count in RIP. The default is 1.</p> <p><i>probe <second 1-65535></i> – DVMRP defined an extension to IGMP that allows routers to query other routers to determine if a DVMRP neighbor is present on a given subnetwork or not. This is referred to as a 'probe'. This entry will set an intermittent probe (in seconds) on the device that will transmit dvmrp messages, depending on the time specified. This probe is also used to "keep alive" the connection between DVMRP enabled devices. The default value is 10 seconds.</p> <p><i>neighbor_timeout <second 1-65535></i> – The time period for which DVMRP will hold Neighbor Router reports before issuing poison route messages. The default value is 35 seconds.</p> <p><i>state [enable disable]</i> – Allows DVMRP to be enabled or disabled.</p>

config dvmrp

Restrictions	Only Administrator and Operator-level users can issue this command.
--------------	---

Example usage:

To configure DVMRP configurations of IP interface "System":

```
DGS-3627:admin# config dvmrp ipif System neighbor_timeout 30 metric 1 probe 5
Command: config dvmrp ipif System neighbor_timeout 30 metric 1 probe 5

Success

DGS-3627:admin#
```

enable dvmrp

Purpose	Used to enable DVMRP.
Syntax	enable dvmrp
Description	This command, in combination with the disable dvmrp command below, is used to enable and disable DVMRP on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable DVMRP:

```
DGS-3627:admin# enable dvmrp
Command: enable dvmrp

Success.

DGS-3627:admin#
```

disable dvmrp

Purpose	Used to disable DVMRP.
Syntax	disable dvmrp
Description	This command is used, in combination with the enable dvmrp command above, is used to enable and disable DVMRP on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable DVMRP:

```
DGS-3627:admin# disable dvmrp
Command: disable dvmrp

Success.

DGS-3627:admin#
```

show dvmrp routing_table

Purpose	Used to display the current DVMRP routing table.
Syntax	show dvmrp routing table {ipaddress <network_address>}
Description	The command is used to display the current DVMRP routing table.
Parameters	<i>ipaddress <network_address></i> – The IP address and netmask of the destination. The address and mask information can be specified using the traditional format (for example, 10.1.2.3/255.0.0.0 or in CIDR format, 10.1.2.3/8).
Restrictions	None.

Example usage:

To display DVMRP routing table:

```
DGS-3627:admin# show dvmrp routing_table
Command: show dvmrp routing_table

DVMRP Routing Table
Source Address/Netmask Upstream Neighbor Metric Learned Interface Expire
-----
10.0.0.0/8 10.90.90.90 1 Local System -
20.0.0.0/8 20.1.1.1 2 Dynamic ip2 117
30.0.0.0/8 30.1.1.1 2 Dynamic ip3 106

Total Entries: 3

DGS-3627:admin#
```

show dvmrp neighbor

Purpose	Used to display the DVMRP neighbor table.
Syntax	show dvmrp neighbor {ipif <ipif_name 12> ipaddress <network_address>}
Description	This command will display the current DVMRP neighbor table.
Parameters	<i><ipif_name 12></i> – The name of the IP interface for which to display the DVMRP neighbor table. <i>ipaddress <network_address></i> – The IP address and netmask of the destination. The address and mask information can be specified using the traditional format (for example, 10.1.2.3/255.0.0.0 or in CIDR format, 10.1.2.3/8).
Restrictions	None.

Example usage:

To display DVMRP neighbor table:

```
DGS-3627:admin# show dvmrp neighbor
```

```
Command: show dvmrp neighbor
```

DVMRP Neighbor Address Table

Interface	Neighbor Address	Generation ID	Expire Time
System	10.2.1.123	2	35

Total Entries: 1

```
DGS-3627:admin#
```

show dvmrp nexthop

Purpose	Used to display the current DVMRP routing next hop table.
Syntax	show dvmrp nexthop {ipaddress <network_address> ipif <ipif_name 12>}
Description	This command will display the DVMRP routing next hop table.
Parameters	<p><ipif_name 12> – The name of the IP interface for which to display the current DVMRP routing next hop table.</p> <p>ipaddress <network_address> – The IP address and netmask of the destination. The address and mask information can be specified using the traditional format (for example, 10.1.2.3/255.0.0.0 or in CIDR format, 10.1.2.3/8).</p>
Restrictions	None.

Example usage:

To display DVMRP routing next hop table:

```
DGS-3627:admin# show dvmrp nexthop
```

```
Command: show dvmrp nexthop
```

DVMRP Routing Next Hop Table

Source Addresss/Netmask	Interface Name	Type
10.0.0.0/8	ip2	Leaf
10.0.0.0/8	ip3	Leaf
20.0.0.0/8	System	Leaf
20.0.0.0/8	ip3	Leaf
30.0.0.0/8	System	Leaf
30.0.0.0/8	ip2	Leaf

Total Entries: 6

```
DGS-3627:admin#
```

show dvmrp

Purpose	Used to display the current DVMRP settings on the Switch.
Syntax	show dvmrp{<ipif_name 12>}
Description	The command will display the current DVMRP configurations.
Parameters	<ipif_name 12> – This parameter will allow the user to display DVMRP settings for a specific IP interface.

show dvmrp

Restrictions None.

Example usage:

To show DVMRP configurations:

```
DGS-3627:admin# show dvmrp
```

```
Command: show dvmrp
```

```
DVMRP Global State : Disabled
```

Interface	IP Address	Neighbor Timeout	Probe	Metric	State
System	10.90.90.90/8	35	10	1	Disabled
Zira	12.1.1.1/8	35	10	1	Enabled

```
Total Entries: 2
```

```
DGS-3627:admin#
```

ETHERNET RING PROTECTION SWITCHING (ERPS) COMMANDS

ITU-T G.8032 Ethernet Ring protection switching (ERPS) is used to provide a reliable mechanism of malfunction recovery in an Ethernet ring topology network.

The Ethernet Ring Protection Switching (ERPS) Resolver commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
enable erps	
disable erps	
create erps raps_vlan	<vlanid>
delete erps raps_vlan	<vlanid>
config erps raps_vlan	<vlanid> ring mel <value 0-7>
config erps raps_vlan	<vlanid> ring_port [west [<port> virtual_channel] east [<port> virtual_channel]]
config erps raps_vlan	<vlanid> [rpl_port [west east none] rpl_owner [enable disable]]
config erps raps_vlan	<vlanid> protected_vlan [add delete] vlanid <vidlist>
config erps raps_vlan	<vlanid> timer {holdoff_time < value 0-10000> guard_time <value 10-2000> wtr_time <min 5-12>} (1)
config erps log	[enable disable]
show erps	{raps_vlan <vlanid> {sub_ring}}
config erps trap	[enable disable]
config erps raps_vlan	<vlanid> state [enable disable]
config erps raps_vlan	<vlanid> [add delete] sub_ring raps_vlan <vlanid>
config erps raps_vlan	<vlanid> sub_ring raps_vlan <vlanid> tc_propagation state [enable disable]

Each command is listed, in detail, in the following sections.

enable erps

Purpose	Used to enable the global ERPS function on a switch.
Syntax	enable erps
Description	<p>This command is used to enable the global ERPS function on a switch. When both the global state and the specified ring ERPS state are enabled, the specified ring will be activated.</p> <p>The global ERPS function cannot be enabled, when any ERPS ring on the device is enabled and the integrity of any ring parameter is not available. For each ring with the ring state enabled when ERPS is enabled, the following integrity will be checked:</p> <p>R-APS VLAN is created.</p> <p>The Ring port is a tagged member port of the R-APS VLAN.</p> <p>The RPL port is specified if the RPL owner is enabled.</p>

enable erps

	The default state is disabled.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable ERPS:

```
DGS-3627:admin# enable erps
Command: enable erps

Success.

DGS-3627:admin#
```

disable erps

Purpose	Used to disable the global ERPS function on a switch.
Syntax	disable erps
Description	This command is used to disable the global ERPS function on a switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable ERPS:

```
DGS-3627:admin# disable erps
Command: disable erps

Success.

DGS-3627:admin#
```

create erps raps_vlan

Purpose	Used to create an R-APS VLAN on a switch.
Syntax	create erps raps_vlan <vlanid>
Description	This command is used to create an R-APS VLAN on a switch. Only one R-APS VLAN should be used to transfer R-APS messages. Note: The R-APS VLAN must already have been created by the create vlan command.
Parameters	<i>raps_vlan</i> - Specifies the VLAN which will be the R-APS VLAN.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create and ERPS R-APS VLAN:

```
DGS-3627:admin# create erps raps_vlan 4094
Command: create erps raps_vlan 4094

Success.

DGS-3627:admin#
```

delete erps raps_vlan

Purpose	Used to delete an R-APS VLAN on a switch.
Syntax	delete erps raps_vlan <vlanid>
Description	This command is used to delete an R-APS VLAN on a switch. When an R-APS VLAN is deleted, all parameters related to this R-APS VLAN will also be deleted. This command can only be issued when the ring is not active.
Parameters	<i>raps_vlan</i> - Specifies the VLAN which will be the R-APS VLAN.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an ERPS R-APS VLAN:

```
DGS-3627:admin# delete erps raps_vlan 4094
Command: delete erps raps_vlan 4094
Success.

DGS-3627:admin#
```

config erps ring_mel

Purpose	Used to configure the MEL of the ERPS ring for a specific R-APS VLAN.
Syntax	config erps raps_vlan <vlanid> ring mel <value 0-7>
Description	This command is used to configure the ring MEL for a R-APS VLAN. The ring MEL is one field in the R-APS PDU. Note: If CFM (Connectivity Fault Management) and ERPS are used at the same time, the R-APS PDU is one of a suite of Ethernet OAM PDU. The behavior for forwarding of R-APS PDU should follow the Ethernet OAM. If the MEL of R-APS PDU is not higher than the level of the MEP with the same VLAN on the ring ports, the R-APS PDU cannot be forwarded on the ring.
Parameters	<i>ring mel</i> - Specifies the ring MEL of the R-APS function. The default ring MEL is 1.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure a MEL of the ERPS ring:

```
DGS-3627:admin# config erps raps_vlan 4094 ring mel 2
Command: config erps raps_vlan 4094 ring mel 2

Success.

DGS-3627:admin#
```

config erps raps_vlan ring_port

Purpose	Used to configure the ports of the ERPS ring for a specific R-APS VLAN.
Syntax	config erps raps_vlan <vlanid> ring_port [west [<port> virtual_channel] east [<port> virtual_channel]]
Description	This command is used to configure the port that participates in the ERPS ring. Restrictions apply for ports that are included in a link aggregation group. A link aggregation group can be configured as a ring port by specifying the master port of the link aggregation port. Only the master port can be specified as a ring port. If the specified link aggregation group is eliminated, the master port retains its ring port status. If the ring port configured on virtual channel, the ring which the port connects to will be considered as a sub-ring. Note: The ring ports cannot be modified when ERPS is enabled.
Parameters	<i>west <port></i> - Specifies the port as the west ring port. <i>virtual_channel</i> - Specifies the port as west port on virtual channel. <i>east <port></i> - Specifies the port as the east ring port. <i>virtual_channel</i> - Specifies the port as east port on virtual channel.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the ports of an ERPS ring for a specific R-APS VLAN:

```
DGS-3627:admin# config erps raps_vlan 4094 ring_port west 5
Command: config erps raps_vlan 4094 ring_port west 5
```

Success.

```
DGS-3627:admin#
```

config erps raps_vlan rpl

Purpose	Used to configure the RPL port or the RPL owner for a specific R-APS VLAN.
Syntax	config erps raps_vlan <vlanid> [rpl_port [west east none] rpl_owner [enable disable]]
Description	This command is used to configure the RPL port and the RPL owner. RPL port: Specifies one of the R-APS VLAN ring ports as the RPL port. To remove an RPL port from an R-APS VLAN, use the none designation for rpl_port. RPL owner: Specifies the node as the RPL owner. Note: The RPL port and RPL owner cannot be modified when ERPS is enabled; and the virtual channel cannot be configured as RPL. For example, if a ring port is configured on the virtual channel and the ring port is configured as an RPL port, an error message will be display and the configuration will fail.
Parameters	<i>port</i> - See below. <i>west</i> - Specifies the west ring port as the RPL port. <i>east</i> - Specifies the east ring port as the RPL port. <i>none</i> - No RPL port on this node. By default, the node has no RPL port. <i>owner</i> - See below. <i>enable</i> - Specifies the device as an RPL owner node. <i>disable</i> - This node is not an RPL owner. By default, the RPS owner is disabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the RPL port or the RPL owner for a specific R-APS VLAN:

```
DGS-3627:admin# config erps raps_vlan 4094 rpl port west owner enable
Command: config erps raps_vlan 4094 rpl port west owner enable

Success.

DGS-3627:admin#
```

config erps raps_vlan protected_vlan

Purpose	Used to configure the protected VLAN for a specific R-APS VLAN.
Syntax	config erps raps_vlan <vlanid> protected_vlan [add delete] vlanid <vidlist>
Description	This command is used to configure the VLANs that are protected by the ERPS function. The R-APS VLAN cannot be the protected VLAN. The protected VLAN can be one that has already been created, or it can be used for a VLAN that has not yet been created.
Parameters	<i>protected_vlan</i> - See below: <i>add</i> - Add VLANs to the protected VLAN group. <i>delete</i> - Delete VLANs from the protected VLAN group.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the protected VLAN for a specific R-APS VLAN:

```
DGS-3627:admin# config erps raps_vlan 4094 protected_vlan add vlanid 10-20
Command: config erps raps_vlan 4094 protected_vlan add vlanid 10-20

Success.

DGS-3627:admin#
```

config erps raps_vlan timer

Purpose	Used to configure the ERPS timers for a specific R-APS VLAN.
Syntax	config erps raps_vlan <vlanid> timer {holdoff_time <value 0-10000> guard_time <value 10-2000> wtr_time <min 5-12>} (1)
Description	This command is used to configure the protocol timers. Holdoff timer: The Holdoff timer is used to filter out intermittent link faults when link failures occur during the protection switching process. When a ring node detects a link failure, it will start the holdoff timer and report the link failure event (R-APS BPDU with SF flag) after the link failure is confirmed within period of time specified. Guard timer: Guard timer is used to prevent ring nodes from receiving outdated R-APS messages. This timer is used during the protection switching process after the link failure recovers. When the link node detects the recovery of the link, it will report the link failure recovery event (R-APS PDU with NR flag) and start the guard timer. Before the guard timer expires, all received R-APS messages are ignored by this ring node, except in the case where a burst of three R-APS event messages that indicates the topology of a sub-ring has changed and the node needs to flush FDB are received on the node. In this case the recovered link does not go into a blocking state. The Guard Timer should be greater than the maximum expected forwarding delay for which one R-APS message circles around the ring. WTR timer: WTR timer is used to prevent frequent operation of the protection switch due to

config erps raps_vlan timer

an intermittent defect. This timer is used during the protection switching process when a link failure recovers. It is only used by the RPL owner. When the RPL owner in protection state receives R-APS PDU with an NR flag, it will start the WTR timer. The RPL owner will block the original unblocked RPL port and start to send R-APS PDU with an RB flag after the link recovery is confirmed within this period of time.

Parameters

holdoff_time - Specifies the holdoff time of the R-APS function. The default holdoff time is 0 milliseconds.

guard_time - Specifies the guard time of the R-APS function. The default guard time is 500 milliseconds.

wtr_time - Specifies the WTR time of the R-APS function. The range is from 5 to 12 minutes. The default WTR time is 5 minutes.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the ERPS timers for a specific R-APS VLAN:

```
DGS-3627:admin# config erps raps_vlan 4094 holdoff_time 100 guard_time 1000 wtr_time 10
Command: config erps raps_vlan 4094 holdoff_time 100 guard_time 1000 wtr_time 10
```

Success.

```
DGS-3627:admin#
```

config erps log

Purpose

Used to configure the ERPS log state.

Syntax

config erps log [enable | disable]

Description

This command is used to configure the log state of ERPS events.

Parameters

log - Enable or disable the log state. The default value is disabled.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the ERPS log state:

```
DGS-3627:admin# config erps log enable
Command: config erps log enable
```

Success.

```
DGS-3627:admin#
```

show erps

Purpose

Used to display ERPS information.

Syntax

show erps {raps_vlan <vlanid> {sub_ring}}

Description

This command is used to display ERPS configuration and operation information.

The port state of the ring port may be as "Forwarding", "Blocking", "Signal Fail". "Forwarding" indicates that traffic is able to be forwarded. "Blocking" indicates that traffic is blocked by ERPS and a signal failure is not detected on the port. "Signal Fail" indicates that a signal

show erps

failure is detected on the port and traffic is blocked by ERPS.

The RPL owner administrative state could be configured to "Enabled" or "Disabled". But the RPL owner operational state may be different from the RPL owner administrative state, for example, the RPL owner conflict occurs. "Active" is used to indicate that the RPL owner administrative state is enabled and the device is operated as the active RPL owner. "Inactive" is used to indicate that the RPL owner administrative state is enabled, but the device is operated as the inactive RPL owner.

Parameters	<i>laps_vlan</i> <vlanid> - Specifies the R-APS VLAN. <i>sub_ring</i> - Display sub-ring configuration information.
Restrictions	None.

Example usage:

To display ERPS information:

```

DGS-3627:admin# show erps
Command: show erps

ERPS Information
Global Status      : Enabled
Log Status         : Disabled
Trap Status       : Disabled
-----
R-APS VLAN        : 4092
Ring Status       : Enabled
West Port         : 5 (Blocking)
East Port         : 7 (Forwarding)
RPL Port         : West Port
RPL Owner         : Enabled (Active)
Protected VLANs   : 100-300, 4093, 4094
Ring MEL          : 2
Holdoff Time      : 0 milliseconds
Guard Time       : 500 milliseconds
WTR Time         : 5 minutes
Current Ring State : Idle
-----
R-APS VLAN        : 4093
Ring Status       : Enabled
West Port         : Virtual Channel
East Port         : 10 (Forwarding)
RPL Port         : None
RPL Owner         : Disabled
Protected VLANs   : 200-220
Ring MEL          : 2
Holdoff Time      : 0 milliseconds
Guard Time       : 500 milliseconds
WTR Time         : 5 minutes
Current Ring State : Idle
-----
R-APS VLAN        : 4094
Ring Status       : Enabled
West Port         : Virtual Channel
East Port         : 12 (Forwarding)
RPL Port         : None
RPL Owner         : Disabled
Protected VLANs   : 250-300
Ring MEL          : 2
Holdoff Time      : 0 milliseconds
Guard Time       : 500 milliseconds
WTR Time         : 5 minutes
Current Ring State : Idle
-----
Total Ring: 3

DGS-3627:admin#

```

config erps trap

Purpose	Used to configure the trap state of the ERPS.
Syntax	config erps trap [enable disable]
Description	This command is used to configure trap state of ERPS events.
Parameters	<i>trap</i> - Enable or disable trap state. The default value is disabled.

config erps trap

Restrictions	Only Administrator and Operator-level users can issue this command.
--------------	---

Example usage:

To configure the trap state of the ERPS:

```
DGS-3627:admin# config erps trap enable
Command: config erps trap enable

Success.

DGS-3627:admin#
```

config erps raps_vlan state

Purpose	Used to configure the state of the specified ring.
Syntax	config erps raps_vlan <vlanid> state [enable disable]
Description	<p>This command is used to configure ring state of the specified ring. When both the global state and the specified ring ERPS state are enabled, the specified ring will be activated. STP and LBD should be disabled on the ring ports before the specified ring is activated.</p> <p>The ring cannot be enabled before the R-APS VLAN is created, and ring ports, RPL port, RPL owner, are configured. Note that these parameters cannot be changed when the ring is activated.</p> <p>In order to guarantee correct operation, the following integrity will be checked when the ring is enabled and the global ERPS state is enabled.</p> <ul style="list-style-type: none"> R-APS VLAN is created. The Ring port is the tagged member port of the R-APS VLAN. The RPL port is specified if RPL owner is enabled. The default state of the ring is disabled.
Parameters	<p><i>state</i> - See below:</p> <ul style="list-style-type: none"> <i>enable</i> - Enable the state of the specified ring. <i>disable</i> - Disable the state of the specified ring. <p>The default value is disabled.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the ring state of the ERPS:

```
DGS-3627:admin# config erps raps_vlan state enable
Command: config erps raps_vlan state enable

Success.

DGS-3627:admin#
```

config erps raps_vlan sub_ring

Purpose	Used to configure a sub-ring connected to another ring.
Syntax	config erps raps_vlan <vlanid> [add delete] sub_ring raps_vlan <vlanid>

config erps raps_vlan sub_ring

Description	This command is used to configure a sub-ring connected to another ring. This command is applied on the interconnection node.
Parameters	<i>raps_vlan</i> <vlanid> - Specifies the R-APS VLAN. <i>add</i> - Connect the sub-ring to another ring. <i>delete</i> - Disconnect the sub-ring from the connected ring.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure a sub-ring connected to another ring:

```
DGS-3627:admin# config erps raps_vlan 4094 add sub_ring raps_vlan 4093
Command: config erps raps_vlan 4094 add sub_ring raps_vlan 4093

Success.

DGS-3627:admin#
```

config erps raps_vlan tc_propagation

Purpose	Used to configure the state of topology change propagation for the sub-ring.
Syntax	config erps raps_vlan <vlanid> sub_ring raps_vlan <vlanid> tc_propagation state [enable disable]
Description	This command is used to configure the state of topology change propagation for the sub-ring. This command is applied on the interconnection node.
Parameters	<i>raps_vlan</i> <vlanid> - Specifies the R-APS VLAN. <i>state</i> - See below: <i>enable</i> - Enable the propagation state of topology change for the sub-ring. <i>disable</i> - Disable the propagation state of topology change for the sub-ring. The default value is disabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the state of topology change propagation:

```
DGS-3627:admin# config erps raps_vlan 4094 sub_ring raps_vlan 4093 tc_propagation state
enable
Command: config erps raps_vlan 4094 sub_ring raps_vlan 4093 tc_propagation state enable

Success.

DGS-3627:admin#
```

FILTER DATABASE (FDB) COMMANDS

This section describes the Filter Database functionality and specifications based on IEEE 802.1d 2001 standard and IEEE 802.1Q-2003 standard. Functions of this software module apply on L2 and L3 Ethernet switches.

The Filter Database (FDB) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create fdb	<vlan_name 32> <macaddr> port <port>
create multicast_fdb	<vlan_name 32> <macaddr>
config multicast_fdb	<vlan_name 32> <macaddr> [add delete] <portlist>
config fdb aging_time	<sec 10-1000000>
config multicast filtering_mode	[<vlan_name 32> all] [forward_all_groups forward_unregistered_groups filter_unregistered_groups]
delete fdb	<vlan_name 32> <macaddr>
clear fdb	[vlan <vlan_name 32> port <port> all]
show multicast_fdb	{[vlan <vlan_name 32> vlanid <vidlist >]} mac_address <macaddr>
show fdb	{port <port> [vlan <vlan_name 32> vlanid <vidlist>] mac_address <macaddr> static aging_time}
show multicast filtering_mode	{vlan <vlan_name 32>}
enable cpu_rx_rate_control	{<class_id 0-2>}
disable cpu_rx_rate_control	{<class_id 0-2>}
show cpu_rx_rate_control	

Each command is listed, in detail, in the following sections.

create fdb

Purpose	Used to create a static entry in the unicast MAC address forwarding table (database).
Syntax	create fdb <vlan_name 32> <macaddr> port <port>
Description	The create fdb command places an entry into the switch's unicast MAC address forwarding database
Parameters	<i>vlan_name</i> - Specifies a VLAN name associated with a MAC address. <i>macaddr</i> - The MAC address to be added to the static forwarding table. <i>port</i> - The port number corresponding to the MAC destination address. The switch will always forward traffic to the specified device through this port.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a unicast MAC forwarding:

```
DGS-3627:admin# create fdb default 00-00-00-00-01-02 port 2:5
Command: create fdb default 00-00-00-00-01-02 port 2:5

Success.

DGS-3627:admin#
```

create multicast_fdb

Purpose	Used to create a static entry in the multicast MAC address forwarding table (database).
Syntax	create multicast_fdb <vlan_name 32> <macaddr>
Description	The create multicast_fdb is used to make an entry in the switch's multicast MAC address forwarding database.
Parameters	<i>vlan_name</i> - The name of the VLAN on which the MAC address resides. The maximum length is 32. <i>macaddr</i> - The multicast MAC address to be added to the static forwarding table.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create multicast MAC forwarding:

```
DGS-3627:admin# create multicast_fdb default 01-00-00-00-00-01
Command: create multicast_fdb default 01-00-00-00-00-01

Success.

DGS-3627:admin#
```

config multicast_fdb

Purpose	Used to configure the switch's multicast MAC address forwarding database.
Syntax	config multicast_fdb <vlan_name 32> <macaddr> [add delete] <portlist>
Description	The config multicast_fdb command is used to configure the multicast MAC address forwarding table.
Parameters	<i>vlan_name</i> - The name of the VLAN on which the MAC address resides. The maximum name length is 32. <i>macaddr</i> - The MAC address that will be added or deleted to the forwarding table. <i>portlist</i> - Specifies a range of ports to be configured. (UnitID: port number).
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To add multicast MAC forwarding:

```
DGS-3627:admin# config multicast_fdb default 01-00-00-00-00-01 add 1:1-1:5
Command: config multicast_fdb default 01-00-00-00-00-01 add 1:1-1:5

Success.

DGS-3627:admin#
```

config fdb aging_time

Purpose	Used to configure the switch's MAC address aging time.
Syntax	config fdb aging_time <sec 10-1000000>
Description	The config fdb aging_time command is used to set the age-out timer for the switch's dynamic unicast MAC address forwarding tables.
Parameters	<i>aging_time</i> - Specifies the time, in seconds, that a dynamically learned MAC address will remain in the switch's MAC address forwarding table, without being accessed, before being dropped from the database. The range of the value is 10 to 1000000.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the MAC address aging time:

```
DGS-3627:admin# config fdb aging_time 300
Command: config fdb aging_time 300

Success.

DGS-3627:admin#
```

config multicast filtering_mode

Purpose	Used to configure the multicast packet filtering mode for VLANs.
Syntax	config multicast filtering_mode [<vlan_name 32> all] [forward_all_groups forward_unregistered_groups filter_unregistered_groups]
Description	The config multicast_fdb command configures the multicast packet filtering mode for VLANs. This switch support vlan filtering mode.
Parameters	<i>vlan_name</i> - Specifies the name of the VLAN. <i>forward_all_groups</i> - All multicast groups forwarded based on VLAN. <i>forward_unregistered_groups</i> - The registered group forwarded based on register table. The un-register group forwarded based on VLAN. <i>filter_unregistered_groups</i> - The registered group forwarded based on register table. The un-register group filtered.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the multicast packet filtering mode for VLANs:

```
DGS-3627:admin# config multicast filtering_mode 200 forward_all_groups
Command: config multicast filtering_mode 200 forward_all_groups
Success.

DGS-3627:admin#
```

delete fdb

Purpose	Used to delete an entry from the switch's forwarding database.
Syntax	delete fdb <vlan_name 32> <macaddr>
Description	The delete fdb deletes a permanent FDB entry.
Parameters	<i>vlan_name</i> - The name of the VLAN on which the MAC address resides. The maximum length is 32 characters. <i>macaddr</i> - The multicast MAC address to be deleted from the static forwarding table.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete a permanent FDB entry:

```
DGS-3627:admin# delete fdb default 00-00-00-00-01-02
Command: delete fdb default 00-00-00-00-01-02

Success.

DGS-3627:admin#
```

clear fdb

Purpose	Used to clear the switch's forwarding database of all dynamically learned MAC addresses.
Syntax	clear fdb [vlan <vlan_name 32> port <port> all]
Description	The clear fdb command clears all dynamically learned MAC addresses from the switch's forwarding database..
Parameters	<i>vlan_name</i> - The name of the VLAN on which the MAC address resides. The maximum length is 32 characters. <i>port</i> - The port number corresponding to the MAC destination address. The switch will always forward traffic to the specified device through this port.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To clear all FDB dynamic entries:

```
DGS-3627:admin# clear fdb all
Command: clear fdb all

Success.

DGS-3627:admin#
```

show multicast_fdb

Purpose	Used to display the contents of the switch's multicast forwarding database.
Syntax	show multicast_fdb {[vlan <vlan_name 32> vlanid <vidlist >]} mac_address <macaddr>}
Description	The show multicast_fdb command displays the entries of the switch's multicast forwarding database.
Parameters	<p><i>vlan_name</i> - The name of the VLAN on which the MAC address resides. The maximum length is 32 characters.</p> <p><i>vlanid</i> - Display the entries for the VLANs indicated by VID list.</p> <p><i>macaddr</i> - Specifies a MAC address, for which FDB entries will be displayed.</p> <p>If no parameter is specified, all multicast FDB entries will be displayed.</p>
Restrictions	None.

Example usage:

To display the multicast MAC address table:

```
DGS-3627:admin# show multicast_fdb
Command: show multicast_fdb

VLAN Name       : default
MAC Address      : 01-00-00-00-00-01
Egress Ports    : 1:1-1:5,1:26,2:26
Mode             : Static

Total Entries : 1
```

show fdb

Purpose	Used to display the current unicast MAC address forwarding database.
Syntax	show fdb { port <port> [vlan <vlan_name 32> vlanid <vidlist>]} mac_address <macaddr> static aging_time }
Description	The show fdb command displays the current unicast MAC address forwarding database.
Parameters	<p><i>port</i> - Displays the entries for one port.</p> <p><i>vlan_name</i> - Displays the entries for a specific VLAN.</p> <p><i>vlanid</i> - Display the entries for the VLANs indicated by VID list.</p> <p><i>static</i> - Displays all permanent entries.</p> <p><i>aging_time</i> - Displays the unicast MAC address aging time.</p> <p>If no parameter is specified, system will display the unicast address table.</p>
Restrictions	None.

Example usage:

To display the FDB table:

DGS-3627:admin# show fdb

Command: show fdb

Unicast MAC Address Aging Time = 300

VID	VLAN Name	MAC Address	Port	Type
1	default	00-00-00-00-00-01	1:25	Dynamic
1	default	00-00-00-00-00-02	1:25	Dynamic
1	default	00-00-00-00-00-03	T1	Static
1	default	00-00-00-00-00-04	T1	Static
1	default	00-00-00-00-00-0A	CPU	Self
1	default	00-00-00-00-00-06	-	Static

Total Entries: 6

DGS-3627:admin#

To display the security FDB table:

DGS-3627:admin# show fdb

Command: show fdb

Unicast MAC Address Aging Time = 300

VID	VLAN Name	MAC Address	Port	Type
1	default	00-00-00-00-01-02	2:5	Permanent
1	default	00-01-02-03-04-00	CPU	Self
2	VLAN_2	00-00-01-02-03-04	-	Permanently Drop
1	default	00-00-00-00-00-07	1:3	Permanent
1	default	00-00-00-00-00-08	1:4	BlockByAddrBind
1	default	00-00-00-00-00-09	1:4	UnblockByAddrBind
1	default	00-00-00-00-00-10	1:5	BlockByMBA
1	default	00-00-00-00-00-11	1:5	UnBlockByMBA
1	default	00-00-00-00-00-12	1:6	BlockBySecurity
1	default	00-00-00-00-00-13	1:6	UnBlockBySecurity
1	default	00-00-00-00-00-14	1:7	JWAC_Authing
1	default	00-00-00-00-10-15	1:7	JWAC_Authed
1	default	00-00-00-00-10-16	1:7	JWAC_Blocked
1	default	00-00-00-00-10-18	1:8	Asymmetric_VLAN
1	default	00-00-00-00-10-19	-	BlackHole
1	default	00-00-00-00-10-21	1:11	Del_on_Reset
1	default	00-00-00-00-10-22	1:12	Del_on_Timeout
1	default	00-00-00-00-10-23	1:13	Secured_Permanent
1	default	00-00-00-00-10-24	1:14	Del_on_Reset
1	default	00-00-00-00-10-25	1:15	SVL

Total Entries: 19

DGS-3627:admin#

show multicast filtering_mode

Purpose	Used to show the multicast packet filtering mode for VLANs.
Syntax	show multicast filtering_mode {vlan <vlan_name 32>}
Description	The show multicast vlan_filtering_mode command show the multicast packet filtering mode for VLAN.

show multicast filtering_mode

Parameters	<i>vlanid</i> - Specifies a list of VLANs to be configured. <i>vlan</i> – Specifies the VLAN name to be configured. If no parameter is specified, the device will show all multicast filtering settings in the device.
Restrictions	None.

Example usage:

To show the multicast `vlan_filtering_mode` for VLANs:

```
DGS-3627:admin# show multicast filtering_mode  
Command: show multicast filtering_mode
```

VLAN Name	Multicast Filter Mode
Sales	forward_all_groups
PM	forward_all_groups
Customer	filter_unregistered_groups

```
DGS-3627:admin#
```


FLASH FILE SYSTEM (FFS) COMMANDS

The Flash File System (FFS) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
show storage_media_info	{{unit <unitid 1-12> all}}
cd	{<pathname 64>}
dir	{{unit [<unitid 1-12> all]} <drive_id>}
rename	{{unit <unit_id 1-12>} <drive_id>} <pathname 64> <filename 64>
erase	{{unit <unit_id 1-12>} <drive_id>} <pathname 64>
copy	{<drive_id>} <pathname 64> {{unit <unit_id 1-12>} <drive_id>} <pathname 64>

Each command is listed, in detail, in the following sections.

show storage_media_info

Purpose	This command is used to display the information of the storage media available on the system.
Syntax	show storage_media_info {{unit <unitid 1-12> all}}
Description	This command is used to display the information of the storage media available on the system. There can be one or multiple media on the system. The information for a media includes the drive number, the media identification.
Parameters	<p><i>unit</i> - (Optional) Specifies a unit ID if in the stacking system. If not specified, it refers to the master unit.</p> <p><i><unitid 1-12></i> - Enter the unit ID here. This value must be between 1 and 12.</p> <p><i>all</i> - Specifies all units.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To display the storage media's information:

```
DGS-3627:admin#show storage_media_info
Command: show storage_media_info

-----
Unit ID is 1
Drive   Media_Type   Size   Label       FS_Type
C:      Flash        15 MB  FLASH-A     FAT16_V2
-----
DGS-3627:admin#
```

cd

Purpose	This command is used to change the current directory.
Syntax	cd {<pathname 64>}
Description	This command is used to change the current directory. The current directory is changed under the current drive. If you want to change the working directory to the directory in another drive, then you need to change the current drive to the desired drive, and then change the current directory. The current drive and current directory will be displayed if the <pathname> is not specified.
Parameters	<pathname 64> - (Optional) Specifies the directory to be removed. The path name can be specified either as a full path name or partial name. For partial path name, it indicates the file is in the current directory. This name can be up to 64 characters long.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To change to other directory or display current directory path:

```
DGS-3627:admin#cd c:\
Command: cd c:\

Change Unit 1 path to c:\

Success.

DGS-3627:admin#
```

dir

Purpose	List all of the files located in a directory of a drive.
Syntax	dir {{unit [<unitid 1-12> all]} <drive_id>}
Description	List all of the files located in a directory of a drive. If pathname is not specified, then all of the files in the specified drive will be displayed. If none of the parameters are specified, the files in the current drive will be displayed.
Parameters	<i>unit</i> - (Optional) Specifies a unit ID if in the stacking system. If not specified, it refers to the master unit. <unit 1-12> - Enter the unit ID here. This value must be between 1 and 12. <i>all</i> - (Optional) Lists all unit located files in stacking system. <drive_id> - Specifies the drive ID used.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

List the files without specified the parameter "all":

```
DGS-3627:admin#dir C:\
Command: dir C:\

-----
Current Unit ID: 1
Current Directory: C:\

File Name                               Size(byte)    Update Time
-----
612.CFG                                 19915 bytes   2010/06/12 14:52
LOG.TXT                                 1835008 bytes 2010/05/11 17:06
R250B51.HAD                             3548272 bytes 2010/04/29 15:51
RUN.HAD                                  (*) 4672664 bytes 2010/06/17 10:38
STARTUP.CFG                             (*) 19166 bytes   2010/06/17 15:30
TESTCFG                                  18329 bytes   2010/05/07 14:09
-----
Total Files                             6
Total Size                               10113354 bytes
Free Space                               5177344 bytes
'*' means boot up section

DGS-3627:admin#
```

List ALL files (include the removed files) by specifies the parameter "all":

```
DGS-3650:admin#dir unit all C:\
Command: dir unit all C:\

-----
Current Unit ID: 1
Current Directory: C:\

File Name                               Size(byte)    Update Time
-----
612.CFG                                 19915 bytes   2010/06/12 14:52
LOG.TXT                                 1835008 bytes 2010/05/11 17:06
R250B51.HAD                             3548272 bytes 2010/04/29 15:51
RUN.HAD                                  (*) 4672664 bytes 2010/06/17 10:38
STARTUP.CFG                             (*) 19166 bytes   2010/06/17 15:30
TESTCFG                                  18329 bytes   2010/05/07 14:09
-----
Total Files                             6
Total Size                               10113354 bytes
Free Space                               5177344 bytes
'*' means boot up section

-----
Current Unit ID: 2
Current Directory: C:\

File Name                               Size(byte)    Update Time
-----
429                                     19866 bytes   2010/04/29 16:05
LOG.TXT                                 1835008 bytes 2010/04/01 14:27
R250B51.HAD                             3548272 bytes 2010/04/29 15:51
RUN.HAD                                  (*) 4672664 bytes 2010/06/17 10:38
STARTUP.CFG                             (*) 19129 bytes   2010/06/17 15:30
-----
```

Total Files	5
Total Size	10094939 bytes
Free Space	4063232 bytes
'*' means boot up section	
DGS-3627:admin#	

rename	
Purpose	This command is used to rename a file.
Syntax	rename {{unit <unit_id 1-12>} <drive_id>} <pathname 64> <filename 64>
Description	This command is used to rename a file. Note that for standalone device, the unit argument is not needed. This command is used to rename a file in the file system. The pathname specifies the file (in path form) to be renamed and the filename specifies the new filename. If the pathname is not a full path, then it refers to a path under the current directory for the drive. The renamed file will stay in the same directory.
Parameters	<i>unit</i> - (Optional) Specifies a unit ID if in the stacking system. If not specified, it refers to the master unit. <unitid 1-12> - Enter the unit ID here. This value must be between 1 and 12. <drive_id> - Specifies the drive ID used. <pathname 64> - Specified the file (in path form) to be renamed. This name can be up to 64 characters long. <filename 64> - Specified the new name of the file. This name can be up to 64 characters long.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To rename a file:

```

DGS-3627:admin#rename run.had run1.had
Command: rename run.had run1.had

Please wait, do not power off!
Process .....Done.

Success.

DGS-3627:admin#
```

erase	
Purpose	This command is used to delete a file stored in the file system.
Syntax	erase {{unit <unit_id 1-12>} <drive_id>} <pathname 64>
Description	System will prompt if the target file is a FW or configuration whose type is boot up or backup.
Parameters	<i>unit</i> - (Optional) Specifies a unit ID if in the stacking system. If not specified, it refers to the master unit. <unit 1-12> - Enter the unit ID here. This value must be between 1 and 12. <drive_id> - Specifies the drive ID used. <pathname 64> - Specifies the file to be deleted. If it is specified in the associated form, then it is related to the current directory. This name can be up to 64 characters long.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To erase a file:

```
DGS-3627:admin#dir C:\
Command: dir C:\

-----
Current Unit ID: 1
Current Directory: C:\

File Name                               Size(byte)    Update Time
-----
612                                     19915 bytes   2010/06/12 14:52
LOG.TXT                                1835008 bytes 2010/05/11 17:06
R250B51.HAD                             3548272 bytes 2010/04/29 15:51
RUN.HAD                                  (*) 4672664 bytes 2010/06/17 10:38
STARTUP.CFG                             (*) 19166 bytes   2010/06/17 15:30
TESTCFG                                  18329 bytes   2010/05/07 14:09
-----

Total Files                             6
Total Size                               10113354 bytes
Free Space                               5177344 bytes
'*' means boot up section

DGS-3627:admin#erase C:\ R250B51.had
Command: erase C:\ R250B51.had

Please wait, do not power off!
Process .....Done.

Success.

DGS-3627:admin#
```

copy

Purpose	This command is used to copy a file to another file in the file system.
Syntax	copy <drive_id> <pathname 64> {{unit <unit_id 1-12>} <drive_id> <pathname 64>
Description	A file located in a drive of a unit can be copied to another file located in another drive of another unit. For project that does not support file system on the flash, the system file such as runtime image/configuration / prom /log can still be copied to media or from media that support sfile system via this command using the reserved keyword. The keyword here refers to image_id, config_id, prom, or log.
Parameters	<drive_id> - Specifies the drive ID used. unit - (Optional) Unit ID in the stacking system. If not specified, it refers to the master unit. <unitid 1-12> - Enter the unit ID here. This value must be between 1 and 12. <pathname 64> - Specifies the file to be copied. The path name can be specified either as a full path name or partial name. For partial path name, it indicates the file is in the current directory. This name can be up to 64 characters long. <pathname 64> - Specifies the file to copy to. The path name can be specified either as a full path name or partial name. For partial path name, it indicates the file is in the current directory. This name can be up to 64 characters long.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To copy a file:

```
DGS-3627:admin#copy C:\ config C:\ test.cfg
Command: copy C:\ config C:\ test.cfg

Please wait, do not power off!
Process .....Done.

Success.

DGS-3627:admin#
```

GRATUITOUS ARP COMMANDS

The Gratuitous ARP commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config gratuitous_arp send ipif_status_up	[enable disable]
config gratuitous_arp send dup_ip_detected	[enable disable]
config gratuitous_arp learning	[enable disable]
config gratuitous_arp send periodically	ipif <ipif_name 12> interval <value 0-65535>
enable gratuitous_arp	{ipif <ipif_name 12>} {trap log}
disable gratuitous_arp	{ipif <ipif_name 12>} {trap log}
show gratuitous_arp	{ipif <ipif_name 12>}

Each command is listed, in detail, in the following sections.

config gratuitous_arp send ipif_status_up

Purpose	Used to enable or disable send gratuitous ARP request while IP interface status become up.
Syntax	config gratuitous_arp send ipif_status_up [enable disable]
Description	The command is used to enable/disable sending of gratuitous ARP request packet while IPIF interface become up. This is used to automatically announce the interface's IP address to other nodes. By default, the state is disabled. After enable this state, one gratuitous ARP packet will be broadcast.
Parameters	<i>enable</i> - Enable sending of gratuitous ARP when IPIF status become up. <i>disable</i> - Disable sending of gratuitous ARP when IPIF status become up.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable send gratuitous ARP request in normal situation:

```
DGS-3627:admin# config gratuitous_arp send ipif_status_up enable
Command: config gratuitous_arp send ipif_status_up enable
```

Success.

```
DGS-3627:admin#
```

config gratuitous_arp send duplicate_ip_detected

Purpose	Used to enable or disable sending of gratuitous ARP request while duplicate IP address is detected.
Syntax	config gratuitous_arp send dup_ip_detected [enable disable]

config gratuitous_arp send duplicate_ip_detected

Description	The command is used to enable/disable sending of gratuitous ARP request packet while duplicate IP is detected. By default, the state is disabled. For this command, the duplicate IP detected means that the system received an ARP request packet that is sent by an IP address that match the system's own IP address. In this case, the system knows that some body out there uses an IP address that is conflict with the system. In order to reclaim the correct host of this IP address, the system can send out the gratuitous ARP request packet for this duplicate IP address.
Parameters	<i>enable</i> - Enable sending of gratuitous ARP when duplicate IP is detected. <i>disable</i> - Disable sending of gratuitous ARP when duplicate IP is detected.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable send gratuitous ARP request when duplicate IP is detected:

```
DGS-3627:admin# config gratuitous_arp send dup_ip_detected enable
Command: config gratuitous_arp send dup_ip_detected enable

Success.

DGS-3627:admin#
```

config gratuitous_arp learning

Purpose	Used to enable or disable learning of ARP entry in ARP cache based on the received gratuitous ARP packet.
Syntax	config gratuitous_arp learning [enable disable]
Description	Normally, the system will only learn the ARP reply packet or a normal ARP request packet that asks for the MAC address that corresponds to the system's IP address. The command is used to enable/disable learning of ARP entry in ARP cache based on the received gratuitous ARP packet. The gratuitous ARP packet is sent by a source IP address that is identical to the IP that the packet is queries for. Note that, with the gratuitous ARP learning, the system will not learn new entry but only do the update on the ARP table based on the received gratuitous ARP packet. By default, the state is disabled.
Parameters	<i>enable</i> - Enable learning of ARP entry based on the received gratuitous ARP packet. <i>disable</i> - Disable learning of ARP entry based on the received gratuitous ARP packet.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable update ARP table when Gratuitous ARP received:

```
DGS-3627:admin# config gratuitous_arp learning enable
Command: config gratuitous_arp learning enable

Success.

DGS-3627:admin#
```

config gratuitous_arp periodical_send

Purpose	Used to configure the interval for periodical sending of gratuitous ARP request packet.
Syntax	config gratuitous_arp send periodically ipif <ipif_name 12> interval <value 0-65535>

config gratuitous_arp periodical_send

Description	The command is used to configure the interval for periodical sending of gratuitous ARP request packet. By default, the interval is 0.
Parameters	<i>ipif <ipif_name 12></i> - Interface name of L3 interface. <i>interval <value 0-65535></i> - Periodically send gratuitous ARP interval time in seconds.0 means not send gratuitous ARP periodically.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure gratuitous ARP interval to 5 for IPIF System:

```
DGS-3627:admin# config gratuitous_arp send periodically ipif System interval 5
Command: config gratuitous_arp send periodically ipif System interval 5

Success.
DGS-3627:admin#
```

enable gratuitous_arp trap

Purpose	Used to enable gratuitous ARP trap and log state.
Syntax	enable gratuitous_arp {ipif <ipif_name 12>} {trap log}
Description	The command is used to enable gratuitous ARP trap and log state. The switch can trap and log the IP conflict event to inform the administrator. By default, trap is disabled and event log is enabled.
Parameters	<i>ipif <ipif_name 12></i> - Interface name of L3 interface <i>trap</i> – Specify to enable traps for gratuitous ARP. <i>log</i> – Specify to enable the log for gratuitous ARP.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable system interface's gratuitous ARP log and trap:

```
DGS-3627:admin# enable gratuitous_arp ipif System trap log
Command: enable gratuitous_arp ipif System trap log

Success.
DGS-3627:admin#
```

disable gratuitous_arp trap

Purpose	Used to disable interface's gratuitous ARP log and trap.
Syntax	disable gratuitous_arp {ipif <ipif_name 12>} {trap log}
Description	The command is used to disable gratuitous ARP trap and log state.
Parameters	<i>ipif <ipif_name 12></i> - Interface name of L3 interface <i>trap</i> – Specify to disable traps for gratuitous ARP. <i>log</i> – Specify to disable the log for gratuitous ARP.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable system interface's gratuitous ARP log and trap:

```
DGS-3627:admin# disable gratuitous_arp ipif System trap log
Command: disable gratuitous_arp ipif System trap log

Success.

DGS-3627:admin#
```

show gratuitous_arp

Purpose	Used to display gratuitous ARP configuration.
Syntax	show gratuitous_arp {ipif <ipif_name 12>}
Description	The show gratuitous_arp command is used to display gratuitous ARP configuration.
Parameters	<i>ipif <ipif_name 12></i> - Interface name of L3 interface.
Restrictions	None.

Example usage:

To display gratuitous ARP configuration:

```
DGS-3627:admin# show gratuitous_arp
Command: show gratuitous_arp

Send on IPIF status up           : Enabled
Send on Duplicate_IP_Detected    : Disabled
Gratuitous ARP Learning          : Enabled

IP Interface Name : System
Gratuitous ARP Trap           : Disabled
Gratuitous ARP Log           : Enabled
Gratuitous ARP Periodical Send Interval : 5

IP Interface Name : ip1
Gratuitous ARP Trap           : Enabled
Gratuitous ARP Log           : Disabled
Gratuitous ARP Periodical Send Interval : 6
Total Entries: 2

DGS-3627:admin#
```

IEEE 802.1Q VLAN COMMANDS

Along with normal VLAN configurations, this Switch now incorporate Double VLANs. Better known as Q-IN-Q VLANs, Double VLANs allow network providers to expand their VLAN configurations to place VLANs within a larger inclusive VLAN, which adds a new layer to the VLAN configuration. This basically lets large ISP's create L2 Virtual Private Networks and also create transparent LANs for their customers, which will connect two or more customer LAN points without over complicating configurations on the client's side. Not only will over-complication be avoided, but now the administrator has over 4000 VLANs in which over 4000 VLANs can be placed, therefore greatly expanding the VLAN network.

Implementation of this feature adds a VLAN frame to an existing VLAN frame for the ISP VLAN recognition and classification. To ensure devices notice this added VLAN frame, an Ethernet encapsulation, here known as a tpid, is also added to the frame. The device recognizes this tpid and therefore checks the VLAN tagged packet to see if a provider VLAN tag has been added. If so, the packet is then routed through this provider VLAN, which contains smaller VLANs with similar configurations to ensure speedy and guaranteed routing destination of the packet.

The IEEE 802.1Q VLAN commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create vlan	<vlan_name 32> {tag <vlanid 2-4094> type 1q_vlan advertisement}
delete vlan	<vlan_name 32>
config vlan	<vlan_name 32> {[add [tagged untagged forbidden] delete] <portlist> advertisement [enable disable]}
config vlan	<vlan_name 32> delete <portlist>
config gvrp	[<portlist> all] {state [enable disable] ingress_checking [enable disable] acceptable_frame [tagged_only admit_all] pvid <vlanid 1-4094>}
enable gvrp	
disable gvrp	
show vlan	{<vlan_name 32> vlanid <vidlist>} ports <portlist>
show gvrp	{<portlist>}
enable double_vlan	
disable double_vlan	
create double_vlan	<vlan_name 32> spvid <vlanid 1-4094> {tpid <hex 0x0-0xffff>}
config double_vlan	<vlan_name> {[add [access uplink] delete] <portlist> tpid <hex 0x0-0xffff>}
delete double_vlan	<vlan_name>
show double_vlan	{<vlan_name>}
enable pvid auto_assign	
disable pvid auto_assign	
show pvid auto_assign	

Each command is listed, in detail, in the following sections.

create vlan

Purpose	Used to create a VLAN on the Switch.
Syntax	create vlan <vlan_name 32> {tag <vlanid 2-4094> type 1q_vlan advertisement}
Description	This command allows the creation of a VLAN on the Switch.
Parameters	<p><i><vlan_name 32></i> – The name of the VLAN to be created.</p> <p><i>tag <vlanid 2-4094></i> – The VLAN ID of the VLAN to be created. Allowed values = 2-4094</p> <p><i>type</i> – This parameter uses the <i>type</i> field of the packet header to determine the packet protocol and destination VLAN:</p> <p><i>1q_vlan</i> – Allows the creation of a normal 802.1Q VLAN on the Switch.</p> <p><i>advertisement</i> – Specifies that the VLAN is able to join GVRP.</p>
Restrictions	Each VLAN name can be up to 32 characters. Only Administrator and Operator-level users can issue this command.

Example usage:

To create a VLAN v1, tag 2:

```
DGS-3627:admin# create vlan v1 tag 2
Command: create vlan v1 tag 2

Success.

DGS-3627:admin#
```

delete vlan

Purpose	Used to delete a previously configured VLAN on the Switch.
Syntax	delete vlan <vlan_name 32>
Description	This command will delete a previously configured VLAN on the Switch.
Parameters	<i><vlan_name 32></i> – The VLAN name of the VLAN to delete.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To remove the VLAN "v1":

```
DGS-3627:admin# delete vlan v1
Command: delete vlan v1

Success.

DGS-3627:admin#
```

config vlan

Purpose	Used to add additional ports to a previously configured VLAN.
Syntax	config vlan <vlan_name 32> {[add [tagged untagged forbidden] delete] <portlist> advertisement [enable disable]}
Description	This command is used to add ports to the port list of a previously configured VLAN. Additional ports may be specified as tagging, untagging, or forbidden. The default is to assign the ports as untagging.
Parameters	<p><i><vlan_name 32></i> – The name of the VLAN to add or delete ports to.</p> <p><i>add</i> – Specifies which ports to add. The user may also specify if the ports are:</p> <ul style="list-style-type: none"> • <i>tagged</i> – Specifies the additional ports as tagged. • <i>untagged</i> – Specifies the additional ports as untagged. • <i>forbidden</i> – Specifies the additional ports as forbidden. <p><i>delete</i> – Specifies which ports to delete.</p> <p><i><portlist></i> – A port or range of ports to add to the VLAN. The beginning and end of the port list range are separated by a dash.</p> <p><i>advertisement [enable disable]</i> – Enables or disables GVRP on the specified VLAN.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To add 4 through 8 as tagged ports to the VLAN v1:

```
DGS-3627:admin# config vlan v1 add tagged 1:4-1:8
```

```
Command: config vlan v1 add tagged 1:4-1:8
```

```
Success.
```

```
DGS-3627:admin#
```

config gvrp

Purpose	Used to configure GVRP on the Switch.
Syntax	config gvrp [<portlist> all] {state [enable disable] ingress_checking [enable disable] acceptable_frame [tagged_only admit_all] pvid <vlanid 1-4094>}
Description	This command is used to configure the GARP VLAN Registration Protocol on the Switch. Configurable settings include ingress checking, the sending and receiving of GVRP information, and the Port VLAN ID (PVID).
Parameters	<p><i><portlist></i> – A port or range of ports for which to configure GVRP. The beginning and end of the port list range are separated by a dash.</p> <p><i>all</i> – Specifies all of the ports on the Switch.</p> <p><i>state [enable disable]</i> – Enables or disables GVRP for the ports specified in the port list.</p> <p><i>ingress_checking [enable disable]</i> – Enables or disables ingress checking for the specified port list.</p> <p><i>acceptable_frame [tagged_only admit_all]</i> – This parameter states the frame type that will be accepted by the Switch for this function. <i>tagged_only</i> implies that only VLAN tagged frames will be accepted, while <i>admit_all</i> implies tagged and untagged frames will be accepted by the Switch.</p> <p><i>pvid</i> – Specifies the default VLAN ID associated with the port.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set the ingress checking status, the sending and receiving GVRP information :

```
DGS-3627:admin# config gvrp 1:1-1:4 state enable ingress_checking enable acceptable_frame
tagged_only pvid 2
Command: config gvrp 1:1-1:4 state enable ingress_checking enable acceptable_frame
tagged_only pvid 2

Success.

DGS-3627:admin#
```



NOTE: When the PVID Auto Assign function is disabled, users must manually configure the PVID for untagged ports or the host may not connect to the Switch correctly.

enable gvrp

Purpose	Used to enable GVRP on the Switch.
Syntax	enable gvrp
Description	This command, along with disable gvrp below, is used to enable and disable GVRP globally on the Switch, without changing the GVRP configuration on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the generic VLAN Registration Protocol (GVRP):

```
DGS-3627:admin# enable gvrp
Command: enable gvrp

Success.

DGS-3627:admin#
```

disable gvrp

Purpose	Used to disable GVRP on the Switch.
Syntax	disable gvrp
Description	This command, along with enable gvrp above, is used to enable and disable GVRP on the Switch, without changing the GVRP configuration on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the Generic VLAN Registration Protocol (GVRP):

```
DGS-3627:admin# disable gvrp
Command: disable gvrp

Success.

DGS-3627:admin#
```

show vlan

Purpose	Used to display the current VLAN configuration on the Switch.
Syntax	show vlan {[<vlan_name 32> vlanid <vidlist>] ports <portlist>}
Description	This command displays summary information about each VLAN including the VLAN ID, VLAN name, the Tagging/Untagging status, and the Member/Non-member/Forbidden status of each port that is a member of the VLAN.
Parameters	<p><vlan_name 32> – The VLAN name of the VLAN for which to display a summary of settings.</p> <p>vlanid <vidlist> – Users may alternately choose the VLAN to be displayed by entering the VLAN ID.</p> <p>ports <portlist> – Users may also view VLANs by designated port.</p>
Restrictions	None.

Example usage:

To display the Switch's current VLAN settings:

```
DGS-3627:admin# show vlan
Command: show vlan

VID          : 1          VLAN Name    : default
VLAN Type    : Static    Advertisement : Enabled
Member Ports : 1:1-1:25
Static Ports : 1:1-1:25
Current Tagged Ports :
Current Untagged Ports: 1:1-1:25
Static Tagged Ports :
Static Untagged Ports : 1:1-1:25
Forbidden Ports :

VID          : 4094       VLAN Name    : v1
VLAN Type    : Static    Advertisement : Disabled
Member Ports : 1:4,1:8
Static Ports : 1:4,1:8
Current Tagged Ports : 1:4,1:8
Current Untagged Ports:
Static Tagged Ports : 1:4,1:8
Static Untagged Ports :
Forbidden Ports :

Total Entries: 2

DGS-3627:admin#
```

show gvrp

Purpose	Used to display the GVRP status for a port list on the Switch.
Syntax	show gvrp {<portlist>}
Description	This command displays the GVRP status for a port list on the Switch.
Parameters	<portlist> – Specifies a range of ports for which the GVRP status is to be displayed. The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex: 1-3,7-9)
Restrictions	None.

Example usage:

To display GVRP port status:

```
DGS-3627:admin# show gvrp
```

```
Command: show gvrp
```

```
Global GVRP : Disabled
```

Port	PVID	GVRP	Ingress Checking	Acceptable Frame Type
1:1	1	Disabled	Enabled	All Frames
1:2	1	Disabled	Enabled	All Frames
1:3	1	Disabled	Enabled	All Frames
1:4	1	Disabled	Enabled	All Frames
1:5	1	Disabled	Enabled	All Frames
1:6	1	Disabled	Enabled	All Frames
1:7	1	Disabled	Enabled	All Frames
1:8	1	Disabled	Enabled	All Frames
1:9	1	Disabled	Enabled	All Frames
1:10	1	Disabled	Enabled	All Frames
1:11	1	Disabled	Enabled	All Frames
1:12	1	Disabled	Enabled	All Frames
1:13	1	Disabled	Enabled	All Frames
1:14	1	Disabled	Enabled	All Frames
1:15	1	Disabled	Enabled	All Frames
1:16	1	Disabled	Enabled	All Frames
1:17	1	Disabled	Enabled	All Frames
1:18	1	Disabled	Enabled	All Frames

```
CTRL+C ESC q Quit SPACE n Next Page Enter Next Entry a All
```

enable double_vlan

Purpose	Used to enable the Double VLAN feature on the Switch.
Syntax	enable double_vlan
Description	This command, along with the disable double_vlan command, enables and disables the Double Tag VLAN. When Double VLANs are enabled, the system configurations for VLANs will return to the default setting, except IP address, log, user accounts and banner setting, in order to enable the Double VLAN mode. In the Double VLAN mode, normal VLANs and GVRP functions are disabled. The Double VLAN default setting is disabled.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the Double VLAN feature on the Switch, thus disabling normal VLANs and GVRP.

```
DGS-3627:admin# enable double_vlan
Command: enable double_vlan
Current Double VLAN mode : Disabled
Enable Double VLAN need to reset system config. Are you sure?(y/n)y

Success.

DGS-3627:admin#
```

disable double_vlan

Purpose	Used to disable the Double VLAN feature on the Switch.
Syntax	disable double_vlan
Description	This command, along with the enable double_vlan command, enables and disables the Double Tag VLAN. When Double VLANs are enabled, the system configurations for VLANs will return to the default setting, except IP address, log, user accounts, and banner setting, in order to enable the Double VLAN mode. In the Double VLAN mode, normal VLANs and GVRP functions are disabled. The Double VLAN default setting is disabled.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the Double VLAN feature on the Switch

```
DGS-3627:admin# disable double_vlan
Command: disable double_vlan
Current Double VLAN mode : Enabled
Disable Double VLAN need to reset system config. Are you sure?(y/n)y

Success.

DGS-3627:admin#
```

create double_vlan

Purpose	Used to create a Double VLAN on the Switch.
Syntax	create double_vlan <vlan_name 32> spvid <vlanid 1-4094> {tpid <hex 0x0-0xffff>}
Description	This command is used to create a Double VLAN (service provider VLAN) on the Switch.
Parameters	<p><i>vlan <vlan_name 32></i> – The name of the Double VLAN to be created. The user is to enter an alphanumeric string of up to 32 characters to identify this VLAN.</p> <p><i>spvid <vlanid 1-4094></i> – The VLAN ID of the service provider VLAN. The user is to identify this VLAN with a number between 1 and 4094.</p> <p><i>tpid <hex 0x0-0xffff></i> – The tag protocol ID. This ID, identified here in hex form, will help identify packets to devices as Double VLAN tagged packets. The default setting is 0x8100.</p>
Restrictions	Only Administrator and Operator-level users can issue this command. Users must have the Switch enabled for Double VLANs.

Example usage:

To create a Double VLAN on the Switch

```
DGS-3627:admin# create double_vlan RG spvid 2 tpid 0x9100
Command: create double_vlan RG spvid 2 tpid 0x9100

Success.

DGS-3627:admin#
```

config double_vlan

Purpose	Used to config the parameters for a previously created Double VLAN on the Switch.
Syntax	config double_vlan <vlan_name> [[[add [access uplink] delete] <portlist> tpid <hex 0x0-0xffff>]]
Description	This command is used to configure a Double VLAN (service provider VLAN) on the Switch.
Parameters	<p><i>vlan <vlan_name 32></i> – The name of the Double VLAN to be configured. The user is to enter an alphanumeric string of up to 32 characters to identify this VLAN.</p> <p><i>add</i> – Specify this parameter to add ports configured in the <i><portlist></i> as one of the two following types of ports.</p> <ul style="list-style-type: none"> <i>uplink</i> – Add this parameter to configure these ports as uplink ports. Uplink ports are for connecting Switch VLANs to the Provider VLANs on a remote source. Only gigabit ports can be configured as uplink ports. <i>access</i> – Add this parameter to configure these ports as access ports. Access ports are for connecting Switch VLANs to customer VLANs. <i>portlist</i> – Enter a list of ports to be added to this VLAN. The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex: 1-3,7-9) <p><i>delete</i> – Specify this parameter to delete ports configured in the <i><portlist></i> from this VLAN.</p> <ul style="list-style-type: none"> <i>portlist</i> – Enter a list of ports to be deleted from this VLAN. The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex: 1-3,7-9) <p><i>tpid <hex 0x0-0xffff></i> – The tag protocol ID. This ID, identified here in hex form, will help identify packets to devices as Double VLAN tagged packets. The default setting is 0x8100.</p>
Restrictions	Only Administrator and Operator-level users can issue this command. Users must have the Switch enabled for Double VLANs.

Example usage:

To add ports 4 through 8 as access ports to the Double VLAN “RG”:

```
DGS-3627:admin# config double_vlan RG add access 1:4-1:8
Command: config double_vlan RG add access 1:4-1:8

Success.

DGS-3627:admin#
```

Example usage:

To delete ports 4 through 8 on the Double VLAN “RG”:

```
DGS-3627:admin# config double_vlan Drazen delete 1:4-1:8
Command: config double_vlan Drazen delete 1:4-1:8

Success.

DGS-3627:admin#
```

show double_vlan

Purpose	Used to display the Double VLAN settings on the Switch.
Syntax	show double_vlan {<vlan_name>}
Description	This command will display the current double VLAN parameters configured on the Switch.
Parameters	<i>vlan_name</i> – Enter the name of a previously created VLAN for which to display the settings.
Restrictions	None.

Example usage:

To display parameters for the Double VLAN “RG”:

```
DGS-3627:admin# show double_vlan RG
Command: show double_vlan RG

Global Double VLAN : Enabled
=====
SPVID      : 2
VLAN Name  : RG
TPID       : 0x9100
Uplink Ports :
Access Ports : 1:4-1:8
Unknow Ports :
-----
Total Entries : 1
DGS-3627:admin#
```

enable pvid auto_assign

Purpose	Used to enable auto assignment of PVID.
Syntax	enable pvid auto_assign
Description	If “Auto-assign PVID” is enabled, PVID will be possibly changed by PVID or VLAN configuration. When a user configures a port to VLAN X’s untagged membership, this port’s PVID will be updated with VLAN X. In the form of VLAN list command, PVID is updated with the last item of the VLAN list. When a user removes a port from the untagged membership of the PVID’s VLAN, the port’s PVID will be assigned with “default VLAN”. The default setting is enabled.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the auto-assign PVID:

```
DGS-3627:admin# enable pvid auto_assign
Command: enable pvid auto_assign

Success.

DGS-3627:admin#
```

disable pvid auto_assign

Purpose	Used to disable auto assignment of PVID.
Syntax	disable pvid auto_assign
Description	If “auto-assign PVID” is disabled, PVID can only be changed by PVID configuration (user changes explicitly). The VLAN configuration will not automatically change PVID. The default setting is enabled.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the auto-assign PVID:

```
DGS-3627:admin# disable pvid auto_assign
Command: disable pvid auto_assign

Success.

DGS-3627:admin#
```

show pvid auto_assign

Purpose	Used to display the PVID auto-assign status.
Syntax	show pvid auto_assign
Description	The show pvid auto_assign command displays the PVID auto assignment state.
Parameters	None.
Restrictions	None.

Example usage:

To display the PVID auto assignment state:

```
DGS-3627:admin# show pvid auto_assign
Command: show pvid auto_assign

PVID Auto-assignment: Enabled

DGS-3627:admin#
```

IEEE 802.1QINQ COMMANDS

QinQ, also known as VLAN stacking, is a powerful, yet simple and cost-effective solution that allows Service Providers to offer IP-based Services, including Metro-Ethernet in scalable implementations. QinQ can also be used to provide multiple virtual connections and access to multiple services available over the Metro (ISPs, ASPs, storage services, etc.)

The IEEE 802.1QinQ commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
enable qinq	
disable qinq	
show qinq	
config qinq ports	[<portlist> all] {role [nni uni] missdrop [enable disable] [outer_ tpid tpid]<hex 0x1 - 0xffff> use_inner_priority [enable disable]}(1)
show qinq ports	{<portlist>}
delete vlan_translation ports	[<portlist> all] { cvid <vidlist>}
show vlan_translation	{[ports <portlist>]}
create vlan_translation ports	[<portlist> all] cvid <vidlist> [add replace] svid <vlanid 1-4094> {priority <value 0-7>}

Each command is listed, in detail, in the following sections.

enable qinq

Purpose	Used to enable QinQ.
Syntax	enable qinq
Description	When QinQ is enabled, all network port roles will be NNI port and outer TPID will be set to 0x88A8; All existed static VLAN will run as S-VLAN; All dynamic learned L2 address will be cleared; All dynamic registered VLAN entries will be cleared, and GVRP will be disabled. If need to run GVRP on the switch, administrator should enable GVRP manually. In QinQ mode, GVRP protocol will employ reserve address 01-80-C2-00-00-0D. The default setting of QinQ is disabled.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable qinq:

```
DGS-3627:admin#enable qinq
Command: enable qinq

Success.

DGS-3627:admin#
```

disable qinq

Purpose	Used to disable the QinQ.
Syntax	disable qinq
Description	When QinQ is disabled, all dynamic learned L2 address will be cleared, all dynamic registered VLAN entries will be cleared, and GVRP will be disabled. If need to run GVRP on the switch, administrator should enable GVRP manually.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable qinq:

```
DGS-3627:admin# disable qinq
Command: disable qinq

Success.

DGS-3627:admin#
```

show qinq

Purpose	Used to show global QinQ status.
Syntax	show qinq
Description	Use this command to display the global QinQ status.
Parameters	None.
Restrictions	None.

Example usage:

To show qinq:

```
DGS-3627:admin# show qinq
Command: show qinq

Qinq Status: Enable

Success.

DGS-3627:admin#
```

config qinq ports

Purpose	Used to configure QinQ ports parameters.
Syntax	config qinq ports [<portlist> all] {role [nni uni] missdrop [enable disable] [outer_tpid tpid]<hex 0x1 - 0xffff> use_inner_priority [enable disable]}(1)
Description	The command used to configure QinQ port parameters, include: Role of a port. Missdrop of a port. Outer-TPID of a port. Use inner-priority of a port.
Parameters	<i>ports</i> - A range of ports to configure. <i>role</i> - Port role in QinQ mode <i>UNI</i> - Port is connecting to customer network. <i>NNI</i> - Port is connecting to service provider network. <i>outer_tpid</i> <i>tpid</i> - Outer-TPID of a port. <i>use_inner_priority</i> - Specify whether to use the priority in the C-VLAN tag as the priority in the S-VLAN tag. By default, the setting is disabled. <i>missdrop</i> - Enable/disable miss drop of port.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To config port list 1-4 as NNI port, set TPID to 0x88A8:

```
DGS-3627:admin# config qinq ports 1-4 role nni outer_tpid 0x88a8
Command: config qinq ports 1-4 role nni outer_tpid 0x88a8

Success.

DGS-3627:admin#
```

show qinq ports

Purpose	Used to show qinq configuration of ports.
Syntax	show qinq ports {<portlist>}
Description	The command used to show qinq configuration of ports, include: Role of port. Outer-TPID of port. Miss drop state of port. Use inner-priority of a port.
Parameters	<i>portlist</i> - Specifies a range of ports to be displayed. (Unit ID: port number). If no parameter specified, system will display all ports information.
Restrictions	None.

Example usage:

To show QinQ mode for ports 1-4 of unit 1:

```
DGS-3627:admin# show qinq ports 1:1-1:4
Command: show qinq ports 1:1-1:4

Port    Role    Missdrop    TPID    Use Inner Priority
-----
1:1     Normal  Disabled    0x8100  Disabled
1:2     Normal  Disabled    0x8100  Disabled
1:3     Normal  Disabled    0x8100  Disabled
1:4     Normal  Disabled    0x8100  Disabled

DGS-3627:admin#
```

delete vlan_translation ports

Purpose	Used to delete existed VLAN translation rules.
Syntax	delete vlan_translation ports [<portlist> all] { cvid <vidlist> }
Description	The delete vlan_translation command is used to delete translation relationship between C-VLAN and S-VLAN.
Parameters	<i>ports</i> - The translation rule for the specified ports. <i>cvid</i> - The rules for the specified CVIDs. If CVID is not specified, all rules configured for the port will be deleted.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete VLAN translation rule on ports 1-4:

```
DGS-3627:admin# delete vlan_translation ports 1-4
Command: delete vlan_translation ports 1-4

Success.

DGS-3627:admin#
```

show vlan_translation

Purpose	Used to show existed C-VLAN based VLAN translation rules.
Syntax	show vlan_translation {[ports <portlist>]}
Description	Used to show existed C-VLAN based VLAN translation rules.
Parameters	<i>ports</i> - The C-VLAN based VLAN translation rule of the ports.
Restrictions	None.

Example usage:

To show C-VLAN based VLAN translation rules in the system:


```
DGS-3627:admin# show vlan_translation
Commands: show vlan_translation
Port      CVID    SVID    Action  Priority
-----  -
1         10     100     Add     4
1         20     100     Add     5
1         30     200     Add     6
2         10     100     Add     7
2         20     100     Add     1

Total Entries: 5

DGS-3627:admin#
```

create vlan_translation ports

Purpose	Use this command to create the CVID VLAN translation rules.
Syntax	create vlan_translation ports [<portlist> all] cvid <vidlist> [add replace] svid <vlanid 1-4094> {priority <value 0-7>}
Description	Use this command to create the CVID VLAN translation rules.
Parameters	<p><i>portlist</i> - A range of ports on which the S-VLAN will be translated to C-VLAN</p> <p><i>add</i> - The action indicates to add a tag for the assigned S-VLAN before the C-VLAN tag.</p> <p><i>replace</i> - The action indicates to replace the C-VLAN tag with the SP VLAN.</p> <p><i>cvid</i> - Specify the C-VLAN ID to match.</p> <p><i>svid</i> - Specify the S-VLAN ID.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To replace C-Tag which CVID is 20 by S-Tag, S-VID is 200, at UNI Port 1:

```
DGS-3627:admin# create vlan_translation ports 1 replace cvid 20 svid 200
Command: create vlan_translation ports 1 replace cvid 20 svid 200

Success.

DGS-3627:admin#
```

To Add S-Tag, S-VID is 300, to a packet which CVID is 30 at UNI Port 1:

```
DGS-3627:admin# create vlan_translation ports 1 add cvid 30 svid 300
Command: create vlan_translation ports 1 add cvid 30 svid 300

Success.

DGS-3627:admin#
```

IGMP AND MLD SNOOPING COMMANDS

The Internet Group Management Protocol (IGMP) is a Layer 4 protocol used to manage the membership of Internet Protocol multicast groups. IGMP is used by IP hosts and adjacent multicast routers to establish multicast group memberships. IGMP snooping, as implied by the name, is a feature that allows a Layer 2 switch to "listen in" on the IGMP conversation between hosts and routers by processing the Layer 4 IGMP packets sent in a multicast network.

The Multicast Listener Discovery (MLD) is protocol used by an IPv6 router to discover the presence of multicast listeners (that is, nodes wishing to receive multicast packets) on its directly attached links, and to discover specifically which multicast addresses are of interest to those neighboring nodes.

Multicast Listener Discovery (MLD) Snooping is an IPv6 function used similarly to IGMP snooping in IPv4. It is used to discover ports on a VLAN that are requesting multicast data. Instead of flooding all ports on a selected VLAN with multicast traffic, MLD snooping will only forward multicast data to ports that wish to receive this data through the use of queries and reports produced by the requesting ports and the source of the multicast traffic.

MLD snooping is accomplished through the examination of the layer 3 part of an MLD control packet transferred between end nodes and a MLD router. When the Switch discovers that this route is requesting multicast traffic, it adds the port directly attached to it into the correct IPv6 multicast table, and begins the process of forwarding multicast traffic to that port. This entry in the multicast routing table records the port, the VLAN ID and the associated multicast IPv6 multicast group address and then considers this port to be a active listening port. The active listening ports are the only ones to receive multicast group data.

MLD Control Messages

Three types of messages are transferred between devices using MLD snooping. These three messages are all defined by three ICMPv6 packet headers, labeled 130, 131 and 132.

- **Multicast Listener Query** – Similar to the IGMPv2 Host Membership Query for IPv4, and labeled as 130 in the ICMPv6 packet header, this message is sent by the router to ask if any link is requesting multicast data. There are three types of MLD query messages emitted by the router. The General Query is used to advertise all multicast addresses that are ready to send multicast data to all listening ports, the Multicast Specific query advertises a specific multicast address that is also ready, and the MLD Query, which is a Multicast Specific-source query used for MLD Snooping version 2. These different types of messages are distinguished by a multicast destination address located in the IPv6 header and a multicast address in the Multicast Listener Query Message. MLDv2 has three types of messages General Query, Multicast Group Specific Query and Multicast Group-and-Source Specific Query.
- **Multicast Listener Report** – Comparable to the Host Membership Report in IGMPv2, and labeled as 131 in the ICMP packet header, this message is sent by the listening port to the Switch stating that it is interested in receiving multicast data from a multicast address in response to the Multicast Listener Query message. MLDv2 introduces the concept of 'Source List' and 'Filtering Mode' therefore its listener report is labeled as 143 in the packet header. There has also been six new filtering report modes added which include; MODE_IS_INCLUDE, MODE_IS_EXCLUDE, CHANGE_TO_INCLUDE, CHANGE_TO_EXCLUDE, ALLOW_NEW and BLOCK_OLD.
- **Multicast Listener Done** – Akin to the Leave Group Message in IGMPv2, and labeled as 132 in the ICMPv6 packet header, this message is sent by the multicast listening port stating that it is no longer interested in receiving multicast data from a specific multicast group address, therefore stating that it is "done" with the multicast data from this address. Once this message is received by the Switch, it will no longer forward multicast traffic from a specific multicast group address to this listening port.

The IGMP and MLD Snooping commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config igmp_snooping	[vlan_name <vlan_name 32> all] {host_timeout <sec 1-16711450> router_timeout <sec 1-16711450> leave_timer <sec 1-16711450> state [enable disable] fast_leave [enable disable] report_suppression [enable disable]}(1)
config igmp_snooping querier	[vlan_name <vlan_name 32> all]{ query_interval <sec 1-65535> max_response_time <sec 1-25> robustness_variable <value 1-255> last_member_query_interval <sec 1-25> state [enable disable]} version <value 1-3> }
config router_ports	<vlan_name 32> [add delete] <portlist>
config router_ports_forbidden	<vlan_name 32> [add delete] <portlist>
enable igmp_snooping	{forward_mrouter_only}
disable igmp_snooping	{forward_mrouter_only}
create igmp_snooping static_group	[vlan<vlan_name 32> vlanid <vlanid_list>] <ipaddr>
delete igmp_snooping static_group	[vlan<vlan_name 32> vlanid <vlanid_list>] <ipaddr>
config igmp_snooping static_group	[vlan <vlan_name 32> vlanid <vlanid_list>] < ipaddr > [add delete] <portlist>
show igmp_snooping static_group	{[vlan <vlan_name 32> vlanid <vlanid_list>] < ipaddr >}
show igmp_snooping	{vlan <vlan_name 32>}
show igmp_snooping group	{vlan <vlan_name 32>}
show igmp_snooping forwarding	{vlan <vlan_name 32>}
show router_ports	{vlan <vlan_name 32>} {static dynamic forbidden}
config mld_snooping	[vlan_name <vlan_name 32> all] {node_timeout <sec 1-16711450> router_timeout <sec 1-16711450> done_timer <sec 1-16711450> state [enable disable] fast_done [enable disable]}(1)
config mld_snooping querier	[vlan_name <vlan_name 32> all] {query_interval <sec 1-65535> max_response_time <sec 1-25> robustness_variable <value 1-255> last_listener_query_interval <sec 1-25> state [enable disable] version <value 1-2> }(1)
config mld_snooping mrouter_ports	vlan <vlan_name 32> [add delete] <portlist>
config mld_snooping mrouter_ports_forbidden	vlan <vlan_name 32> [add delete] <portlist>
enable mld_snooping	{forward_mrouter_only}
disable mld_snooping	{forward_mrouter_only}
show mld_snooping	{vlan <vlan_name 32>}
show mld_snooping group	{vlan <vlan_name 32>}
show mld_snooping forwarding	{[vlan <vlan_name 32> vlanid <vlanid_list>]}
show mld_snooping mrouter_ports	vlan <vlan_name 32> {[static dynamic forbidden]}

Each command is listed, in detail, in the following sections.

config igmp_snooping

Purpose Used to configure IGMP snooping on the switch.

config igmp_snooping

Syntax	config igmp_snooping [vlan_name <vlan_name 32> all] {host_timeout <sec 1-16711450> router_timeout <sec 1-16711450> leave_timer <sec 1-16711450> state [enable disable] fast_leave [enable disable] report_suppression [enable disable]}(1)
Description	The config igmp_snooping command configures IGMP snooping on the switch. Note: A fast leave enabled switch can not be attached to another report suppression enabled switch's downstream interface. That is, if switch A is attached to switch B's downstream interface, you can not enable the fast leave feature on switch A and enable report suppression on switch B simultaneously.
Parameters	<i>vlan_name</i> - Specify the name of the VLAN for which IGMP snooping is to be configured. All indicates all VLANs. <i>host_timeout</i> – Specify the host time-out value here. <i>router_timeout</i> – Specify the router time-out value here. <i>leave_timer</i> – Specify the leave timer value here. <i>state</i> - Enable or disable IGMP snooping for the chosen VLAN. <i>fast_leave</i> - Enable or disable the IGMP snooping fast leave function. If enabled, the membership is immediately removed when the system receives the IGMP leave message. <i>report_suppression</i> - When IGMP report suppression is enabled (the default), the switch sends the first IGMP report from all hosts for a group to all the multicast routers. The switch does not send the remaining IGMP reports for the group to the multicast routers. If the multicast router query includes requests only for IGMPv1 and IGMPv2 reports, the switch forwards only the first IGMPv1 or IGMPv2 report from all hosts for a group to all the multicast routers. If the multicast router query also includes requests for IGMPv3 reports, the switch forwards all IGMPv3 reports for a group to the multicast devices.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure IGMP snooping:

```
DGS-3627:admin# config igmp_snooping vlan default state enable
Command: config igmp_snooping vlan default state enable

Success.

DGS-3627:admin#
```

config igmp_snooping querier

Purpose	Used to configure the time in seconds between general query transmissions, the maximum time in seconds to wait for reports from members, and the permitted packet loss that guarantees IGMP snooping.
Syntax	config igmp_snooping querier [vlan_name <vlan_name 32> all]{ query_interval <sec 1-65535> max_response_time <sec 1-25> robustness_variable <value 1-255> last_member_query_interval <sec 1-25> state [enable disable]} version <value 1-3> }
Description	This command configures the IGMP snooping querier.
Parameters	<i>vlan_name</i> - Specify the name of the VLAN for which IGMP snooping querier is to be configured. <i>query_interval</i> - Specify the amount of time in seconds between general query transmissions. The default setting is 125 seconds. <i>max_reponse_time</i> - Specify the maximum time in seconds to wait for reports from members.

config igmp_snooping querier

The default setting is 10 seconds.

robustness_variable - Provides fine-tuning to allow for expected packet loss on a subnet. The value of the robustness variable is used in calculating the following IGMP message intervals:

Group member interval - Amount of time that must pass before a multicast router decides there are no more members of a group on a network. This interval is calculated as follows: (robustness variable x query interval) + (1 x query response interval).

Other querier present interval - Amount of time that must pass before a multicast router decides that there is no longer another multicast router that is the querier. This interval is calculated as follows: (robustness variable x query interval) + (0.5 x query response interval).

Last member query count - Number of group-specific queries sent before the router assumes there are no local members of a group. The default number is the value of the robustness variable.

By **default**, the robustness variable is set to 2. You might want to increase this value if you expect a subnet to be loosely.

last_member_query_interval - Specify the maximum amount of time between group-specific query messages, including those sent in response to leave-group messages. You might lower this interval to reduce the amount of time it takes a router to detect the loss of the last member of a group.

On receiving a leave message, the router will assume there are no local members on the interface if there are no reports received after the response time (which is last member query interval * robustness variable)

state - If the state is enabled, it allows the switch to be selected as an IGMP Querier (sends IGMP query packets). If the state is disabled, then the switch cannot play the role as a querier.

Note: If the I3 router connected to the switch provide only the IGMP proxy function but does not provide the multicast routing function, then this state must be configured as disabled. Otherwise, if the I3 router is not selected as the querier, it will not send the IGMP query packet. Since it will not send the multicast-routing protocol packet, the port will be timed out as a router port.

version - Specify the version of IGMP packet that will be sent by this port. If an IGMP packet received by the interface has a version higher than the specified version, this packet will be dropped.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the IGMP snooping querier:

```
DGS-3627:admin# config igmp_snooping querier vlan default query_interval 125 state enable
Command: config igmp_snooping querier vlan default query_interval 125 state enable
```

Success.

```
DGS-3627:admin#
```

config router_ports

Purpose Used to configure ports as router ports.

Syntax `config router_ports <vlan_name 32> [add | delete] <portlist>`

Description This command allows you to designate a range of ports as being connected to multicast-enabled routers. This will ensure that all packets with such a router as its destination will reach the multicast-enabled router, regardless of protocol, etc.

config router_ports

Parameters	<i>vlan</i> - Specify the name of the VLAN on which the router port resides. <i>add delete</i> - Specify to add or delete the router ports. <i>portlist</i> - Specify a range of ports to be configured. (UnitID:port number)
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set up static router ports:

```
DGS-3627:admin# config router_ports default add 2:1-2:10
Command: config router_ports default add 2:1-2:10
```

Success.

```
DGS-3627:admin#
```

config router_ports_forbidden

Purpose	Used to configure ports as forbidden router ports.
Syntax	config router_ports_forbidden <vlan_name 32> [add delete] <portlist>
Description	This command allows you to designate a range of ports as being not connected to multicast-enabled routers. This ensures that the forbidden router port will not propagate routing packets out.
Parameters	<i>vlan</i> - Specify the name of the VLAN on which the router port resides. <i>add delete</i> - Specify to add or delete the router ports. <i>portlist</i> - Specify a range of ports to be configured. (UnitID:port number)
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set up port range 1-10 to forbidden router ports of default VLAN:

```
DGS-3627:admin# config router_ports_forbidden default add 1-10
Command: config router_ports_forbidden default add 1-10
```

Success.

```
DGS-3627:admin#
```

enable igmp_snooping

Purpose	Used to enable IGMP snooping on the switch.
Syntax	enable igmp_snooping {forward_mcrouter_only}
Description	This command allows you to enable IGMP snooping on the switch. The <i>forward_mcrouter_only</i> function is disabled by default. The <i>enable igmp_snooping forward_mcrouter_only</i> command will enable the IGMP snooping function and the forward multicast router only function. If forward multicast router only is enabled, the switch will forward all multicast traffic to the multicast router, only. Otherwise, the switch forwards all multicast traffic to any IP router.
Parameters	<i>forward_mcrouter_only</i> - If specified, the switch will learn the router port based on

enable igmp_snooping

identification of the multicast routing protocol packet and IGMP control packet. If not specified, the switch will learn the router port based on identification of the unicast routing protocol packet, the multicast routing protocol packet, and the IGMP control packet. When the switch receives an IGMP report packet from a port, this port will be learned as a member port of the multicast group that the port is reported, and the router will be a default member of this multicast group. The multicast packet destined for this multicast group will be forwarded to all the members of this multicast group.

The identification of a router port will also affect the forwarding of the IGMP control packet. When the switch receives the IGMP report packet from the client member, it will forward the packet to the router port. If the switch receives the IGMP query packet from the router port, it will forward the packet to the client member port. (If the switch itself is the querier, then it will issue the query packet to the client member port.)

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To enable IGMP snooping on the switch:

```
DGS-3627:admin# enable igmp_snooping
```

```
Command: enable igmp_snooping
```

```
Success.
```

```
DGS-3627:admin#
```

disable igmp_snooping

Purpose	Used to disable IGMP snooping on the switch.
Syntax	disable igmp_snooping {forward_mcrouter_only}
Description	This command disables IGMP snooping on the switch. Disabling IGMP snooping allows all IGMP and IP multicast traffic to flood within a given IP interface. Note that disabling IGMP snooping will also disable the forward multicast router only function. The disable mld_snooping forward_mcrouter_only command will only disable the forward multicast router only function.
Parameters	<i>forward_mcrouter_only</i> - If specified, the switch will learn the router port based on identification of the multicast routing protocol packet and IGMP control packet. If not specified, the switch will learn the router port based on identification of the unicast routing protocol packet, the multicast routing protocol packet, and the IGMP control packet. When the switch receives an IGMP report packet from a port, this port will be learned as a member port of the multicast group that the port is reported, and the router will be a default member of this multicast group. The multicast packet destined for this multicast group will be forwarded to all the members of this multicast group. The identification of a router port will also affect the forwarding of the IGMP control packet. When the switch receives the IGMP report packet from the client member, it will forward the packet to the router port. If the switch receives the IGMP query packet from the router port, it will forward the packet to the client member port. (If the switch itself is the querier, then it will issue the query packet to the client member port.)
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable IGMP snooping on the switch:

```
DGS-3627:admin# disable igmp_snooping
```

```
Command: disable igmp_snooping
```

```
Success.
```

```
DGS-3627:admin#
```

create igmp_snooping static_group

Purpose	Used to configure an IGMP snooping multicast static group.
Syntax	create igmp_snooping static_group [vlan<vlan_name 32> vlanid <vlanid_list>] <ipaddr >
Description	<p>This command allows you to create an IGMP snooping static group. Member ports can be added to the static group. The static member and the dynamic member port form the member ports of a group.</p> <p>The static group will only take effect when IGMP snooping is enabled on the VLAN. For those static member ports, the device needs to emulate the IGMP protocol operation to the querier, and forward the traffic destined to the multicast group to the member ports.</p> <p>For a layer 3 device, the device is also responsible to route the packet destined for this specific group to static member ports.</p> <p>The static member port will only affect V2 IGMP operation. The Reserved IP multicast address 224.0.0.X must be excluded from the configured group. The VLAN must be created first before a static group can be created.</p>
Parameters	<p><i>vlan_name</i> - Specify the name of the VLAN on which the router port resides.</p> <p><i>ipaddr</i> - Specify the multicast group IP address (for Layer 3 switch).</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create an IGMP snooping static group for VLAN 1, group 239.1.1.1:

```
DGS-3627:admin# create igmp_snooping static_group vlan vlan1 239.1.1.1
```

```
Command: create igmp_snooping static_group vlan vlan1 239.1.1.1
```

```
Success.
```

```
DGS-3627:admin#
```

delete igmp_snooping static_group

Purpose	Used to delete a IGMP snooping multicast static group.
Syntax	delete igmp_snooping static_group [vlan<vlan_name 32> vlanid <vlanid_list>] <ipaddr>
Description	The deletion of an IGMP snooping static group will not affect the IGMP snooping dynamic member ports for a group.
Parameters	<p><i>vlan</i> - Specify the name of the VLAN on which the router port resides.</p> <p><i>vlanid</i> - Specify the ID of the VLAN on which the router port resides.</p> <p><i>ipaddr</i> - Specify the multicast group IP address (for Layer 3 switch).</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an IGMP snooping static group for VLAN 1, group 239.1.1.1:

```
DGS-3627:admin# delete igmp_snooping static_group vlan vlan1 239.1.1.1
Command: delete igmp_snooping static_group vlan vlan1 239.1.1.1

Success.

DGS-3627:admin#
```

config igmp_snooping static_group

Purpose	Used to configure an IGMP snooping multicast group static member port.
Syntax	config igmp_snooping static_group [vlan <vlan_name 32> vlanid <vlanid_list>] <ipaddr > [add delete] <portlist>
Description	When a port is configured as a static member port, the IGMP protocol will not operate on this port. For example, suppose that a port is a dynamic member port learned by IGMP. If this port is configured as a static member later, then the IGMP protocol will stop operating on this port. The IGMP protocol will resume once this port is removed from static member ports. The static member port will only affect V2 IGMP operation.
Parameters	<i>vlan</i> - Specify the name of the VLAN on which the static group resides. <i>vlanid</i> - Specify the ID of the VLAN on which the static group resides. <i>ipaddr</i> - Specify the multicast group IP address (for Layer 3 switch). <i>add delete</i> - Specify to add or delete the member ports. <i>portlist</i> - Specify a range of ports to be configured.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To unset port range 9-10 from IGMP snooping static member ports for group 239.1.1.1 on default VLAN:

```
DGS-3627:admin# config igmp_snooping static_group vlan default 239.1.1.1 delete 2:9-2:10
Command: create igmp_snooping static_group vlan default 239.1.1.1 delete 2:9-2:10

Success.

DGS-3627:admin#
```

show igmp_snooping static_group

Purpose	Used to display an IGMP Snooping multicast group static member port.
Syntax	show igmp_snooping static_group {[vlan <vlan_name 32> vlanid <vlanid_list>] <ipaddr >}
Description	This command is used to display the IGMP snooping multicast group static members.
Parameters	<i>vlan</i> - Specify the name of the VLAN on which the static group resides. <i>vlanid</i> - Specify the ID of the VLAN on which the static group resides. <i>ipaddr</i> - Specify the multicast group IP address (for Layer 3 switch).
Restrictions	None.

Example usage:

To display all the IGMP snooping static groups:

```
DGS-3627:admin# show igmp_snooping static_group
```

```
Command: show igmp_snooping static_group
```

VLAN ID/Name	IP Address	Static Member Ports
1 / Default	239.1.1.1	2:9-2:10

```
Total Entries : 1
```

```
DGS-3627:admin#
```

To display the IGMP snooping information for the default VLAN:

```
DGS-3627:admin# show igmp_snooping vlan default
```

```
Command: show igmp_snooping vlan default
```

```
IGMP Snooping Global State      : Disabled
Multicast router Only           : Disabled
```

```
VLAN Name                       : default
Query Interval                  : 125
Max Response Time               : 10
Robustness Value                : 2
Last Member Query Interval      : 1
Host Timeout                    : 260
Router Timeout                  : 260
Leave Timer                      : 2
Querier State                   : Disabled
Querier Router Behavior         : Non-Querier
State                           : Disabled
Fast Leave                      : Disabled
Report Suppression              : Disabled
Version                         : 3
```

```
Total Entries: 1
```

```
DGS-3627:admin#
```

show igmp_snooping group

Purpose	Used to display the current IGMP snooping group configuration on the switch.
Syntax	show igmp_snooping group {vlan <vlan_name 32>}
Description	This command displays the current IGMP snooping group configuration on the switch.
Parameters	<i>vlan</i> - Specify the name of the VLAN for which you want to view IGMP snooping group information. If VLAN, ports and IP address are not specified, the system will display all current IGMP snooping group information.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show IGMP snooping groups:

```
DGS-3627:admin# show igmp_snooping group
```

```
Command: show igmp_snooping group
```

```
Source/Group      : 10.0.0.2/225.0.0.2
VLAN Name/VID     : default/1
Port Memer       : 1-2
Mode              : INCLUDE
```

```
Source/Group      : 10.0.0.2/225.0.0.3
VLAN Name/VID     : default/1
Port Memer       : 3
Mode              : EXCLUDE
```

```
Source/Group      : NULL/225.0.0.5
VLAN Name/VID     : default/1
Port Memer       : 4-5
Mode              : EXCLUDE
```

```
Total Entries : 3
```

```
DGS-3627:admin#
```

show igmp_snooping forwarding

Purpose	Used to display the switch's current IGMP snooping forwarding table.
Syntax	show igmp_snooping forwarding {vlan <vlan_name 32>}
Description	This command displays the switch's current IGMP snooping forwarding table. It provides an easy way for users to check the list of ports that the multicast group that comes from a specific sources will be forwarded to. The packet comes from the source VLAN. They will be forwarded to the forwarding VLAN. The IGMP snooping further restricts the forwarding ports.
Parameters	<i>vlan</i> - Specify the name of the VLAN for which you want to view IGMP snooping forwarding table information. If no parameter is specified, the system will display all current IGMP snooping forwarding table entries of the switch.
Restrictions	None.

Example usage:

To show all IGMP snooping forwarding entries located on the switch:

```
DGS-3627:admin# show igmp_snooping forwarding
```

```
Command: show igmp_snooping forwarding
```

```
VLAN Name      : default
Source IP      : 10.90.90.114
Multicast Group: 225.0.0.0
Port Member    : 2,7
```

```
VLAN Name      : default
Source IP      : 10.90.90.10
Multicast Group: 225.0.0.1
Port Member    : 2,5
```

```
VLAN Name      : default
Source IP      : 10.90.90.20
Multicast Group: 225.0.0.2
Port Member    : 2,8
```

```
Total Entries : 3
```

```
DGS-3627:admin#
```

show router_ports

Purpose	Used to display the currently configured router ports on the switch.
Syntax	show router_ports {vlan <vlan_name 32>} {static dynamic forbidden}
Description	This command displays the currently configured router ports on the switch.
Parameters	<p><i>vlan</i> - Specify the name of the VLAN on which the router port resides.</p> <p><i>static</i> - Displays router ports that have been statically configured.</p> <p><i>dynamic</i> - Displays router ports that have been dynamically configured.</p> <p><i>forbidden</i> - Displays forbidden router ports that have been statically configured.</p> <p>If no parameter is specified, the system will display all currently configured router ports on the switch.</p>
Restrictions	None.

Example usage:

To display router ports:

```
DGS-3627:admin# show router_ports
```

```
Command: show router_ports
```

```
VLAN Name           : default
Static Router Port   : 1-10
Dynamic Router Port  :
Forbidden router port :
```

```
VLAN Name           : vlan2
Static router port    :
Dynamic router port   :
Forbidden router port :
```

```
Total Entries : 2
```

```
DGS-3627:admin#
```

config mld_snooping

Purpose	Used to configure MLD snooping on the switch.
Syntax	config mld_snooping [vlan_name <vlan_name 32> vlanid <vlanid_list> all] {node_timeout <sec 1-16711450> router_timeout <sec 1-16711450> done_timer <sec 1-16711450> state [enable disable] fast_done [enable disable]}(1)
Description	This command is used to configure MLD snooping on the switch.
Parameters	<p><i>vlan_name</i> - Specify the name of the VLAN for which MLD snooping is to be configured.</p> <p><i>vlanid</i> - Specify the ID of the VLAN for which MLD snooping is to be configured.</p> <p><i>all</i> - Specify all VLANs for which MLD snooping is to be configured.</p> <p><i>node_timeout</i> – Specify the node time-out value here.</p> <p><i>router_timeout</i> – Specify the router time-out value here.</p> <p><i>done_timer</i> – Specify the done timer here.</p> <p><i>state</i> - Enable or disable MLD snooping for the chosen VLAN.</p> <p><i>fast_done</i> - Enable or disable MLD snooping fast_leave function.</p> <p>If enable, the membership is immediately removed when the system receive the MLD leave message.</p> <p>If the multicast router query includes requests only for MLDv1 reports, the switch forwards only the first MLDv1 report from all hosts for a group to all the multicast routers.</p> <p>If the multicast router query also includes requests for MLDv2 reports, the switch forwards all MLDv2 reports for a group to the multicast devices.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure MLD snooping:

```
DGS-3627:admin# config mld_snooping vlan default state enable
```

```
Command: config mld_snooping vlan default state enable
```

```
Success.
```

```
DGS-3627:admin#
```

config mld_snooping querier

Purpose	Used to configure the time in seconds between general query transmissions, the maximum time in seconds to wait for reports from members, and the permitted packet loss that
---------	---

config mld_snooping querier

	guarantees MLD snooping.
Syntax	config mld_snooping querier [vlan_name <vlan_name 32> all] {query_interval <sec 1-65535> max_response_time <sec 1-25> robustness_variable <value 1-255> last_listener_query_interval <sec 1-25> state [enable disable] version <value 1-2>}(1)
Description	This command configures the timer in seconds between general query transmissions, the maximum time in seconds to wait for reports from listeners, and the permitted packet loss that is guaranteed by MLD snooping.
Parameters	<p><i>vlan_name</i> - Specify the name of the VLAN for which MLD snooping querier is to be configured.</p> <p><i>all</i> - Specify all VLANs for which MLD snooping querier is to be configured.</p> <p><i>query_interval</i> - Specify the amount of time in seconds between general query transmissions. The default setting is 125 seconds..</p> <p><i>max_reponse_time</i> - Specify the maximum time in seconds to wait for reports from listeners. The default setting is 10 seconds.</p> <p><i>robustness_variable</i> - Provides fine-tuning to allow for expected packet loss on a subnet. The value of the robustness variable is used in calculating the following MLD message intervals:</p> <p>Group listener interval - Amount of time that must pass before a multicast router decides there are no more listeners of a group on a network. This interval is calculated as follows: (robustness variable * query interval) + (1 * query response interval).</p> <p>Other querier present interval - Amount of time that must pass before a multicast router decides that there is no longer another multicast router that is the querier. This interval is calculated as follows: (robustness variable * query interval) + (0.5 * query response interval).</p> <p>Last listener query count - Number of group-specific queries sent before the router assumes there are no local listeners of a group. The default number is the value of the robustness variable.</p> <p>By default, the robustness variable is set to 2. You might want to increase this value if you expect a subnet to be loosely.</p> <p><i>last_listener_query_interval</i> - Specify the maximum amount of time between group-specific query messages, including those sent in response to done-group messages. You might lower this interval to reduce the amount of time it takes a router to detect the loss of the last listener of a group.</p> <p><i>state</i> - This allows the switch to be specified as an MLD Querier (sends MLD query packets) or a Non-Querier (does not send MLD query packets). Set to enable or disable.</p> <p><i>version <value 1-2></i> - Specify the version of MLD packet that will be sent by this port. If a MLD packet received by the interface has a version higher than the specified version, this packet will be dropped.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the MLD snooping querier:

```
DGS-3627:admin# config mld_snooping querier vlan default query_interval 125 state enable
Command: config mld_snooping querier vlan default query_interval 125 state enable

Success.

DGS-3627:admin#
```

config mld_snooping mrouter_ports

Purpose	Used to configure ports as router ports.
---------	--

config mld_snooping mrouter_ports

Syntax	config mld_snooping mrouter_ports vlan <vlan_name 32> [add delete] <portlist>
Description	This command allows you to designate a range of ports as being connected to multicast-enabled routers. This will ensure that all packets with such a router as its destination will reach the multicast-enabled router, regardless of protocol, etc.
Parameters	<i>vlan</i> - Specify the name of the VLAN on which the router port resides. <i>add delete</i> - Specify to add or delete the router ports. <i>portlist</i> - Specify a range of ports to be configured. (UnitID:port number)
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set up static router ports:

```
DGS-3627:admin# config mld_snooping mrouter_ports default add 2:1-2:10
Command: config mld_snooping mrouter_ports default add 2:1-2:10
```

Success.

```
DGS-3627:admin#
```

config mld_snooping mrouter_ports_forbidden

Purpose	Used to configure ports as forbidden router ports.
Syntax	config mld_snooping mrouter_ports_forbidden vlan <vlan_name 32> [add delete] <portlist>
Description	This command allows you to designate a range of ports as being not connected to multicast-enabled routers. This ensures that the forbidden router port will not propagate routing packets out.
Parameters	<i>vlan</i> - Specify the name of the VLAN on which the router port resides. <i>add delete</i> - Specify to add or delete the router ports. <i>portlist</i> - Specify a range of ports to be configured. (UnitID:port number)
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set up port range 1-10 to forbidden router ports of the default VLAN:

```
DGS-3627:admin# config mld_snooping mrouter_ports_forbidden default add 1-10
Command: config mld_snooping mrouter_ports_forbidden default add 1-10
```

Success.

```
DGS-3627:admin#
```

enable mld_snooping

Purpose	Used to enable MLD snooping on the switch.
Syntax	enable mld_snooping {forward_mrouter_only}
Description	This command allows you to enable MLD snooping on the switch. The <i>forward_mrouter_only</i> function is disabled by default. The <i>enable mld_snooping</i>

enable mld_snooping

	<p>forward_mcrouter_only command will enable the MLD snooping function and the forward multicast router only function.</p> <p>If forward multicast router only is enabled, the switch will forward all multicast traffic to the multicast router, only. Otherwise, the switch forwards all multicast traffic to any IP router.</p>
Parameters	<p><i>forward_mcrouter_only</i> - If specified, the switch will learn the router port based on identification of the multicast routing protocol packet and MLD control packet.</p> <p>If not specified, the switch will learn the router port based on identification of the unicast routing protocol packet, the multicast routing protocol packet, and the MLD control packet.</p> <p>When the switch receives an MLD report packet from a port, this port will be learned as a member port of the multicast group that the port is reported, and the router will be a default member of this multicast group. The multicast packet destined for this multicast group will be forwarded to all the members of this multicast group.</p> <p>The identification of a router port will also affect the forwarding of the MLD control packet. When the switch receives the MLD report packet from the client member, it will forward the packet to the router port. If the switch receives the MLD query packet from the router port, it will forward the packet to the client member port. (If the switch itself is the querier, then it will issue the query packet to the client member port.)</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable MLD snooping on the switch:

```
DGS-3627:admin# enable mld_snooping
```

```
Command: enable mld_snooping
```

```
Success.
```

```
DGS-3627:admin#
```

disable mld_snooping

Purpose	Used to disable MLD snooping on the switch.
Syntax	disable mld_snooping {forward_mcrouter_only}
Description	<p>This command disables MLD snooping on the switch. Disabling MLD snooping allows all MLD and IP multicast traffic to flood within a given IP interface. Note that disabling MLD snooping will also disable the forward multicast router only function.</p> <p>The disable mld_snooping forward_mcrouter_only command will only disable the forward multicast router only function.</p>
Parameters	<p><i>forward_mcrouter_only</i> - If specified, the switch will learn the router port based on identification of the multicast routing protocol packet and MLD control packet.</p> <p>If not specified, the switch will learn the router port based on identification of the unicast routing protocol packet, the multicast routing protocol packet, and the MLD control packet.</p> <p>When the switch receives an MLD report packet from a port, this port will be learned as a member port of the multicast group that the port is reported, and the router will be a default member of this multicast group. The multicast packet destined for this multicast group will be forwarded to all the members of this multicast group.</p> <p>The identification of a router port will also affect the forwarding of the MLD control packet. When the switch receives the MLD report packet from the client member, it will forward the packet to the router port. If the switch receives the MLD query packet from the router port, it will forward the packet to the client member port. (If the switch itself is the querier, then it will issue the query packet to the client member port.)</p>

disable mld_snooping

Restrictions	Only Administrator and Operator-level users can issue this command.
--------------	---

Example usage:

To disable MLD snooping on the switch:

```
DGS-3627:admin# disable mld_snooping
Command: disable mld_snooping

Success.

DGS-3627:admin#
```

show mld_snooping

Purpose	Used to show the current status of MLD snooping on the switch.
Syntax	show mld_snooping {vlan <vlan_name 32>}
Description	This command will display the current MLD snooping configuration on the switch.
Parameters	<i>vlan</i> - Specify the name of the VLAN for which you want to view the IGMP snooping configuration. If VLAN is not specified, the system will display all current MLD snooping configurations.
Restrictions	None.

Example usage:

To show MLD snooping:

```

DGS-3627:admin# show mld_snooping
Command: show mld_snooping

MLD Snooping Global State           : Disabled
Multicast router Only                : Disabled

VLAN Name                            : default
  Query Interval                     : 125
  Max Response Time                  : 10
  Robustness Value                   : 2
  Last Listener Query Interval       : 1
  Node Timeout                       : 260
  Router Timeout                     : 260
  Done Timer                         : 2
  Querier State                      : Disabled
  Querier Router Behavior            : Non-Querier
  State                             : Enabled
  Fast Done                          : Disabled
  Version                            : 2

VLAN Name                            : 6
  Query Interval                     : 125
  Max Response Time                  : 10
  Robustness Value                   : 2
  Last Listener Query Interval       : 1
  Node Timeout                       : 260
  Router Timeout                     : 260
  Done Timer                         : 2
  Querier State                      : Disabled
  Querier Router Behavior            : Non-Querier
  State                             : Enabled
  Fast Done                          : Disabled
  Version                            : 2

DGS-3627:admin#
    
```

show mld_snooping group

Purpose	Used to display the current MLD snooping group information on the switch.
Syntax	show mld_snooping group {vlan <vlan_name 32>}
Description	This command displays the current MLD snooping group information on the switch.
Parameters	<i>vlan</i> - Specify the name of the VLAN for which you want to view MLD snooping group information. If VLAN and ports and IP address are not specified, the system will display all current IGMP snooping group information.
Restrictions	None.

Example usage:

To show an MLD snooping group:

```

DGS-3627:admin# show mld_snooping group
Command: show mld_snooping group

Source/Group           : 2001::1/FE1E::1
VLAN Name/VID          : default/1
Port Member            : 1-2
Mode                   : INCLUDE

Source/Group           : 2002::2/FE1E::1
VLAN Name/VID          : default/1
Port Member            : 3
Mode                   : EXCLUDE

Source/Group           : NULL/FE1E::2
VLAN Name/VID          : default/1
Port Member            : 4-5
Mode                   : EXCLUDE

Total Entries : 3

DGS-3627:admin#

```

show mld_snooping forwarding

Purpose	This command displays the switch's current MLD snooping forwarding table.
Syntax	show mld_snooping forwarding {[vlan <vlan_name 32> vlanid <vlanid_list>]}
Description	It provides an easy way for users to check the list of ports that the multicast group that comes from specific sources will be forwarded to. The packet comes from the source VLAN. They will be forwarded to the forwarding VLAN. The MLD snooping further restricts the forwarding ports.
Parameters	<p><i>vlan</i> - (Optional) Specify the name of the VLAN for which you want to view MLD snooping forwarding table information.</p> <p><vlan_name 32> - Enter the VLAN name here. The VLAN name can be up to 32 characters long.</p> <p><i>vlanid</i> - (Optional) Specify the ID of the VLAN for which you want to view MLD snooping forwarding table information.</p> <p><vlanid_list> - Enter the VLAN ID list here.</p> <p>If no parameter is specified, the system will display all current MLD snooping forwarding table entries of the switch.</p>
Restrictions	None.

Example usage:

To show all MLD snooping forwarding entries located on the switch:

```
DGS-3627:admin# show mld_snooping forwarding
```

```
Command: show mld_snooping forwarding
```

```
VLAN Name      : default
Source IP      : 2001::1
Multicast Group: FE1E::1
Port Member    : 2,7
```

```
VLAN Name      : default
Source IP      : 2001::2
Multicast Group: FF1E::1
Port Member    : 5
```

```
Total Entries : 2
```

```
DGS-3627:admin#
```

show mld_snooping mrouter_ports

Purpose	Used to display the currently configured router ports on the switch.
Syntax	show mld_snooping mrouter_ports vlan <vlan_name 32> {[static dynamic forbidden]}
Description	This command displays the currently configured router ports on the switch.
Parameters	<p><i>vlan</i> - Specify the name of the VLAN on which the router port resides.</p> <p><i>vlanid</i> - Specify the ID of the VLAN on which the router port resides.</p> <p><i>all</i> - Specify all VLANs on which the router port resides.</p> <p><i>static</i> - Displays router ports that have been statically configured.</p> <p><i>dynamic</i> - Displays router ports that have been dynamically configured.</p> <p><i>forbidden</i> - Displays forbidden router ports that have been statically configured.</p> <p>If no parameter is specified, the system will display all currently configured router ports on the switch.</p>
Restrictions	None.

Example usage:

To display the mld_snooping router ports:

```
DGS-3426P:admin#show mld_snooping mrouter_ports
```

```
Command: show mld_snooping mrouter_ports
```

```
VLAN Name      : default
Static mrouter port :
Dynamic mrouter port : 1-10
Forbidden mrouter port:
```

```
Total Entries: 1
```

```
DGS-3627:admin#
```

INTERNET GROUP MANAGEMENT PROTOCOL (IGMP) COMMANDS

IGMP or Internet Group Management Protocol is a protocol implemented by systems utilizing IPv4 to collect the membership information needed by the multicast routing protocol through various query messages sent out from the router or switch. Computers and network devices that want to receive multicast transmissions need to inform nearby routers that they will become members of a multicast group. The Internet Group Management Protocol (IGMP) is used to communicate this information. IGMP is also used to periodically check the multicast group for members that are no longer active.

In the case where there is more than one multicast router on a subnetwork, one router is elected as the 'querier'. This router then keeps track of the membership of the multicast groups that have active members. The information received from IGMP is then used to determine if multicast packets should be forwarded to a given subnetwork or not. The router can check, using IGMP, to see if there is at least one member of a multicast group on a given subnetwork. If there are no members on a subnetwork, packets will not be forwarded to that subnetwork.

The current release of the Switch now implements IGMPv3. Improvements of IGMPv3 over version 2 include:

- The introduction of the SSM or Source Specific Multicast. In previous versions of IGMP, the host would receive all packets sent to the multicast group. Now, a host will receive packets only from a specific source or sources. This is done through the implementation of include and exclude filters used to accept or deny traffic from these specific sources.
- In IGMPv2, Membership reports could contain only one multicast group whereas in v3, these reports can contain multiple multicast groups.
- Leaving a multicast group could only be accomplished using a specific leave message in v2. In v3, leaving a multicast group is done through a Membership report which includes a block message in the group report packet.
- For version 2, the host could respond to either a group query but in version 3, the host is now capable to answer queries specific to the group and the source.

IGMPv3 is backwards compatible with other versions of IGMP and all IGMP protocols must be used in conjunction with PIM or DVMRP for optimal use.

The Internet Group Management Protocol (IGMP) is used by IPv4 systems (hosts and routers) to report their IP multicast group memberships to any neighboring multicast routers.

Note that an IP multicast router can simultaneously be a member of one or more multicast groups, in which case it performs dual functions as both a multicast router (the "multicast router part" of the protocol, namely to collect the membership information needed by its multicast routing protocol); and as a group member (the "group member part" of the protocol, that is to inform itself and other neighboring multicast routers of its memberships).

The Internet Group Management Protocol (IGMP) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config igmp	[ipif <ipif_name 12> all] { version <value 1-3> query_interval <sec 1-31744> max_response_time <sec 1-25> robustness_variable <value 1-255> last_member_query_interval <value 1-25> state [enable disable]}
show igmp	{ipif <ipif_name 12>}
show igmp group	{group <group>} {ipif <ipif_name 12>}
config igmp check_subscriber_source_network	[ipif <ipif_name 12> all] [enable disable]
show igmp check_subscriber_source_network	{ipif <ipif_name 12>}

Each command is listed, in detail, in the following sections.

config igmp

Purpose	This command is used to configure IGMP on the switch.
Syntax	config igmp [ipif <ipif_name 12> all] { version <value 1-3> query_interval <sec 1-31744> max_response_time <sec 1-25> robustness_variable <value 1-255> last_member_query_interval <value 1-25> state [enable disable]}
Description	The config igmp command is used to configure IGMP on switch.
Parameters	<p><i>ipif_name</i> - The name of the IP interface for which you want to configure IGMP.</p> <p><i>all</i> - Specifies all the IP interfaces on the switch.</p> <p><i>version</i> - IGMP version. The default value is 3.</p> <p><i>query_interval</i> - The time in seconds between general query transmissions. The default value is 125.</p> <p><i>max_response_time</i> - The maximum time in seconds to wait for reports from members. The default value is 10.</p> <p><i>robustness_variable</i> - The permitted packet loss that guarantees IGMP. The default value is 2.</p> <p><i>last_member_query_interval</i> - Max Response Time inserted into Group-Specific Queries sent in response to Leave Group messages, and is also the amount of time between Group-Specific Query messages. The default setting is 1.</p> <p><i>state</i> - Enable or disable IGMP on a router interface.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the IGMP for the IP interface "System":

```
DGS-3627:admin# config igmp ipif System version 1 state enable
Command: config igmp ipif System version 1 state enable
```

Success.

```
DGS-3627:admin#
```

To configure the IGMPv2 for all IP interfaces:

```
DGS-3627:admin# config igmp all version 2
Command: config igmp all version 2

Success.

DGS-3627:admin#
```

show igmp

Purpose	This command is used to display the IGMP configurations.
Syntax	show igmp {ipif <ipif_name 12>}
Description	The show igmp command displays the IGMP configurations.
Parameters	<i>ipif_name</i> - IP interface name. If no parameter specified, the system will display all IGMP configurations.
Restrictions	None.

Example usage:

To display IGMP configurations for all interfaces:

```
DGS-3627:admin# show igmp
Command: show igmp

IGMP Interface Configurations

Interface      IP Address/Netmask  Ver-  Query  Maximum  Robust-  Last  State
                 sion          Time  ness   Value    Member
                 sion          Time  Value    Query
                 sion          Time  Value    Interval
-----
System         10.90.90.90/8       3     125    10       2       1     Disabled

Total Entries: 1

DGS-3627:admin#
```

show igmp group

Purpose	This command is used to display the switch's IGMP group table.
Syntax	show igmp group {group <group>} {ipif <ipif_name 12>}
Description	The show igmp group command displays the switch's IGMP group table.
Parameters	<i>group</i> - The multicast group ID. <i>ipif_name</i> - The name of the IP interface the IGMP group is part of. If no parameter specified, the system will display all IGMP group tables.
Restrictions	None.

Example usage:

To display IGMP group table:

```
DGS-3627:admin# show igmp group
```

```
Command: show igmp group
```

Interface	Multicast Group	Last Reporter	IP Querier	IP Expire
System	224.0.0.2	10.42.73.111	10.48.74.122	260
System	224.0.0.9	10.20.53.1	10.48.74.122	260
System	224.0.1.24	10.18.1.3	10.48.74.122	259
System	224.0.1.41	10.1.43.252	10.48.74.122	259
System	224.0.1.149	10.20.63.11	10.48.74.122	259

```
Total Entries : 5
```

```
DGS-3627:admin#
```

config igmp check_subscriber_source_network

Purpose	Used to configure the flag that determines whether or not to check the subscriber source IP when an IGMP report or leave message is received.
Syntax	config igmp check_subscriber_source_network [ipif <ipif_name 12> all] [enable disable]
Description	When check_subscriber_source_network is enabled on an interface, any IGMP report or leave message received by the interface will be checked to determine whether its source IP is in the same network as the interface. If the check is disabled, the IGMP report or leave message with any source IP will be processed by IGMP protocol.
Parameters	<i>ipif_name</i> - Specifies the IP interface to be configured. <i>all</i> - All IP interfaces will be configured. <i>enable</i> - Enable the check state. The default state is enabled. <i>disable</i> - Disable the check state.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable igmp check_subscriber_source_network state on interface "System":

```
DGS-3627:admin# config igmp check_subscriber_source_network ipif System enable
```

```
Command: config igmp check_subscriber_source_network ipif System enable
```

```
Success.
```

```
DGS-3627:admin#
```

show igmp check_subscriber_source_network

Purpose	Used to display the status of the IGMP report/leave message source IP check.
Syntax	show igmp check_subscriber_source_network { ipif <ipif_name 12> }
Description	Display the IGMP check_subscriber_source_network status for a single interface or all interfaces.
Parameters	<i>ipif_name</i> - Specified the IP interface to be displayed. If no parameter specified, the system will display all interfaces.
Restrictions	None.

Example usage:

To show igmp check_subscriber_source_network state on interface "n20":

```
DGS-3627:admin# show igmp check_subscriber_source_network ipif n20
Command: show igmp check_subscriber_source_network ipif n20

Interface      IP Address/Netmask  Check Subscriber Source Network
-----
n20            20.1.1.1/8         Disabled

Total Entries: 1

DGS-3627:admin#
```

To show igmp check_subscriber_source_network state on all interfaces:

```
DGS-3627:admin# show igmp check_subscriber_source_network
Command: show igmp check_subscriber_source_network

Interface      IP Address/Netmask  Check Subscriber Source Network
-----
System        10.90.90.90/8      Enabled
n1            1.1.1.1/8         Disabled
n11           11.1.1.1/8        Disabled
n20           20.1.1.1/8        Disabled
n100          100.3.2.2/8       Disabled

Total Entries: 5

DGS-3627:admin#
```

IP DIRECTED BROADCAST COMMANDS

The IP Directed Broadcast commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config ipif	<ipif_name 12> [{ipaddress <network_address> vlan <vlan_name 32> state [enable disable] proxy_arp [enable disable] {local [enable disable]}} bootp dhcp ipv6 ipv6address <ipv6networkaddr> ip_mtu <value 512-1712> dhcpv6_client [enable disable] ip_directed_broadcast [enable disable]]

Each command is listed, in detail, in the following sections.

config ipif

Purpose	This command is used to configure the IP directed-broadcast state of the interface.
Syntax	config ipif <ipif_name 12> [{ipaddress <network_address> vlan <vlan_name 32> state [enable disable] proxy_arp [enable disable] {local [enable disable]}} bootp dhcp ipv6 ipv6address <ipv6networkaddr> ip_mtu <value 512-1712> dhcpv6_client [enable disable] ip_directed_broadcast [enable disable]]
Description	<p>This command will enabled or disabled the IP directed-broadcast state of a specified interface.</p> <p>An IP directed broadcast is an IP packet whose destination address is a valid broadcast address of some IP subnet, but which originates from a node that is not a part of that destination subnet.</p> <p>The Switch that is not directly connected to its destination subnet and forwards an IP directed broadcast in the same way that it would forward unicast IP packets to a host on that subnet. When a directed broadcast packet reaches a router that is directly connected to its destination subnet, and that packet is "exploded" as a broadcast on the destination subnet. It only works on layer 3 Switch.</p>
Parameters	<p>The only highlighted parameter for this chapter is:</p> <p><i>ip_directed_broadcast</i> - See below:</p> <ul style="list-style-type: none"> <i>enable</i> - Enabled the IP directed-broadcast state of the interface. <i>disable</i> - Disabled the IP directed-broadcast state of the interface.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set the IP Directed Broadcast state of System interface to enable:

```
DGS-3627:admin# config ipif System ip_directed_broadcast enable
Command: config ipif System ip_directed_broadcast enable
```

Success.

```
DGS-3627:admin#
```

To display the IP Directed Broadcast settings of System interface:

```
DGS-3627:admin# show ipif System
```

```
Command: show ipif System
```

```
IP Interface           : System
VLAN Name              : default
Interface Admin State  : Enabled
DHCPv6 Client State    : Disabled
IPv4 Address           : 10.90.90.90/821 (Manual) Primary
Proxy ARP              : Disabled (Local : Disabled)
IP Directed Broadcast  : Enabled
IP MTU                 : 1580
```

IP MULTICASTING COMMANDS

The IP multicasting commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
show ipmc cache	{group <group>} {ipaddress <network_address>}
show ipmc	{ipif <ipif_name 12> protocol [inactive dvmrp pim]}

Each command is listed, in detail, in the following sections.

show ipmc cache

Purpose	Used to display the current IP multicast forwarding cache.
Syntax	show ipmc cache {group <group>} {ipaddress <network_address>}
Description	This command will display the current IP multicast forwarding cache.
Parameters	<i>group <group></i> – The multicast group IP address. <i>ipaddress <network_address></i> – The IP address and netmask of the source. The address and mask information can be specified using the traditional format (for example, 10.1.2.3/255.0.0.0) or in CIDR format, 10.1.2.3/8).
Restrictions	None.

Example usage:

To display the current IP multicast forwarding cache:

```
DGS-3627:admin# show ipmc cache
Command: show ipmc cache
```

Multicast Group	Source Address/Netmask	Upstream Neighbor	Expire Time	Routing Protocol
224.1.1.1	10.48.74.121/32	10.48.75.63	30	DVMRP
224.1.1.1	20.48.74.25 /32	20.48.75.25	20	DVMRP
224.1.2.3	10.48.75.3 /3	10.48.76.6	30	DVMRP

```
Total Entries: 3
DGS-3627:admin#
```

show ipmc

Purpose	Used to display the IP multicast interface table.
Syntax	show ipmc {ipif <ipif_name 12> protocol [inactive dvmrp pim]}
Description	This command will display the current IP multicast interface table.
Parameters	<ipif_name 12> – The name of the IP interface for which to display the IP multicast

show ipmc

interface table for.

protocol – Allows the user to specify whether or not to use one of the available protocols to display the IP multicast interface table. For example, if DVMRP is specified, the table will display only those entries that are related to the DVMRP protocol.

- *inactive* – Specifying this parameter will display entries that are currently inactive.
- *dvmrp* – Specifying this parameter will display only those entries that are related to the DVMRP protocol.
- *pim* – Specifying this parameter will display only those entries that are related to the PIM protocol.

Restrictions

None.

Usage example

To display the current IP multicast interface table by DVMRP entry:

```
DGS-3627:admin# show ipmc protocol dvmrp
Command: show ipmc protocol dvmrp

Interface Name      IP Address          Multicast Routing
-----
Triton              11.1.1.1            DVMRP

Total Entries: 1

DGS-3627:admin#
```

IP ROUTE FILTER COMMANDS

The IP Route Filter commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create ip prefix_list	<list_name 16>
config ip prefix_list	<list_name 16> [[add delete] {sequence <value 1-65535 >} <network_address> {ge <value 1-32>}{le <value 1-32>}[deny permit]][description <desc 80> clear_description]]
delete ip prefix_list	[list_name <list_name 16> all]
show ip prefix_list	{<list_name 16>}
create ip standard access_list	<list_name 16>
config ip standard access_list	<list_name 16> [add delete] <network_address> [deny permit]
delete ip standard access_list	[list_name <list_name 16> all]
show ip standard access_list	{<list_name 16>}
clear ip prefix_list counter	[list_name <list_name 16> {<network_address>} all]
create route_map	<map_name 16>
delete route_map	[map_name <map_name 16>{all_sequence} all]
show route_map	{<map_name 16>}
config route_map	<map_name 16> [add delete] sequence <value 1-65535 > {[deny permit]}
config route_map	<map_name 16> sequence <value 1-65535> match [add delete] [as_path <list_name 16 > community_list <list_name 16> {exact} ip address <list_name 16> ip address prefix_list <list_name 16> ip next_hop <list_name 16> ip next_hop prefix_list <list_name 16> metric <value 0-4294967294>]
config route_map	<map_name 16> sequence <value 1-65535> set [add delete] [next_hop [<ipaddr> peer_address] metric < uint 0-4294967295> local_preference < uint 0-4294967295> weight <value 0-65535> as_path <aspath_list> community {< communit_set 80 > internet no_export no_advertise local_as} {additive} origin[egp igp incomplete] dampening <min 1-45> <value 1-20000> <value 1-20000><min 1-255> <min 1-45>]
debug routefilter show	[prefix_list access_list route_map]

Each command is listed, in detail, in the following sections.

create ip prefix_list

Purpose	This command is used to create a prefix list.
Syntax	create ip prefix_list <list_name 16>
Description	The create ip prefix_list command creates an IP prefix list, which can be further applied to routes as a filter list.
Parameters	<list_name 16> - The name to identify the prefix list.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

The following example creates one IP prefix list named 1:

```
DGS-3627:admin# create ip prefix_list 1
Command: create ip prefix_list 1

Success.

DGS-3627:admin#
```

config ip prefix_list

Purpose	Used to configure a prefix list by adding/deleting a prefix list entry or adding/deleting the description of a prefix_list.
Syntax	config ip prefix_list <list_name 16> [[add delete] {sequence <value 1-65535 >} <network_address> {ge <value 1-32>}{le <value 1-32>}[deny permit]][description <desc 80> clear_description]]
Description	<p>The config ip prefix_list command defines the rule entry for an IP route prefix list. A prefix list can have multiple rule entries; each is represented by a sequence number. The rule with the lower sequence number will be evaluated first.</p> <p>If the sequence number is not specified for the defined rule entry, the sequence number will be automatically given. The automatically given sequence number will be a multiple of 5. Therefore, if the defined rule is the first rule in the prefix list, the automatically given sequence number will be 5. If the defined rule is not the first rule in the prefix list, the sequence number will be the number that is a multiple of 5 and larger than the largest sequence number of an existing rule in the prefix list.</p> <p>A prefix list consists of an IP address and a bit mask. The bit mask is entered as a number from 1 to 32. An implicit deny is applied to traffic that does not match any prefix-list entry.</p>
Parameters	<p><i><list_name 16></i> - Specifies the name for the prefix list.</p> <p><i>sequence</i> - Specifies the sequence number for the rule entry.</p> <p><i>deny</i> - The specified network will be denied.</p> <p><i>permit</i> - The specified network will be permitted.</p> <p><i>add</i> - Add a rule entry.</p> <p><i>delete</i> - Delete a rule entry.</p> <p><i><network_address></i> - Configures the network address</p> <p><i>clear_discription</i> - Specifies the description for the prefix list to null.</p> <p><i>discription</i> - Specifies the description for the prefix list.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

The following example configures a prefix list 1 to permit routes from the 10.0.0.0/8 network that have a mask length that is less than or equal to 24 bits:

```
DGS-3627:admin# config ip prefix_list 1 add sequence 10 10.0.0.0/8 le 24 permit
Command: config ip prefix_list 1 add sequence 10 10.0.0.0/8 le 24 permit

Success.

DGS-3627:admin#
```

delete ip prefix_list

Purpose	Used to delete the IP prefix list
Syntax	delete ip prefix_list [list_name <list_name 16> all]
Description	The command is used to delete an IP prefix list.
Parameters	<list_name 16> - The name of the prefix list that will be deleted.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an IP prefix list named "list1":

```
DGS-3627:admin# delete ip prefix_list list_name list1
Command: delete ip prefix_list list_name list1

Success.
DGS-3627:admin#
```

show ip prefix_list

Purpose	This command is used to show an IP prefix list.
Syntax	show ip prefix_list {<list_name 16>}
Description	The command is used to show a prefix list entry.
Parameters	<list_name 16> - The name of the prefix_list will be show.
Restrictions	None.

Example usage:

This example shows an IP prefix list named "list1":

```
DGS-3627:admin# create ip prefix_list list1
Command: create ip prefix_list list1

Success.

DGS-3627:admin# config ip prefix_list 1 add sequence 10 10.0.0.0/8 le 24 permit
Command: config ip prefix_list 1 add sequence 10 10.0.0.0/8 le 24 permit

Success.

DGS-3627:admin# show ip prefix_list list1
Command:4# show ip prefix_list list1

IP Prefix list: list1
Description:
Total Rule Number:1
    sequence 5 permit 10.0.0.0/8 le 24

DGS-3627:admin#
```

create ip standard access_list

Purpose	To create an access list used to filter routes.
---------	---

create ip standard access_list

Syntax	create ip standard access_list <list_name 16>
Description	This command is used to create an access list.
Parameters	<list_name 16> - The name of the access list.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create an access list named "List1":

```
DGS-3627:admin# create ip standard access_list List1
Command: create ip standard access_list List1
```

Success.

```
DGS-3627:admin#
```

config ip standard access_list

Purpose	This command is used to configure an access list to add/delete an entry.
Syntax	config ip standard access_list <list_name 16> [add delete] <network_address> [deny permit]
Description	This command creates an IP Route access list. It is used to filter the routes.
Parameters	<list_name 16> - The name of the access list. <network_address> - The network works as the filter condition of the access_list.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

This example configures access list "list1" to add one entry:

```
DGS-3627:admin# config ip standard access_list List1 add 10.10.10.0/24 permit
Command: config ip standard access_list List1 add 10.10.10.0/24 permit
```

Success.

```
DGS-3627:admin#
```

delete ip standard access_list

Purpose	To delete an access list used to route filters.
Syntax	delete ip standard access_list [list_name <list_name 16> all]
Description	This command deletes an access list identified by the access list name.
Parameters	<list_name> - The name of the access list.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an access list named "List1":

```
DGS-3627:admin# delete ip standard access_list list_name List1
Command: delete ip standard access_list list_name List1

Success.

DGS-3627:admin#
```

show ip standard access_list

Purpose	This command is used to show the information of access list.
Syntax	show ip standard access_list {<list_name 16>}
Description	This command is used to show the information of an access list.
Parameters	<list_name> - The name of the access list.
Restrictions	None.

Example usage:

Show the information of an access list named "List1":

```
DGS-3627:admin# config ip standard access_list List1 add 10.10.10.0/24 permit
Command:4# config ip standard access_list List1 add 10.10.10.0/24 permit
Success.

DGS-3627:admin# show ip standard access_list List1
Command:4# show ip standard access_list List1

IP standard Access_list:   List1
Total entries number   :   1
      filter : permit 10.10.10.0/24

Total Access_list number :   1

DGS-3627:admin#
```

clear ip prefix_list counter

Purpose	To clear prefix list hit counters.
Syntax	clear ip prefix_list counter [list_name <list_name 16> {<network_address>} all]
Description	This command is used to clear prefix list hit counters. The hit count is a value indicating the number of matches to a specific prefix list entry.
Parameters	<list_name 16> - Name of the prefix list from which the hit count is to be cleared. <network_address> - Specifies that IPv4 network which the hit count is to be cleared.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To clear prefix list counters for the prefix list named "first_list" that matches the 192.168.10.0/24 prefix:

```
DGS-3627:admin# clear ip prefix_list counter first_list 192.168.10.0/24
Command: clear ip prefix_list counter first_list 192.168.10.0/24

Success.

DGS-3627:admin#
```

create route_map

Purpose	This command is used to create a route map or add and delete sequences to a route map.
Syntax	create route_map <map_name 16>
Description	A route map can have multiple rule entries, each with a different sequence number. When creating a route map, a sequence ID of 10 will be added to the route map. If the sequence number is not specified, it will be automatically given. The automatically given sequence number will be a multiple of 10.
Parameters	<map_name 16> - The route map name.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a route map named “map1” and add one sequence ID of 20 to the route map:

```
DGS-3627:admin# create route_map map1
Command:4# create route_map map1

Success.

DGS-3627:admin# config route_map map1 add sequence 20
Command:4# config route_map map1 add sequence 20

Success.
DGS-3627:admin#
```

delete route_map

Purpose	This command is used to delete a route map configuration.
Syntax	delete route_map [map_name <map_name 16>{all_sequence} all]
Description	This command is used to delete a route map configuration.
Parameters	<map_name 16> - The route map name. all_sequence - Remove all sequence entries from the route map. The route map is not deleted. all - Use to delete all route_maps.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the route map named “map1”:

```
DGS-3627:admin# delete route_map map_name map1
Command: delete route_map map_name map1

Success.

DGS-3627:admin#
```

show route_map

Purpose	This command is used o show a route map configuration.
Syntax	show route_map {<map_name 16>}
Description	This command is used to show a route map configuration.
Parameters	<map_name 16> - Route map name.
Restrictions	None.

Example usage:

To show the route map named "map1":

```
DGS-3627:admin# show route_map map1
Command:4# show route_map map1

route_map : map1
-----
sequence : 10 (Permit)
  Match clauses:
  Set clauses:
-----
sequence : 20 (Permit)
  Match clauses:
  Set clauses:

DGS-3627:admin#
```

config route_map

Purpose	Used to configure the route map or add/delete sequences to the route map.
Syntax	config route_map <map_name 16> [add delete] sequence <value 1-65535 > {[deny permit]}
Description	A route map can have multiple rule entries, each with a different sequence number. When creating a route map, a sequence ID of 10 will be added to the route map. If the sequence number is not specified, it will be automatically given. The automatically given sequence number will be a multiple of 10. If permit/deny is not specified, permit is implied.
Parameters	<map_name 16> - The route map name. <value 1-65535> - The sequence number for the route map rule. <i>permit</i> - Specifies to permit the route if the rule is matched <i>deny</i> - Specifies to deny the route if the rule is matched.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure a route map named “map1” and add one sequence ID of 20 to the route map:

```
DGS-3627:admin# config route_map map1 add sequence 20
Command:4# config route_map map1 add sequence 20

Success.
DGS-3627:admin#
```

config route_map sequence

Purpose	To define the conditions for redistributing routes from one routing protocol into another, or to enable policy routing, use the route map command in global configuration mode and the match and set command in route map configuration modes.
Syntax	config route_map <map_name 16> sequence <value 1-65535> match [add delete] [as_path <list_name 16 > community_list <list_name 16> {exact} ip address <list_name 16> ip address prefix_list <list_name 16> ip next_hop <list_name 16> ip next_hop prefix_list <list_name 16> metric <value 0-4294967294>] [<portlist> all] max_entry [<value 1-n> no_limit]
Description	<p>Route map can be used for redistribution or used as an inbound or outbound BGP session filter.</p> <p>A route map can have multiple rules; each rule is associated with a sequence number. If one sequence entry is matched, then the following entries will not be checked.</p> <p>A rule is formed by two parts, the match part and the set part. The match part defines the match condition for the rule, and the set part defines the action that will be taken if the rule is matched.</p> <p>If a rule only has the set part defined but has no match part, then the rule will permit all, and set part will take effect.</p> <p>If a rule only has the match part defined but has no set part, and then if the rule is matched, no action will be taken. If a rule has multiple match statements, then all the statements must be matched in order for the rule to be matched.</p> <p>If a rule has multiple set statements, then all the set will be applied if the rule is matched. If the sequence number is not specified for the defined rule entry, the sequence number will be automatically given. The automatically given sequence number will be a multiple of 10. Therefore, if the defined rule is the first rule in the route map, the automatically given sequence number will be 10. If the defined rule is not the first rule in the route map, the sequence number will be the number that is a multiple of 10 and larger than the largest sequence number of existing rules in the route map.</p>
Parameters	<p><i><map_name 16></i> - The route map name.</p> <p><i><value 1-65535></i> - Specifies the sequence number for the rule. This is the number that indicates the position a new route map will have in the list of route maps already configured with the same name. Default: 10.</p> <p><i>match deny</i> - Specifies to deny the route if the rule is matched.</p> <p><i>match permit</i> - Specifies to permit the route if the rule is matched.</p> <p><i>match as_path</i> - Specifies to match the AS path of the route against the AS path list. The AS path list specified here needs to be a sub-list of the AS path list associated with the route.</p> <p><i>match community_list</i> - Specify to match the community of the route against the community string.</p> <p><i>exact</i> - All of the communities and only those communities specified must be present.</p> <p><i>match ip address</i> - Specify to match the route according to the access list.</p> <p><i>match ip address prefix_list</i> - Specify to match the route according to the prefix list.</p>

config route_map sequence

match ip next_hop - Specify to match the next hop of the route according to the access list.

match ip next_hop prefix_list - Specify to match the next hop of the route according to the prefix list.

match metric - Specify to match the metric of the route.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the route map match access list "ac_list1" and set the metric to 50:

```
DGS-3627:admin# config route_map map1 sequence 10 match add ip address ac_list1
Command:4# config route_map map1 sequence 10 match add ip address ac_list1
```

```
DGS-3627:admin# config route_map map1 sequence 10 set add metric 50
Command:4# config route_map map1 sequence 10 set add metric 50
```

Success.

```
DGS-3627:admin#
```

config route_map sequence set

Purpose

To define the conditions for redistributing routes from one routing protocol into another, or to enable policy routing, use the `route_map` command in global configuration mode and the `match` and `set` commands in route map configuration modes.

Syntax

```
config route_map <map_name 16> sequence <value 1-65535> set [add | delete]
[next_hop [<ipaddr> | peer_address ] | metric < uint 0-4294967294> | local_preference <
uint 0-4294967295> | weight <value 0-65535> | as_path <aspath_list> | community {<
communit_set 80 > | internet | no_export | no_advertise | local_as} {additive} |
origin[egp | igp | incomplete] | dampening <min 1-45> <value 1-20000> <value 1-
20000><min 1-255> <min 1-45>]
```

Description

Route map can be used for redistribution or used as an inbound or outbound BGP session filter.

A route map can have multiple rules; each rule is associated with a sequence number.

If one sequence entry is matched, then the following entries will not be checked.

A rule is formed by two parts, the match part and the set part. The match part defines the match condition for the rule, and the set part defines the action that will be taken if the rule is matched.

If a rule only has the set part defined but has no match part, then the rule will permit all, and set part will take effect.

If a rule only has the match part defined but has no set part, and then if the rule is matched, no action will be taken. If a rule has multiple match statements, then all the statements must be matched in order for the rule to be matched.

If a rule has multiple set statements, then all the set will be applied if the rule is matched.

If the sequence number is not specified for the defined rule entry, the sequence number will be automatically given. The automatically given sequence number will be a multiple of 10. Therefore, if the defined rule is the first rule in the route map, the automatically given sequence number will be 10. If the defined rule is not the first rule in the route map, the sequence number will be the number that is a multiple of 10 and larger than the largest sequence number of the existing rule in the route map.

config route_map sequence set

Parameters	<p><i><map_name 16></i> - The route map name.</p> <p><i><value 1-65535></i> - Specifies the sequence number for the rule.</p> <p>This is the number that indicates the position a new route map will have in the list of route maps already configured with the same name. Default: 10.</p> <p><i>set next_hop</i> - Set the next hop attribute.</p> <p>This will take effect for both the ingress and egress direction.</p> <p>When <i>set next_hop</i> to peer address, for ingress direction, the next hop will be set to the neighbor peer address. For egress direction, the next hop associated with the route in the packet will be the neighbor peer address.</p> <p><i>set metric</i> - Specifies to set the metric.</p> <p>BGP router will not send metrics associated with a route by default unless the metric is egress set in the route map.</p> <p>If BGP route receive a route with a metric, then this metric will be used in best path selection. This can be overwritten by the metric that is ingress set for the route. If the received route has neither metric attribute nor metric ingress metric set, then the default metric (0) will be associated with the route for the best path selection. If <i>med-missing-as-worst</i> is enabled for the router, then a value of infinite will be associated with the route.</p> <p>This will take effect for both ingress and egress direction.</p> <p><i>set local_preference</i> - Specifies to set the local preference for the matched route. By default, BGP router will send the default local preference with the routes. It can be overwritten by the local preference set by the route map. For the received route, the local preference sent with the route will be used in the best path selection. This local preference will be overwritten if local preference is ingress set by the route map.</p> <p>For the local routes, the default local preference will be used for them in the best path selection.</p> <p>This will take effect for both ingress and egress direction.</p> <p><i>set weight</i> - Set the weight for the matched routes.</p> <p>It will overwrite the weight specified by the neighbor weight command for the routes received from the neighbor.</p> <p>If weight is neither specified by the neighbor weight command nor set by the route map, then routes learned through another BGP peer have a default weight of 0.</p> <p>The weight of local routes is always 32768.</p> <p>This will only take effect for ingress egress direction.</p> <p><i>set as_path</i> - Specifies an AS path list which is used to prepend the AS list. A format example is:100, 200, 300.</p> <p><i>set community</i> - Specifies a community to be used or to be appended to the original communities of the route.</p> <p><i>internet</i> - Routes with this community will be sent to all peers either internal or external.</p> <p><i>local_as</i> - Routes with this community will be sent to peers in the same AS, but will not be sent to peers in other sub ASs in the same confederation and to the external peers.</p> <p><i>no_advertise</i> - Routes with this community will not be advertised to any peer either internal or external.</p> <p><i>no_export</i> - Routes with this community will be sent to peers in the same AS or in other sub autonomous systems within a confederation, but will not be sent to an external BGP (eBGP) peer.</p> <p><i><community_set 80></i> - A community is 4 bytes long, including the 2 byte's autonomous system number and 2 bytes' network number This value is configured with two 2-byte numbers separated by a colon. The valid range of both numbers is from 1 to 65535.</p> <p>A community list can be formed by multiple communities, separated by comma.</p> <p>An example of a community string is 200:1024, 300:1025, 400:1026.</p> <p><i>additive</i> - If this keyword is specified, the specified community string will be appended to the original community string.</p> <p>If not specified, the specified community string will replace the original community string.</p> <p><i>set origin</i> - Set the origin for the route. It can be one of the following three values, EGP, IGP,</p>
------------	---

config route_map sequence set

	or incomplete.
	<i>dampening</i> - The dampening timer and parameter.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the route map match access list "ac_list1" and set the metric to 50:

```
DGS-3627:admin# config route_map map1 sequence 10 match add ip address ac_list1
Command:4# config route_map map1 sequence 10 match add ip address ac_list1
```

```
DGS-3627:admin# config route_map map1 sequence 10 set add metric 50
Command:4# config route_map map1 sequence 10 set add metric 50
```

Success.

```
DGS-3627:admin#
```

debug routefilter show

Purpose	This command is used to show route filter information in kernel, including prefix list, access list, and route map.
Syntax	debug routefilter show [prefix_list access_list route_map]
Description	This command is used to show route filter information in kernel, including prefix list, access list, and route map.
Parameters	<i>enable</i> - Enable the routefilter debug function <i>disable</i> - Disable the routefilter debug function
Restrictions	Only Administrator level users can issue this command.

Example usage:

To show route filter information in kernel.

```
DGS-3627:admin# debug routefilter show route_map
Command:4# debug routefilter show route_map
```

```
route-map map1,r_id:1,permit
Sequence 10
  Match clauses:
    ip address (access-lists): ac_list1
  Set clauses:
    metric 50
Sequence 20
  Match clauses:
  Set clauses:
```

Success.

IP-MAC-PORT BINDING (IMPB) COMMANDS

The IP network layer uses a four-byte address. The Ethernet link layer uses a six-byte MAC address. Binding these two address types together allows the transmission of data between the layers. The primary purpose of IP-MAC-Port binding (IMPB) is to restrict the access to a switch to a number of authorized users. Only the authorized client can access the Switch's port by checking the pair of IP-MAC addresses with the pre-configured database. If an unauthorized user tries to access an IMPB-enabled port, the system will block the access by dropping its packet. The maximum number of IP-MAC-Port binding entries is dependant on chip capability (e.g. the ARP table size) and storage size of the device. For the DGS-3600 Series, the maximum number of IMPB entries is 511. The creation of authorized users can be manually configured by CLI or Web. The function is port-based, meaning a user can enable or disable the function on the individual port.

ACL Mode

Due to some special cases that have arisen with IP-MAC-Port binding, this Switch has been equipped with a special ACL Mode for IMPB, which should alleviate this problem for users. When enabled, the Switch will create one entry in the Access Profile Table. The entry may only be created if there is at least one Profile ID available on the Switch. If not, when the ACL Mode is enabled, an error message will be prompted to the user. When the ACL Mode is enabled, the Switch will only accept packets from a created entry in the IP-MAC-Port binding Setting screen. All others will be discarded.

To configure the ACL mode, the user must first set up IP-MAC-Port binding using the **create address_binding ip_mac ipaddress** command to create an entry. Then the user must enable the mode by entering the **config address_binding ports <portlist> mode acl** command.



NOTE: When configuring the ACL mode function of the IP-MAC-Port binding function, please pay close attention to previously set ACL entries. Since the ACL mode entries will fill the first available access profile and access profile IDs denote the ACL priority, the ACL mode entries may take precedence over other configured ACL entries. This may render some user-defined ACL parameters inoperable due to the overlapping of settings combined with the ACL entry priority (defined by profile ID). For more information on ACL settings, please see "Configuring the Access Profile" section mentioned previously in this chapter.



NOTE: Once ACL profiles have been created by the Switch through the IP-MAC-Port binding function, the user cannot modify, delete or add ACL rules to these ACL mode access profile entries. Any attempt to modify, delete or add ACL rules will result in a configuration error as seen in the previous figure.



NOTE: When downloading configuration files to the Switch, be aware of the ACL configurations loaded, as compared to the ACL mode access profile entries set by this function, which may cause both access profile types to experience problems.

IP-MAC-Port Binding (IMPB) is a security application found on edge switches which are usually directly connected to hosts. IMPB enables administrators to configure (or snoop) pairs of MAC and IP addresses that are allowed to access networks through the switch. IMPB binds together the network layer IP address, and the Ethernet link layer MAC address, and the receiving port, to allow the transmission of data between the layers.

The IP-MAC-Port Binding (IMPB) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config address_binding ip_mac ports	[<portlist> all] { state [enable {[strict loose] [ipv6 all]} disable {[ipv6 all]}] allow_zeroip [enable disable] forward_dhcppkt [enable disable] mode [arp acl] stop_learning_threshold<int 0-500>} (1)
create address_binding ip_mac	[ipaddress < ipaddr > ipv6address <ipv6addr>] mac_address < macaddr > { ports [portlist all]}
delete address_binding	[ip_mac [[ipaddress < ipaddr > ipv6address <ipv6addr>] mac_address < macaddr > all] blocked [all vlan_name < vlan_name > mac_address < macaddr >]]
config address_binding ip_mac	[ipaddress < ipaddr > ipv6address <ipv6addr>] mac_address < macaddr > {ports [portlist all]}
show address_binding	{[ip_mac [all [ipaddress <ipaddr> ipv6address <ipv6addr>] mac_address <macaddr>] blocked [all vlan_name <vlan_name> mac_address <macaddr>] ports {<portlist>}]}
enable address_binding dhcp_snoop	{[ipv6 all]}
disable address_binding dhcp_snoop	{[ipv6 all]}
clear address_binding dhcp_snoop binding_entry ports	[<portlist> all] {[ipv6 all]}
show address_binding dhcp_snoop	{[max_entry { ports <portlist>} binding_entry {port <port>}]}
config address_binding dhcp_snoop max_entry ports	[<portlist> all] limit [<value 1-50> no_limit]
enable address_binding trap_log	
disable address_binding trap_log	
config address_binding recover_learning ports	[<portlist> all]
enable address_binding nd_snoop	
disable address_binding nd_snoop	
show address_binding nd_snoop	
show address_binding nd_snoop binding_entry	{port <port>}
clear address_binding nd_snoop binding_entry ports	[<portlist> all]
debug address_binding	[event dhcp all]
no debug address_binding	

Each command is listed, in detail, in the following sections.

config address_binding ip_mac ports

Purpose	Used to configure the state of IMPB on the switch for each port.
Syntax	config address_binding ip_mac ports [<portlist> all] { state [enable {[strict loose] [ipv6 all]} disable {[ipv6 all]}] allow_zeroip [enable disable] forward_dhcppkt [enable disable] mode [arp acl] stop_learning_threshold<int 0-500>} (1)
Description	Used to configure the per port state of IMPB on the switch. If a port has been configured as group member of an aggregated link, then the IMPB function

config address_binding ip_mac ports

cannot be enabled.

When the binding check state is enabled for IP packets and ARP packets received by this port, the switch will check whether the IP address and MAC address matches the binding entry. If the packet does not match it will be dropped.

For this function, the switch can operate in ACL mode or ARP mode. In ARP mode, only ARP packets are checked for binding. In ACL mode, both ARP packets and IP packets are checked for binding. Therefore, the ACL mode provides more strict checks for packets.

Parameters

state - This parameter configures the IMPB port state to be enabled or disabled. When the state is enabled, the port will perform the binding check.

ipv6 - For "state enable ipv6", only the IPv6 filter table applied to the driver.

For "state enable" without specifying "ipv6", only the IPv4 filtering table is applied to driver.

For "state enable all", both IPv4 and IPv6 filtering tables are applied to the driver.

For example, if IPv6 is enabled, but IPv4 is disabled, only the IPv6 Snooping entry is used to create a HW filtering table, if the FDB is used as the HW filtering table, and one IPv6 entry is allowed to be forwarded, all IPv4 packets get forwarded.

strict - Used to implement a mode of strict control. When strict control is used, all ARP and IP broadcast packets are sent to the CPU and checked for IMPB before forwarding. Packets with MAC addresses that match IMPB entries are set to dynamic state while MAC addresses with no match are set to block. All other packets are dropped.

loose - Used to implement a more loose or less strict mode of control.

In loose mode, ARP and IP broadcast packets are sent to the CPU for IMPB checking. Packets are forwarded unless the check finds a specified source MAC address that is blocked. Packets with MAC addresses that match IMPB entries are set to dynamic state while MAC addresses with no match are set to block. All other packets are bypassed.

allow_zeroip - Specify whether to allow ARP packets with a source IP address of 0.0.0.0. If the IP address 0.0.0.0 is not configured in the binding list and this setting is enabled, ARP packets with the source IP address of 0.0.0.0 will be allowed; If the IP address 0.0.0.0 is not configured in the binding list and this setting is disabled, ARP packets with the source IP address of 0.0.0.0 will not be allowed. This option does not affect the IMPB ACL Mode.

forward_dhcp - By default, DHCP packets with a broadcast DA will be flooded.

When set to disabled, the broadcast DHCP packet received by the specified port will not be forwarded.

This setting is effective when DHCP Snooping is enabled, in this case DHCP packets trapped by the CPU must be forwarded by the software.

This setting controls the forwarding behavior in this situation.

mode - When configuring the mode of the port to be ACL mode, the switch will create an ACL access entry corresponding to the entries of the port. If the port changes to ARP mode, all ACL access entries are deleted automatically. The default mode for a port is ARP mode.

stop_learning_threshold - When the number of blocked entries exceeds the threshold, the port will stop learning new addresses. Packets with a new address will be dropped. The range is 0-500. 0 means no limit.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To enable IMPB on port 1:

```
DGS-3627:admin# config address_binding ip_mac ports 1 state enable
Command: config address_binding ip_mac ports 1 state enable

Success.

DGS-3627:admin#
```

create address_binding ip_mac

Purpose	Used to create an IMPB entry.
Syntax	create address_binding ip_mac [ipaddress < ipaddr > ipv6address <ipv6addr>] mac_address < macaddr > { ports [portlist all]}
Description	Use this command to create an IMPB entry. One MAC address can map to multiple IP address
Parameters	<i>ipaddr</i> - Specify the IP address used for the IMPB entry. <i>ipv6addr</i> - Specify the IPv6 address used for the IMPB entry. <i>macaddr</i> - Specify the MAC address used for the IMPB entry. <i>ports</i> - Specify the portlist the entry will apply to. If not ports are specified, the settings will be applied to all ports.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create an IMPB entry:

```
DGS-3627:admin# create address_binding ip_mac ipaddress 10.1.1.1 mac_address 00-00-00-00-00-11
Command: create address_binding ip_mac ipaddress 10.1.1.1 mac_address 00-00-00-00-00-11

Success.

DGS-3627:admin#
```

To create a static IPv6 IMPB entry:

```
DGS-3627:admin# create address_binding ip_mac ipv6address fe80::240:5ff:fe00:28
mac_address 00-00-00-00-00-11
Command: create address_binding ip_mac ipv6address fe80::240:5ff:fe00:28 mac_address 00-00-00-00-00-11

Success.

DGS-3627:admin#
```

delete address_binding

Purpose	Used to delete an IMPB entry or blocked entry.
Syntax	delete address_binding [ip_mac [[ipaddress < ipaddr > ipv6address <ipv6addr>] mac_address < macaddr > all] blocked [all vlan_name < vlan_name > mac_address < macaddr >]]
Description	Use this command to delete an IMPB entry or a blocked entry. If the ACL mode is enabled, the switch will delete the related ACL access entries automatically.

delete address_binding

Parameters	<p><i>ip_mac</i> - Specify the user created IMPB database.</p> <p><i>blocked</i> - Specify the address database that the system has automatically learned and blocked.</p> <p><i>ipaddr</i> - Specify the learned IP address of the entry in the database.</p> <p><i>ipv6addr</i> - Specify the learned IPv6 address of the entry in the database.</p> <p><i>macaddr</i> - Specify the MAC address of the entry or the blocked MAC address.</p> <p><i>vlan_name</i> - Specify the name of the VLAN to which the blocked MAC address belongs.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an IMPB entry:

```
DGS-3627:admin# delete address_binding ip_mac ipaddress 10.1.1.1 mac_address 00-00-00-00-00-11
Command: delete address_binding ip_mac ipaddress 10.1.1.1 mac_address 00-00-00-00-00-11

Success.

DGS-3627:admin#
```

To delete a static ipv6 IMPB entry:

```
DGS-3627:admin# delete address_binding ip_mac ipv6address fe80::240:5ff:fe00:28
mac_address 00-00-00-00-00-11
Command: delete address_binding ip_mac ipv6address fe80::240:5ff:fe00:28 mac_address 00-00-00-00-00-11

Success.

DGS-3627:admin#
```

To delete a blocked address:

```
DGS-3627:admin# delete address_binding blocked vlan_name v31 mac_address 00-00-00-00-00-11
Command: delete address_binding blocked vlan_name v31 mac_address 00-00-00-00-00-11

Success.

DGS-3627:admin#
```

config address_binding ip_mac

Purpose	Used to update an IMPB entry.
Syntax	config address_binding ip_mac [ipaddress < ipaddr > ipv6address <ipv6addr>] mac_address < macaddr > {ports [portlist all]}
Description	This command is used to update an IMPB entry.

config address_binding ip_mac

Parameters	<p><i>ipaddr</i> - Specify the IP address of the entry being updated.</p> <p><i>ipv6addr</i> - Specify the IPv6 address of the entry being updated.</p> <p><i>macaddr</i> - Specify the MAC address of the entry being updated</p> <p><i>ports</i> - Specify which ports are used for the IMPB entry being updated. If not specified, then it is applied to all ports.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure an IMPB entry:

```
DGS-3627:admin# config address_binding ip_mac ipaddress 10.1.1.1 mac_address 00-00-00-00-00-11
Command: config address_binding ip_mac ipaddress 10.1.1.1 mac_address 00-00-00-00-00-11

Success.

DGS-3627:admin#
```

To configure a static IPv6 IMPB entry:

```
DGS-3627:admin#config address_binding ip_mac ipv6address fe80::240:5ff:fe00:28
mac_address 00-00-00-00-00-11
Command: config address_binding ip_mac ipv6address fe80::240:5ff:fe00:28 mac_address 00-00-00-00-00-11

Success.

DGS-3627:admin#
```

show address_binding

Purpose	Used to display the IMPB entries, blocked MAC entries and port status.
Syntax	show address_binding {[ip_mac [all [ipaddress <ipaddr> ipv6address <ipv6addr>] mac_address <macaddr>] blocked [all vlan_name <vlan_name> mac_address <macaddr>] ports {<portlist>}}}
Description	This command is used to show the IMPB information.
Parameters	<p><i>ip_mac</i> - Specify the user created IMPB database.</p> <p><i>blocked</i> - Specify the addresses in the database that the system has auto learned and blocked.</p> <p><i>ipaddr</i> - Specify the learned IP address of the entry in the database.</p> <p><i>ipv6addr</i> - Specify the learned IPv6 address of the entry in the database.</p> <p><i>macaddr</i> - Specify the MAC address of the entry or the blocked MAC address.</p> <p><i>vlan_name</i> - Specify the name of the VLAN to which the blocked MAC address belongs.</p> <p><i>ports</i> - Specify the ports for which the information is displayed. If not specified, all ports are displayed.</p>
Restrictions	None.

Example usage:

To show the IMPB global configuration:

DGS-3627:admin# show address_binding

Command: show address_binding

```
Trap/Log           : Enabled
DHCP Snoop(IPv4)  : Disabled
DHCP Snoop(IPv6)  : Enabled
ND Snoop           : Disabled
```

DGS-3627:admin#

To show the IMPB ports:

DGS-3627:admin#show address_binding ports

Command: show address_binding ports

Port	IPv4 State	IPv6 State	Mode	Zero IP	DHCP Packet	Stop Learning Threshold/Mode
1	Loose	Enabled	ARP	Allow	Forward	100/Stop
2	Strict	Enabled	ARP	Not Allow	Not Forward	200/Normal
3	Disabled	Enabled	ACL	Not Allow	Not Forward	200/Normal
4	Strict	Disabled	ARP	Not Allow	Not Forward	200/Normal
5	Disabled	Disabled	ACL	Not Allow	Not Forward	200/Normal
6	Strict	Disabled	ARP	Not Allow	Not Forward	200/Normal
7	Disabled	Disabled	ACL	Not Allow	Not Forward	200/Normal
8	Strict	Disabled	ARP	Not Allow	Not Forward	200/Normal
9	Disabled	Disabled	ACL	Not Allow	Not Forward	200/Normal
10	Strict	Disabled	ARP	Not Allow	Not Forward	200/Normal
11	Disabled	Disabled	ACL	Not Allow	Not Forward	200/Normal
12	Strict	Disabled	ARP	Not Allow	Not Forward	200/Normal

DGS-3627:admin#

To show IMPB entries:

DGS-3627:admin# show address_binding ip_mac all

Command: show address_binding ip_mac all

M(Mode) - D:DHCP,N:ND,S:Static ACL - A:Active I:Inactive

IP Address	MAC Address	M	ST	Ports
10.1.1.1	00-00-00-00-00-11	S	I	1,3,5,7,8
10.1.1.2	00-00-00-00-00-12	S	A	1
10.1.1.10	00-00-00-00-00-aa	D	A	1
2001:1111:2222:3333:4444:5555:6666:7777	00-00-00-00-00-02	D	I	2
2001:1111::1	00-00-00-00-00-03	N	I	5

Total Entries : 3

DGS-3627:admin#

To show the IMPB entries that are blocked:

DGS-3627:admin# show address_binding blocked

Command: show address_binding blocked

VID	VLAN Name	MAC Address	Port
1	default	00-01-02-03-29-38	7
1	default	00-0C-6E-5C-67-F4	7
1	default	00-0C-F8-20-90-01	7
1	default	00-0E-35-C7-FA-3F	7
1	default	00-0E-A6-8F-72-EA	7
1	default	00-0E-A6-C3-34-BE	7
1	default	00-11-2F-6D-F3-AC	7
1	default	00-50-8D-36-89-48	7
1	default	00-50-BA-00-05-9E	7
1	default	00-50-BA-10-D8-F6	7
1	default	00-50-BA-38-7D-E0	7
1	default	00-50-BA-51-31-62	7
1	default	00-50-BA-DA-01-58	7
1	default	00-A0-C9-01-01-23	7
1	default	00-E0-18-D4-63-1C	7

Total entries : 15

DGS-3627:admin#

enable address_binding dhcp_snoop

Purpose	Used to enable DHCP snooping mode.
Syntax	enable address_binding dhcp_snoop {[ipv6 all]}
Description	<p>By default, DHCP snooping is disabled.</p> <p>If a user enables DHCP sSnooping mode, all ports which have IMPB disabled will become server ports. (The switch will learn the IP addresses through server ports (by using DHCP Offer and DHCP ACK packets).</p> <p>Note that the DHCP discover packet cannot be passed thru the user ports if the allow_zeroip function is disabled on the port.</p> <p>The auto-learned IMPB entry will be mapped to a specific source port based on the MAC address learning function. This entry will be created as an ACL-mode binding entry for this specific port. Each entry is associated with a lease time. When the lease time has expires, the expired entry will be removed from the port. The auto-learned binding entry can be moved from one port to another port if the DHCP snooping function has learned that the MAC address has moved to a different port.</p> <p>If a situation occurs where a binding entry learned by DHCP snooping conflicts with a statically configured entry. The binding relation has conflicted. For example, if IP A is binded to MAC X with a static configuration and suppose that the binding entry learned by DHCP snooping is that IP A is bound to MAC Y, and then it is conflict. When the DHCP snooping learned entry binds with the static configured entry, and the DHCP snooping learned entry will not be created.</p> <p>In a situation where the same IMPB pair has been statically configured, the auto-learned entry will not be created. In a situation where the learned information is consistent with the statically configured entry the auto-learned entry will not be created. In a situation where the entry is statically configured in ARP mode the auto learned entry will not be created. In a situation where the entry is statically configured on one port and the entry is auto-learned on another port, the auto-learned entry will not be created.</p>
Parameters	<p><i>ipv6</i> - Enable DHCP snooping for IPv6.</p> <p><i>all</i> - Enable IPv4 and IPv6 DHCP snooping.</p> <p>If no parameter is specified, IPv4 snooping is enabled.</p>

enable address_binding dhcp_snoop

Restrictions	Only Administrator and Operator-level users can issue this command.
--------------	---

Example usage:

To enable DHCP IPv4 snooping mode:

```
DGS-3627:admin# enable address_binding dhcp_snoop
Command: enable address_binding dhcp_snoop

Success.

DGS-3627:admin#
```

To enable DHCP IPv6 snooping mode:

```
DGS-3627:admin# enable address_binding dhcp_snoop ipv6
Command: enable address_binding dhcp_snoop ipv6

Success.

DGS-3627:admin#
```

disable address_binding dhcp_snoop

Purpose	Used to disable DHCP snooping mode.
Syntax	disable address_binding dhcp_snoop {[ipv6 all]}
Description	When the DHCP snooping function is disabled, all of the auto-learned binding entries will be removed.
Parameters	<i>ipv6</i> - Disable IPv6 DHCP snooping. <i>all</i> - Disable IPv4 and IPv6 DHCP snooping. If no parameter is specified, IPv4 snooping is disabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable DHCP IPv4 snooping mode:

```
DGS-3627:admin# disable address_binding dhcp_snoop
Command: disable address_binding dhcp_snoop

Success.

DGS-3627:admin#
```

To disable DHCP IPv6 snooping mode:

```
DGS-3627:admin# disable address_binding dhcp_snoop ipv6
Command: disable address_binding dhcp_snoop ipv6

Success.

DGS-3627:admin#
```

clear address_binding dhcp_snoop binding_entry

Purpose	Used to clear the DHCP snooping entries learned for the specified ports.
Syntax	clear address_binding dhcp_snoop binding_entry ports [<portlist> all] {[ipv6 all]}
Description	To clear the DHCP Snooping entries learned for the specified ports.
Parameters	<i>ports</i> - Specify the list of ports to clear the DHCP snooping learned entries. <i>ipv6</i> - Clear IPv6 DHCP snooping learned entries. <i>all</i> - Clear both IPv4 and IPv6 DHCP snooping learned entries.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To clear DHCP IPv4 snooping entries on ports 1-3:

```
DGS-3627:admin# clear address_binding dhcp_snoop binding_entry ports 1-3
Command: clear address_binding dhcp_snoop binding_entry ports 1-3

Success.

DGS-3627:admin#
```

To clear DHCP IPv6 snooping entries on ports 1-3:

```
DGS-3627:admin# clear address_binding dhcp_snoop binding_entry ports 1-3 ipv6
Command: clear address_binding dhcp_snoop binding_entry ports 1-3 ipv6

Success.

DGS-3627:admin#
```

show address_binding dhcp_snoop

Purpose	Used to display the DHCP snooping configuration and learning database.
Syntax	show address_binding dhcp_snoop {[max_entry { ports <portlist> } binding_entry {port <port>}]}
Description	This command is used to show all DHCP snooping configuration and learning databases.
Parameters	<i>max_entry</i> - To show the maximum number of entries per port. <i>binding_entry</i> - To show DHCP snooping binding entries on ports. If no ports specified show all binding entries. If no parameters are specified, show DHCP snooping displays the enable/disable state.
Restrictions	None.

Example usage:

To show the DHCP snooping state:

```
DGS-3627:admin# show address_binding dhcp_snoop
Command: show address_binding dhcp_snoop

DHCP Snoop(IPv4) : Enabled
DHCP Snoop(IPv6) : Enabled

DGS-3627:admin#
```

To display DHCP snooping maximum entry configuration:

```
DGS-3627:admin# show address_binding dhcp_snoop max_entry
Command: show address_binding dhcp_snoop max_entry

Port          Max Entry
-----
1             10
2             10
3             10
4             No Limit
5             No Limit
6             No Limit
7             No Limit
8             No Limit
9             No Limit
10            No Limit
11            No Limit
12            No Limit

DGS-3627:admin#
```

To display the DHCP snooping binding entries:

```
DGS-3627:admin# show address_binding dhcp_snoop binding_entry
Command: show address_binding dhcp_snoop binding_entry

LT(Lease Time)  ST(Status) - A:Active I:Inactive
IP Address      MAC Address      LT(secs)  Port  ST
-----
10.62.58.35     00-0B-5D-05-34-0B  35964     1     A
10.33.53.82     00-20-c3-56-b2-ef  2590      2     I
2001:2222:1111:7777:5555:6666:7777:8888  00-00-00-00-00-02  50        5     I
2001:::1        00-00-00-00-03-02  100       6     A

Total Entries: 4

DGS-3627:admin#
```

config address_binding dhcp_snoop max_entry

Purpose	Used to specify the maximum number of entries that can be learned by a specified port.
Syntax	config address_binding dhcp_snoop max_entry ports [<portlist> all] limit [<value 1-50> no_limit]
Description	By default, the maximum number of port entries is unlimited. This command specifies the maximum number of entries that can be learned by the specified ports.
Parameters	<i>portlist</i> - Specify the list of ports you would like to set the maximum number of entries that

config address_binding dhcp_snoop max_entry

can be learned.
all - indicates all ports on the Switch.
limit - See below:
 <value 1-50> - Specify the maximum number.
 no_limit - Specifies that the maximum number of learned entries is unlimited.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To set the maximum number of DHCP IPv4 snooping entries that ports 1–3 can learned to 10:

```
DGS-3627:admin# config address_binding dhcp_snoop max_entry ports 1-3 limit 10.
Command: config address_binding dhcp_snoop max_entry ports 1-3 limit 10.
```

Success.

```
DGS-3627:admin#
```

enable address_binding trap_log

Purpose	Used to enable IMPB traps and logs.
Syntax	enable address_binding trap_log
Description	This command is used to send traps and logs when the IMPB module detects an illegal IP and MAC address.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the IMPB traps and logs:

```
DGS-3627:admin# enable address_binding trap_log
Command: enable address_binding trap_log
```

Success.

```
DGS-3627:admin#
```

disable address_binding trap_log

Purpose	Used to disable the IMPB traps and logs.
Syntax	disable address_binding trap_log
Description	This command is used to disable IMPB traps and logs.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable IMPB traps and logs:

```
DGS-3627:admin# disable address_binding trap_log
Command: disable address_binding trap_log

Success.

DGS-3627:admin#
```

config address_binding recover_learning ports

Purpose	Used to recover IMPB checking.
Syntax	config address_binding recover_learning ports [<portlist> all]
Description	Use this command to recover the IMPB check function, which was previously stopped.
Parameters	<i>ports</i> - See below: <portlist> - Specify the list of ports that need to recover the IMPB check. <i>all</i> - Indicates all the ports on the Switch.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To recover IMPB checking for ports 6 to 7:

```
DGS-3627:admin# config address_binding recover_learning ports 6-7
Command: config address_binding recover_learning ports 6-7

Success.

DGS-3627:admin#
```

enable address_binding nd_snoop

Purpose	Use to enable ND snooping on the switch.
Syntax	enable address_binding nd_snoop
Description	This command allows the user to enable ND snooping on the switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the ND snooping function on the switch:

```
DGS-3627:admin# enable address_binding nd_snoop
Command: enable address_binding nd_snoop

Success.

DGS-3627:admin#
```

disable address_binding nd_snoop

Purpose	Use to disable ND snooping on the switch.
Syntax	disable address_binding nd_snoop

disable address_binding nd_snoop

Description	This command allows the user to disable ND Snooping on switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the DHCPv6 snooping function on the switch:

```
DGS-3627:admin# disable address_binding nd_snoop
Command: disable address_binding nd_snoop

Success.

DGS-3627:admin#
```

show address_binding nd_snoop

Purpose	Use to display the status of ND snooping on the switch.
Syntax	show address_binding nd_snoop
Description	This command allows the user to display the ND snooping state on the switch.
Parameters	None.
Restrictions	None.

Example usage:

To show ND snooping state:

```
DGS-3627:admin# show address_binding nd_snoop
Command: show address_binding nd_snoop

ND Snoop      : Enabled

DGS-3627:admin#
```

show address_binding nd_snoop binding_entry

Purpose	Used to show binding entries of ND snooping on the switch.
Syntax	show address_binding nd_snoop binding_entry {port <port>}
Description	This command allows the user to display binding entries of ND Snooping on the switch.
Parameters	<i>port</i> - Specify port number If no parameter is specified, it will show all ND snooping binding entries.
Restrictions	None.

Example usage:

To display the ND snooping binding entry:

```
DGS-3627:admin# show address_binding nd_snoop binding_entry
Command: show address_binding nd_snoop binding_entry
LT(Lease Time)  ST(Status) - A:Active I:Inactive
IP Address          MAC Address          LT(secs)  Port  ST
-----
2001:2222:1111:7777:5555:6666:7777:8888  00-00-00-00-00-02  50        5    I
2001::1            00-00-00-00-03-02  100       6    A

Total Entries: 2
```

clear address_binding nd_snoop binding_entry

Purpose	Used to clear the ND snooping entries on specified ports.
Syntax	clear address_binding nd_snoop binding_entry ports [<portlist> all]
Description	To clear the entries learned for the specified ports.
Parameters	<i>ports</i> - Specify the list of ports that you would like to clear the ND snoop learned entry. <i>all</i> - Clear all ND snooping learned entries.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To clear ND snooping entry on ports 1-3:

```
DGS-3627:admin# clear address_binding nd_snoop binding_entry ports 1-3
Command: clear address_binding nd_snoop binding_entry ports 1-3

Success.

DGS-3627:admin#
```

debug address_binding

Purpose	Start the IMPB debug when the IMPB module receives an ARP/IP packet or a DHCP packet.
Syntax	debug address_binding [event dhcp all]
Description	Use this command to start the IMPB debug when the IMPB module receives an ARP/IP packet or a DHCP packet.
Parameters	<i>event</i> - To print out the debug messages when IMPB module receives ARP/IP packets. <i>dhcp</i> - To print out the debug messages when the IMPB module receives the DHCP packets. <i>all</i> - Print out all debug messages.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To print out all debug IMPB messages:

```
DGS-3627:admin# debug address_binding all
Command: debug address_binding all

Success.

DGS-3627:admin#
```

no debug address_binding

Purpose	Stop the IMPB debug starting when the IMPB module receives an ARP/IP packet or a DHCP packet.
Syntax	no debug address_binding
Description	Use this command to stop the IMPB debug starting when the IMPB module receives an ARP/IP packet or a DHCP packet.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To stop IMPB debug: starting when the IMPB module receives an ARP/IP or DHCP packet:

```
DGS-3627:admin# no debug address_binding
```

```
Command: no debug address_binding
```

```
Success.
```

```
DGS-3627:admin#
```


IPv6 Neighbor Discover Commands

The IPv6 Neighbor Discover commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create ipv6 neighbor_cache ipif	<ipif_name 12> <ipv6addr> <macaddr>
delete ipv6 neighbor_cache ipif	[<ipif_name 12> all] [<ipv6addr> static dynamic all]
show ipv6 neighbor_cache ipif	[<ipif_name 12> all] [ipv6address <ipv6addr> static dynamic all]
config ipv6 nd ns ipif	<ipif_name 12> retrans_time <millisecond 0-4294967295>
config ipv6 nd ra ipif	<ipif_name 12> {state [enable disable] life_time <sec 0-9000> reachable_time < millisecond 0-3600000> retrans_time <millisecond 0-4294967295> hop_limit <value 0-255> managed_flag [enable disable] other_config_flag [enable disable] min_rtr_adv_interval <sec 3-1350> max_rtr_adv_interval <sec 4-1800>} (1)
config ipv6 nd ra prefix_option ipif	<ipif_name 12> <ipv6networkaddr> {preferred_life_time <sec 0-4294967295> valid_life_time <sec 0-4294967295> on_link_flag [enable disable] autonomous_flag [enable disable]} (1)
show ipv6 nd	{ipif <ipif_name 12>}

Each command is listed, in detail, in the following sections.

create ipv6 neighbor_cache

Purpose	Adds a static neighbor on an IPv6 interface.
Syntax	create ipv6 neighbor_cache ipif <ipif_name 12> <ipv6addr> <macaddr>
Description	Adds a static neighbor on an IPv6 interface.
Parameters	<i>ipif_name</i> - Interface's name. <i>ipv6addr</i> - The address of the neighbor. <i>macaddr</i> - The MAC address of the neighbor.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a static neighbor cache entry on the interface System, with an IPv6 address of 3ffc::1 and a MAC address of 00:01:02L03:04:05:

```
DGS-3627:admin# create ipv6 neighbor_cache ipif System 3ffc::1 00:01:02:03:04:05
Command: create ipv6 neighbor System _cache ipif 3FFC::1 00:01:02:03:04:05
```

Success.

```
DGS-3627:admin#
```

delete ipv6 neighbor_cache

Purpose	Deletes an IPv6 neighbor from the interface neighbor address cache.
Syntax	delete ipv6 neighbor_cache ipif [<ipif_name 12> all] [<ipv6addr> static dynamic all]
Description	Deletes a neighbor cache entry or static neighbor cache entries from the address cache or all address cache entries on this IP interface. Both static and dynamic entries can be deleted.
Parameters	<i>ipif_name</i> - The IPv6 interface name <i>ipv6addr</i> - The neighbor's address. <i>all</i> - All entries including static and dynamic entries will be deleted. <i>dynamic</i> - Delete matching dynamic entries. <i>static</i> - Delete matching static entries.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the neighbor cache entry for IPv6 address 3ffc::1 on the IP interface "System":

```
DGS-3627:admin# delete ipv6 neighbor_cache ipif System 3ffc::1
```

```
Command: delete ipv6 neighbor_cache ipif System 3FFC::1
```

```
Success.
```

```
DGS-3627:admin#
```

show ipv6 neighbor_cache

Purpose	Shows the IPv6 neighbor cache.
Syntax	show ipv6 neighbor_cache ipif [<ipif_name 12> all] [ipv6address <ipv6addr> static dynamic all]
Description	Displays the neighbor cache entry for the specified interface. You can display a specific entry, all static entries, all dynamic entries, or all entries.
Parameters	<i>ipif_name</i> - The IPv6 interface name <i>ipv6addr</i> - The neighbor's address. <i>all</i> - Displays all interfaces. <i>dynamic</i> - Display all dynamic entries. <i>static</i> - Display all static neighbor cache entries. <i>all</i> - Displays all entries including static and dynamic entries.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show all neighbor cache entries for the IP interface "System":

```
DGS-3627:admin# show ipv6 neighbor_cache ipif System all
Command: show ipv6 neighbor_cache ipif System all

IPv6 Address: 2000::221:91FF:FE8D:4D9F          State: Reachable
MAC Address  : 00-21-91-8D-4D-9F    Port  : 1:31
Interface   : ipif1                  VID   : 4094

IPv6 Address: 3000::100                      State: Reachable
MAC Address  : 00-21-91-8D-4D-9F    Port  : 1:31
Interface   : ipif1                  VID   : 4094

IPv6 Address: FE80::221:91FF:FE8D:4D9F        State: Reachable
MAC Address  : 00-21-91-8D-4D-9F    Port  : 1:31
Interface   : ipif1                  VID   : 4094

Total Entries: 3

DGS-3627:admin#
```

config ipv6 nd ns retrans_time

Purpose	Configures the IPv6 ND neighbor solicitation retransmit time · which is the time between the retransmission of neighbor solicitation messages to a neighbor, when resolving the address or when probing the reachability of a neighbor.
Syntax	config ipv6 nd ns ipif <ipif_name 12> retrans_time <millisecond 0-4294967295>
Description	Configures the retransmit time of IPv6 ND neighbor solicitation.
Parameters	<p><i>ipif_name</i> - The IPv6 interface name.</p> <p><i>retrans_time</i> - Neighbor solicitation's retransmit timer in milliseconds. It has the same value as the RA retrans_time in the config IPv6 ND RA command. If the retrans_time parameter is configured in one of the commands, the retrans_time value in the other command will also change so that the values in both commands are the same.</p> <p>If the value user configured is less than 1000ms, Neighbor solicitation's retransmit timer of the device will use 1000ms instead of that value.</p> <p>If the value user configured is large than 1000ms, Neighbor solicitation's retransmit timer of the device will use that value.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the retrans_time of IPv6 ND neighbor solicitation to be 1000000 milliseconds:

```
DGS-3627:admin# config ipv6 nd ns ipif Zira retrans_time 1000000
Command: config ipv6 nd ns ipif Zira retrans_time 1000000

Success.

DGS-3627:admin#
```

config ipv6 nd ra

Purpose	Configures router advertisement related arguments.
Syntax	config ipv6 nd ra ipif <ipif_name 12> {state [enable disable] life_time <sec 0-9000> reachable_time < millisecond 0-3600000> retrans_time <millisecond 0-4294967295> hop_limit <value 0-255> managed_flag [enable disable] other_config_flag [enable disable] min_rtr_adv_interval <sec 3-1350> max_rtr_adv_interval <sec 4-1800>} (1)

config ipv6 nd ra

Description	Configures the router advertisement related parameters.
Parameters	<p><i>ipif_name</i> - The name of the interface.</p> <p><i>state</i> - Router advertisement state.</p> <p><i>life_time</i> - Indicates the lifetime of the router as the default router in seconds.</p> <p><i>reachable_time</i> - Indicates the amount of time that a node can consider a neighboring node reachable after receiving a reachability confirmation in milliseconds.</p> <p><i>retrans_time</i> - Indicates the amount of time between retransmissions of router advertisement messages in milliseconds, where the router advertisement packet will be taken to it's host. If the value user configured is less than 1000ms, the device will send RA with that value, but the device's(which received RA) retransmission time of NS messages will use 1000ms instead of it.</p> <p>If the value user configured is large than 1000ms, the device will send RA with that value, and the device's(which received RA) retransmission time of NS messages will also use that value.</p> <p><i>hop_limit</i> - Indicates the default value of the hop limit field in the IPv6 header for packets sent by hosts that receive this RA message.</p> <p><i>managed_flag</i> - When set to enable, it indicates that hosts receiving this RA must use a stateful address configuration protocol to obtain an address, in addition to the addresses derived from the stateless address configuration.</p> <p><i>other_config_flag</i> - When set to enable, it indicates that hosts receiving this RA must use a stateful address configuration protocol to obtain on-address configuration information,.</p> <p><i>min_rtr_adv_interval</i> - The minimum time allowed between sending unsolicited multicast Router Advertisements from the interface, in seconds. MUST be no less than 3 seconds and no greater than $.75 * \text{MaxRtrAdvInterval}$. Default: $0.33 * \text{MaxRtrAdvInterval}$.</p> <p><i>max_rtr_adv_interval</i> - The maximum time allowed between sending unsolicited multicast Router Advertisements from the interface, in seconds. MUST be no less than 4 seconds and no greater than 1800 seconds. Default: 600 seconds.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the RA state as enabled and the life_time of the "triton" interface to be 1000 seconds:

```
DGS-3627:admin#config ipv6 nd ra ipif triton state enable life_time 1000
Command: config ipv6 nd ra ipif triton state enable life_time 1000
```

Success.

```
DGS-3627:admin#
```

config ipv6 nd ra prefix_option

Purpose	Configures the prefix option for the router advertisement function.
Syntax	config ipv6 nd ra prefix_option ipif <ipif_name 12> <ipv6networkaddr> {preferred_life_time <sec 0-4294967295> valid_life_time <sec 0-4294967295> on_link_flag [enable disable] autonomous_flag [enable disable]} (1)
Description	Configures the prefix option for the router advertisement function.
Parameters	<p><i>ipif_name</i> - The name of the interface.</p> <p><i>preferred_life_time</i> - Indicates the number of seconds that an address, based on the specified prefix using the stateless address configuration, remains in preferred state. For an infinite valid lifetime the value can be set to 0xffffffff.</p> <p><i>valid_life_time</i> - Indicates the number of seconds that an address, based on the specified prefix, using the stateless address configuration, remains valid. For an infinite valid lifetime</p>

config ipv6 nd ra prefix_option

the value can be set to 0xffffffff.

on_link_flag - When set to 1 the addresses implied by the specified prefix are available on the link where the RA message is received.

autonomous_flag - When set to 1 the specified prefix will be used to create an autonomous address configuration.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the value of the preferred_life_time of prefix option to be 1000 seconds for the prefix 3ffe:501:ffff:100::/64, which is the prefix of the ip1 interface :

```
DGS-3627:admin# config ipv6 nd ra prefix_option ipif ip1 3ffe:501:ffff:100::/64
preferred_life_time 1000
```

```
Command: config ipv6 nd ra prefix_option ipif ip1 3ffe:501:ffff:100::/64
preferred_life_time 1000
```

Success.

```
DGS-3627:admin#
```

show ipv6 nd

Purpose Used to display information regarding neighbor detection on the switch.

Syntax **show ipv6 nd {ipif <ipif_name 12>}**

Description To show IPv6 ND related configuration.

Parameters *ipif_name* - The name of the interface.

If no IP interface is specified, it will show the IPv6 ND related configuration of all interfaces.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To show IPv6 ND related configuration:

```
DGS-3627:admin# show ipv6 nd ipif System
```

```
Command: show ipv6 nd ipif System
```

```
Interface Name          : System
Hop Limit               : 64
NS Retransmit Time     : 0 (ms)
Router Advertisement    : Disabled
RA Max Router AdvInterval : 600 (s)
RA Min Router AdvInterval : 198 (s)
RA Router Life Time    : 1800 (s)
RA Reachable Time      : 1200000 (ms)
RA Retransmit Time     : 0 (ms)
RA Managed Flag        : Disabled
RA Other Config Flag   : Disabled
```

Prefix	Preferred	Valid	OnLink	Autonomous
2000::/64	604800	2592000	Enabled	Enabled
2002::/64	604800	2592000	Enabled	Enabled

IPV6 ROUTE COMMANDS

The IPv6 Route commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create ipv6route	[default <ipv6networkaddr>] [[<ipif_name 12> <ipv6addr> <ipv6addr>] {<metric 1-65535>} {primary backup}] ip_tunnel <tunnel_name 12>]
delete ipv6route	[[default <ipv6networkaddr>] [<ipif_name 12> <ipv6addr> <ipv6addr> ip_tunnel <tunnel_name 12>] all]
show ipv6route	{<ipv6networkaddr>} {static ripng ospfv3}

Each command is listed, in detail, in the following sections.

create ipv6route

Purpose	Used to create static IPv6 route entry to Switch's IPv6 routing table.
Syntax	create ipv6route [default <ipv6networkaddr>] [[<ipif_name 12> <ipv6addr> <ipv6addr>] {<metric 1-65535>} {primary backup}] ip_tunnel <tunnel_name 12>]
Description	<p>Create a static IPv6 route entry. If the next hop is a global address, it is not needed to indicate the interface name of the next hop. If the next hop is a link local address, then the interface name of the next hop must be specified. And the unspecified address, loop back address or multicast address can't be configured as the next hop.</p> <p>Note: If an IPv6 global address is added on interface, this local route will be wrote into IPv6 routing table automatically.</p> <p>If both the destination network address and next hop of the new route entry are the same with existed entry, the created command for the new entry will return failure. If only the destination network address is the same with the existed entry and both primary and backup route entries are already existed, the created command for the new entry will return failure. The IP tunnel route doesn't support to create the backup route.</p>
Parameters	<p><i>default</i> - Specify that this route is created as a default route.</p> <p><i>ipv6networkaddr</i> - The destination network of the route.</p> <p><i>ipif_name</i> - The interface name of the next hop, with the maximum of 12 characters.</p> <p><i>ipv6addr</i> - The next hop address of this route.</p> <p><i>metric</i> - The metric for this route, the default value is 1.</p> <p><i>primary</i> - Specify the route as the primary route to the destination.</p> <p><i>backup</i> - Specify the route as the backup route to the destination. If the route is not specified as the primary route or the backup route, then it will be auto-assigned by the system. The first created is the primary, the second created is the backup.</p> <p><i>tunnel_name</i> - The IP tunnel interface name of the next hop. When this option is specified, it is indicated that this new created route is an IP tunnel route.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To add a single static IPv6 route entry in IPv6 format:

```
DGS-3627:admin# create ipv6route 3004::/64 Intface_1 3000::4
Command: create ipv6route 3004::/64 Intface_1 3000::4

Success.

DGS-3627:admin#
```

To add an IP tunnel route entry:

```
DGS-3627:admin# create ipv6route default ip_tunnel ip6_tn
Command: create ipv6route default ip_tunnel ip6_tn

Success.

DGS-3627:admin#
```

delete ipv6route

Purpose	Delete static IPv6 route entries or specified static route entry from Switch's IPv6 routing table
Syntax	delete ipv6route [[default <ipv6networkaddr>] [<ipif_name 12> <ipv6addr> <ipv6addr> ip_tunnel <tunnel_name 12>] all]
Description	Delete a static IPv6 route. If the next hop is a global address, it is not needed to specify the interface name of the next hop. If the next hop is a link local address, then the interface name of the next hop must be specified.
Parameters	<p><i>default</i> - Specify that the route to be deleted is a default route.</p> <p><i>ipv6networkaddr</i> - The destination network of the route.</p> <p><i>ipif_name</i> - The interface name of the next hop, with the maximum of 12 characters.</p> <p><i>ipv6addr</i> - The next hop address of the default route.</p> <p><i>tunnel_name</i> - The tunnel name of the next hop. When this option is specified, it is indicated that this route to be deleted is an IP tunnel route.</p> <p><i>all</i> - All static IPv6 routes will be deleted.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Delete a static IPv6 route specified by network address:

```
DGS-3627:admin# delete ipv6route 3004::/64 Intface_1 3000::4
Command: delete ipv6route 3004::/64 Intface_1 3000::4
Success.

DGS-3627:admin#
```

show ipv6route

Purpose	Display the Switch's current IPv6 routing table or specified route entries.
Syntax	show ipv6route {<ipv6networkaddr>} {[static ripng ospfv3]}
Description	Display IPv6 routes in the switch. If this command is not specified by address or route protocol, it will display all the route entries in the routing table. And if this command specified by address or route protocol, it will display the specified IPv6 route entries.
Parameters	<p><i>ipv6networkaddr</i> - The destination network of the route.</p> <p><i>static</i> - Display the static route entries.</p>

show ipv6route*ripng* - Display the RIPng route entries.*ospfv3* - Display the OSPFv3 route entries.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

Show the IPv6 route entries without specified address or route protocol:

DGS-3627:admin# show ipv6route

Command: show ipv6route

```

IPv6 Prefix: ::/0                                Protocol: Static   Metric: 1
Next Hop   : 3000::2                             IPIF      : Intface_1

IPv6 Prefix: 3000::/64                          Protocol: Local    Metric: 1
Next Hop   : ::                                  IPIF      : Intface_1

IPv6 Prefix: 3004::/64                          Protocol: Static   Metric: 1
Next Hop   : 3000::4                             IPIF      : Intface_1

IPv6 Prefix: 3005::/64                          Protocol: RIPng    Metric: 1
Next Hop   : 3000::5                             IPIF      : Intface_1

IPv6 Prefix: 4000::/64                          Protocol: Local    Metric: 1
Next Hop   : ::                                  IPIF      : Intface_2

IPv6 Prefix: 4005::/64                          Protocol: RIPng    Metric: 1
Next Hop   : 4000::5                             IPIF      : Intface_2

Total Entries: 6

DGS-3627:admin#

```

IPV6 TUNNEL COMMANDS

Industry is in the early stages of large scale IPv6 production deployment, and first-generation products need to make tradeoffs between available IPv6 services. Although the success of IPv6 will ultimately depend on the new applications that run over IPv6, there might be organizations or hosts within organizations that will continue to use IPv4 indefinitely.

A key part of the IPv6 design is its ability to integrate into and coexist with existing IPv4 networks. It is expected that IPv4 and IPv6 hosts will need to coexist for a substantial time during the steady migration from IPv4 to IPv6, and the development of transition strategies, tools, and mechanisms has been part of the basic IPv6 design from the start.

The IPv6 tunneling mechanism is one of the strategies for solving the transition from IPv4 to IPv6. This document describes three types of IPv6 tunnels: IPv6 Manually Configured tunnels, Automatic 6to4 Tunnels and ISATAP Tunnels.

The IPv6 Tunnel commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create ip_tunnel	<tunnel_name 12>
delete ip_tunnel	<tunnel_name 12>
config ip_tunnel manual	<tunnel_name 12> {ipv6address <ipv6networkaddr> source <ipaddr> destination <ipaddr>}(1)
config ip_tunnel 6to4	<tunnel_name 12> {ipv6address <ipv6networkaddr> source <ipaddr >}(1)
config ip_tunnel isatap	<tunnel_name 12> {ipv6address <ipv6networkaddr> source <ipaddr>}(1)
show ip_tunnel	{<tunnel_name 12>}
enable ip_tunnel	{<tunnel_name 12>}
disable ip_tunnel	{<tunnel_name 12>}

Each command is listed, in detail, in the following sections.

create ip_tunnel

Purpose	Used to create an IPv6 tunnel interface.
Syntax	create ip_tunnel < tunnel_name 12>
Description	The create ip_tunnel command is used to create an IPv6 tunnel interface on the Switch.
Parameters	<tunnel_name 12> - IPv6 Tunnel interface name, maximum of 12 characters.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create an IPv6 tunnel interface (Tunnel name is "tn2").:

```
DGS-3627:admin# create ip_tunnel tn2
Command: create ip_tunnel tn2
```

Success.

```
DGS-3627:admin#
```

delete ip_tunnel

Purpose	Used to delete an IPv6 tunnel interface.
Syntax	delete ip_tunnel < tunnel_name 12>
Description	The delete ip_tunnel command is used to delete a specific IPv6 tunnel on the switch.
Parameters	< tunnel_name 12> - IPv6 Tunnel interface name, maximum of 12 characters.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an IPv6 tunnel interface (Tunnel name is "tn2"):

```
DGS-3627:admin# delete ip_tunnel tn2
Command: delete ipif tunnel tn2

Success.

DGS-3627:admin#
```

config ip_tunnel manual

Purpose	This command is used to configure an IPv6 manual tunnel.
Syntax	config ip_tunnel manual <tunnel_name 12> {ipv6address <ipv6networkaddr> source <ipaddr> destination <ipaddr>}(1)
Description	<p>The config ip_tunnel manual command is used to configure an existing IPv6 tunnel as an IPv6 manual tunnel on the switch. If this tunnel has previously been configured in another mode, the tunnel's information will still exist in the database. However, whether the tunnel's former information is invalid or not, will depend on the current mode.</p> <p>IPv6 Manual tunnels are simple point-to-point tunnels that can be used within a site or between sites.</p>
Parameters	<p>< tunnel_name 12> - IPv6 Tunnel interface name, maximum of 12 characters.</p> <p><i>ipv6address <ipv6networkaddr></i> - The IPv6 address assigned to this IPv6 tunnel interface. IPv6 processing would be enabled on this IPv6 tunnel interface when an IPv6 address is configured. This IPv6 address is not connected with tunnel source or destination IPv4 address.</p> <p><i>source <ipaddr></i> - The source IPv4 address of this IPv6 tunnel interface. It is used as the source address for packets in this IPv6 tunnel.</p> <p><i>destination <ipaddr></i> - The destination IPv4 address of this IPv6 tunnel interface. It is used as the destination address for packets in this IPv6 tunnel. It is not required for 6to4 and ISATAP tunnels.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure an IPv6 manual tunnel (Tunnel name is "tn2", Tunnel source IPv4 address is 1.0.0.1, Tunnel destination IPv4 address is 1.0.0.2, Tunnel IPv6 address is 2001::1/64):

```
DGS-3627:admin# config ip_tunnel manual tn2 source 1.0.0.1 destination 1.0.0.2
Command: config ip_tunnel manual tn2 source 1.0.0.1 destination 1.0.0.2

Success.

DGS-3627:admin# config ip_tunnel manual tn2 ipv6address 2001::1/64
Command: config ip_tunnel manual tn2 ipv6address 2001::1/64

Success.

DGS-3627:admin#
```

config ip_tunnel 6to4

Purpose	Used to configure an IPv6 6to4 tunnel.
Syntax	config ip_tunnel 6to4 <tunnel_name 12> {ipv6address <ipv6networkaddr> source <ipaddr >}(1)
Description	<p>The config ip_tunnel 6to4 command is used to configure an existing IPv6 tunnel as an IPv6 6to4 tunnel on the switch. If this tunnel has previously been configured in another mode, the tunnel's information will still exist in the database. However, whether the tunnel's former information is invalid or not will depend on the current mode. A maximum of one IPv6 6to4 tunnel can exist on the system.</p> <p>IPv6 6to4 tunnels are point-to-multipoint tunnels that can be used to connect isolated IPv6 sites. Each IPv6 site has at least one connection to a shared IPv4 network and this IPv4 network could be the global Internet or a corporate backbone. The key requirement is that each site has a globally unique IPv4 address, which is used to construct a 48-bit globally unique 6to4 IPv6 prefix (It starts with the prefix 2002::/16).</p>
Parameters	<p><i><tunnel_name 12></i> - IPv6 Tunnel interface name, maximum of 12 characters.</p> <p><i>ipv6address <ipv6networkaddr></i> - The IPv6 address assigned to this IPv6 tunnel interface. IPv6 processing would be enabled on this IPv6 tunnel interface when an IPv6 address is configured. The 32 bits following the initial 2002::/16 prefix correspond to an IPv4 address assigned to the tunnel source.</p> <p><i>source <ipaddr></i> - The source IPv4 address of this IPv6 tunnel interface. It is used as the source address for packets in this IPv6 tunnel. The tunnel destination IPv4 address is extracted from the remote tunnel endpoint's IPv6 6to4 address that starts with the prefix 2002::/16.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure an IPv6 6to4 tunnel (Tunnel name is "tn2", Tunnel source IPv4 address is 10.0.0.1, Tunnel IPv6 address is 2002:a00:1::1/64):

```
DGS-3627:admin# config ip_tunnel 6to4 tn2 source 10.0.0.1
Command: config ip_tunnel 6to4 tn2 source 10.0.0.1

Success.

DGS-3627:admin# config ip_tunnel 6to4 tn2 ipv6address 2002:a00:1::1/64
Command: config ip_tunnel 6to4 tn2 ipv6address 2002:a00:1::1/64

Success.

DGS-3627:admin#
```

config ip_tunnel isatap

Purpose	Used to configure an IPv6 ISATAP tunnel.
Syntax	config ip_tunnel isatap <tunnel_name 12> {ipv6address <ipv6networkaddr> source <ipaddr>}(1)
Description	The config ip_tunnel isatap command is used to configure an existing IPv6 tunnel as an IPv6 ISATAP tunnel on the switch. If this tunnel has previously been configured in another mode, the tunnel's information will still exist in the database. However, whether the tunnel's former information is invalid or not will depend on the current mode. IPv6 ISATAP tunnels are point-to-multipoint tunnels that can be used to connect systems within a site. An IPv6 ISATAP address is a well-defined unicast address that includes a 64-bit unicast IPv6 prefix (it can be link local or global prefixes), a 32-bit value 0000:5EFE and a 32-bit tunnel source IPv4 address.
Parameters	<p><i><tunnel_name 12></i> - IPv6 Tunnel interface name, maximum of 12 characters.</p> <p><i>ipv6address <ipv6networkaddr></i> - The IPv6 address assigned to this IPv6 tunnel interface. IPv6 processing would be enabled on this IPv6 tunnel interface when an IPv6 address is configured. The last 32 bits of the IPv6 ISATAP address correspond to an IPv4 address assigned to the tunnel source.</p> <p><i>source <ipaddr></i> - The source IPv4 address of this IPv6 tunnel interface. It is used as the source address for packets in this IPv6 tunnel. The tunnel destination IPv4 address is extracted from the last 32 bits of the remote tunnel endpoint's IPv6 ISATAP address.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure an IPv6 ISATAP tunnel (Tunnel name is "tn2", Tunnel source IPv4 address is 10.0.0.1, Tunnel IPv6 address is 2001::5efe:a00:1/64):

```
DGS-3627:admin# config ip_tunnel isatap tn2 source 10.0.0.1
Command: config ip_tunnel isatap tn2 source 10.0.0.1

Success.

DGS-3627:admin# config ip_tunnel isatap tn2 ipv6address 2001::5efe:a00:1/64
Command: config ip_tunnel isatap tn2 ipv6address 2001::5efe:a00:1/64

Success.

DGS-3627:admin#
```

show ip_tunnel

Purpose	Used to show one or all IPv6 tunnel interfaces' information.
Syntax	show ip_tunnel {<tunnel_name 12>}
Description	The show ip_tunnel command is used to show one or all IPv6 tunnel interfaces' information.
Parameters	<p><i><tunnel_name 12></i> - IPv6 Tunnel interface name, maximum of 12 characters.</p> <p>If no tunnel is specified, all tunnels on the Switch will be displayed.</p>
Restrictions	None.

Example usage:

To show an IPv6 tunnel interface's information (Tunnel name is "tn2"):

```
DGS-3627:admin# show ip_tunnel tn2
Command: show ip_tunnel tn2

Tunnel Interface      : tn2
Interface Admin State : Enabled
Tunnel Mode           : Manual
IPv6 Address          : 2000::1/64
Tunnel Source         : 1.0.0.1
Tunnel Destination    : 1.0.0.2

Success.

DGS-3627:admin#
```

enable ip_tunnel

Purpose	Used to enable an IPv6 tunnel interface or all IPv6 tunnel interfaces.
Syntax	enable ip_tunnel {<tunnel_name 12>}
Description	The enable ip_tunnel command is used to enable an IPv6 tunnel or all IPv6 tunnels on the switch.
Parameters	<tunnel_name 12> - IPv6 Tunnel interface name, maximum of 12 characters. If no tunnel is specified, all tunnels on the Switch will be enabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable an IPv6 tunnel interface (Tunnel name is "tn2").:

```
DGS-3627:admin# enable ipif tunnel tn2
Command: enable ipif tunnel tn2

Success.

DGS-3627:admin#
```

disable ip_tunnel

Purpose	Used to disable an IPv6 tunnel interface or all tunnel interfaces.
Syntax	disable ip_tunnel {<tunnel_name 12>}
Description	The disable ip_tunnel command is used to disable an IPv6 tunnel or all IPv6 tunnels on the switch.
Parameters	<tunnel_name 12> - IPv6 Tunnel interface name, maximum of 12 characters. If no tunnel is specified, all tunnels on the Switch will be disabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable an IPv6 tunnel interface (Tunnel name is "tn2").:

```
DGS-3627:admin# disable ip_tunnel tn2
```

```
Command: disable ip_tunnel tn2
```

```
Success.
```

```
DGS-3627:admin#
```

JAPANESE WEB-BASED ACCESS CONTROL (JWAC) COMMANDS

The Japanese Web-based Access Control (JWAC) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
enable jwac	
disable jwac	
enable jwac redirect	
disable jwac redirect	
enable jwac forcible_logout	
disable jwac forcible_logout	
enable jwac udp_filtering	
disable jwac udp_filtering	
enable jwac quarantine_server_monitor	
disable jwac quarantine_server_monitor	
config jwac quarantine_server_error_timeout	<sec 5-300>
config jwac redirect	{destination [quarantine_server jwac_login_page] delay_time <sec 0-10>} (1)
config jwac virtual_ip	<ipaddr> {url [<string 128> clear]}
config jwac quarantine_server_url	<string 128>
config jwac clear_quarantine_server_url	
config jwac update_server	[add delete] ipaddress <network_address> {[tcp_port < port_number 1-65535> udp_port < port_number 1-65535>]}
config jwac switch_http_port	<tcp_port_number 1-65535> {[http https]}
config jwac ports	[<portlist> all] {state [enable disable] max_authenticating_host <value 0-50> aging_time [infinite <min 1-1440>] idle_time [infinite <min 1-1440>] block_time [<sec 0-300>] auth_mode [host_based port_based]} (1)
config jwac radius_protocol	[local pap chap ms_chap ms_chapv2 eap_md5]
create jwac user	<username 15> {vlan <vlanid 1-4094>}
config jwac user	<username 15> {vlan <vlanid 1-4094>}
delete jwac	[user <username 15> all_users]
show jwac user	
clear jwac auth_state	[ports [all <portlist>] { authenticated authenticating blocked } mac_addr <macaddr>]
config jwac authorization attributes	{radius [enable disable] local [enable disable]} (1)

Command	Parameters
show jwac	
show jwac update_server	
show jwac auth_state ports	{<portlist>}
show jwac ports	{<portlist>}
config jwac authentication_page element	[japanese english] [default page_title <desc 128> login_window_title < desc 32> user_name_title < desc 16> password_title < desc 16> logout_window_title < desc 32> notification_line <line value 1-5> <desc 128>]
show jwac authenticate_page	
config jwac authenticate_page	[japanese english]

Each command is listed, in detail, in the following sections.

enable jwac

Purpose	Used to enable JWAC function.
Syntax	enable jwac
Description	The enable jwac command enables JWAC function. JWAC and WAC are mutual exclusive function. That is, they can not be enabled at the same time.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable JWAC function:

```
DGS-3627:admin# enable jwac
Command: enable jwac

Success.

DGS-3627:admin#
```

disable jwac

Purpose	Used to disable JWAC function.
Syntax	disable jwac
Description	The disable jwac command disables JWAC function; all authentication entries related to JWAC will be deleted.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable JWAC function:

```
DGS-3627:admin# disable jwac
Command: disable jwac

Success.

DGS-3627:admin#
```

enable jwac redirect

Purpose	Used to enable JWAC redirect function.
Syntax	enable jwac redirect
Description	When redirecting quarantine server is specified, the unauthenticated host will be redirected to quarantine server when it tries to access a random URL. When redirecting JWAC login page is specified, the unauthenticated host will be redirected to JWAC login page in the Switch to finish authentication. When redirect is enabled, all the web accesses are redirect to quarantine server or JWAC login page. When redirecting to quarantine server is specified, a quarantine server must be configured first before enabling JWAC globally.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable JWAC redirect function:

```
DGS-3627:admin# enable jwac redirect
Command: enable jwac redirect

Success.

DGS-3627:admin#
```

disable jwac redirect

Purpose	Used to disable JWAC redirect function.
Syntax	disable jwac redirect
Description	When redirect is disabled, all web accesses are denied except for accesses to quarantine server or JWAC login page.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable JWAC redirect function:

```
DGS-3627:admin# disable jwac redirect
Command: disable jwac redirect

Success.

DGS-3627:admin#
```

enable jwac forcible_logout

Purpose	Used to enable JWAC forcibly logout function.
Syntax	enable jwac forcible_logout
Description	When forcibly logout feature is enabled, a PING packet from an authenticated host to the JWAC Switch with TTL=1 will be regarded as a logout request, and the host will be moved back to unauthenticated state.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable JWAC forcibly logout function:

```
DGS-3627:admin# enable jwac forcible_logout
```

```
Command: enable jwac forcible_logout
```

```
Success.
```

```
DGS-3627:admin#
```

disable jwac forcible_logout

Purpose	Used to disable JWAC forcibly logout function.
Syntax	disable jwac forcible_logout
Description	When forcibly logout feature is disabled, even a PING packet from an authenticated host to the JWAC Switch with TTL=1 will be ignored, and the host is still in an authenticated state.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable JWAC forcibly logout function:

```
DGS-3627:admin# disable jwac forcible_logout
```

```
Command: disable jwac forcible_logout
```

```
Success.
```

```
DGS-3627:admin#
```

enable jwac udp_filtering

Purpose	Used to enable or disable JWAC UDP filtering function.
Syntax	enable jwac udp_filtering
Description	When UDP filtering feature is enabled, all UDP and ICMP packets except for DHCP and DNS packets from unauthenticated hosts will be dropped.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable JWAC UDP filtering function:

```
DGS-3627:admin# enable jwac udp_filtering
Command: enable jwac udp_filtering

Success.

DGS-3627:admin#
```

disable jwac udp_filtering

Purpose	Used to disable JWAC UDP filtering function.
Syntax	disable jwac udp_filtering
Description	When UDP filtering feature is disabled, all UDP and ICMP packets are permitted.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable JWAC UDP filtering function:

```
DGS-3627:admin# disable jwac udp_filtering
Command: disable jwac udp_filtering

Success.

DGS-3627:admin#
```

enable jwac quarantine_server_monitor

Purpose	Used to enable JWAC Quarantien Server monitor function.
Syntax	enable jwac quarantine_server_monitor
Description	When JWAC Quarantine Server monitor feature is enabled, the JWAC Switch will monitor the Quarantine Server to ensure the server is OK. If the Switch detects no Quarantine Server, it will redirect all unauthenticated HTTP accesses to JWAC Login Page forcibly if the redirect is enabled and the redirect destination is configured to be Quarantine Server.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable JWAC Quarantine Server monitor function:

```
DGS-3627:admin# enable jwac quarantine_server_monitor
Command: enable jwac quarantine_server_monitor

Success.

DGS-3627:admin#
```

disable jwac quarantine_server_monitor

Purpose	Used to disable JWAC Quarantien Server monitor function.
---------	--

disable jwac quarantine_server_monitor

Syntax	disable jwac quarantine_server_monitor
Description	Disable JWAC Quarantine Server function enabled previously.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable Quarantine Server monitor function:

```
DGS-3627:admin# disable jwac quarantine_server_monitor
Command: disable jwac quarantine_server_monitor

Success.

DGS-3627:admin#
```

config jwac quarantine_server_error_timeout

Purpose	Used to set Quarantine Server error timeout.
Syntax	config jwac quarantine_server_error_timeout <sec 5-300>
Description	When Quarantine Server monitor is enabled, the JWAC Switch will periodically check if the Quarantine works OK. If the Switch does not receive any response from Quarantine Server during the configured error timeout, the Switch then regards it as working improperly.
Parameters	<sec 5-300> - To specify the error timeout interval.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set Quarantine Server error timeout:

```
DGS-3627:admin# config jwac quarantine_server_error_timeout 60
Command: config jwac quarantine_server_error_timeout 60

Success.

DGS-3627:admin#
```

config jwac redirect

Purpose	Used to configure redirect destination and delay time before an unauthenticated host is redirect to Quarantine Server or JWAC login web page.
Syntax	config jwac redirect {destination [quarantine_server jwac_login_page] delay_time <sec 0-10>} (1)
Description	This command allows you to configure redirect destination and delay time before an unauthenticated host is redirected to Quarantine Server or the JWAC login web page. 0 means no delaying the redirect.
Parameters	<i>destination</i> - To specify the destination which the unauthenticated host will be redirected to. <i>delay_time</i> - To specify the time period after which the unauthenticated host will be redirected. Unit of this timer is second.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the redirect destination and delay time:

```
DGS-3627:admin# config jwac redirect destination jwac_login_page delay_time 5
Command: config jwac redirect_ destination jwac_login_page delay_time 5

Success.

DGS-3627:admin#
```

config jwac virtual_ip

Purpose	Used to configure JWAC virtual ipaddress to accept authentication requests from unauthenticated hosts.
Syntax	config jwac virtual_ip <ipaddr> {url [<string 128> clear]}
Description	The virtual IP of JWAC is used to accept authentication request from unauthenticated host. Only requests sent to this IP will get response correctly. This IP does not respond to ARP request or ICMP packet!
Parameters	<i><ipaddr></i> - To specify the IP address of the virtual IP. <i>url</i> - This parameter is used to set the URL of virtual IP.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure virtual IP address to accept authentication request from host:

```
DGS-3627:admin# config jwac virtual_ip 1.1.1.1 url www.kyoto.ac.jp
Command: config jwac virtual_ip 1.1.1.1 url www.kyoto.ac.jp

Success.

DGS-3627:admin#
```

config jwac quarantine_server_url

Purpose	Used to configure JWAC Quarantine Server URL.
Syntax	config jwac quarantine_server_url <string 128>
Description	This command allows you to configure URL of Quarantine Server. If the redirection is enabled and the redirection destination is Quarantine Server, when a HTTP request from unauthenticated host which is not headed to Quarantine Server reaches the Switch, the Switch will handle this HTTP packet and send back a message to the host to make it access Quarantine Server with the configured URL When the PC connected to the specified URL, the quarantine server will request the PC user to input the user name and password to authenticate. NOTE: If the quarantine server is linked to the JWAC enabled port on the switch, it must be added to the static FDB correctly before it can work properly.
Parameters	<i><string 128></i> - To specify the entire URL of authentication page on Quarantine Server
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure Quarantine Server URL:

```
DGS-3627:admin# config jwac quarantine_server_url http://10.90.90.88/authpage.html
Command: config jwac quarantine_server_url http://10.90.90.88/authpage.html

Success.

DGS-3627:admin#
```

config jwac clear_quarantine_server_url

Purpose	Used to clear Quarantine Server configuration.
Syntax	config jwac clear_quarantine_server_url
Description	This command will clear Quarantine Server configuration.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To clear Quarantine Server configuration:

```
DGS-3627:admin# config jwac clear_quarantine_server_url
Command: config jwac clear_quarantine_server_url

Success.

DGS-3627:admin#
```

config jwac update_server

Purpose	Used to configure the update server network that PC need to access in order to complete the JWAC authentication.
Syntax	config jwac update_server [add delete] ipaddress <network_address> {[tcp_port < port_number 1-65535> udp_port < port_number 1-65535>]}
Description	<p>The config jwac update server command allows you to add or delete server network address to which the traffic from unauthenticated client host will not be blocked by the JWAC Switch.</p> <p>Any servers (update.microsoft.com or some sites of the Anti-Virus software companies, which the ActiveX needs to access to accomplish the authentication before the client passes the authentication) should be added with its IP address or with the network address it resident. By adding the network address, an entry can serve multiple update servers on the same network.</p> <p>NOTE: If the update server is linked to the JWAC enabled port on the switch, it must be added to the static FDB before it can work properly.</p>
Parameters	<p><i>add</i> - To add an update server network. The total number of Update Servers is depending on project.</p> <p><i>delete</i> - To delete a update server network.</p> <p><i>ipaddress</i> - To specify the network address for the update server network.</p> <p>To set a specific IP address, please use the format x.x.x.x/32</p> <p>If TCP port or UDP port number is not specified, all TCP/UDP ports are accessible.</p> <p><i>tcp_port</i> - The accessible TCP port for the specified update server network.</p> <p><i>udp_port</i> - The accessible UDP port for the specified update server network.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the update server which the un-authenticated host need to access:

```
DGS-3627:admin# config jwac update_server add ipaddress 10.90.90.109/24
Command: config jwac update_server add ipaddress 10.90.90.109/24
Update Server 10.90.90.0/24 is added.

Success.

DGS-3627:admin#
```

config jwac switch_http_port

Purpose	Used to configure the HTTP port which the JWAC Switch listens to.
Syntax	config jwac switch_http_port < tcp_port_number 1-65535> {[http https]}
Description	<p>The config jwac switch_http_port command allows you to configure the TCP port number which the JWAC Switch listens to. This port number is used in the second stage of the authentication. PC user will connect the page on the switch to input the user name and password.</p> <p>If not specified, the default port number is 80.</p> <p>If no protocol specified, the protocol is HTTP.</p> <p>The HTTP cannot run at TCP port 443, and the HTTPS cannot run at TCP port 80.</p>
Parameters	<p><i><tcp_port_number 1-65535></i> - A TCP port which the JWAC Switch listens to and uses to finish the authenticating process.</p> <p><i>http</i> - To specify the JWAC runs HTTP protocol on this TCP port</p> <p><i>https</i> - To specify the JWAC runs HTTPS protocol on this TCP port</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the HTTP port which the Switch listens to:

```
DGS-3627:admin# config jwac switch_http_port 8888 http
Command: config jwac switch_http_port 8888 http

Success.

DGS-3627:admin#
```

config jwac ports

Purpose	Used to configure port's state of JWAC.
Syntax	config jwac ports [<portlist> all] {state [enable disable] max_authenticating_host <value 0-n> aging_time [infinite <min 1-1440>] idle_time [infinite <min 1-1440>] block_time [<sec 0-300>] auth_mode [host_based port_based]} (1)
Description	<p>The config JWAC ports command allows you to configure the port state and other parameters of JWAC. The default value of max_authenticating_host is 50.</p> <p>The default value of aging_time is 1440 minutes.</p> <p>The default value of idle_time is infinite.</p> <p>The default value of block_time is 60 seconds.</p>
Parameters	<i><portlist></i> - A port range to set their JWAC state.

config jwac ports

all - All the Switch ports' JWAC state is to be configured.
state - To specify the port state of JWAC
max_authenticating_host - Max number of host process authentication on each port at the same time
aging_time - A time period during which an authenticated host will keep in authenticated state. "infinite" indicates never to age out the authenticated host on the port
idle_time - If there is no traffic during idle_time, the host will be moved back to unauthenticated state "infinite" indicates never to check the idle state of the authenticated host on the port.
block_time - If a host fails to pass the authentication, it will be blocked for a period specified by block_time.
auth_mode - The port authentication mode can be either host based or port based.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To configure state and other parameters of the ports:

```
DGS-3627:admin# config jwac ports 1-9 state enable
Command: config jwac ports 1-9 state enable

Success.

DGS-3627:admin#
```

config jwac radius_protocol

Purpose	Used to configure RADIUS protocol used by JWAC.
Syntax	config jwac radius_protocol [local pap chap ms_chap ms_chapv2 eap_md5]
Description	The config jwac radius_protocol command allows you to specify the RADIUS protocol used by JWAC to complete RADIUS authentication. JWAC shares other RADIUS configuration with 802.1x, when using this command to set the RADIUS protocol, you must make sure the RADIUS server added by "config radius ..." command supports the protocol.
Parameters	<i>local</i> - JWAC Switch uses local user DB to complete the authentication <i>pap</i> - JWAC Switch uses PAP to communicate with RADIUS Server <i>chap</i> - JWAC Switch uses CHAP to communicate with RADIUS Server <i>ms_chap</i> - JWAC Switch uses MS-CHAP to communicate with RADIUS Server <i>ms_chapv2</i> - JWAC Switch uses MS-CHAPv2 to communicate with RADIUS Server <i>eap_md5</i> - JWAC Switch uses EAP MD5 to communicate with RADIUS Server
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure authentication protocol:

```
DGS-3627:admin# config jwac radius_protocol ms_chapv2
Command: config jwac radius_protocol ms_chapv2

Success.

DGS-3627:admin#
```

create jwac user

Purpose	Used to create JWAC user into local DB.
Syntax	create jwac user <username 15> {vlan <vlanid 1-4094>}
Description	The create jwac user command creates JWAC users into the local DB. And when “local” is chosen when configuring JWAC RADIUS protocol, the local DB will be used.
Parameters	<username 15> - The user name to be created <vlanid 1-4094> - Target VLAN ID for authenticated host which uses this user account to pass authentication
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a local user:

```
DGS-3627:admin# create jwac user 112233
Command: create jwac user 112233

Enter a case-sensitive new password:***
Enter the new password again for confirmation:***
Success.

DGS-3627:admin#
```

config jwac user

Purpose	Used to update local user DB.
Syntax	config jwac user <username 15> {vlan <vlanid 1-4094>}
Description	The config jwac user command updates the local user DB. Only created user can be configured.
Parameters	<username 15> - The user name to be configured <vlanid 1-4094> - Target VLAN ID for authenticated host which uses this user account to pass authentication
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure a local user:

```
DGS-3627:admin# config jwac user juser_tom vlan 3
Command: create jwac user juser_tom vlan 3

Enter a case-sensitive new password:***
Enter the new password again for confirmation:***
Success.

DGS-3627:admin#
```

delete jwac user

Purpose	Used to delete JWAC user into local DB.
Syntax	delete jwac [user <username 15> all_users]
Description	The delete jwac user command deletes JWAC users from the local DB.
Parameters	<i>user</i> - To specify the user name to be deleted <i>all_users</i> - All user accounts in local DB will be deleted.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete a local user.

```
DGS-3627:admin# delete jwac user juser_tom
Command: delete jwac user juser_tom

Success.

DGS-3627:admin#
```

show jwac user

Purpose	Used to show JWAC user into local DB.
Syntax	show jwac user
Description	The show jwac user command displays JWAC users in the local DB.
Parameters	None.
Restrictions	None.

Example usage:

This example displays the JWAC users in the local database:

```
DGS-3627:admin# show jwac user
Command: show jwac user

User Name      Password      VID
-----
juser_tom      1             3

Total Entries : 1

DGS-3627:admin#
```

clear jwac auth_state

Purpose	Used to clear the JWAC authentication entry.
Syntax	clear jwac auth_state [ports [all <portlist>] { authenticated authenticating blocked } mac_addr <macaddr>]
Description	The user can use this command to clear the authentication entry.
Parameters	<p><i>ports</i> - To specify the port range to delete host on them.</p> <p><i>authenticated</i> - To specify the state of host to delete.</p> <p><i>authenticating</i> - To specify the state of host to delete.</p> <p><i>blocked</i> - To specify the state of host to delete.</p> <p><i><macaddr></i> - To delete a specified host with this MAC.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete authentication entry:

```
DGS-3627:admin# clear jwac auth_state ports all blocked
Command: clear jwac auth_state ports all blocked

Success.

DGS-3627:admin#
```

config jwac authorization attributes

Purpose	The enable authorization command will enable acceptance of authorized configuration.
Syntax	config jwac authorization attributes {radius [enable disable] local [enable disable]} (1)
Description	<p>Used to enable or disable acceptance of authorized configuration.</p> <p>When the authorization is enabled for JWAC's RADIUS, the authorized data assigned by the RADIUS server will be accepted if the global authorization network is enabled.</p> <p>When the authorization is enabled for JWAC's local, the authorized data assigned by the local database will be accepted.</p>
Parameters	<p><i>radius</i> - If specified to enable, the authorized data assigned by the RADIUS server will be accepted if the global authorization network is enabled. The default state is enabled.</p> <p><i>local</i> - If specified to enable, the authorized data assigned by the local database will be accepted if the global authorization network is enabled. The default state is enabled.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

The following example will disable the configuration authorized from the local database:

```
DGS-3627:admin# config jwac authorization attributes local disable
Command: config jwac authorization attributes local disable

Success.

DGS-3627:admin#
```

show jwac

Purpose	Used to display the configuration of JWAC.
Syntax	show jwac
Description	The show jwac command allows you to show all the configuration of JWAC.
Parameters	None.
Restrictions	None.

Example usage:

To display global configuration of JWAC:

```
DGS-3627:admin# show jwac
Command: show jwac

State                : Enabled
Enabled Ports        : 1:1,1:11,1:23,1:25,1:35
Virtual IP/URL       : 1.1.1.1/www.kyoto.ac.jp
Switch HTTP Port     : 21212 (HTTP)
UDP Filtering        : Enabled
Forcible Logout      : Enabled
Redirect State       : Enabled
Redirect Delay Time  : 3 Seconds
Redirect Destination : Quarantine Server
Quarantine Server    : http://172.18.212.147/pcinventory
Q-Server Monitor     : Enabled (Running)
Q-Server Error Timeout : 5 Seconds
RADIUS Auth-Protocol : PAP
RADIUS Authorization : Enabled
Local Authorization  : Enabled

DGS-3627:admin#
```

show jwac update_server

Purpose	Used to display the configuration of JWAC update server.
Syntax	show jwac update_server
Description	This command displays the configured update server's network and their accessible ports. The function will use system's common resource, thus some entries may not active if the resource is not sufficient when JWAC is enabled.
Parameters	None.
Restrictions	None.

Example usage:

To show update server:

```
DGS-3627:admin# show jwac update_server
```

```
Command: show jwac update_server
```

Index	IP	TCP/UDP	Port	State
1	10.0.0.0/8	-	-	Inactive
2	10.1.1.1/32	UDP	90	Inactive
3	10.3.3.3/32	TCP	80	Inactive
4	10.3.3.4/32	-	-	Inactive
5	10.3.3.5/32	-	-	Inactive
6	10.3.3.6/32	-	-	Inactive
7	10.3.3.7/32	-	-	Inactive
8	10.3.3.9/32	-	-	Inactive
9	10.3.3.10/32	-	-	Inactive
10	100.100.100.100/32	TCP	9080	Inactive

```
DGS-3627:admin#
```

show jwac auth_state

Purpose	Used to display information of JWAC client host.
Syntax	show jwac auth_state ports {<portlist>}
Description	The show jwac auth_state command allows you to show the information of JWAC client host.
Parameters	<i>ports</i> - A port range to show the information of client host. If no port is specified, all ports' JWAC authentication state will be displayed.
Restrictions	None.

Example usage:

Supposed that port 1 is in host-based mode:

MAC 00-00-00-00-00-01 is authenticated without VLAN assigned (may be the specified target VLAN does not exist or target VLAN has not been specified at all), the ID of RX VLAN will be displayed (RX VLAN ID is 4004 in this example).

MAC 00-00-00-00-00-02 is authenticated with target VLAN assigned, the ID of target VLAN will be displayed (target VLAN ID is 1234 in this example)

MAC 00-00-00-00-00-03 failed to pass authentication, the VID field will be shown as "-" indicating that packets with SA 00-00-00-00-00-03 will be dropped no matter which VLAN these packets are from.

MAC 00-00-00-00-00-04 attempts to start authentication, the VID field will be shown as "-" until authentication completed.

Supposed that port 2 is in port-based mode:

MAC 00-00-00-00-00-10 is the MAC which made port 2 pass authentication, MAC address is followed by "(P)" indicating that this authentication is from a port in port-based mode.

Supposed that port 3 is in port-based mode:

MAC 00-00-00-00-00-20 attempts to start authentication, MAC address is followed by "(P)" to indicate the port-based mode authentication.

MAC 00-00-00-00-00-21 failed to pass authentication, MAC address is followed by "(P)" to indicate the port-based mode authentication.

NOTE: In port-based mode, the VLAN ID field is displayed in the same way as host-based mode.

```
DGS-3627:admin# show jwac auth_state ports 1-2
```

```
Command: show jwac auth_state ports 1-2
```

```
Pri - Priority. State - A:Authenticated, B:Blocked, -:Authenticating
```

```
Time - Aging Time/Idle Time for authenticated entries.
```

Port	MAC Address	State	VID	Pri	Time	IP	User Name
1	00-00-00-00-00-01	A	4004	3	-/40	192.168.101.239	juser_tom
1	00-00-00-00-00-02	A	1234	-	-/50	172.18.61.242	name_of_15chars
1	00-00-00-00-00-03	B	-	-	60	172.18.61.242	Jack
1	00-00-00-00-00-04	-	-	-	10	-	-
2	00-00-00-00-00-10(P)	A	1234	2	1440/20	10.10.10.90	Logan
3	00-00-00-00-00-20(P)	-	-	-	20	10.10.10.131	-
3	00-00-00-00-00-21(P)	B	-	-	200	-	Victor
Total Authenticating Hosts		:		2			
Total Authenticated Hosts		:		3			
Total Blocked Hosts		:		2			

```
DGS-3627:admin#
```

show jwac ports

Purpose	Used to display port configuration of JWAC.
Syntax	show jwac ports {<portlist>}
Description	The show jwac port command allows you to display port configuration of JWAC.
Parameters	<i>all</i> - To show all ports' configuration of JWAC <portlist> - To specify a port range to show the configuration of JWAC If no port is specified, the configuration for all ports will be displayed.
Restrictions	None.

Example usage:

To display port configuration:

```
DGS-3627:admin# show jwac ports 1-4
```

```
Command: show jwac ports 1-4
```

Port	State	Aging Time (min)	Idle Time (min)	Block Time (sec)	Auth Mode	Max Hosts
1	Enabled	Infinite	20	10	Port-Based	10
2	Disabled	60	10	2	Port-Based	10
3	Enabled	1440	Infinite	2	Host-Based	50
4	Enabled	600	30	5	Host-Based	50

```
DGS-3627:admin#
```

config jwac authentication_page element

Purpose	Used to customize the authenticate page.
Syntax	config jwac authentication_page element [japanese english] [default page_title <desc 128> login_window_title < desc 32> user_name_title < desc 16> password_title < desc 16> logout_window_title < desc 32> notification_line <line value 1-5> <desc 128>]
Description	This command let administrator customize the JWAC authenticate page.

config jwac authentication_page element

Parameters	<p><i>japanese</i> - Change to Japanese page.</p> <p><i>english</i> - Change to English page.</p> <p><i>default</i> - Reset the page element to default.</p> <p><i>page_title</i> - The title of the authenticate page.</p> <p><i>login_window_title</i> - The login window title of the authenticate page</p> <p><i>user_name_title</i> - The user name title of the authenticate page</p> <p><i>password_title</i> - The password title of the authenticate page</p> <p><i>logout_window_title</i> - The logout window title mapping of the authenticate page</p> <p><i>notification_line</i> - This parameter is used to set the notification information by line in authentication web pages.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To customize the authenticate page:

```
DGS-3627:admin# config jwac page_element japanese page_title "ディーリンクジャパン株式会社"
"
Command: config jwac page_element japanese page_title "ディーリンクジャパン株式会社"

Success.

DGS-3627:admin#
```

show jwac authenticate_page

Purpose	Used to show the element mapping of the customized authenticate page.
Syntax	show jwac authenticate_page
Description	Used to show the element mapping of the customized authenticate page.
Parameters	None.
Restrictions	None.

Example usage:

The following example displays the default authentication page:


```
DGS-3627:admin# show jwac authenticate_page
```

```
Command: show jwac authenticate_page
```

```
Current Page :English Version
```

```
English Page Element
```

```
-----
Page Title           : Alpha Networks Inc.
Login Window Title   : Authentication Login
User Name Title      : User Name
Password Title       : Password
Logout Window Title  : Logout
Notification         :
Copyright @ 2010 D-Link All Rights Reserved
Site: http://support.dlink.com
```

```
Japanese Page Element
```

```
-----
Page Title           :
Login Window Title   : 社内 LAN 認証ログイン
User Name Title      : ユーザ ID
Password Title       : パスワード
Logout Window Title  : 社内 LAN 認証ログアウト
Notification         :
Copyright @ 2010 ディーリンクジャパン株式会社
    サイト (http://www.dlink-jp.com)
```

```
DGS-3627:admin#
```

config jwac authenticate_page

Purpose	Used to choose authenticate page language.
Syntax	config jwac authenticate_page [japanese english]
Description	This let administrator decide which authenticated page need to be used.
Parameters	<i>japanese</i> - Choose the Japanese page <i>english</i> - Choose the English page. This is the default page.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To choose authenticate page language:

```
DGS-3627:admin# config jwac authenticate_page japanese
```

```
Command: config jwac authenticate_page japanese
```

```
Success.
```

```
DGS-3627:admin#
```

JUMBO FRAME COMMANDS

Certain switches can support jumbo frames (frames larger than the Ethernet frame size of 1536 bytes). To transmit frames of up to 9K (and 9216 bytes tagged), the user can increase the maximum transmission unit (MTU) size from the default of 1536 by enabling the Jumbo Frame command.

The jumbo frame commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
enable jumbo_frame	
disable jumbo_frame	
show jumbo_frame	

Each command is listed, in detail, in the following sections.

enable jumbo_frame

Purpose	Used to enable the jumbo frame function on the Switch.
Syntax	enable jumbo_frame
Description	This command will allow ethernet frames larger than 1536 bytes to be processed by the Switch. The maximum size of the jumbo frame may not exceed 9216 bytes tagged.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the jumbo frame function on the Switch:

```
DGS-3627:admin# enable jumbo_frame
Command: enable jumbo_frame

Success.

DGS-3627:admin#
```

disable jumbo_frame

Purpose	Used to disable the jumbo frame function on the Switch.
Syntax	disable jumbo_frame
Description	This command will disable the jumbo frame function on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the jumbo frame function on the Switch:

```
DGS-3627:admin# disable jumbo_frame
Command: disable jumbo_frame

Success.

DGS-3627:admin#
```

show jumbo_frame

Purpose	Used to show the status of the jumbo frame function on the Switch.
Syntax	show jumbo_frame
Description	This command will show the status of the jumbo frame function on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To show the jumbo frame status currently configured on the Switch:

```
DGS-3627:admin# show jumbo_frame
Command: show jumbo_frame

Jumbo frame state: disabled
Maximum frame size: 1536 bytes

DGS-3627:admin#
```

LIMITED IP MULTICAST ADDRESS COMMANDS

The Limited IP Multicast command allows the administrator to permit or deny access to a port or range of ports by specifying a range of multicast addresses. The Limited IP Multicast Commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config limited multicast address	<portlist> {from <multicast_ipaddr> to <multicast_ipaddr> access [permit deny] state [enable disable]}
delete limited multicast address	[all <portlist>]
show limited multicast address	{<portlist>}
create multicast_range	<range_name 32> from <multicast_ipaddr> to <multicast_ipaddr>
delete multicast_range	[<range_name 32> all]
show multicast_range	{<range_name 32>}
config limited_multicast_addr ports	<portlist> {add multicast_range <range_name 32> delete multicast_range [<range_name 32> all] {access [permit deny] state [enable disable]}}
show limited_multicast_addr	{ports <portlist>}

Each command is listed in detail in the following sections.

config limited multicast address

Purpose	Used to configure limited IP multicast address range.
Syntax	config limited multicast address <portlist> {from <multicast_ipaddr> to <multicast_ipaddr> access [permit deny] state [enable disable]}
Description	The config limited multicast address command allows the user to configure the multicast address range, access level, and state.
Parameters	<p><i><portlist></i> – A port or range of ports to config the limited multicast address. The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex:1-3, 7-9)</p> <p><i>from</i> – Enter the lowest multicast IP address of the range.</p> <p><i>to</i> – Enter the highest multicast IP address of the range.</p> <p><i>access</i> – Use the access field to either <i>permit</i> or <i>deny</i> to limit or grant access to a specified range of Multicast addresses on a particular port or range of ports.</p> <p><i>state</i> – This parameter allows the user to <i>enable</i> or <i>disable</i> the limited multicast address range on a specific port or range of ports.</p>
Restrictions	Only Administrator and Operator-level users can issue this command. This command is used as a backwards compatible command for legacy devices and firmware.

Example usage:

To configure the limited multicast address on ports 1 to 3:

```
DGS-3627:admin# config limited multicast address 1-3 from 224.1.1.1 to 224.1.1.2 access
permit state enable
Command: config limited multicast address 1-3 from 224.1.1.1 to 224.1.1.2 access permit
state enable

Success.

DGS-3627:admin#
```

delete limited multicast address

Purpose	Used to delete Limited IP multicast address range.
Syntax	delete limited multicast address [all <portlist>]
Description	The delete limited multicast address command allows the user to delete all multicast address ranges or a selected range based on what port or ports the range has been assigned to.
Parameters	<p><i>all</i> – Allows the user to delete all limited multicast addresses that have been configured on the Switch.</p> <p><i><portlist></i> – Allows the user to delete only those multicast address ranges that have been assigned to a particular port or range of ports. The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex: 1-3,7-9)</p>
Restrictions	Only Administrator and Operator-level users can issue this command. This command is used as a backwards compatible command for legacy devices.

Example usage:

To delete the limited multicast address on ports 1 to 3:

```
DGS-3627:admin# delete limited multicast address 1-3
Command: delete limited multicast address 1-3

Success.

DGS-3627:admin#
```

show limited multicast address

Purpose	Used to show per-port limited IP multicast address range.
Syntax	show limited multicast address {<portlist>}
Description	The show limited multicast address command allows users to show multicast address range by ports.
Parameters	<portlist> – A port or range of ports on which the limited multicast address range to be shown has been assigned. The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex: 1-3,7-9)
Restrictions	None. This command is used as a backwards compatible command for legacy devices.

Example usage:

To show the limited multicast address on ports 1 to 2:

```
DGS-3627:admin# show limited multicast address 1-2
```

```
Command: show limited multicast address 1-2
```

```
Port      : 1
State     : Disabled
Access    : None
```

No.	Name	From	To
----	-----	-----	-----

```
Port      : 2
State     : Disabled
Access    : None
```

No.	Name	From	To
----	-----	-----	-----

```
Total Entries: 0
```

```
DGS-3627:admin#
```

create multicast_range

Purpose	Used to create a range of multicast IP addresses that will be specified under a given name.
Syntax	create multicast_range <range_name 32> from <multicast_ipaddr> to <multicast_ipaddr>
Description	This command will create a multicast range of IP addresses that will be specified under a given name. Once created, this range name can be added to the config limited_multicast_addr command, therefore setting a list of multicast addresses that will be permitted or denied by the switch.
Parameters	<p><i><range_name 32></i> – Enter a name of up to 32 alphanumeric characters that will be used to identify this multicast range.</p> <p><i>from <multicast_ipaddr></i> – Enter the beginning IP address of the multicast range.</p> <p><i>to <multicast_ipaddr></i> – Enter the ending IP address of the multicast range.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create the multicast range “accounting”:

```
DGS-3627:admin# create multicast_range accounting from 224.19.62.34 to 224.19.62.200
Command: create multicast_range accounting from 224.19.62.34 to 224.19.62.200
```

Success.

```
DGS-3627:admin#
```

delete multicast_range

Purpose	Used to delete a range of multicast IP addresses that will be specified under a given name.
Syntax	delete multicast_range [<range_name 32> all]
Description	This command will delete a multicast range that was created with the create multicast_range command.
Parameters	<p><i><range_name 32></i> – Enter a name of up to 32 alphanumeric characters that will be used to identify this multicast range to be deleted.</p> <p><i>all</i> – Use this parameter to delete all multicast address ranges configured on the Switch.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the multicast range “accounting”:

```
DGS-3627:admin# delete multicast_range accounting
Command: create multicast_range accounting
```

Success.

```
DGS-3627:admin#
```

show multicast_range

Purpose	Used to display a range of multicast IP addresses that are specified under a given name.
Syntax	show multicast_range {<range_name 32>}
Description	This command will display a multicast range that was created with the create multicast_range command.
Parameters	<i><range_name 32></i> – Enter a name of up to 32 alphanumeric characters that will be used to identify this multicast range to be displayed. Entering this command without the specified range_name will display all multicast ranges created on the Switch.
Restrictions	None.

Example usage:

To display the multicast range “accounting”:

```
DGS-3627:admin# show multicast_range accounting
Command:show multicast_range accounting
```

No.	Name	From	To
1	accounting	224.19.62.34	224.19.62.200

Total Entries: 1

```
DGS-3627:admin#
```


config limited_multicast_addr ports

Purpose	Used to add or delete ports to a previously created multicast address range and then to give that range access to or denial from the Switch.
Syntax	config limited_multicast_addr ports <portlist> [add multicast_range <range_name 32> delete multicast_range [<range_name 32> all] {access [permit deny] state [enable disable]}]
Description	This command will perform three tasks for the multicast range. It may add switch ports to the range, delete ports from the multicast range and it may also give these multicast addresses access to the switch, or configure them to be restricted from accessing the Switch.
Parameters	<p><i>ports <portlist></i> – Used to add a list of ports to the multicast range. The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex: 1-3,7-9)</p> <p><i>add</i> – Use this parameter to add ports to the multicast range specified by the following parameter.</p> <ul style="list-style-type: none"> <i>multicast_range <range_name 32></i> – Enter a name of up to 32 alphanumeric characters that will be used to identify this multicast range to be configured. <p><i>delete</i> – Use this parameter to delete ports from the multicast range specified by the following parameters.</p> <ul style="list-style-type: none"> <i>multicast_range <range_name 32></i> – Enter a name of up to 32 alphanumeric characters that will be used to identify this multicast range to be configured. <i>all</i> – Use this parameter to delete these ports from all multicast ranges. <p><i>access</i> – Use this parameter to grant or deny permission of the multicast addresses for the ports based on the following parameters.</p> <ul style="list-style-type: none"> <i>permit</i> – Use this parameter to grant permission to the switch for this multicast range. <i>deny</i> – Use this parameter to deny access from the switch for this multicast range. <p><i>state [enable disable]</i> – Use these parameters to enable or disable this multicast configuration.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To add ports to the multicast range:

```
DGS-3627:admin# config limited_multicast_addr ports 5-8 add multicast_range accounting
Command: config limited_multicast_addr ports 5-8 add multicast_range accounting
```

Success.

```
DGS-3627:admin#
```

Example usage:

To grant the multicast range permission to access the ports:

```
DGS-3627:admin# config limited_multicast_addr ports 5-8 access permit
Command: config limited_multicast_addr ports 5-8 add access permit
```

Success.

```
DGS-3627:admin#
```

show limited_multicast_addr

Purpose	Used to display the limited multicast address range on a per port basis.
Syntax	show limited_multicast_addr {ports <portlist>}
Description	This command will display the limited multicast address range on a per port basis.
Parameters	<i>ports <portlist></i> – Enter a port or list of ports to be displayed. The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex: 1-3,7-9) Entering this command without the portlist parameter will display the limited multicast range for all ports on the switch.
Restrictions	None.

Example usage:

To display the multicast range Trinity:

```
DGS-3627:admin# show limited_multicast_addr ports 5
Command: show limited_multicast_addr ports 5

Port      : 5
State     : Disabled
Access    : None

No.       Name                From                To
-----  -
1         accounting          224.19.62.34       224.19.62.200

Total Entries: 1

DGS-3627:admin#
```

LINK AGGREGATION COMMANDS

The link aggregation commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Link aggregation, also known as trunking, is a method of grouping physical link segments of the same media type and speed, and treating them as if they were part of a single, logical link segment. In general, link aggregation provides two important benefits: increased performance and increased resiliency.

Command	Parameters
create link_aggregation group_id	<value 1-32> {type [lacp static]}
delete link_aggregation group_id	<value 1-32>
config link_aggregation group_id	<value 1-32> {master_port <port> ports <portlist> state [enable disable]}
config link_aggregation algorithm	[mac_source mac_destination mac_source_dest ip_source ip_destination ip_source_dest]
show link_aggregation	{group_id <value 1-32> algorithm}
config lacp_port	<portlist> mode [active passive]
show lacp_port	{<portlist>}

Each command is listed, in detail, in the following sections.

create link_aggregation

Purpose	Used to create a link aggregation group on the Switch.
Syntax	create link_aggregation group_id <value 1-32> {type [lacp static]}
Description	This command will create a link aggregation group with a unique identifier.
Parameters	<p><value> – Specifies the group ID. The Switch allows up to 32 link aggregation groups to be configured. The group number identifies each of the groups.</p> <p><i>type</i> – Specify the type of link aggregation used for the group. If the type is not specified the default type is <i>static</i>.</p> <ol style="list-style-type: none"> 1. <i>lacp</i> – This designates the port group as LACP compliant. LACP allows dynamic adjustment to the aggregated port group. LACP compliant ports may be further configured (see config lacp_ports). LACP compliant must be connected to LACP compliant devices. 2. <i>static</i> – This designates the aggregated port group as static. Static port groups can not be changed as easily as LACP compliant port groups since both linked devices must be manually configured if the configuration of the trunked group is changed.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a link aggregation group:

```
DGS-3627:admin# create link_aggregation group_id 1
Command: create link_aggregation group_id 1

Success.

DGS-3627:admin#
```

delete link_aggregation group_id

Purpose	Used to delete a previously created link aggregation group.
Syntax	delete link_aggregation group_id <value 1-32>
Description	This command is used to delete a previously configured link aggregation group.
Parameters	<i><value 1-32></i> – Specifies the group ID. The Switch allows up to 32 link aggregation groups to be configured. The group number identifies each of the groups.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete link aggregation group:

```
DGS-3627:admin# delete link_aggregation group_id 6
Command: delete link_aggregation group_id 6

Success.

DGS-3627:admin#
```

config link_aggregation

Purpose	Used to configure a previously created link aggregation group.
Syntax	config link_aggregation group_id <value 1-32> {master_port <port> ports <portlist> state [enable disable]}
Description	This command allows users to configure a link aggregation group that was created with the create link_aggregation command above.
Parameters	<p><i>group_id <value 32></i> – Specifies the group ID. The Switch allows up to 32 link aggregation groups to be configured. The group number identifies each of the groups.</p> <p><i>master_port <port></i> – Master port ID. Specifies which port (by port number) of the link aggregation group will be the master port. All of the ports in a link aggregation group will share the port configuration with the master port.</p> <p><i>ports <portlist></i> – Specifies a port or range of ports that will belong to the link aggregation group including the master port. The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex: 1-3,7-9)</p> <p><i>state [enable disable]</i> – Allows users to enable or disable the specified link aggregation group.</p>
Restrictions	Only Administrator and Operator-level users can issue this command. Link aggregation groups may not overlap.

Example usage:

To define a load-sharing group of ports, group-id 1, master port 5 with group members ports 5-7 plus port 9:

```
DGS-3627:admin# config link_aggregation group_id 1 master_port 1:5 ports 1:5-1:7,9
Command: config link_aggregation group_id 1 master_port 1:5 ports 1:5-1:7,1:9
Success.

DGS-3627:admin#
```

config link_aggregation algorithm

Purpose	Used to configure the link aggregation algorithm.
Syntax	config link_aggregation algorithm [mac_source mac_destination mac_source_dest ip_source ip_destination ip_source_dest]
Description	This command configures the part of the packet examined by the Switch when selecting the egress port for transmitting load-sharing data. This feature is only available using the address-based load-sharing algorithm.
Parameters	<p><i>mac_source</i> – Indicates that the Switch should examine the source MAC address.</p> <p><i>mac_destination</i> – Indicates that the Switch should examine the destination MAC address.</p> <p><i>mac_source_dest</i> – Indicates that the Switch should examine the source and destination MAC addresses</p> <p><i>ip_source</i> – Indicates that the Switch should examine the source IP address.</p> <p><i>ip_destination</i> – Indicates that the Switch should examine the destination IP address.</p> <p><i>ip_source_dest</i> – Indicates that the Switch should examine the source and the destination IP address.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure link aggregation algorithm for mac-source-dest:

```
DGS-3627:admin# config link_aggregation algorithm mac_source_dest
Command: config link_aggregation algorithm mac_source_dest

Success.

DGS-3627:admin#
```

show link_aggregation

Purpose	Used to display the current link aggregation configuration on the Switch.
Syntax	show link_aggregation {group_id <value 1-32> algorithm}
Description	This command will display the current link aggregation configuration of the Switch.
Parameters	<p><value 1-32> – Specifies the group ID. The Switch allows up to 32 link aggregation groups to be configured. The group number identifies each of the groups.</p> <p><i>algorithm</i> – Allows you to specify the display of link aggregation by the algorithm in use by that group.</p>
Restrictions	None.

Example usage:

To display Link Aggregation configuration:

```
DGS-3627:admin# show link_aggregation
Command: show link_aggregation

Link Aggregation Algorithm = IP-source
Group ID       : 1
Type           : TRUNK
Master Port    : 1:5
Member Port    : 1:5-1:7,1:9
Active Port    :
Status        : Disabled
Flooding Port  :

Total Entries : 1
DGS-3627:admin#
```

config lacp_ports

Purpose	Used to configure settings for LACP compliant ports.
Syntax	config lacp_ports <portlist> mode [active passive]
Description	This command is used to configure ports that have been previously designated as LACP ports (see create link_aggregation).
Parameters	<p><i><portlist></i> – Specifies a port or range of ports to be configured. The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex: 1-3,7-9)</p> <p><i>mode</i> – Select the mode to determine if LACP ports will process LACP control frames.</p> <ol style="list-style-type: none"> <i>active</i> – Active LACP ports are capable of processing and sending LACP control frames. This allows LACP compliant devices to negotiate the aggregated link so the group may be changed dynamically as needs require. In order to utilize the ability to change an aggregated port group, that is, to add or subtract ports from the group, at least one of the participating devices must designate LACP ports as active. Both devices must support LACP. <i>passive</i> – LACP ports that are designated as passive cannot process LACP control frames. In order to allow the linked port group to negotiate adjustments and make changes dynamically, at one end of the connection must have “active” LACP ports (see above).
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure LACP port mode settings:

```
DGS-3627:admin# config lacp_port 1:1-1:12 mode active
Command: config lacp_port 1:1-1:12 mode active

Success.

DGS-3627:admin#
```

show lacp_port

Purpose	Used to display current LACP port mode settings.
Syntax	show lacp_port {<portlist>}
Description	This command will display the LACP mode settings as they are currently configured.
Parameters	<i><portlist></i> – Specifies a port or range of ports to be configured. The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex: 1-3,7-9) If no parameter is specified, the system will display the current LACP status for all ports.
Restrictions	None.

Example usage:

To display LACP port mode settings:

```
DGS-3627:admin# show lacp_port 1-10
Command: show lacp_port 1-10
```

```
Port      Activity
-----  -
1:1      Active
1:2      Active
1:3      Active
1:4      Active
1:5      Active
1:6      Active
1:7      Active
1:8      Active
1:9      Active
1:10     Active
```

```
DGS-3627:admin#
```

LINK LAYER DISCOVERY PROTOCOL (LLDP) COMMANDS

The Link Layer Discovery Protocol (LLDP) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

The Link Layer Discovery Protocol (LLDP) specified in this standard allows stations attached to an 802 LAN to advertise to other stations attached to the same 802 LAN the connectivity and management information necessary to identify to those management entities the station's point of attachment to the 802 LAN. The information distributed via this protocol is stored by its recipients in a standard management information base (MIB), making it possible for the information to be accessed by a network management system (NMS) using a management protocol such as the Simple Network Management Protocol (SNMP)

Command	Parameters
enable lldp	
disable lldp	
config lldp	message_tx_interval <sec 5-32768>
config lldp	message_tx_hold_multiplier <int 2-10>
config lldp	tx_delay <sec 1-8192>
config lldp	reinit_delay <sec 1-10>
config lldp	notification_interval <sec 5-3600>
config lldp ports	[<portlist> all] notification [enable disable]
config lldp ports	[<portlist> all] admin_status [tx_only rx_only tx_and_rx disable]
config lldp ports	[<portlist> all] mgt_addr [ipv4 <ipaddr> ipv6 <ipv6addr>] [enable disable]
config lldp ports	[<portlist> all] basic_tlvs [all {port_description system_name system_description system_capabilities}] [enable disable]
config lldp ports	[<portlist> all] dot1_tlv_pvid [enable disable]
config lldp ports	[<portlist> all] dot1_tlv_protocol_vid [vlan [all <vlan_name 32>] vlanid <vidlist>] [enable disable]
config lldp ports	[<portlist> all] dot1_tlv_vlan_name [vlan [all <vlan_name 32>] vlanid <vidlist>] [enable disable]
config lldp ports	[<portlist> all] dot1_tlv_protocol_identity[all { eapol lacp gvrp stp}] [enable disable]
config lldp ports	[<portlist> all] dot3_tlvs [all {mac_phy_configuration_status link aggregation maximum_frame_size}] [enable disable]
config lldp	forward_message [enable disable]
show lldp	
show lldp mgt_addr	{[ipv4 <ipaddr> ipv6 <ipv6addr>]}
show lldp ports	{<portlist>}
show lldp local_ports	{<portlist>} {mode [brief normal detailed]}
show lldp remote_ports	{<portlist>} {mode [brief normal detailed]}
show lldp statistics	
show lldp statistics ports	{<portlist>}

Each command is listed, in detail, in the following sections.

enable lldp

Purpose	Used to enable LLDP operation on the Switch.
Syntax	enable lldp
Description	This is a global control for the LLDP function. When this function is enabled, the switch can start to transmit LLDP packets and receive and process the LLDP packets. The specific function of each port will depend on the per port LLDP setting. For the advertisement of LLDP packets, the switch announces the information to its neighbor through ports. For the receiving of LLDP packets, the switch will learn the information from the LLDP packets advertised from the neighbor in the Neighbor's table. The default state for LLDP is disabled.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable LLDP:

```
DGS-3627:admin# enable lldp
Command: enable lldp

Success.

DGS-3627:admin#
```

disable lldp

Purpose	Used to disable LLDP operation on the Switch.
Syntax	disable lldp
Description	This command will stop the sending and receiving of LLDP advertisement packets on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable LLDP:

```
DGS-3627:admin# disable lldp
Command: disable lldp

Success.

DGS-3627:admin#
```

config lldp message_tx_interval

Purpose	Used to change the packet transmission interval.
Syntax	config lldp message_tx_interval <sec 5 – 32768>
Description	This interval controls how often active ports retransmit advertisements to their neighbors.
Parameters	<i>message_tx_interval</i> – Changes the interval between consecutive transmissions of LLDP advertisements on any given port. The range is from 5 seconds to 32768 seconds. The default setting is 30 seconds.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show the packet transmission interval:

```
DGS-3627:admin# config lldp message_tx_interval 30
Command: config lldp message_tx_interval 30

Success.

DGS-3627:admin#
```

config lldp message_tx_hold_multiplier

Purpose	Used to configure the message hold multiplier.
Syntax	config lldp message_tx_hold_multiplier <int 2-10 >
Description	This parameter is a multiplier on the msgTxInterval that is used to compute the TTL value of txTTL in an LLDPDU. TheTTL will be carried in the LLDPDU packet. The lifetime will be the minimum of 65535 and (message_tx_interval * message_tx_hold_multiplier). At the partner switch, when the time-to-live for a given advertisement expires, the advertised data is deleted from the neighbor switch's MIB
Parameters	<i>message_hold_multiplier</i> – The range is from 2 to 10. The default setting is 4.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To change the multiplier value:

```
DGS-3627:admin# config lldp message_tx_hold_multiplier 3
Command: config lldp message_tx_hold_multiplier 3

Success.

DGS-3627:admin#
```

config lldp tx_delay

Purpose	Used to change the minimum time (delay-interval) LLDP ports will delay in advertising successive LLDP advertisements due to a change in LLDP MIB content. The tx_delay defines the minimum interval between sending of LLDP messages due to constantly change of MIB content.
Syntax	config lldp tx_delay < sec 1–8192 >
Description	The LLDP message_tx_interval (transmit interval) must be greater than or equal to (4 x tx_delay interval).
Parameters	<i>tx_delay</i> – The range is from 1 second to 8192 seconds. The default setting is 2 seconds. NOTE: txDelay should be less than or equal to 0.25 * msgTxInterval
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the delay interval:

```
DGS-3627:admin# config lldp tx_delay 8
Command: config lldp tx_delay 8

Success.

DGS-3627:admin#
```

config lldp reinit_delay

Purpose	Change the minimum time of the reinitialization delay interval.
Syntax	config lldp reinit_delay <sec 1 - 10>
Description	A re-enabled LLDP port will wait for reinit_delay after last disable command before reinitializing.
Parameters	<i>reinit_delay</i> – The range is from 1 second to 10 seconds. The default setting is 2 seconds.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To changes the re-initialization delay interval to five seconds:

```
DGS-3627:admin# config lldp reinit_delay 5
Command: config lldp reinit_delay 5

Success.

DGS-3627:admin#
```

config lldp notification _interval

Purpose	Used to configure the timer of the notification interval for sending notification to configured SNMP trap receiver(s).
Syntax	config lldp notification_interval <sec 5 – 3600 >
Description	Globally change the interval between successive LLDP change notifications generated by the switch.
Parameters	<i>notification_interval</i> – The range is from 5 seconds to 3600 seconds. The default setting is 5 seconds.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To change the notification interval to 10 seconds:

```
DGS-3627:admin# config lldp notification_interval 10
Command: config lldp notification_interval 10

Success.

DGS-3627:admin#
```

config lldp ports notification

Purpose	Used to configure each port for sending notification to configured SNMP trap receiver(s).
Syntax	config lldp ports [<portlist> all] notification [enable disable]
Description	Enable or disable each port for sending changes notification to configured SNMP trap receiver(s) if an LLDP data change is detected in an advertisement received on the port from an LLDP neighbor. The definition of change includes new available information, information timeout, information update. And the changed type includes any data update /insert/remove.
Parameters	<i><portlist></i> – Use this parameter to define ports to be configured. <i>all</i> – Use this parameter to set all ports in the system. <i>notification</i> – Enables or disables the SNMP trap notification of LLDP data changes detected on advertisements received from neighbor devices. The default notification state is disabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To change the SNMP notification state of ports 1 to 5 to enable:

```
DGS-3627:admin# config lldp ports 1:1-1:5 notification enable
Command: config lldp ports 1:1-1:5 notification enable

Success.

DGS-3627:admin#
```

config lldp ports admin_status

Purpose	Used to configure per-port transmit and receive modes.
Syntax	config lldp ports [<portlist> all] admin_status [tx_only rx_only tx_and_rx disable]
Description	These options enable the user to control which ports participate in LLDP traffic and whether the participating ports allow LLDP traffic in only one direction or in both directions.
Parameters	<p><portlist> – Use this parameter to define ports to be configured.</p> <p>all – Use this parameter to set all ports in the system.</p> <p>admin_status – tx_only: Configure the specified port(s) to transmit LLDP packets, but block inbound LLDP packets from neighbor devices; rx_only: Configure the specified port(s) to receive LLDP packets from neighbors, but block outbound packets to neighbors; tx_and_rx: Configure the specified port(s) to both transmit and receive LLDP packets; disable: Disable LLDP packet transmit and receive on the specified port(s). The default per port state is tx_and_rx.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure ports 1 to 5 to transmit and receive:

```
DGS-3627:admin# config lldp ports 1:1-1:5 admin_status tx_and_rx
Command: config lldp ports 1:1-1:5 admin_status tx_and_rx

Success.

DGS-3627:admin#
```

config lldp ports mgt_addr

Purpose	Used to enable or disable port(s) specified for advertising indicated management address instance.
Syntax	config lldp ports [<portlist> all] mgt_addr [ipv4 <ipaddr> ipv6 <ipv6addr>] [enable disable]
Description	This command specifies whether the system's IP address needs to be advertised from the specified port. For layer 3 devices, each managed address can be individually specified. The management addresses that are added in the list will be advertised in the LLDP from the specified interface associated with each management address. The interface for that management address will be also advertised in the if-index form
Parameters	<p><portlist> – Use this parameter to define ports to be configured.</p> <p>all – Use this parameter to set all ports in the system.</p> <p>ipv4 – The IP address of IPv4.</p> <p>ipv6 – The IP address of IPv6.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable ports 1 to 2 to manage address entry:

```
DGS-3627:admin# config lldp ports 1:1-1:2 mgt_addr ipv4 192.168.254.10 enable
Command: config lldp ports 1:1-1:2 mgt_addr ipv4 192.168.254.10 enable

Success.

DGS-3627:admin#
```

config lldp ports basic_tlvs

Purpose	Used to configure an individual port or group of ports to exclude one or more optional TLV data types from outbound LLDP advertisements.
Syntax	config lldp ports [<portlist> all] basic_tlvs [all {port_description system_name system_description system_capabilities}] [enable disable]
Description	An active LLDP port on the switch always includes the mandatory data in its outbound advertisements. And there are four optional data that can be configured for an individual port or group of ports to exclude one or more of these data types from outbound LLDP advertisements. The mandatory data type include four basic types of information (end f LLDPDU TLV, chassis ID TLV, port ID TLV, and Time to Live TLV). The mandatory type can not be disabled. There are also four data types which can be optionally selected. They are <i>port_description</i> , <i>system_name</i> , <i>system_description</i> , and <i>system_capability</i> .
Parameters	<p><i><portlist></i> – Use this parameter to define ports to be configured.</p> <p><i>all</i> – Use this parameter to set all ports in the system.</p> <p><i>port_description</i> – This TLV optional data type indicates that LLDP agent should transmit 'Port Description TLV' on the port. The default state is disabled.</p> <p><i>system_name</i> – This TLV optional data type includes indicates that LLDP agent should transmit 'System Name TLV'. The default state is disabled.</p> <p><i>system_description</i> – This TLV optional data type includes indicates that LLDP agent should transmit 'System Description TLV'. The default state is disabled.</p> <p><i>system_capabilities</i> – This TLV optional data type includes indicates that LLDP agent should transmit 'System Capabilities TLV'. The system capability will indicate whether the device provides repeater, bridge, or router function, and whether the provided functions are currently enabled. The default state is disabled.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure exclude the system name TLV from the outbound LLDP advertisements for all ports:

```
DGS-3627:admin# config lldp ports all basic_tlvs system_name enable
Command: config lldp ports all basic_tlvs system_name enable

Success.

DGS-3627:admin#
```

config lldp dot1_tlv_pvid

Purpose	Used to configure an individual port or group of ports to exclude one or more of IEEE 802.1 organization port VLAN ID TLV data types from outbound LLDP advertisements.
Syntax	config lldp ports [<portlist> all] dot1_tlv_pvid [enable disable]
Description	This TLV optional data type determines whether the IEEE 802.1 organization defined port VLAN TLV transmission is allowed on a given LLDP transmission capable port.
Parameters	<p><portlist> – Use this parameter to define ports to be configured.</p> <p>all – Use this parameter to set all ports in the system.</p> <p>dot1_tlv_pvid – This TLV optional data type determines whether the IEEE 802.1 organization defined port VLAN ID TLV transmission is allowed on a given LLDP transmission capable port. The default state is disabled.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure exclude the VLAN name TLV from the outbound LLDP advertisements for all ports:

```
DGS-3627:admin# config lldp ports all dot1_tlv_pvid enable
Command: config lldp ports all dot1_tlv_pvid enable
```

Success.

```
DGS-3627:admin#
```

config lldp dot1_tlv_protocol_vid

Purpose	Used to configure an individual port or group of ports to exclude one or more of IEEE 802.1 organization port and protocol VLAN ID TLV data types from outbound LLDP advertisements.
Syntax	config lldp ports [<portlist> all] dot1_tlv_protocol_vid [vlan [all <vlan_name 32>] vlanid <vidlist>] [enable disable]
Description	This TLV optional data type indicates whether the corresponding Local System's port and protocol VLAN ID instance will be transmitted on the port. If a port is associated with multiple protocol VLANs, those enabled port and protocol VLAN IDs will be advertised.
Parameters	<p><portlist> – Use this parameter to define ports to be configured.</p> <p>all – Use this parameter to set all ports in the system.</p> <p>dot1_tlv_protocol_vid – This TLV optional data type determines whether the IEEE 802.1 organization defined port and protocol VLAN ID TLV transmission is allowed on a given LLDP transmission capable port. The default state is disabled.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure exclude the port and protocol VLAN ID TLV from the outbound LLDP advertisements for all ports:

```
DGS-3627:admin# config lldp ports all dot1_tlv_protocol_vid vlnid 1-3 enable
Command: config lldp ports all dot1_tlv_protocol_vid vlnid 1-3 enable
```

Success.

```
DGS-3627:admin#
```


config lldp dot1_tlv_vlan_name

Purpose	Used to configure an individual port or group of ports to exclude one or more of IEEE 802.1 organization VLAN name TLV data types from outbound LLDP advertisements.
Syntax	config lldp ports [<portlist> all] dot1_tlv_vlan_name [vlan [all <vlan_name 32>] vlanid <vidlist>] [enable disable]
Description	This TLV optional data type indicates whether the corresponding Local System's VLAN name instance will be transmitted on the port. If a port is associated with multiple VLANs, those enabled VLAN IDs will be advertised.
Parameters	<p><portlist> – Use this parameter to define ports to be configured.</p> <p>all – Use this parameter to set all ports in the system.</p> <p>dot1_tlv_vlan_name – This TLV optional data type indicates whether the corresponding Local System's VLAN name instance will be transmitted on the port. If a port is associated with multiple VLANs, those enabled VLAN IDs will be advertised. The default state is disabled.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure exclude the VLAN name TLV from the outbound LLDP advertisements for all ports:

```
DGS-3627:admin# config lldp ports all dot1_tlv_vlan_name vlanid 1-3 enable
Command: config lldp ports all dot1_tlv_vlan_name vlanid 1-3 enable

Success.

DGS-3627:admin#
```

config lldp dot1_tlv_protocol_identity

Purpose	Used to configure an individual port or group of ports to exclude one or more of IEEE 802.1 organization protocol identity TLV data types from outbound LLDP advertisements.
Syntax	config lldp ports [<portlist> all] dot1_tlv_protocol_identity [all {eapol lacp gvrp stp }] [enable disable]
Description	This TLV optional data type indicates whether the corresponding Local System's Protocol Identity instance will be transmitted on the port. The Protocol Identity TLV provides a way for stations to advertise protocols that are important to the operation of the network. Such as Spanning Tree Protocol, the Link Aggregation Control Protocol, and numerous vendor proprietary variations are responsible for maintaining the topology and connectivity of the network. If EAPOL, GVRP, STP (including MSTP), and LACP protocol identity is enabled on this port and it is enabled to be advertised, then this protocol identity will be advertised.
Parameters	<p><portlist> – Use this parameter to define ports to be configured.</p> <p>all – Use this parameter to set all ports in the system.</p> <p>dot1_tlv_protocol_identity – This TLV optional data type indicates whether the corresponding Local System's Protocol Identity instance will be transmitted on the port. The Protocol Identity TLV provides a way for stations to advertise protocols that are important to the operation of the network, such as Spanning Tree Protocol, the Link Aggregation Control Protocol, and numerous vendor proprietary variations which are responsible for maintaining the topology and connectivity of the network. If EAPOL, GVRP, STP (including MSTP), and LACP protocol identity is enabled on this port and it is enabled to be advertised, then this protocol identity will be advertised. The default state is disabled.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure exclude the protocol identity TLV from the outbound LLDP advertisements for all ports:

```
DGS-3627:admin# config lldp ports all dot1_tlv_protocol_identity all enable
Command: config lldp ports all dot1_tlv_protocol_identity all enable

Success.

DGS-3627:admin#
```

config lldp dot3_tlvs

Purpose	Used to configure an individual port or group of ports to exclude one or more of IEEE 802.3 organization specific TLV data types from outbound LLDP advertisements.
Syntax	config lldp ports [<portlist>] all dot3_tlvs [all { mac_phy_configuration_status link_aggregation maximum_frame_size }] [enable disable]
Description	Each Specific TLV in this extension can be enabled individually.
Parameters	<p><portlist> – Use this parameter to define ports to be configured.</p> <p>all – Use this parameter to set all ports in the system.</p> <p>mac_phy_configuration_status – This TLV optional data type indicates that LLDP agent should transmit 'MAC/PHY configuration/status TLV'. This type indicates it is possible for two ends of an IEEE 802.3 link to be configured with different and/or speed settings and still establish some limited network connectivity. More precisely, the information includes whether the port support the auto-negotiation function, whether the function is enabled, the auto-negotiated advertised capability, and the operational MAU type. The default state is disabled.</p> <p>link_aggregation – This TLV optional data type indicates that LLDP agent should transmit 'Link Aggregation TLV'. This type indicates the current link aggregation status of IEEE 802.3 MACs. More precisely, the information should include whether the port is capable of doing link aggregation, whether the port is aggregated in a aggregated link, and the aggregated port ID. The default state is disabled.</p> <p>power_via_mdi – This TLV optional data type indicates that the LLDP agent should transmit 'Power via MDI TLV'. Three IEEE 802.3 PMD implementations (10BASE-T, 100BASE-TX, and 1000BASE-T) allow power to be supplied over the link for connected non-powered systems. The Power Via MDI TLV allows network management to advertise and discover the MDI power support capabilities of the sending IEEE 802.3 LAN station. The default state is disabled.</p> <p>NOTE: Not supported in the current release.</p> <p>maximum_frame_size – This TLV optional data type indicates that LLDP agent should transmit 'Maximum-frame-size TLV'. The default state is disabled.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure exclude the MAC/PHY configuration/status TLV from the outbound LLDP advertisements for all ports:

```
DGS-3627:admin# config lldp ports all dot3_tlvs mac_phy_configuration_status enable
Command: config lldp ports all dot3_tlvs mac_phy_configuration_status enable

Success.

DGS-3627:admin#
```

config lldp forward_message

Purpose	Used to configure the forwarding of LLDPDU packets when LLDP is disabled.
Syntax	config lldp forward_message [enable disable]
Description	When LLDP is disabled and LLDP forward_message is enabled, the received LLDPDU packets will be forwarded. The default state is disabled.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure LLDP forward_message:

```
DGS-3627:admin# config lldp forward_message enable
Command: config lldp forward_message enable

Success.

DGS-3627:admin#
```

show lldp

Purpose	This command displays the switch's general LLDP configuration status.
Syntax	show lldp
Description	This command displays the switch's general LLDP configuration status.
Parameters	None.
Restrictions	None.

Example usage:

To display the LLDP system level configuration status:

```
DGS-3627:admin# show lldp
Command: show lldp

LLDP System Information
  Chassis ID Subtype      : MAC Address
  Chassis ID              : 00-19-5B-F5-26-C0
  System Name             :
  System Description      : Gigabit Ethernet Switch
  System Capabilities     : Repeater, Bridge

LLDP Configurations
  LLDP Status             : Disabled
  LLDP Forward Status     : Disabled
  Message Tx Interval     : 30
  Message Tx Hold Multiplier: 4
  ReInit Delay            : 2
  Tx Delay                : 2
  Notification Interval   : 5

DGS-3627:admin#
```

show lldp mgt_addr

Purpose	Used to display the LLDP management address information.
Syntax	show lldp mgt_addr {[ipv4 <ipaddr> ipv6 <ipv6addr>]}
Description	Displays the LLDP management address information.
Parameters	<i>ipv4</i> – The IP address of IPv4. <i>ipv6</i> – The IP address of IPv6.
Restrictions	None.

Example usage:

To display management address information for port 1:

```
DGS-3627:admin# show lldp mgt_addr ipv4 192.168.254.10
Command: show lldp mgt_addr ipv4 192.168.254.10
```

Address 1

```
-----
Subtype           : IPv4
Address           : 192.168.254.10
IF type          : Unknown
OID              : 1.3.6.1.4.1.171.10.36.1.11
Advertising Ports : 1:1-1:5, 1:7, 2:10-2:20
```

```
DGS-3627:admin#
```

show lldp ports

Purpose	Display the LLDP per port configuration for advertisement options.
Syntax	show lldp ports {<portlist>}
Description	This command displays the LLDP per port configuration for advertisement options.
Parameters	<portlist> – Use this parameter to define ports to be configured.
Restrictions	None.

Example usage:

To display the LLDP per port TLV option configuration:

```
DGS-3627:admin# show lldp ports 1
```

```
Command: show lldp ports 1
```

```
Port ID : 1:1
```

```
-----
```

```
Admin Status : TX_and_RX
```

```
Notification Status : Disabled
```

```
Advertised TLVs Option :
```

```
Port Description Disabled
```

```
System Name Disabled
```

```
System Description Disabled
```

```
System Capabilities Disabled
```

```
Enabled Management Address
```

```
(None)
```

```
Port VLAN ID Disabled
```

```
Enabled Port_and_Protocol_VLAN_ID
```

```
(None)
```

```
Enabled VLAN Name
```

```
(None)
```

```
Enabled Protocol_Identity
```

```
(None)
```

```
MAC/PHY Configuration/Status Disabled
```

```
Link Aggregation Disabled
```

```
Maximum Frame Size Disabled
```

```
DGS-3627:admin#
```

show lldp local_ports

Purpose	Used to display the per-port information currently available for populating outbound LLDP advertisements.
Syntax	show lldp local_ports {<portlist>} {mode [brief normal detailed]}
Description	This command displays the per-port information currently available for populating outbound LLDP advertisements.
Parameters	<p><portlist> – Use this parameter to define ports to be configured.</p> <p><i>brief</i> – Display the information in brief mode.</p> <p><i>normal</i> – Display the information in normal mode. This is the default display mode.</p> <p><i>detailed</i> – Display the information in detailed mode.</p>
Restrictions	None.

Example usage:

To display outbound LLDP advertisements for port 1:

```
DGS-3627:admin# show lldp local_ports 1
```

```
Command: show lldp local_ports 1
```

```
Port ID : 1:1
```

```
-----
Port ID Subtype           : Local
Port ID                   : 1/1
Port Description          :
Port PVID                 : 1
Management Address Count : 1
PPVID Entries Count      : 0
VLAN Name Entries Count  : 1
Protocol Identity Entries Count : 0
MAC/PHY Configuration/Status : (See Detail)
Link Aggregation         : (See Detail)
Maximum Frame Size       : 1536
```

```
CTRL+C ESC q Quit SPACE n Next Page Enter Next Entry a All
```

show lldp remote_ports

Purpose	Used to display the information learned from the neighbor.
Syntax	show lldp remote_ports {<portlist>} {mode [brief normal detailed]}
Description	This command display the information learned from the neighbor parameters. Due to a memory limitation, only 32 VLAN Name entries and 10 Management Address entries can be received.
Parameters	<p><i><portlist></i> – Use this parameter to define ports to be configured.</p> <p><i>mode</i> – Choose from three options:</p> <p><i>brief</i> – Display the information in brief mode.</p> <p><i>normal</i> – Display the information in normal mode. This is the default display mode.</p> <p><i>detailed</i> – Display the information in detailed mode.</p>
Restrictions	None.

Example usage:

To display remote table in brief mode:

```
DGS-3627:admin# show lldp remote_ports 1-2 mode brief
```

```
Command: show lldp remote_ports 1-2 mode brief
```

```
Port ID: 1:1
```

```
-----
Remote Entities Count   : 1
```

```
Entity 1
```

```
Chassis ID Subtype     : MAC Address
Chassis ID             : 00-01-0-2-03-04-01
Port ID Subtype        : Local
Port ID                : 1/3
Port Description       : RMON Port 1 on Unit 3
```

```
CTRL+C ESC q Quit SPACE n Next Page Enter Next Entry a All
```

show lldp statistics

Purpose	Used to display the system LLDP statistics information.
Syntax	show lldp statistics
Description	The global LLDP statistics displays an overview of neighbor detection activity on the switch.
Parameters	None.
Restrictions	None.

Example usage:

To display global statistics information:

```
DGS-3627:admin# show lldp statistics
```

```
Command: show lldp statistics
```

```
Last Change Time      : 4875
Number of Table Insert : 0
Number of Table Delete : 0
Number of Table Drop   : 0
Number of Table Ageout : 0
```

```
DGS-3627:admin#
```

show lldp statistics ports

Purpose	Used to display the ports LLDP statistics information.
Syntax	show lldp statistics ports{<portlist>}
Description	The per-port LLDP statistics command displays per-port LLDP statistics.
Parameters	<portlist> – Use this parameter to define ports to be configured. When portlist is not specified, information for all ports will be displayed.
Restrictions	None.

Example usage:

To display statistics information of port 1:

```
DGS-3627:admin# show lldp statistics ports 1
```

```
Command: show lldp statistics ports 1
```

```
Port ID : 1:1
```

```
-----
LLDPStatsTxPortFramesTotal      : 0
LLDPStatsRxPortFramesDiscardedTotal : 0
LLDPStatsRxPortFramesErrors     : 0
LLDPStatsRxPortFramesTotal      : 0
LLDPStatsRxPortTLVsDiscardedTotal : 0
LLDPStatsRxPortTLVsUnrecognizedTotal : 0
LLDPStatsRxPortAgeoutsTotal     : 0
```

```
DGS-3627:admin#
```

LOOPBACK INTERFACE COMMANDS

The Loopback Interface commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config loopdetect	{recover_timer [0 <sec 60-1000000>] interval <sec 1-32767> mode [port-based vlan-based]}(1)
config loopdetect ports	[<portlist> all] state [enable disable]
enable loopdetect	
disable loopdetect	
show loopdetect	
show loopdetect ports	{<portlist>}
config loopdetect trap	[none loop_detected loop_cleared both]

Each command is listed, in detail, in the following sections.

config loopdetect

Purpose	This command is used to setup the loop-back detection function (LBD) for the entire Switch. □
Syntax	config loopdetect {recover_timer [0 <sec 60-1000000>] interval <sec 1-32767> mode [port-based vlan-based]}(1)
Description	This command is used to setup the loop-back detection function (LBD) for the entire Switch. □
Parameters	<p><i>recover_timer</i> - (Optional) The time interval (in seconds) used by the Auto-Recovery mechanism to decide how long to check before determining that the loop status has gone. The valid range is from 60 to 1000000. 0 is a special value that specifies that the auto-recovery mechanism should be disabled. When the auto-recovery mechanism is disabled, a user would need to manually recover a disabled port. The default value for the recover timer is 60 seconds.</p> <p>0 - Specifies that the value of 0 will be set to the recovery timer.</p> <p><sec 60-1000000> - Enter the recovery timer value here. This value must be between 60 and 1000000 seconds.</p> <p><i>interval</i> - (Optional) The time interval (in seconds) that the device will transmit all the CTP (Configuration Test Protocol) packets to detect a loop-back event. The default setting is 10 seconds. The valid range is from 1 to 32767 seconds.</p> <p><sec - 1-32767> - Enter the time interval value here. This value must be between 1 and 32767 seconds.</p> <p><i>mode</i> - (Optional) Specify the loop-detection operation mode. In port-based mode, the port will be shut down (disabled) when loop has been detected. In VLAN-based mode, the port cannot process the packets of the VLAN that has detected the loop.</p> <p><i>port-based</i> - Specifies that the loop-detection operation mode will be set to port-based mode.</p> <p><i>vlan-based</i> - Specifies that the loop-detection operation mode will be set to vlan-based mode.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set the auto-recover time to 0, which disables the auto-recovery mechanism, the interval to 20 seconds and specify VLAN-based mode:

```
DGS-3627:admin# config loopdetect recover_timer 0 interval 20 vlan-based
Command: config loopdetect recover_timer 0 interval 20 vlan-based

Success.

DGS-3627:admin#
```

config loopdetect ports

Purpose	This command is used to setup the loop-back detection function for the interfaces on the Switch.
Syntax	config loopdetect ports [<portlist> all] state [enable disable]
Description	This command is used to setup the loop-back detection function for the interfaces on the Switch.
Parameters	<p><i>ports</i> - Specify the range of ports that LBD will be configured on.</p> <p><i><portlist></i> - Enter a list of ports</p> <p><i>all</i> - To set all ports in the system, you may use the “all” parameter.</p> <p><i>state</i> - Specify whether the LBD function should be enabled or disabled on the ports specified in the port list. The default state is disabled.</p> <p><i>enable</i> - Specify to enable the LBD function.</p> <p><i>disable</i> - Specify to disable the LBD function.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the LBD function on ports 1:1-1:5:

```
DGS-3627:admin# config loopdetect ports 1:1-1:5 state enable
Command: config loopdetect ports 1:1-1:5 state enable

Success.

DGS-3627:admin#
```

enable loopdetect

Purpose	This command is used to enable the LBD function globally on the Switch.
Syntax	enable loopdetect
Description	This command is used to enable the LBD function globally on the Switch. The default state is enabled.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the LBD function globally:

```
DGS-3627:admin# enable loopdetect
Command: enable loopdetect

Success.

DGS-3627:admin#
```

disable loopdetect

Purpose	This command is used to disable the LBD function globally on the Switch.
Syntax	disable loopdetect
Description	This command is used to disable the LBD function globally on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the LBD function globally:

```
DGS-3627:admin# disable loopdetect
Command: disable loopdetect

Success.

DGS-3627:admin#
```

show loopdetect

Purpose	This command is used to display the LBD global configuration.
Syntax	show loopdetect
Description	This command is used to display the LBD global configuration.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show the LBD global settings:

```
DGS-3627:admin# show loopdetect
Command: show loopdetect
LBD Global Settings
-----
Status      : Enabled
Mode        : VLAN-based
Interval    : 20 sec
Recover Time : 60 sec
Trap State  : None
Log State   : Enabled

DGS-3627:admin#
```

show loopdetect ports

Purpose	This command is used to display the LBD per-port configuration.
Syntax	show loopdetect ports {<portlist>}
Description	This command is used to display the LBD per-port configuration.
Parameters	<i>ports</i> - Specify the range of member ports that will display the LBD settings. <i><portlist></i> - Enter the list of port to be configured here. If no port is specified, the configuration for all ports will be displayed.
Restrictions	None.

Example usage:

To show the LBD settings on ports 1-9:

```
DGS-3627:admin# show loopdetect ports 1-9
Command: show loopdetect ports 1-9
```

Port	Loopdetect State	Loop Status
1	Enabled	Normal
2	Enabled	Normal
3	Enabled	Normal
4	Enabled	Normal
5	Enabled	Loop!
6	Enabled	Normal
7	Enabled	Loop!
8	Enabled	Normal
9	Enabled	Normal

```
DGS-3627:admin#
```

config loopdetect trap

Purpose	This command is used to configure the trap modes for LBD.
Syntax	config loopdetect trap [none loop_detected loop_cleared both]
Description	This command is used to configure the trap modes for LBD.
Parameters	<i>none</i> - There is no trap in the LBD function. <i>loop_detected</i> - Trap will only be sent when the loop condition is detected. <i>loop_cleared</i> - Trap will only be sent when the loop condition is cleared. <i>both</i> - Trap will either be sent when the loop condition is detected or cleared.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To specify that traps will be sent when the loop condition is detected or cleared:

```
DGS-3627:admin# config loopdetect trap both
Command: config loopdetect trap both
```

```
Success.
```

```
DGS-3627:admin#
```

LOOPBACK INTERFACE COMMANDS

A loopback interface is a logical IP interface which is always active, until you disable or delete it. It is independent of the state of any physical interfaces.

The Loopback Interface commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create loopback ipif	<ipif_name 12> {<network_address>} {state [enable disable]}
config loopback ipif	<ipif_name 12> [{ipaddress <network_address> state [enable disable]]}
show loopback ipif	{< ipif_name 12 >}
delete loopback ipif	[< ipif_name 12 > all]

Each command is listed, in detail, in the following sections.

create loopback ipif

Purpose	Creates a loopback interface on the switch.
Syntax	create loopback ipif <ipif_name 12> {<network_address>} {state [enable disable]}
Description	This command creates a loopback interface on the switch. This interface can be configured with IPv4. Currently, it has a restriction. An interface can have only one IPv4 address defined. User can only create 8 loopback interfaces at most.
Parameters	<i><ipif_name 12></i> - The name of the loopback interface. Note: the loopback ipif has the same name domain space with the regular ipif, so its name can't duplicate with the regular ipif. <i>network_address</i> - IPv4 network address (xxx.xxx.xxx/xx) of the loopback interface. It specifies a host address and length of network mask. <i>state</i> - The state of loopback interface.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create one loopback interface named loopback1 with subnet address 20.1.1.1/8 and enable the admin state:

```
DGS-3627:admin# create loopback ipif loopback1 20.1.1.1/8 state enable
Command: create loopback ipif loopback1 20.1.1.1/8 state enable
```

Success.

```
DGS-3627:admin#
```

config loopback ipif

Purpose	Configure the loopback interface parameters.
Syntax	config loopback ipif <ipif_name 12> [{ipaddress <network_address> state [enable disable]]}

config loopback ipif

Description	Configure the parameters for the loopback interface. For IPv4, only the system interface can be specified for the way to get the IP address.
Parameters	<p><ipif_name 12> - The name of the loopback interface .</p> <p>Note: the loopback ipif has the same name domain space with the regular ipif, so its name can't duplicate with the regular ipif.</p> <p>network_address - IPv4 network address (xxx.xxx.xxx/xx) of the loopback interface. It specifies a host address and length of network mask.</p> <p>state - The state of loopback interface.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the loopback interface named loopback1 with subnet address 10.0.0.1/8:

```
DGS-3627:admin# config loopback ipif loopback1 ipaddress 10.0.0.1/8
Command: config loopback ipif loopback1 ipaddress 10.0.0.1/8
```

Success.

```
DGS-3627:admin#
```

show loopback ipif

Purpose	Show the information of the loopback interface.
Syntax	show loopback ipif {< ipif_name 12 >}
Description	To show the information of the loopback interface.
Parameters	<p><ipif_name 12> - The name of the loopback interface.</p> <p>Note: the loopback ipif has the same name domain space with the regular ipif, so its name can't duplicate with the regular ipif.</p>
Restrictions	None.

Example usage:

To show the information of the loopback interface named loopback1:

```
DGS-3627:admin# show loopback ipif loopback1
Command: show loopback ipif loopback1

Loopback Interface      : loopback1
Interface Admin State   : Enabled
IPv4 Address            : 10.0.0.1/8 (MANUAL)
```

Total Entries:1

```
DGS-3627:admin#
```

delete loopback ipif

Purpose	Delete the loopback interface.
Syntax	delete loopback ipif [< ipif_name 12 > all]

delete loopback ipif

Description	Delete the specified loopback interface.
Parameters	<p><ipif_name 12> - The name of the loopback interface.</p> <p>Note: the loopback ipif has the same name domain space with the regular ipif, so its name can't duplicate with the regular ipif.</p> <p><i>all</i> - All of the loopback interfaces.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the loopback interface named loopback1:

```
DGS-3627:admin# delete loopback ipif loopback1
```

```
Command: delete loopback ipif loopback1
```

```
Success.
```

```
DGS-3627:admin#
```

MAC NOTIFICATION COMMANDS

The MAC notification commands in the Command Line Interface (CLI) are listed, in the following table, along with their appropriate parameters.

Command	Parameters
enable mac_notification	
disable mac_notification	
config mac_notification	{interval <int 1-2147483647> historysize <int 1-500>}
config mac_notification ports	[<portlist> all] [enable disable]
show mac_notification	
show mac_notification ports	{<portlist>}

Each command is listed, in detail, in the following sections.

enable mac_notification

Purpose	Used to enable global MAC address table notification on the Switch.
Syntax	enable mac_notification
Description	This command is used to enable MAC address notification without changing configuration.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable MAC notification without changing basic configuration:

```
DGS-3627:admin# enable mac_notification
Command: enable mac_notification
```

```
Success.
```

```
DGS-3627:admin#
```

disable mac_notification

Purpose	Used to disable global MAC address table notification on the Switch.
Syntax	disable mac_notification
Description	This command is used to disable MAC address notification without changing configuration.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable MAC notification without changing basic configuration:

```
DGS-3627:admin# disable mac_notification
Command: disable mac_notification

Success.

DGS-3627:admin#
```

config mac_notification

Purpose	Used to configure MAC address notification.
Syntax	config mac_notification {interval <int 1-2147483647> historysize <int 1-500>}
Description	MAC address notification is used to monitor MAC addresses learned and entered into the FDB.
Parameters	<i>interval <sec 1-2147483647></i> – The time in seconds between notifications. The user may choose an interval between 1 and 2,147,483,647 seconds. <i>historysize <1-500></i> – The maximum number of entries listed in the history log used for notification.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the Switch's MAC address table notification global settings:

```
DGS-3627:admin# config mac_notification interval 1 historysize 500
Command: config mac_notification interval 1 historysize 500

Success.

DGS-3627:admin#
```

config mac_notification ports

Purpose	Used to configure MAC address notification status settings.
Syntax	config mac_notification ports [<portlist> all] [enable disable]
Description	MAC address notification is used to monitor MAC addresses learned and entered into the FDB.
Parameters	<i><portlist></i> – Specify a port or range of ports to be configured. The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex: 1-3,7-9) <i>all</i> – Entering this command will set all ports on the system. <i>[enable disable]</i> – These commands will enable or disable MAC address table notification on the Switch.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable port 7 for MAC address table notification:


```
DGS-3627:admin# config mac_notification ports 7 enable
Command: config mac_notification ports 7 enable

Success.

DGS-3627:admin#
```

show mac_notification

Purpose	Used to display the Switch's MAC address table notification global settings
Syntax	show mac_notification
Description	This command is used to display the Switch's MAC address table notification global settings.
Parameters	None.
Restrictions	None.

Example usage:

To view the Switch's MAC address table notification global settings:

```
DGS-3627:admin# show mac_notification
Command: show mac_notification

Global Mac Notification Settings

State          : Enabled
Interval       : 1
History Size   : 1

DGS-3627:admin#
```

show mac_notification ports

Purpose	Used to display the Switch's MAC address table notification status settings
Syntax	show mac_notification ports {<portlist>}
Description	This command is used to display the Switch's MAC address table notification status settings.
Parameters	<portlist> – Specify a port or group of ports to be viewed. The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex: 1-3,7-9) Entering this command without the parameter will display the MAC notification table for all ports.
Restrictions	None.

Example usage:

To display all port's MAC address table notification status settings:

```
DGS-3627:admin# show mac_notification ports
```

```
Command: show mac_notification ports
```

```
Port #   MAC Address Table Notification State
```

```
-----  
1         Disabled  
2         Disabled  
3         Disabled  
4         Disabled  
5         Disabled  
6         Disabled  
7         Disabled  
8         Disabled  
9         Disabled  
10        Disabled  
11        Disabled  
12        Disabled  
13        Disabled  
14        Disabled  
15        Disabled  
16        Disabled  
17        Disabled  
18        Disabled  
19        Disabled  
20        Disabled
```

```
CTRL+C  ESC  q  Quit  SPACE  n  Next Page  p  Previous Page  r  Refresh
```

MAC-BASED ACCESS CONTROL COMMANDS

MAC-based Access Control (MAC) is a method to authenticate and authorize a port/host network access right based on the MAC address on which the user is located rather than user's identification (e.g. user name and password).

MAC users need to complete authentication before accessing a network. Both local authentication and remote RADIUS server authentication are supported. MAC user information in local databases or RADIUS server databases will be searched for authentication, and following the authentication result, users will gain different types of authorization.

The MAC-based Access Control commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
enable mac_based_access_control	
disable mac_based_access_control	
config mac_based_access_control password	<passwd 16>
config mac_based_access_control method	[local radius]
config mac_based_access_control guest_vlan ports	<portlist>
config mac_based_access_control ports	[<portlist> all] {state [enable disable] mode [port_based host_based] aging_time [infinite <min 1-1440>] [block_time hold_time] [infinite <sec 1-300>] max_users [<value 1-4000> no_limit]}(1)
create mac_based_access_control	[guest_vlan <vlan_name 32> guest_vlanid <vlanid 1-4094>]
delete mac_based_access_control	[guest_vlan <vlan_name 32> guest_vlanid <vlanid 1-4094>]
clear mac_based_access_control auth_state	[ports [all <portlist>] mac_addr <macaddr>]
create mac_based_access_control_local mac	<macaddr> {[vlan <vlan_name 32> vlanid <vlanid 1-4094>]}
config mac_based_access_control_local mac	<macaddr> [vlan <vlan_name 32> vlanid <vlanid 1-4094> clear_vlan]
delete mac_based_access_control_local	[mac <macaddr> vlan <vlan_name 32> vlanid <vlanid 1-4094>]
config mac_based_access_control authorization network	{radius [enable disable] local [enable disable]} (1)
show mac_based_access_control	{ports {<portlist>}}
show mac_based_access_control_local	{[mac <macaddr> vlan <vlan_name 32> vlanid <1-4094>]}
show mac_based_access_control auth_state ports	{<portlist>}
config mac_based_access_control max_users	[<value 1-4000> no_limit]

Each command is listed, in detail, in the following sections.

enable mac_based_access_control

Purpose	Used to enable MAC-based Access Control.
Syntax	enable mac_based_access_control
Description	This command enables the MAC-based Access Control function.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the MAC-based Access Control global state:

```
DGS-3627:admin# enable mac_based_access_control
Command: enable mac_based_access_control

Success.

DGS-3627:admin#
```

disable mac_based_access_control

Purpose	Used to disable MAC-based Access Control.
Syntax	disable mac_based_access_control
Description	This command disables the MAC-based Access Control function.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the MAC-based Access Control global state:

```
DGS-3627:admin# disable mac_based_access_control
Command: disable mac_based_access_control

Success.

DGS-3627:admin#
```

config mac_based_access_control password

Purpose	Used to configure the RADIUS authentication password for MAC-based Access Control.
Syntax	config mac_based_access_control password <passwd 16>
Description	This command will set the password that will be used for authentication via the RADIUS server.
Parameters	<passwd 16> - In RADIUS mode, the switch will communicate with the RADIUS server using this password. The maximum length of the key is 16.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set the MAC-based Access Control password:

```
DGS-3627:admin# config mac_based_access_control password switch
Command: config mac_based_access_control password switch

Success.

DGS-3627:admin#
```

config mac_based_access_control method

Purpose	Used to configure the MAC-based Access Control authentication method.
Syntax	config mac_based_access_control method [local radius]

config mac_based_access_control method

Description	Specify the authentication method used via the local database or via the RADIUS server.
Parameters	<i>local</i> - Specify to authenticate via the local database. <i>radius</i> - Specify to authenticate via a RADIUS server.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set the MAC-based Access Control authentication method as local:

```
DGS-3627:admin# config mac_based_access_control method local
Command: config mac_based_access_control method local
```

Success.

```
DGS-3627:admin#
```

config mac_based_access_control guest_vlan

Purpose	Used to configure the MAC-based Access Control guest VLAN membership.
Syntax	config mac_based_access_control guest_vlan ports <portlist>
Description	This command will assign a specified port list to the MAC-based Access Control guest VLAN. Ports that are not contained in port list will be removed from the MAC-based Access Control guest VLAN.
Parameters	<portlist> - Specify MAC-based Access Control guest VLAN membership.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set the MAC-based Access Control guest VLAN membership:

```
DGS-3627:admin# config mac_based_access_control guest_vlan ports 1-8
Command: config mac_based_access_control guest_vlan ports 1-8
```

Success.

```
DGS-3627:admin#
```

config mac_based_access_control ports

Purpose	Used to configure the port parameters for MAC-based Access Control.
Syntax	config mac_based_access_control ports [<portlist> all] {state [enable disable] mode [port_based host_based] aging_time [infinite <min 1-1440>] [block_time hold_time] [infinite <sec 1-300>] max_users [<value 1-4000> no_limit]}(1)
Description	This command allows configures MAC-based Access Control port's setting. When the MAC-based Access Control function is enabled for a port and the port is not a MAC-based Access Control guest VLAN member, the user who is attached to this port will not be forwarded unless the user passes the authentication. A user that does not pass the authentication will not be serviced by the switch. If the user passes the authentication, the user will be able to forward traffic operated under the assigned VLAN. When the MAC-based Access Control function is enabled for a port, and the port is a MAC-based Access Control guest VLAN member, the port(s) will be removed from the original

config mac_based_access_control ports

VLAN(s) member ports, and added to MAC-based Access Control guest VLAN member ports. Before the authentication process starts, the user is able to forward traffic under the guest VLAN. After the authentication process, the user will be able to access the assigned VLAN.

If the port authorize mode is port based mode, when the port has been moved to the authorized VLAN, the subsequent users will not be authenticated again. They will operate in the current authorized VLAN. If the port authorize mode is host based mode, then each user will be authorized individually and be capable of getting its own assigned VLAN.

Parameters

ports - Specifies a range of ports for configuring the MAC-based Access Control function parameters.

state - Specifies whether the port's MAC-based Access Control function is enabled or disabled.

mode - See below:

port_based - Port based means that all users connected to a port share the first authentication result.

host_based - Host based means that each user has its own authentication result. If the Switch does not support MAC-based VLANs, the switch will not allow the host based option for ports that are in guest VLAN mode.

aging_time - A time period during which an authenticated host will be kept in an authenticated state. When the aging time has timed-out, the host will be moved back to unauthenticated state. If the aging time is set to infinite, it means that authorized clients will not be aged out automatically.

block_time - If a host fails to pass the authentication, the next authentication will not start within the block time unless the user clears the entry state manually. If the block time is set to 0, it means do not block the client that failed authentication.

block_time – Specify the block time here.

infinite – Specify to set the time to infinite.

max_users - Specify maximum number of users per port. The range is 1 to 4000. The default value is 128.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the MAC-based Access Control state for ports 1 to 8:

```
DGS-3627:admin# config mac_based_access_control ports 1-8 state enable
Command: config mac_based_access_control ports 1-8 state enable
```

Success.

```
DGS-3627:admin#
```

To configure the MAC-based Access Control authorization mode for ports 1 to 8:

```
DGS-3627:admin# config mac_based_access_control ports 1-8 mode host_based
Command: config mac_based_access_control ports 1-8 mode host_based
```

Success.

```
DGS-3627:admin#
```

To configure an unlimited number of maximum users for MAC-based Access Control on ports 1 to 8:

```
DGS-3627:admin# config mac_based_access_control ports 1-8 max_users no_limit
Command: config mac_based_access_control ports 1-8 max_users no_limit

Success.

DGS-3627:admin#
```

To configure the MAC-based Access Control timer parameters to have an infinite aging time and a block time of 120 seconds on ports 1 to 8:

```
DGS-3627:admin# config mac_based_access_control ports 1-8 aging_time infinite block_time 120
Command: config mac_based_access_control ports 1-8 aging_time infinite block_time 120

Success.

DGS-3627:admin#
```

create mac_based_access_control guest_vlan

Purpose	Used to assign a static 802.1Q VLAN as a MAC-based Access Control guest VLAN.
Syntax	create mac_based_access_control [guest_vlan <vlan_name 32> guest_vlanid <vlanid 1-4094>]
Description	Used to assign a static 802.1Q VLAN as a MAC-based Access Control guest VLAN. This command can be used to manage unauthenticated hosts in this guest VLAN, that is, the unauthenticated host will stay in this guest VLAN until a successful authentication attempt.
Parameters	<i>guest_vlan</i> - Specify MAC-based Access Control guest VLAN by name, it must be a static 1Q VLAN. <i>guest_vlanid</i> - Specify MAC-based Access Control guest VLAN by VID, it must be a static 1Q VLAN.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a MAC-based Access Control guest VLAN:

```
DGS-3627:admin# create mac_based_access_control guest_vlan VLAN8
Command: create mac_based_access_control guest_vlan VLAN8

Success.

DGS-3627:admin#
```

delete mac_based_access_control guest_vlan

Purpose	Used to remove a MAC-based Access Control guest VLAN.
Syntax	delete mac_based_access_control [guest_vlan <vlan_name 32> guest_vlanid <vlanid 1-4094>]
Description	Use this command to remove a MAC-based Access Control guest VLAN. When the guest VLAN is removed, the guest VLAN function will be disabled.
Parameters	<i>guest_vlan</i> - Specifies the name of the MAC-based Access Control's guest VLAN <i>guest_vlanid</i> - Specifies the VID of the MAC-based Access Control's guest VLAN
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the MAC-based Access Control guest VLAN called default:

```
DGS-3627:admin# delete mac_based_access_control guest_vlan default
Command: delete mac_based_access_control guest_vlan default

Success.

DGS-3627:admin#
```

clear mac_based_access_control auth_state

Purpose	Used to clear the clients' authentication information by specific port(s) or MAC address.
Syntax	clear mac_based_access_control auth_state [ports [all <portlist>] mac_addr <macaddr>]
Description	This command is used to clear the authentication state of a user (or port). The port (or the user) will return to an un-authenticated state. All the timers associated with the port (or the user) will be reset.
Parameters	<i>ports</i> - To specify the port range to delete MAC addresses on them. <macaddr> - To delete a specified host with this MAC address.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To clear MAC-based Access Control clients' authentication information for all ports:

```
DGS-3627:admin# clear mac_based_access_control auth_state ports all
Command: clear mac_based_access_control auth_state ports all

Success.

DGS-3627:admin#
```

To delete the MAC-based Access Control authentication information for the host that has a MAC address of 00-00-00-47-04-65:

```
DGS-3627:admin# clear mac_based_access_control auth_state mac_addr 00-00-00-47-04-65
Command: clear mac_based_access_control auth_state mac_addr 00-00-00-47-04-65

Success.

DGS-3627:admin#
```

create mac_based_access_control_local

Purpose	Used to create a MAC-based Access Control local database entry that will be used for authentication. This command can also specify the VLAN that an authorized host will be assigned to.
Syntax	create mac_based_access_control_local mac <macaddr> {[vlan <vlan_name 32> vlanid <vlanid 1-4094>]}
Description	This command is used to create a database entry. The user also has the option of specifying a target VLAN for this entry.

create mac_based_access_control_local

Parameters	<p><i>mac</i> - Specify the MAC address that can pass local authentication.</p> <p><i>vlan</i> - Specify the target VLAN by using the VLAN name. When this host is authorized, it will be assigned to this VLAN.</p> <p><i>vlanid</i> - Specify the target VLAN by using the VID. When this host is authorized, it will be assigned to this VLAN if the target VLAN exists.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create one MAC-based Access Control local database entry for MAC address 00-00-00-00-00-01 and specify that the host will be assigned to the “default” VLAN after the host has been authorized:

```
DGS-3627:admin# create mac_based_access_control_local mac 00-00-00-00-00-01 vlan default
Command: create mac_based_access_control_local mac 00-00-00-00-00-01 vlan default
```

Success.

```
DGS-3627:admin#
```

config mac_based_access_control_local

Purpose	Used to configure a MAC-based Access Control local database entry.
Syntax	config mac_based_access_control_local mac <macaddr> [vlan <vlan_name 32> vlanid <vlanid 1-4094> clear_vlan]
Description	This command is used to configure a MAC-based Access Control local database entry.
Parameters	<p><i>mac</i> - Specify the authenticated host's MAC address.</p> <p><i>vlan</i> - Specify the target VLAN by VLAN name. When this host is authorized, the host will be assigned to this VLAN.</p> <p><i>vlanid</i> - Specify the target VLAN by VID. When this host is authorized, the host will be assigned to this VLAN if the target VLAN exists.</p> <p><i>clear_vlan</i> - Clear target VLAN information for specific hosts from the local database.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the target VLAN “default” for the MAC-based Access Control local database entry 00-00-00-00-00-01:

```
DGS-3627:admin# config mac_based_access_control_local mac 00-00-00-00-00-01 vlan default
Command: config mac_based_access_control_local mac 00-00-00-00-00-01 vlan default
```

Success.

```
DGS-3627:admin#
```

delete mac_based_access_control_local

Purpose	Used to delete a MAC-based Access Control local database entry.
Syntax	delete mac_based_access_control_local [mac <macaddr> vlan <vlan_name 32> vlanid <vlanid 1-4094>]
Description	This command is used to delete a MAC-based Access Control local database entry.

delete mac_based_access_control_local

Parameters	<i>mac</i> - Delete local database entry by specific MAC address. <i>vlan</i> - Delete local database entries by specific target VLAN name. <i>vlanid</i> - Delete local database entries by specific target VLAN ID.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the MAC-based Access Control local database entry for MAC address 00-00-00-00-00-01:

```
DGS-3627:admin# delete mac_based_access_control_local mac 00-00-00-00-00-01
Command: delete mac_based_access_control_local mac 00-00-00-00-00-01

Success.

DGS-3627:admin#
```

To delete the MAC-based Access Control local database entry for the VLAN name VLAN3:

```
DGS-3627:admin# delete mac_based_access_control_local vlan VLAN3
Command: delete mac_based_access_control_local vlan VLAN3

Success.

DGS-3627:admin#
```

config mac_based_access_control_authorization_network

Purpose	Used to enable or disable the acceptance of an authorized configuration.
Syntax	config mac_based_access_control_authorization_network {radius [enable disable] local [enable disable]} (1)
Description	Used to enable or disable the acceptance of an authorized configuration. When authorization is enabled for MAC-based Access Controls with RADIUS authentication, the authorized attributes (for example VLAN, 802.1p default priority assigned by the RADIUS server) will be accepted if the global authorization status is enabled. When authorization is enabled for MAC-based Access Controls with local authentication, the authorized attributes assigned by the local database will be accepted.
Parameters	<i>radius</i> - If specified to enable, the authorized attributes (for example VLAN, 802.1p default priority assigned by the RADIUS server) will be accepted if the global authorization status is enabled. The default state is enabled. <i>local</i> - If specified to enable, the authorized attributes assigned by the local database will be accepted if the global authorization status is enabled. The default state is enabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

The following example will disable the configuration authorized from the local database:

```
DGS-3627:admin# config mac_based_access_control authorization attributes local disable
Command: config mac_based_access_control authorization attributes local disable

Success.

DGS-3627:admin#
```

show mac_based_access_control

Purpose	Used to display the MAC-based Access Control setting.
Syntax	show mac_based_access_control {ports {<portlist>}}
Description	This command is used to display the MAC-based Access Control settings.
Parameters	If the ports parameter is not specified, the global MAC-based Access Control settings will be displayed. <portlist> - Displays the MAC-based Access Control settings for a specific port or range of ports. If no port list is specified, the settings will be displayed for ports which have MAC-based Access Control enabled.
Restrictions	None.

Example usage:

To show the MAC-based Access Control port configuration for ports 1 to 4:

```
DGS-3627:admin# show mac_based_access_control ports 1-4
Command: show mac_based_access_control ports 1-4
```

Port	State	Aging Time	Block Time (min)	Auth Mode (sec)	Max Users
1	Disabled	100	100	Port-based	128
2	Disabled	100	200	Host-based	128
3	Disabled	50	0	Port-based	2000
4	Disabled	Infinite	100	Host-based	No Limit

```
DGS-3627:admin#
```

show mac_based_access_control_local

Purpose	Used to display the MAC-based Access Control local database entry(s).
Syntax	show mac_based_access_control_local {[mac <macaddr> vlan <vlan_name 32> vlanid <1-4094>}]
Description	This command is used to display the MAC-based Access Control local database entries.
Parameters	Displays all MAC-based Access Control local database entries. <i>mac</i> - Displays MAC-based Access Control local database entries for a specific MAC address. <i>vlan</i> - Displays MAC-based Access Control local database entries for a specific target VLAN name. <i>vlanid</i> - Displays MAC-based Access Control local database entries for a specific target VLAN ID.
Restrictions	None.

Example usage:

To show the MAC-based Access Control local database:

```
DGS-3627:admin# show mac_based_access_control_local
Command: show mac_based_access_control_local
```

MAC Address	VID
00-00-00-00-00-01	1
00-00-00-00-00-02	123
00-00-00-00-00-03	123
00-00-00-00-00-04	1

Total Entries:4

DGS-3627:admin#

To show the MAC-based Access Control local database for the MAC address 00-00-00-00-00-01:

```
DGS-3627:admin# show mac_based_access_control_local mac 00-00-00-00-00-01
Command: show mac_based_access_control_local mac 00-00-00-00-00-01
```

MAC Address	VID
00-00-00-00-00-01	1

Total Entries:1

DGS-3627:admin#

To show MAC-based Access Control local database for the VLAN called 'default':

```
DGS-3627:admin# show mac_based_access_control_local vlan default
Command: show mac_based_access_control_local vlan default
```

MAC Address	VID
00-00-00-00-00-01	1
00-00-00-00-00-04	1

Total Entries:2

DGS-3627:admin#

show mac_based_access_control_auth_state

Purpose	Used to display the MAC-based Access Control authentication status.
Syntax	show mac_based_access_control_auth_state ports {<portlist>}
Description	This command is used to display the MAC-based Access Control authentication status.
Parameters	<portlist> - Display authentication status by specific port. If not specified port(s), it will display all of MAC-based Access Control ports authentication status.
Restrictions	None.

Example usage:

Suppose that port 1 is in host based mode:

MAC 00-00-00-00-00-01 is authenticated without a VLAN assigned (may be the specified target VLAN does not exist or the target VLAN has not been specified at all), the ID of the RX VLAN will be displayed (RX VLAN ID is 4004 in this example).

MAC 00-00-00-00-00-02 is authenticated with a target VLAN assigned, the ID of the target VLAN will be displayed (target VLAN ID is 1234 in this example).

MAC 00-00-00-00-00-03 fails to pass authentication, the VID field will be shown as "-", indicating that packets with SA 00-00-00-00-00-03 will be dropped no matter which VLAN these packets are from.

MAC 00-00-00-00-00-04 attempts to start authentication, the VID field will be shown as "-" until authentication completes.

Suppose that port 2 is in port based mode:

MAC 00-00-00-00-00-10 is the host which causes port 2 to pass authentication; the MAC address is followed by "(P)" to indicate port based mode authentication.

Suppose that port 3 is in port based mode:

MAC 00-00-00-00-00-20 attempts to start authentication, the MAC address is followed by "(P)" to indicate port based mode authentication.

MAC 00-00-00-00-00-21 fails to pass authentication, the MAC address is followed by "(P)" to indicate port based mode authentication.

NOTE: In port-based mode, the VLAN ID field is displayed in the same way as host based mode.

To display the MAC-based Access Control authentication status on port 1, 2, 3.

```
DGS-3627:admin# show mac_based_access_control auth_state ports 1-3
```

```
Command: show mac_based_access_control auth_state ports 1-3
```

```
(P):Port based
```

Port	MAC Address	State	VID	Priority	Aging Time/ Block Time
1	00-00-00-00-00-01	Authenticated	4004	3	Infinite
1	00-00-00-00-00-02	Authenticated	1234	-	Infinite
1	00-00-00-00-00-03	Blocked	-	-	60
1	00-00-00-00-00-04	Authenticating	-	-	5
2	00-00-00-00-00-10(P)	Authenticated	1234	4	1440
3	00-00-00-00-00-20(P)	Authenticating	-	-	20
3	00-00-00-00-00-21(P)	Blocked	-	-	120

```
Total Authenticating Hosts :2
```

```
Total Authenticated Hosts :3
```

```
Total Blocked Hosts :2
```

```
DGS-3627:admin#
```

config mac_based_access_control max_users

Purpose Used to configure the maximum number of authorized clients.

Syntax `config mac_based_access_control max_users [<value 1-4000> | no_limit]`

Description This setting is a global limitation on the maximum number of users that can be learned via MAC-based Access Control.

In addition, to the global limitation, the maximum number of users per port is also limited.

config mac_based_access_control max_users

	This is specified by the config config mac_based_access_control ports max_users command.
Parameters	<i><value 1–4000></i> - Specify to set the maximum number of authorized clients on the whole device. <i>no_limit</i> - Specify to not limit the maximum number of users on the system. By default, there is no limit on the number of users.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the maximum number of users the MAC-based Access Control system supports:

```
DGS-3627:admin# config mac_based_access_control max_users 128
```

```
Command: config mac_based_access_control max_users 128
```

```
Success.
```

```
DGS-3627:admin#
```

MESSAGE-DIGEST ALGORITHM 5 (MD5) COMMANDS

The Message-Digest algorithm 5 (MD5) configuration commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create md5 key	<key_id 1-255> <password 16>
config md5 key	<key_id 1-255> <password 16>
delete md5 key	<key_id 1-255>
show md5	{key <key_id 1-255>}

Each command is listed, in detail, in the following sections.

create md5 key

Purpose	Used to create a new entry in the MD5 key table.
Syntax	create md5 key <key_id 1-255> <password 16>
Description	This command is used to create an entry for the MD5 key table.
Parameters	<key_id 1-255> – The MD5 key ID. The user may enter a key ranging from 1 to 255. <password> – An MD5 password of up to 16 bytes.
Restrictions	Only Administrator and Operator-level users can issue this command.

Usage example

To create an entry in the MD5 key table:

```
DGS-3627:admin# create md5 key 1 dlink
Command: create md5 key 1 dlink
```

```
Success.
```

```
DGS-3627:admin#
```

config md5 key

Purpose	Used to enter configure the password for an MD5 key.
Syntax	config md5 key <key_id 1-255> <password 16>
Description	This command is used to configure an MD5 key and password.
Parameters	<key_id 1-255> – The previously defined MD5 key ID. <password 16> – The user may change the MD5 password for the md5 key. A new password of up to 16 characters can be created.
Restrictions	Only Administrator and Operator-level users can issue this command.

Usage example

To configure an MD5 Key password:

```
DGS-3627:admin# config md5 key 1 taboo
Command: config md5 key 1 taboo

Success.

DGS-3627:admin#
```

delete md5 key

Purpose	Used to delete an entry in the MD5 key table.
Syntax	delete md5 key <key_id 1-255>
Description	This command is used to delete a specific entry in the MD5 key table.
Parameters	<key_id 1-255> – The MD5 key ID to delete.
Restrictions	Only Administrator and Operator-level users can issue this command.

Usage example

The delete an entry in the MD5 key table:

```
DGS-3627:admin# delete md5 key 1
Command: delete md5 key 1

Success.

DGS-3627:admin#
```

show md5

Purpose	Used to display an MD5 key table.
Syntax	show md5 {key <key_id 1-255>}
Description	This command will display the current MD5 key table.
Parameters	<key_id 1-255> – The MD5 key ID to be displayed.
Restrictions	None.

Usage example

To display the current MD5 key:

```
DGS-3627:admin# show md5
```

```
Command: show md5
```

```
MD5 Key Table Configurations
```

Key-ID	Key
-----	-----
1	dlink
2	develop
3	fireball
4	intelligent

```
Total Entries: 4
```

```
DGS-3627:admin#
```

MIRROR COMMANDS

The primary purpose of the mirror function is to copy frames transmitted and received on a port and redirect the copies to another port.

The application attaches a monitoring device to the mirrored port, such as a sniffer or an RMON probe, to view details about the packets passing through the first port. This is useful for network monitoring and troubleshooting purposes.



NOTE: When the device with the source port has been removed from a stack, the configuration will be disabled temporarily until another device has been installed in its place. If configurations are saved to NVR RAM during this period the configuration will be removed forever.

The Mirror commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config mirror port	<port> {[add delete] source ports <portlist> [rx tx both]}
enable mirror	
disable mirror	
show mirror	{group_id <value 1-4>}
create mirror group_id	<value 1-4>
delete mirror group_id	<value 1-4>
config mirror group_id	<value 1-4> {target_port <port> [add delete] source ports <portlist> [rx tx both] state [enable disable]}(1)

Each command is listed, in detail, in the following sections.

config mirror port

Purpose	Used to configure a mirror port – source port pair on the switch. Traffic from any source port to a target port can be mirrored for real-time analysis. A logic analyzer or an RMON probe then can be attached to study the traffic crossing the source port in a completely unobtrusive manner. When mirroring port traffic, please note that the target port must be configured in the same VLAN and operates at the same speed as the source port. If the target port is operating at a lower speed, the source port will be forced to drop its operating speed to match that of the target port.
Syntax	config mirror port <port> {[add delete] source ports <portlist> [rx tx both]}
Description	The config mirror command allows a range of ports to have all of their traffic also sent to a destination port – where a network sniffer or other device can monitor the network traffic. In addition, you can specify that only traffic received by or sent by or both are mirrored to the target port. This command used for single mirror session configuration primarily. If used for multiple session configurations, it configures the parameters on mirror group 1. If group 1 not exist, create group 1 firstly, and than configure the parameters on group 1.
Parameters	<i>port</i> - The port that will receive the packets duplicated at the mirror port. <i>add</i> - The mirror entry to be added. <i>delete</i> - The mirror entry to be deleted.

config mirror port

portlist - The port that will be mirrored. All packets entering and leaving the source port can be duplicated in the mirror port.

rx - Allows the mirroring packets received (flowing into) the port or ports in the port list.

tx - Allows the mirroring packets sent (flowing out of) the port or ports in the port list.

both - Mirrors all the packets received or sent by the port or ports in the port list.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To add the mirroring ports:

```
DGS-3627:admin# config mirror port 1:3 add source ports 1:7-1:12 both
Command: config mirror port 1:5 add source ports 1:1-1:5 both
```

Success.

```
DGS-3627:admin#
```

enable mirror

Purpose Used to enable mirror globally.

Syntax **enable mirror**

Description This command, combined with the disable mirror command below, allows you to enable or disable mirror function without having to modify the mirror session configuration.

Parameters None.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To enable mirroring function:

```
DGS-3627:admin# enable mirror
Command: enable mirror
```

Success.

```
DGS-3627:admin#
```

disable mirror

Purpose Used to disable mirror globally.

Syntax **disable mirror**

Description This command, combined with the enable mirror command above, allows you to enable or disable mirror function without having to modify the mirror session configuration.

Parameters None.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To disable mirroring function:

```
DGS-3627:admin# disable mirror
Command: disable mirror

Success.

DGS-3627:admin#
```

show mirror

Purpose	Used to show the current ports mirroring configuration on the switch.
Syntax	show mirror {group_id <value 1-4>}
Description	The show mirror command displays the current mirror function state and mirror session configuration on the switch. If don't specify the "group_id" parameter, display the all mirror settings.
Parameters	<i>group_id</i> - The mirror group identify. <i>value</i> - The mirror group identify value.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To display mirroring configuration:

```
DGS-3627:admin# show mirror
Command: show mirror

Mirror Global State: Enabled

Group   State      Target Port   Source Ports
-----
1       Enabled    2:1           RX: 1:1
                          TX: 1:1
3       Enabled    3:5           RX: 1:24
                          TX: 1:24

DGS-3627:admin#
```

create mirror group_id

Purpose	Used to create a mirror group on the switch.
Syntax	create mirror group_id <value 1-4>
Description	This command used to create a mirror group. If the mirror group has existed, do nothing and return success.
Parameters	<i>group_id</i> - The mirror groups identify. <i>value</i> - The mirror groups identify value.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Create mirror group 3:

```
DGS-3627:admin# create mirror group_id 3
Command: create mirror group_id 3

Success.

DGS-3627:admin#
```

delete mirror group_id

Purpose	Used to delete a mirror group on the switch.
Syntax	delete mirror group_id <value 1-4>
Description	This command used to delete a mirror group.
Parameters	<i>group_id</i> - The mirror groups identify. <i>value</i> - The mirror groups identify value.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Create mirror group 2:

```
DGS-3627:admin# delete mirror group_id 3
Command: delete mirror group_id 3

Success.

DGS-3627:admin#
```

config mirror group_id

Purpose	Used to configure mirror group on the switch.
Syntax	config mirror group_id <value 1-4> {target_port <port> [add delete] source ports <portlist> [rx tx both] state [enable disable]}(1)
Description	This command used to configure mirror group's parameters. It can configure mirror group's target port, state and source ports. The mirror group target port can't be a member of all mirror groups' source ports. Each mirror group's target port can be the same port. But each mirror group's source ports can't overlap.
Parameters	<i>group_id</i> - The mirror groups identify. <i>value</i> - The mirror groups identify value. <i>target_port</i> - The port that will receive the packets duplicated at the mirror port. <i>state</i> - The mirror group state to enable or disable the mirror group function <i>add</i> - The mirror source ports to be add. <i>delete</i> - The mirror source ports to be delete <i>portlist</i> - The port list of mirror group source ports <i>rx</i> - Only the received packets on the mirror group source ports will be mirrored to the mirror group target port. <i>tx</i> - Only the sent packets on the mirror group source ports will be mirrored to the mirror group target port. <i>both</i> - Both the received and sent packets on the mirror group source ports will be mirrored to the mirror group target port.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Configure mirror group 2 with state enable and add source ports 1:4-1:9:

```
DGS-3627:admin# config mirror group_id 2 state enable add source ports 1:4-1:9 both  
Command: config mirror group_id 2 state enable add source ports 1:4-1:9 both
```

Success.

```
DGS-3627:admin#
```

MSTP DEBUG ENHANCEMENT COMMANDS

The MSTP Debug Enhancement commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
debug buffer	utilization dump clear upload_toTFTP <ipaddr> <path_filename 64>]
debug output	module mstp [buffer console]
debug stp config ports	[< portlist > all] [event bpdu state_machine all] state [disable brief detail]
debug stp show information	
debug stp show flag	{ports <portlist>}
debug stp show counter	{ports [<portlist> all]}
debug stp clear counter	[ports < portlist > all]
debug stp state	[enable disable]

Each command is listed, in detail, in the following sections.

debug buffer

Purpose	Use the debug buffer command to dump, clear, or upload the debug buffer to the TFTP server.
Syntax	debug buffer [utilization dump clear upload_toTFTP <ipaddr> <path_filename 64>]
Description	Dump, clear or upload the debug buffer to a TFTP server.
Parameters	<p><i>dump</i> - Displays the debug message in the debug message buffer.</p> <p><i>clear</i> - Clears the debug message buffer.</p> <p><i>upload_toTFTP <ipaddr></i> - Uploads the debug message buffer to a TFTP server with a specified IP address</p> <p><i><path_filename 64></i> - Upload the debug message buffer to a TFTP server and name the uploaded file using the string identified in the <path_filename 64> option.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To clear the debug information in the buffer:

```
DGS-3627:admin# debug buffer clear
Command: debug buffer clear
```

Success.

```
DGS-3627:admin#
```


debug output

Purpose	Use the debug output command to specify if the MSTP debug message output should be to the buffer or console.
Syntax	debug output module mstp [buffer console]
Description	Sets if the MSTP debug message output should be set to the buffer or console.
Parameters	<i>buffer</i> - Specifies the debug messages of MSTP will output to the buffer. <i>console</i> - Specifies the debug messages of MSTP will output to the console.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set the MSTP debug information to output to the console:

```
DGS-3627:admin# debug output module mstp console
Command: debug output module mstp console
```

Success.

```
DGS-3627:admin#
```

debug stp config ports

Purpose	Used to configure per-port STP debug level.
Syntax	debug stp config ports [< portlist > all] [event bpdu state_machine all] state [disable brief detail]
Description	This command used to configure per-port STP debug level on the specified ports.
Parameters	<i>debug flags</i> - See below: <i>event</i> - Debug the external operation and event processing. <i>bpdu</i> - Debug the BPDU's that have been received and transmitted. <i>state_machine</i> - Debug the state change of the STP state machine. <i>all</i> - Debug all of the above. <i>ports</i> - See below: <i>portlist</i> - Specifies the STP port range to debug. <i>all</i> - Specifies to debug all ports on the switch. <i>state</i> - See below: <i>disable</i> - Disables the debug mechanism. <i>brief</i> - Sets the debug level to brief. <i>detail</i> - Sets the debug level to detail.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure all STP debug flags to brief level on all ports:

```
DGS-3627:admin# debug stp config ports all all state brief
Command: debug stp config ports all all state brief
```

Success.

```
DGS-3627:admin#
```

debug stp show information

Purpose	Used to show the STP debug information.
Syntax	debug stp show information
Description	This command used to display STP detailed information, such as the hardware tables, the STP state machine, etc.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show STP debug information:

DGS-3627:admin# debug stp show information

Command: debug stp show information

Spanning Tree debug information:

Port status in hardware table:

Instance 0:

Port 1 :BLK Port 2 :BLK Port 3 :BLK Port 4 :BLK Port 5 :BLK Port 6 :BLK
Port 7 :FOR Port 8 :BLK Port 9 :BLK Port 10:BLK Port 11:BLK Port 12:BLK

Instance 1:

Port 1 :BLK Port 2 :BLK Port 3 :BLK Port 4 :BLK Port 5 :BLK Port 6 :BLK
Port 7 :FOR Port 8 :BLK Port 9 :BLK Port 10:BLK Port 11:BLK Port 12:BLK

Root Priority and Times :

Instance 0:

Designated Root Bridge : 32768/00-01-02-03-04-00
External Root Cost : 0
Regional Root Bridge : 32768/00-01-02-03-04-00
Internal Root Cost : 0
Designated Bridge : 32768/00-01-02-03-04-00
Designated Port : 0
Message Age : 0
Max Age : 20
Forward Delay : 15
Hello Time : 2

Instance 1:

Regional Root Bridge : 32769/00-01-02-03-04-00
Internal Root Cost : 0
Designated Bridge : 32769/00-01-02-03-04-00
Designated Port : 0
Remaining Hops : 20

Designated Prioirty and Times

Instance 0:

Port 1 :

Designated Root Bridge : 0 /00-00-00-00-00-00
External Root Cost : 0
Regional Root Bridge : 0 /00-00-00-00-00-00
Internal Root Cost : 0
Designated Bridge : 0 /00-00-00-00-00-00
Designated Port : 0
Message Age : 0
Max Age : 20
Forward Delay : 15
Hello Time : 2

Instance 1:

Port 1 :

Regional Root Bridge : 0 /00-00-00-00-00-00
Internal Root Cost : 0
Designated Bridge : 0 /00-00-00-00-00-00
Designated Port : 0
Remaining Hops : 20

Success.

DGS-3627:admin#

debug stp show flag

Purpose	Used to show the per-port STP debug level.
Syntax	debug stp show flag {ports <portlist>}
Description	This command used to display the STP debug level on specified ports.
Parameters	<i>ports <portlist></i> - Specifies the STP ports to display If no parameter is specified, all ports on the switch will be displayed.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To display the debug STP levels on all ports:

```
DGS-3627:admin# debug stp show flag
Command: debug stp show flag

Global State: Enabled

Port Index   Event flag   BPDU Flag   State Machine Flag
-----
 1           Detail      Brief       Disable
 2           Detail      Brief       Disable
 3           Detail      Brief       Disable
 4           Detail      Brief       Disable
 5           Detail      Brief       Disable
 6           Detail      Brief       Disable
 7           Detail      Brief       Disable
 8           Detail      Brief       Disable
 9           Detail      Brief       Disable
10           Detail      Brief       Disable
11           Detail      Brief       Disable
12           Detail      Brief       Disable

Success.

DGS-3627:admin#
```

debug stp show counter

Purpose	Used to show the STP counters.
Syntax	debug stp show counter { ports [< portlist > all] }
Description	This command used to display the STP counters.
Parameters	<i>ports <portlist></i> - Specifies the STP ports for display.. <i>all</i> - Display all port's counters If no parameter is specified, display the global counters.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show the STP counters for port 9:

```
DGS-3627:admin#debug stp show counter ports 9
```

```
Command: debug stp show counter ports 9
```

STP Counters

```
-----
Port 9 :
Receive:
Total STP Packets      :32
Configuration BPDU    :0
TCN BPDU              :0
RSTP TC-Flag         :15
RST BPDU              :32

Transmit:
Total STP Packets     :32
Configuration BPDU   :0
TCN BPDU             :0
RSTP TC-Flag        :7
RST BPDU            :32

Discarded:
Total Discard BPDU   :0
Global STP Disable  :0
Port STP Disabled   :0
Invalid Packet Format:0
Invalid Protocol    :0
Config BPDU Length  :0
TCN BPDU Length     :0
RST BPDU Length     :0
Invalid Type        :0
Invalid Timers      :0
Success.
```

```
DGS-3627:admin#
```

debug stp clear counter

Purpose	Used to clear STP counters.
Syntax	debug stp clear counter [ports < portlist > all]
Description	This command used to clear the STP counters.
Parameters	<i>ports <portlist></i> - Specifies the port range. <i>all</i> - Clears all port counters.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To clear all STP counters on the switch:

```
DGS-3627:admin#debug stp clear counter all
```

```
Command : debug stp clear counter all
```

```
Success.
```

```
DGS-3627:admin#
```

debug stp state

Purpose	Used to configure the STP debug state.
Syntax	debug stp state [enable disable]
Description	This command is used to enable or disable the STP debug state.

debug stp state

Parameters	<i>state</i> - See below: <i>enable</i> - Enable the STP debug state. <i>disable</i> - Disable the STP debug state.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the STP debug state to enable, and then disable the STP debug state:

```
DGS-3627:admin#debug stp state enable
Command: debug stp state enable

Success.

DGS-3627:admin# debug stp state disable
Command: debug stp state disable

Success.

DGS-3627:admin#
```

IGMP SNOOPING MULTICAST (ISM) VLAN COMMANDS

The IGMP Snooping Multicast (ISM) VLAN commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create igmp_snooping multicast_vlan	<vlan_name 32> <vlanid 2-4094> { remap_priority [<value 0-7> none] { replace_priority } }
config igmp_snooping multicast_vlan	<vlan_name 32> { member_port <portlist> [source_port <portlist> untag_source_port <portlist>] tag_member_port <portlist> state [enable disable] replace_source_ip <ipaddr> remap_priority [<value 0-7> none] { replace_priority } } (1)
config igmp_snooping multicast_vlan_group	<vlan_name 32> [add multicast_range <range_name 32> delete multicast_range [<range_name 32> all]]
show igmp_snooping multicast_vlan_group	{ < vlan_name 32> }
delete igmp_snooping multicast_vlan	<vlan_name 32>
show igmp_snooping multicast_vlan	{ <vlan_name 32> }

Each command is listed, in detail, in the following sections.

create igmp_snooping multicast_vlan

Purpose	Used to create a multicast VLAN.
Syntax	create igmp_snooping multicast_vlan <vlan_name 32> <vlanid 2-4094> { remap_priority [<value 0-7> none] { replace_priority } }
Description	<p>The create igmp_snooping command creates a multicast VLAN and implements relevant parameters as specified. More than one multicast VLANs can be configured. The maximum number of configurable VLANs is project dependent.</p> <p>Newly created IGMP snooping must use a unique VLAN ID and name, i.e. they cannot use the VLAN ID or name of any existing 802.1q VLAN.</p> <p>Also keep in mind the following conditions:</p> <ul style="list-style-type: none"> Multicast VLANs cannot be configured or displayed using 802.1Q VLAN commands. An IP interface cannot be bound to a multicast VLAN. The multicast VLAN snooping function co-exists with the 802.1q VLAN snooping function.
Parameters	<p><i>vlan_name</i> - The name of the multicast VLAN to be created. Each multicast VLAN is given a name that can be up to 32 characters.</p> <p><i>vlanid</i> - The VLAN ID of the multicast VLAN to be created. The range is 2 - 4094.</p> <p><i>remap_priority</i> - The remap priority (0 to 7) to be associated with the data traffic to be forwarded on the multicast VLAN. If none is specified, the packet's original priority will be used. The default setting is none.</p> <p><i>replace_priority</i> - Specify that packet's priority will be changed by the switch, based on the remap priority. This flag will only take effect when the remap priority is set.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create an IGMP snooping multicast VLAN with the VLAN name mv1 and the VID 2:

```
DGS-3627:admin# create igmp_snoop multicast_vlan mv1 2
Command: create igmp_snoop multicast_vlan mv1 2

Success.

DGS-3627:admin#
```

config igmp_snooping multicast_vlan

Purpose	Used to configure the parameters of a specific IGMP snooping multicast VLAN.
Syntax	config igmp_snooping multicast_vlan <vlan_name 32> {[member_port <portlist> tag_member_port <portlist> source_port <portlist> untag_source_port <portlist>] state [enable disable] replace_source_ip [<ipaddr> none] remap_priority [<value 0-7> {replace_priority}}(1)
Description	<p>The config igmp_snooping multicast_vlan command allows you to add member ports and source ports to a list of multicast VLAN member ports. Member ports automatically become untagged members of the multicast VLAN and source ports automatically become tagged members of the multicast VLAN. If the port list of an existing multicast VLAN is changed without specifying add or delete, the newly added port list replaces the existing port list. A member port list cannot overlap with a source port list of the same multicast VLAN. However, member ports of one multicast VLAN are allowed to overlap with member ports on a different multicast VLAN.</p> <p>A multicast VLAN must first be created using the create igmp_snooping multicast_vlan command before the multicast VLAN can be configured.</p>
Parameters	<p><i>vlan_name</i> - The name of the multicast VLAN to be configured. Can be up to 32 characters.</p> <p><i>member_port</i> - A member port or range of member ports to be added to the multicast VLAN. The specified range of ports will become untagged members of the multicast VLAN.</p> <p><i>tag_member_port</i> - Specify the port or range of ports that will become tagged members of the multicast VLAN.</p> <p><i>source_port</i> - A port or range of ports to be added to the multicast VLAN.</p> <p><i>untag_source_port</i> - Specify the source port or range of source ports as untagged members of the multicast VLAN. The PVID of the untagged source port is automatically changed to the multicast VLAN. Source ports must be either tagged or untagged for any single multicast VLAN, i.e. both types cannot be members of the same multicast VLAN.</p> <p><i>state</i> - Used to specify if the multicast VLAN for a chosen VLAN should be enabled or disabled.</p> <p><i>replace_source_ip</i> - Before forwarding the report packet sent by the host, the source IP address in the join packet must be replaced by this IP address. If none is specified, the source IP address will not be replaced.</p> <p><i>remap_priority</i> - The remap priority value (0 to 7) to be associated with the data traffic to be forwarded on the multicast VLAN. If none is specified, the packet's original priority is used. The default setting is none.</p> <p><i>replace_priority</i> - Specify that the packet priority will be changed to the remap_priority, but only if remap_priority is set.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure an IGMP snooping multicast VLAN with the name "v1", make ports 1 and 3 members of the VLAN, and set the state to enable:


```
DGS-3627:admin# config igmp_snooping multicast_vlan v1 member_port 2:1,2:3 state enable
Command: config igmp_snooping multicast_vlan v1 member_port 2:1,2:3 state enable

Success.

DGS-3627:admin#
```

config igmp_snooping multicast_vlan_group

Purpose	Used to configure the IGMP multicast groups learned with the specified multicast VLAN.
Syntax	config igmp_snooping multicast_vlan_group <vlan_name 32>[add multicast_range <range_name 32> delete multicast_range [<range_name 32> all]]
Description	Used to configure the multicast group learned with the specific multicast VLAN. The following two cases can be considered for examples: Case 1- The multicast group is not configured, multicast VLANs do not have any member ports overlapping and the join packet received by the member port is learned on only the multicast VLAN that this port is a member of. Case 2-The join packet is learned with the multicast VLAN that contains the destination multicast group. If the destination multicast group of the join packet cannot be classified into any multicast VLAN to which this port belongs, then the join packet will be learned on the natural VLAN of the packet. Note: A profile cannot overlap in different multicast VLANs. Multiple profiles can be added to a multicast VLAN.
Parameters	<i>vlan_name</i> - The name of the multicast VLAN to be configured. Each multicast VLAN is given a name of up to 32 characters. <i>add</i> - Used to associate a profile to a multicast VLAN. <i>delete</i> - Used to de-associate a profile from a multicast VLAN.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To add an IGMP snooping profile to a multicast VLAN group with the name "v1":

```
DGS-3627:admin# config igmp_snooping multicast_vlan_group v1 add multicast_range channel-1
Command: config igmp_snooping multicast_vlan_group v1 add multicast_range channel-1
Success.

DGS-3627:admin#
```

show igmp_snooping multicast_vlan_group

Purpose	Used to show an IGMP snooping multicast VLAN group.
Syntax	show igmp_snooping multicast_vlan_group {< vlan_name 32> }
Description	The show igmp_snooping multicast_vlan_group command allows you to show the multicast VLAN groups.
Parameters	<vlan_name 32> - Specify the name of the multicast VLAN to be displayed.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show all IGMP snooping multicast VLAN groups setup on the switch:

```
DGS-3627:admin# show igmp_snooping multicast_vlan_group
```

```
Command: show igmp_snooping multicast_vlan_group
```

```
Multicast VLAN          : mv1
```

No.	Name	From	To
1	accounting	224.19.62.34	224.19.62.200

```
DGS-3627:admin#
```

delete igmp_snooping multicast_vlan

Purpose	Used to delete an IGMP snooping multicast VLAN.
Syntax	delete igmp_snooping multicast_vlan <vlan_name 32>
Description	The delete igmp_snooping multicast_vlan command allows you to delete a multicast VLAN.
Parameters	<i>vlan_name</i> - The name of the multicast VLAN to be deleted.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an IGMP snooping multicast VLAN called "v1":

```
DGS-3627:admin# delete igmp_snooping multicast_vlan v1
```

```
Command: delete igmp_snooping multicast_vlan v1
```

```
Success.
```

```
DGS-3627:admin#
```

show igmp_snooping multicast_vlan

Purpose	Used to display information for a multicast VLAN.
Syntax	show igmp_snooping multicast_vlan {<vlan_name 32>}
Description	The show igmp_snooping multicast_vlan command allows information for a specific multicast VLAN to be displayed.
Parameters	<i>vlan_name</i> - The name of the multicast VLAN to be shown.
Restrictions	None.

Example usage:

To display all IGMP snooping multicast VLANs:

```
DGS-3627:admin# show igmp_snooping multicast_vlan
```

```
Command: show igmp_snooping multicast_vlan
```

```
VLAN Name          : test
VID                : 100

Member(Untagged) Ports : 1
Tagged Member Ports  :
Source Ports        : 3
Source(Untagged) Ports :
Status              : Disabled
Replace Source IP    : 0.0.0.0
Remap Priority       : None
```

```
Total Entries: 1
```

```
DGS-3627:admin#
```

MULTIPLE SPANNING TREE PROTOCOL (MSTP) COMMANDS

This Switch supports three versions of the Spanning Tree Protocol; 802.1D STP, 802.1D 2004 RSTP, 802.1Q 2005 MSTP. Multiple Spanning Tree Protocol, or MSTP, is a standard defined by the IEEE community that allows multiple VLANs to be mapped to a single spanning tree instance, which will provide multiple pathways across the network. Therefore, these MSTP configurations will balance the traffic load, preventing wide scale disruptions when a single spanning tree instance fails. This will allow for faster convergences of new topologies for the failed instance. Frames designated for these VLANs will be processed quickly and completely throughout interconnected bridges utilizing either of the three spanning tree protocols (STP, RSTP or MSTP). This protocol will also tag BPDU packets so receiving devices can distinguish spanning tree instances, spanning tree regions and the VLANs associated with them. These instances will be classified by an instance_id. MSTP will connect multiple spanning trees with a Common and Internal Spanning Tree (CIST). The CIST will automatically determine each MSTP region, its maximum possible extent and will appear as one virtual bridge that runs a single spanning tree. Consequentially, frames assigned to different VLANs will follow different data routes within administratively established regions on the network, continuing to allow simple and full processing of frames, regardless of administrative errors in defining VLANs and their respective spanning trees.

Each switch utilizing the MSTP on a network will have a single MSTP configuration that will have the following three attributes:

A configuration name defined by an alphanumeric string of up to 32 characters (defined in the config stp mst_config_id command as name <string>).

A configuration revision number (named here as a revision_level) and;

A 4096 element table (defined here as a vid_range) which will associate each of the possible 4096 VLANs supported by the Switch for a given instance.

To utilize the MSTP function on the Switch, three steps need to be taken:

- The Switch must be set to the MSTP setting (config stp version)
- The correct spanning tree priority for the MSTP instance must be entered (config stp priority).
- VLANs that will be shared must be added to the MSTP Instance ID (config stp instance_id).

The Multiple Spanning Tree Protocol (MSTP) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
show stp	
show stp instance	<value 0-15>
show stp ports	{<portlist>}
show stp mst_config_id	
create stp instance_id	<value 1-15>
delete stp instance_id	<value 1-15>
config stp instance_id	<value 1-15> [add_vlan remove_vlan] <vidlist>
config stp mst_config_id	{name <string> revision_level <int 0-65535>}
enable stp	
disable stp	
config stp version	[mstp rstp stp]
config stp priority	<value 0-61440> instance_id <value 0-15>
config stp	{maxage <value 6-40> maxhops <value 1-40> hellotime <value 1-10> forwarddelay <value 4-30> txholdcount <value 1-10> fbpdu [enable(3) disable(2)] lbd [enable(1) disable(0)] lbd_recover_timer [<value 0> <value 60-1000000>] nni_bpdu_addr [dot1d dot1ad]}(1)
config stp ports	<portlist> {externalCost [auto <value 1-200000000>] hellotime <value 1-10> migrate [yes no] edge [true false auto] p2p [true false auto] state [enable disable] restricted_role [true false] restricted_tcn [true false] lbd [enable disable] fbpdu [enable disable]}(1)
config stp mst_ports	<portlist> instance_id <value 0-15> {internalCost [auto <value 1-200000000>] priority <value 0-240>}

Each command is listed, in detail, in the following sections.

show stp

Purpose	Used to show the bridge parameters global settings. (CIST or msti id=0)
Syntax	show stp
Description	The show stp command is used to show the bridge parameters global settings.
Parameters	None.
Restrictions	None.

Example usage:

To show stp:

```
DGS-3627:admin# show stp
Command: show stp

STP Bridge Global Settings
-----
STP Status           : Enabled
STP Version          : MSTP
Max Age              : 20
Forward Delay        : 15
Max Hops             : 20
TX Hold Count        : 3
Forwarding BPDU      : Enabled
LoopBack Detection   : Enabled
NNI BPDU Address     : dot1d

DGS-3627:admin#
```

show stp instance

Purpose	Used to show each instance parameters settings.
Syntax	show stp instance <value 0-15>
Description	This command displays each instance parameters settings. Value means the instance id, if there is no input of this value, all instance will be shown.
Parameters	<i>instance</i> - MSTP instance id . Instance 0 represents for default instance : CIST. The bridge support total 16 Instance (0-15) at most.
Restrictions	None.

Example usage:

To show stp instance:

```
DGS-3627:admin# show stp instance
Command: show stp instance

STP Instance Settings
-----
Instance Type        : CIST
Instance Status      : Enabled
Instance Priority     : 32768(Bridge Priority : 32768, SYS ID Ext : 0 )

STP Instance Operational Status
-----
Designated Root Bridge : 32768/00-22-22-22-22-00
External Root Cost     : 0
Regional Root Bridge   : 32768/00-22-22-22-22-00
Internal Root Cost     : 0
Designated Bridge      : 32768/00-22-22-22-22-00
Root Port              : None
Max Age                : 20
Forward Delay          : 15
Last Topology Change   : 2430
Topology Changes Count : 0

DGS-3627:admin#
```

show stp ports

Purpose	Used to show the port information includes parameters setting and operational value.
Syntax	show stp ports {<portlist>}
Description	This command displays each port's parameters settings. If not input the portlist, all ports will be shown . If there are multi instances on this bridge , the parameters of the port on different instances will be shown.
Parameters	<p><i>ports</i> - To show parameters of the designated port numbers , to be distinguished from showing parameters of the bridge.</p> <p><i>portlist</i> - One of CLI Value Type , restrict the input value and format of the ports, refer to section 1-4 Switch Numerical Ranges.</p> <p><i>instance_id</i> - specifies the stp instance id.</p>
Restrictions	None.

Example usage:

To show stp ports:

```
DGS-3627:admin# show stp ports
Command: show stp ports

MSTP Port Information
Port Index      : 1    , Hello Time: 2 /2 , Port STP : Enabled , LBD : No
External PathCost : Auto/20000    , Edge Port : False/No , P2P : Auto /Yes
Port RestrictedRole : False, Port RestrictedTCN : False
Port Forward BPDU : Disabled

Msti   Designated Bridge   Internal PathCost   Prio   Status   Role
-----
0      N/A                 200000              128   Disabled Disabled
2      N/A                 200000              128   Disabled Disabled

DGS-3627:admin#
```

show stp mst_config_id

Purpose	Used to show the MST Configuration Identification.
Syntax	show stp mst_config_id
Description	Show the 3 elements of the MST configuration Identification, including: Configuration NameRevision Level, and MST configuration Table. The default Configuration name is the MAC address of the bridge.
Parameters	<i>mst_config_id</i> - If two bridges has the same three elements in mst_config_id, that means they are in the same MST region.
Restrictions	None.

Example usage:

show stp mst_config_id:

```
DGS-3627:admin# show stp mst_config_id
Command: show stp mst_config_id

Current MST Configuration Identification
-----

Configuration Name : 00-22-22-22-22-00                Revision Level :0
MSTI ID      Vid list
-----
   CIST      1-4094

DGS-3627:admin#
```

create stp instance_id

Purpose	To create an MST Instance without mapping the corresponding VLANs yet.
Syntax	create stp instance_id <value 1-15>
Description	To create a new MST instance independent from the default Instance: CIST (Instance 0). After creating the MST instance, need to do the configuration of VLANs, or this newly created MST instance will still be in disable state.
Parameters	<i>instance_id</i> - MSTP instance id. Instance 0 represents for default instance, CIST. The DUT support 16 Instance (0-15) at most.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create mstp instance:

```
DGS-3627:admin# create stp instance_id 2
Command: create stp instance_id 2

Success.

DGS-3627:admin#
```

delete stp instance_id

Purpose	Used to delete MST Instance.
Syntax	delete stp instance_id <value 1-15>
Description	To delete the specified MST Instance . CIST (Instance 0) can not be deleted and only can delete one instance at a time.
Parameters	<i>instance_id</i> - MSTP instance id. Instance 0 represents for default instance, CIST. The DUT support 16 Instance (0-15) at most.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete mstp instance:


```
DGS-3627:admin# delete stp instance_id 2
Command: delete stp instance_id 2

Success.

DGS-3627:admin#
```

config stp instance_id

Purpose	To map or remove the VLAN range of the specified MST instance for the existed MST Instances.
Syntax	config stp instance_id <value 1-15> [add_vlan remove_vlan] <vidlist>
Description	There are 2 different action type to deal with an MST Instance. They are listed as follows: add_vlan: to map specified VLAN lists to an existed MST Instance . remove_vlan: to delete specified VLAN lists from an existed MST Instance.
Parameters	<i>instance_id</i> - MSTP instance id . Instance 0 represents for default instance, CIST. The DUT support 16 Instance (0-15) at most. <i>add_vlan</i> - Defined action type to configure an MST Instance. <i>remove_vlan</i> - Defined action type to configure an MST Instance. <i>vidlist</i> - Specifies a list of VLANs by VLAN ID.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To map vlan id to mstp instance:

```
DGS-3627:admin# config stp instance_id 2 add_vlan 1 to 3
Command: config stp instance_id 2 add_vlan 1 to 3

Success.

DGS-3627:admin#
```

To remove vlan id from mstp instance:

```
DGS-3627:admin# config stp instance_id 2 remove_vlan 2
Command: config stp instance_id 2 remove_vlan 2

Success.

DGS-3627:admin#
```

config stp mst_config_id

Purpose	Used to change the name or revision level of the MST configuration Identification.
Syntax	config stp mst_config_id {name <string> revision_level <int 0-65535>}
Description	To configure configuration name, revision level in the MST configuration Identification. The default configuration name is the MAC address of the bridge.
Parameters	<i>name</i> - The name given for a specified MST region. <i>revision_level</i> - The same given name with different revision level also represents for different MST region.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To change the name and revision level of the MST configuration Identification:

```
DGS-3627:admin# config stp mst_config_id name R&D_BlockG revision_level 1
Commands: config stp mst_config_id name R&D_BlockG revision_level 1

Success.

DGS-3627:admin#
```

enable stp

Purpose	Used to enable STP globally.
Syntax	enable stp
Description	May be we could modify to allow user enable stp per instance. But CIST should be enabled first before enable other instances. Current design is when user enable the CIST, all MSTIs will be enabled automatically if FORCE_VERSION is set to MSTP(3) and there is at least one vlan mapped to this instance.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable stp:

```
DGS-3627:admin# enable stp
Command: enable stp

Success.

DGS-3627:admin#
```

disable stp

Purpose	Used to disable STP globally.
Syntax	disable stp
Description	To disable STP functionality in every existed instance.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable stp:

```
DGS-3627:admin# disable stp
Command: disable stp

Success.

DGS-3627:admin#
```

config stp version

Purpose	Used to enable STP globally.
Syntax	config stp version [mstp rstp stp]
Description	If version is configured as stp or rstp, all currently running MSTIs should be disabled. For version is configured as mstp, current design is enabled all available MSTIs (assume that CIST is enabled). Further discussion needed to decide whether we let user to enable the MSTIs.
Parameters	<i>version</i> - To decide to run under which version of STP. <i>mstp</i> - Multiple Spanning Tree Protocol. <i>rstp</i> - Rapid Spanning Tree Protocol. <i>stp</i> - Spanning Tree Protocol.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To config stp version:

```
DGS-3627:admin# config stp version mstp
Command: config stp version mstp

Success.

DGS-3627:admin#
```

To config stp version with the same value of old configuration:

```
DGS-3627:admin# config stp version mstp
Command: config stp version mstp

Configure value is the same with current value.
Fail!

DGS-3627:admin#
```

config stp priority

Purpose	Used to configure the instance priority.
Syntax	config stp priority <value 0-61440> instance_id <value 0-15>
Description	One of the parameters used to select the Root Bridge.
Parameters	<i>priority</i> - The bridge priority value must be divisible by 4096. <i>instance_id</i> - Identifier to distinguish different STP instances.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To config stp instance_id:

```
DGS-3627:admin# config stp priority 61440 instance_id 0
Command: config stp priority 61440 instance_id 0

Success.

DGS-3627:admin#
```

config stp

Purpose	Used to configure the bridge management parameters for CIST (instance_id = 0).
Syntax	config stp {maxage <value 6-40> maxhops <value 1-40> hellotime <value 1-10> forwarddelay <value 4-30> txholdcount <value 1-10> fbpdudisable(2) lbd [enable(1) disable(0)] lbd_recover_timer [<value 0> <value 60-1000000>] nni_bpdu_addr [dot1d dot1ad]}(1)
Description	This command is used to configure the bridge parameters global settings.
Parameters	<p><i>maxage</i> - Used to determine if a BPDU is valid. The default value is 20.</p> <p><i>maxhops</i> - Used to restrict the forwarded times of one BPDU. The default value is 20.</p> <p><i>forwarddelay</i> - The maximum delay time for one BPDU to be transmitted by a bridge and received from another bridge. The default value is 15.</p> <p><i>txholdcount</i> - Used to restrict the numbers of BPDU transmitted in a time interval (per Hello Time).</p> <p><i>fbpdu</i> - To decide if the Bridge will flood STP BPDU when STP functionality is disabled.</p> <p><i>nni_bpdu_addr</i> - Used to determine the BPDU protocol address for STP in service provide site. It can use 802.1d STP address, 802.1ad service provider STP address or an user defined mutilcast address. The range of the user defined address is 0180C2000000 - 0180C2FFFFFF.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To config stp:

```
DGS-3627:admin# config stp maxage 25
Command: config stp maxage 25

Success.

DGS-3627:admin#
```

config stp ports

Purpose	Used to configure the ports management parameters only at CIST level.
Syntax	config stp ports <portlist> {externalCost [auto <value 1-200000000>] hellotime <value 1-10> migrate [yes no] edge [true false auto] p2p [true false auto] state [enable disable] restricted_role [true false] restricted_tcn [true false] lbd [enable disable] fbpdudisable(2) lbd_recover_timer [<value 0> <value 60-1000000>] nni_bpdu_addr [dot1d dot1ad]}(1)
Description	This command can configure all the parameters of ports, except for Internal Path Cost and Port Priority.
Parameters	<p><i>portlist</i> - One of CLI Value Type , restrict the input value and format of the ports, refer to section 1-4 Switch Numerical Ranges.</p> <p><i>external_cost</i> - The path cost between MST regions from the transmitting Bridge to the CIST Root Bridge. It is only used at CIST level.</p> <p><i>hellotime</i> - The default value is 2 . This is a per-Bridge parameter in RSTP, but it becomes a</p>

config stp ports

per-Port parameter in MSTP.

migrate - Operation of management in order to specify the port to send MSTP BPDU for a delay time.

edge - To decide if this port is connected to a LAN or a Bridged LAN. In auto mode, the bridge will delay for a period to become edge port if no bridge BPUD is received. The default is auto mode.

p2p - To decide if this port is in Full-Duplex or Half-Duplex mode.

state - To decide if this port supports the STP functionality.

restricted_role - To decide if this port not to be selected as Root Port. The default value is false.

restricted_tcn - To decide if this port not to propagate topology change. The default value is false.

fbpdu - To decide if this port will flood STP BPDU when STP functionality is disabled.

When the state is set to enable, the received BPDU will be forwarded.

When the state is set to disable, the received VPDU will be dropped.

hw_filtering is an option that is only required by some legacy chipset which cannot support per L2 protocol packet control. When the state is set to *hw_filtering*, if STP BPDU is received by this port, the port will be changed to BPDU hardware filtering mode such that all layer 2 control packets will be dropped by hardware. The default state is disable.

recover_hw_filtering - When a port is in BPDU hardware filtering mode, it can be recovered by this option.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To config stp ports:

```
DGS-3627:admin# config stp ports 1 external_cost auto
```

```
Command: config stp ports 1 external_cost auto
```

```
Success.
```

```
DGS-3627:admin#
```

config stp mst_ports

Purpose Used to configure the ports management parameters at CIST (instance_id = 0) or MSTI (instance_id = 1) level.

Syntax **config stp mst_ports <portlist> instance_id <value 0-15> {internalCost [auto | <value 1-200000000>] | priority <value 0-240>}**

Description Internal Path Cost and Port Priority of a Port in MSTI can be separately configured to different values from the configuration of CIST (instance_id = 0).

Parameters *mst_ports* - To be distinguished from the parameters of ports only at CIST level.

portlist - One of CLI Value Type , restrict the input value and format of the ports, refer to section 1-4 Switch Numerical Ranges.

instance_id - Instance = 0 represents for CIST , Instance from 1 to 15 represents for MSTI 1 - MSTI 15.

internal_cost - Port Path Cost used in MSTP.

priority - Port Priority.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To config stp mst_ports:

```
DGS-3627:admin# config stp mst_ports 1 instance_id 0 internal_cost auto
```

```
Command: config stp mst_ports 1 instance_id 0 internal_cost auto
```

```
Success.
```

```
DGS-3627:admin#
```

NETWORK LOAD BALANCING (NLB) COMMANDS

The NLB indicates the Network Load Balancing: it is a MAC forwarding control for supporting Microsoft's Network Load Balancing technique.

The Network Load Balancing (NLB) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create nlb multicast_fdb	[<vlan_name 32> vlanid <vlanid>] <macaddr>
delete nlb multicast_fdb	[<vlan_name 32> vlanid <vlanid>] <macaddr>
config nlb multicast_fdb	[<vlan_name 32> vlanid <vlanid>] <macaddr> [add delete] <portlist>
show nlb fdb	

Each command is listed, in detail, in the following sections.

create nlb multicast_fdb

Purpose	Use to create the switch's NLB multicast FDB entry.
Syntax	create nlb multicast_fdb [<vlan_name 32> vlanid <vlanid>] <macaddr>
Description	<p>The create nlb multicast_fdb command creates a NLB multicast FDB entry. The number of supported entries is project dependent.</p> <p>The network load balancing command set is used to support the Microsoft server load balancing application where multiple servers can share the same IP address and MAC address. The requests from clients will be forwarded to all servers, but will only be processed by one of them. The server can work in one different modes – multicast mode. In multicast mode, the client use the multicast MAC address as the destination MAC to reach the server. Regarding of the mode, this destination Mac is the named the shared MAC. The server uses its own MAC address (rather than the shared MAC) as the source MAC address of the reply packet.</p> <p>The NLB multicast FDB entry will be mutual exclusive with the L2 multicast entry.</p>
Parameters	<p><i>vlan_name</i> - Specify the VLAN of the NLB multicast FDB entry to be created.</p> <p><i>vlanid <vlanid></i> - Specify the VLAN by the VLAN ID.</p> <p><i><macaddr></i> - Specify the MAC address of the NLB multicast FDB entry to be created.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a NLB multicast FDB entry:

```
DGS-3627:admin# create nlb multicast_fdb default 03-bf-01-01-01-01
Command: create nlb multicast_fdb default 03-bf-01-01-01-01
Success.
DGS-3627:admin#
```

delete nlb multicast_fdb

Purpose	Use to delete the switch's NLB multicast FDB entry.
---------	---

delete nlb multicast_fdb

Syntax	delete nlb multicast_fdb [<vlan_name 32> vlanid <vlanid>] <macaddr>
Description	The delete nlb multicast_fdb command is used to delete the NLB multicast FDB entry.
Parameters	<vlan_name 32> - Specify the VLAN of the NLB multicast FDB entry to be deleted. vlanid <vlanid> - Specify the VLAN by VLAN ID. <macaddr> - Specify the MAC address of the NLB multicast FDB entry to be deleted.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete NLB multicast FDB entry:

```
DGS-3627:admin# delete nlb multicast_fdb default 03-bf-01-01-01-01
Command: delete nlb multicast_fdb default 03-bf-01-01-01-01
Success.
DGS-3627:admin#
```

config nlb multicast_fdb

Purpose	Use to configure the switch's NLB multicast FDB entry.
Syntax	config nlb multicast_fdb [<vlan_name 32> vlanid <vlanid>] <macaddr> [add delete] <portlist>
Description	The config nlb multicast_fdb command is used to add or delete the forwarding ports for the specified NLB multicast FDB entry.
Parameters	vlan_name - Specify the VLAN of the NLB multicast FDB entry to be configured. vlanid <vlanid> - Specify the VLAN by the VLAN ID. <macaddr> - Specify the Mac address of the NLB multicast FDB entry to be configured. add <portlist> - Specify a list of forwarding ports to be added. delete <portlist> - Specify a list of forwarding ports to be removed.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure NLB multicast MAC forwarding database:

```
DGS-3627:admin# config nlb multicast_fdb default 03-bf-01-01-01-01 add 1:1-1:5
Command: config nlb multicast_fdb default 03-bf-01-01-01-01 add 1:1-1:5
Success.
DGS-3627:admin#
```

show nlb fdb

Purpose	Used to show NLB configured entry.
Syntax	show nlb fdb
Description	The show nlb fdb command is used to show the NLB Configured entry.
Parameters	None.
Restrictions	None.

Example usage:

To display the NLB forwarding table:

```
DGS-3627:admin# show nlb fdb
```

```
Command: show nlb fdb
```

MAC Address	VLAN ID	Egress Ports
03-bf-01-01-01-01	100	1:1-1:5,1:26,2:26
03-bf-01-01-01-01	1	1:1-1:5,1:26,2:26

```
Total Entries : 2
```

```
DGS-3627:admin#
```

OPEN SHORTEST PATH FIRST (OSPFV3) COMMANDS

The Open Shortest Path First (OSPFv3) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config ospfv3 router_id	<ipaddr>
enable ospfv3	
disable ospfv3	
show ospfv3	{[ipif <ipif_name 12> all]}
create ospfv3 area	<area_id> type [normal stub {stub_summary [enable disable] metric <value 0-65535>}]
delete ospfv3 area	<area_id>
config ospfv3 area	<area_id> type [normal stub {stub_summary [enable disable] metric <value 0-65535>}]
show ospfv3 area	{<area_id>}
create ospfv3 aggregation	<area_id> <ipv6networkaddr> advertise [enable disable]
delete ospfv3 aggregation	<area_id> <ipv6networkaddr>
config ospfv3 aggregation	<area_id> <ipv6networkaddr> advertise [enable disable]
show ospfv3 aggregation	{<area_id>}
show ospfv3 lsdb	{area <area_id> type [rtrlink netlink inter_area_prefix inter_area_router asexmlink link_lsa intra_area_prefix]}
show ospfv3 neighbor	{<neighbor_id> ipif <ipif_name 12>}
show ospfv3 virtual_neighbor	{<area_id> <neighbor_id>}
config ospfv3	[ipif <ipif_name 12> all] {area <area_id> priority <value 0-255> hello_interval <sec 1-65535> dead_interval <sec 1-65535> instance <value 0-255> metric <value 1-65535> state [enable disable] passive [enable disable]}(1)
create ospfv3 virtual_link	<area_id> <neighbor_id> {hello_interval <sec 1-65535> dead_interval <sec 1-65535> instance <value 0-255>}
config ospfv3 virtual_link	<area_id> <neighbor_id> {hello_interval <sec 1-65535> dead_interval <sec 1-65535> instance <value 0-255>}(1)
delete ospfv3 virtual_link	<area_id> <neighbor_id>
show ospfv3 virtual_link	{<area_id> <neighbor_id>}

Each command is listed, in detail, in the following sections.

config ospfv3 router_id

Purpose	Used to configure OSPFv3 router ID.
Syntax	config ospfv3 router_id <ipaddr>
Description	This command is used to configure the OSPFv3 router ID.

config ospfv3 router_id

Parameters	<i>router_id</i> - User may enter a 32-bit number in the form of an IPv4 address that uniquely identifies the router in the OSPFv3 domain. Set 0.0.0.0 means auto-selected. Switch will select the largest IPv4 address among the IP interfaces to be the router ID. The default value of OSPFv3 router ID is 0.0.0.0 (auto-selected).
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set OSPFv3 router ID:

```
DGS-3627:admin# config ospfv3 router_id 1.1.1.1
Command: config ospfv3 router_id 1.1.1.1

Success.

DGS-3627:admin#
```

enable ospfv3

Purpose	Used to enable OSPFv3 on the switch.
Syntax	enable ospfv3
Description	This command is used to enable OSPFv3 on the switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable OSPFv3:

```
DGS-3627:admin# enable ospfv3
Command: enable ospfv3

Success.

DGS-3627:admin#
```

disable ospfv3

Purpose	Used to disable OSPFv3 on the switch.
Syntax	disable ospfv3
Description	This command is used to disable OSPFv3 on the switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable OSPFv3:

```
DGS-3627:admin# disable ospfv3
Command: disable ospfv3

Success.

DGS-3627:admin#
```

show ospfv3

Purpose	Used to display the OSPFv3 configurations or OSPFv3 interfaces information.
Syntax	show ospfv3 {[ipif <ipif_name 12> all]}
Description	This command is used to display OSPFv3 configurations, including global state, router ID, OSPFv3 interfaces, areas, virtual links and area aggregations. If the parameter is set, it is used to display the information of one or all OSPFv3 interfaces.
Parameters	<i>ipif</i> - Display the information of one OSPFv3 interface. <i>all</i> - Display the information off all OSPFv3 interfaces.
Restrictions	None.

Example usage:

To display OSPFv3 configuration for System:

```
DGS-3627:admin# show ospfv3 ipif System
Command: show ospfv3 ipif System

Interface Name: System                               Link Local Address: FE80::201:2FF:FE03:400 (Link
Up)
Network Medium Type: BROADCAST                       Metric: 10
Area ID: 0.0.0.0                                     Administrative State: Disabled
Priority: 1                                           DR State: DOWN
DR ID: None                                          Backup DR ID: None
Hello Interval: 10                                   Dead Interval: 40
Transmit Delay: 1                                   Retransmit Time: 5
Passive Mode: Disabled                               Instance ID: 0

Total Entries: 1

DGS-3627:admin#
```

create ospfv3 area

Purpose	Used to create an OSPFv3 area.
Syntax	create ospfv3 area <area_id> type [normal stub {stub_summary [enable disable] metric <value 0-65535>}]
Description	This command is used to create an OSPFv3 area.
Parameters	<i>area</i> - Specifies the OSPFv3 area's ID. It is a 32-bit number in the form of an IPv4 address that uniquely identifies the OSPFv3 area in the OSPFv3 domain. <i>type</i> - The OSPFv3 area mode of operation. There are two types: <i>normal</i> - Define the OSPFv3 area created as a normal area. <i>stub</i> - Define the OSPFv3 area created as a stub area. <i>stub_summary</i> - Specifies the OSPFv3 stub area to import inter-area prefix LSA advertisements or not.

create ospfv3 area

enable - Import inter-area prefix LSA into this stub area.

disable - Do not import inter-area prefix LSA into this stub area.

metric - Specifies the default cost of OSPFv3 stub area. The range of value is 0 to 65535. The default setting is 1.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To create OSPFv3 areas:

```
DGS-3627:admin# create ospfv3 area 1.1.1.1 type normal
```

```
Command: create ospfv3 area 1.1.1.1 type normal
```

Success.

```
DGS-3627:admin# create ospfv3 area 2.2.2.2 type stub stub_summary enable
```

```
Command: create ospfv3 area 2.2.2.2 type stub stub_summary enable
```

Success.

```
DGS-3627:admin#
```

delete ospfv3 area

Purpose

Used to delete an OSPFv3 area.

Syntax

delete ospfv3 area <area_id>

Description

This command is used to delete an OSPFv3 area. The backbone area (0.0.0.0) can not be deleted.

Parameters

area - Specifies the OSPFv3 area's ID. It is a 32-bit number in the form of an IPv4 address that uniquely identifies the OSPFv3 area in the OSPFv3 domain.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an OSPFv3 area:

```
DGS-3627:admin# delete ospfv3 area 1.1.1.1
```

```
Command: delete ospfv3 area 1.1.1.1
```

Success.

```
DGS-3627:admin#
```

config ospfv3 area

Purpose

Used to configure an OSPFv3 area.

Syntax

config ospfv3 area <area_id> type [normal | stub {stub_summary [enable | disable] | metric <value 0-65535>}]

Description

This command is used to configure an OSPFv3 area. The backbone area (0.0.0.0) can not be configured to be stub area.

Parameters

area - Specifies the OSPFv3 area's ID. It is a 32-bit number in the form of an IPv4 address

config ospfv3 area

that uniquely identifies the OSPFv3 area in the OSPFv3 domain.

type - The OSPFv3 area mode of operation. There are two types:

normal - Define the OSPFv3 area created as a normal area.

stub - Define the OSPFv3 area created as a stub area.

stub_summary - Specifies the OSPFv3 stub area to import inter-area prefix LSA advertisements or not.

enable - Import inter-area prefix LSA into this stub area.

disable - Do not import inter-area prefix LSA into this stub area.

metric - Specifies the default cost of OSPFv3 stub area. The range of value is 0 to 65535. The default setting is 1.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To create OSPFv3 areas:

```
DGS-3627:admin# config ospfv3 area 2.2.2.2 type normal
```

```
Command: config ospfv3 area 2.2.2.2 type normal
```

```
Success.
```

```
DGS-3627:admin#
```

show ospfv3 area

Purpose

Used to display OSPFv3 area configurations or information.

Syntax

show ospfv3 area {<area_id>}

Description

This command is used to display OSPFv3 area configurations or information.

Parameters

area - Specifies the OSPFv3 area's ID. It is a 32-bit number in the form of an IPv4 address that uniquely identifies the OSPFv3 area in the OSPFv3 domain.

Restrictions

None.

Example usage:

To display OSPFv3 areas:

```
DGS-3627:admin# show ospfv3 area
```

```
Command: show ospfv3 area
```

OSPFv3 Area Settings

Area ID	Type	Stub	Import	Summary LSA	Stub	Default	Cost
0.0.0.0	Normal	None			None		
2.2.2.2	Normal	None			None		

```
Total Entries: 2
```

```
DGS-3627:admin# show ospfv3 area 0.0.0.0
```

```
Command: show ospfv3 area 0.0.0.0
```

```
Area ID: 0.0.0.0
```

```
Area Type: Normal
```

```
SPF Algorithm Runs For Area 0.0.0.0: 1 time
```

```
Number Of LSA In This Area: 2
```

```
Checksum Sum: 0x0
```

```
Number Of ABR In This Area: 0
```

```
Number Of ASBR In This Area: 0
```

```
Total Entries: 1
```

```
DGS-3627:admin#
```

create ospfv3 aggregation

Purpose	Used to create an OSPFv3 area aggregation.
Syntax	create ospfv3 aggregation <area_id> <ipv6networkaddr> advertise [enable disable]
Description	This command is used to create an OSPFv3 area aggregation.
Parameters	<p><area_id> - Specify the area where the aggregation belongs to.</p> <p><ipv6networkaddr> - Specify the IPv6 network address of the aggregation.</p> <p>advertise - See below:</p> <ul style="list-style-type: none"> enable - OSPFv3 ABR will use this aggregation to aggregate the intra-area routes when it advertise these routes to another area. disable - OSPFv3 ABR will not use this aggregation to aggregate the intra-area routes when it advertise these routes to another area.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create an OSPFv3 area aggregation:

```
DGS-3627:admin# create ospfv3 aggregation 2.2.2.2 2000::/16 advertise enable
```

```
Command: create ospfv3 aggregation 2.2.2.2 2000::/16 advertise enable
```

```
Success.
```

```
DGS-3627:admin#
```

delete ospfv3 aggregation

Purpose	Used to delete an OSPFv3 area aggregation.
---------	--

delete ospfv3 aggregation

Syntax	delete ospfv3 aggregation <area_id> <ipv6networkaddr>
Description	This command is used to delete an OSPFv3 area aggregation.
Parameters	<area_id> - Specify the area where the aggregation belongs to. <ipv6networkaddr> - Specify the IPv6 network address of the aggregation.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an OSPFv3 area aggregation:

```
DGS-3627:admin# delete ospfv3 aggregation 2.2.2.2 2000::/16
Command: delete ospfv3 aggregation 2.2.2.2 2000::/16
```

Success.

```
DGS-3627:admin#
```

config ospfv3 aggregation

Purpose	Used to configure an OSPFv3 area aggregation.
Syntax	config ospfv3 aggregation <area_id> <ipv6networkaddr> advertise [enable disable]
Description	This command is used to configure an OSPFv3 area aggregation.
Parameters	<area_id> - Specify the area where the aggregation belongs to. It is index of area aggregation. <ipv6networkaddr> - Specify the IPv6 network address of the aggregation. It is index of area aggregation. <i>advertise</i> - See below: <i>enable</i> - OSPFv3 ABR will use this aggregation to aggregate the intra-area routes when it advertise these routes to another area. <i>disable</i> - OSPFv3 ABR will not use this aggregation to aggregate the intra-area routes when it advertise these routes to another area.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure an OSPFv3 area aggregation:

```
DGS-3627:admin# config ospfv3 aggregation 2.2.2.2 2000::/16 advertise disable
Command: config ospfv3 aggregation 2.2.2.2 2000::/16 advertise disable
```

Success.

```
DGS-3627:admin#
```

show ospfv3 aggregation

Purpose	Used to display OSPFv3 area aggregation configurations.
Syntax	show ospfv3 aggregation {<area_id>}
Description	This command is used to display OSPFv3 area aggregation configurations.

show ospfv3 aggregation

Parameters	<area_id> - If it is set, only the aggregations that belong to this area will be displayed. If it is not set, all aggregations will be displayed.
Restrictions	None.

Example usage:

To display OSPFv3 area aggregations:

```
DGS-3627:admin# show ospfv3 aggregation
Command: show ospfv3 aggregation

OSPFv3 Area Aggregation Settings

Area ID          Aggregated          LSDB          Advertise
Network Address  Type
-----
1.1.1.1          1000::/16           Summary      Disabled
2.2.2.2          2000::/16           Summary      Disabled

Total Entries: 2

DGS-3627:admin# show ospfv3 aggregation 2.2.2.2
Command: show ospfv3 aggregation 2.2.2.2

OSPFv3 Area Aggregation Settings

Area ID          Aggregated          LSDB          Advertise
Network Address  Type
-----
2.2.2.2          2000::/16           Summary      Disabled

Total Entries: 1

DGS-3627:admin#
```

show ospfv3 lsdb

Purpose	Used to display OSPFv3 LSDB.
Syntax	show ospfv3 lsdb {area <area_id> type [rtrlink netlink inter_area_prefix inter_area_router asextlink link_lsa intra_area_prefix]}
Description	This command is used to display the OSPFv3 LSDB.
Parameters	<p><i>area</i> - If it is set, only the LSAs that belong to this area will be displayed.</p> <p><i>type</i> - If it is set, only this type LSAs will be displayed and detail information for these LSAs will be displayed at the same time. The type includes:</p> <ul style="list-style-type: none"> <i>rtrlink</i> - Router LSA; <i>netlink</i> - Network LSA. <i>inter_area_prefix</i> - Inter-Area-Prefix LSA <i>inter_area_router</i> - Inter-Area-Router LSA <i>asextlink</i> - AS external LSA <i>link_lsa</i> - Link LSA. <i>intra_area_prefix</i> - Intra-Area-Prefix LSA.

show ospfv3 lsdb

Restrictions None.

Example usage:

To display OSPFv3 LSDB:

```
DGS-3627:admin# show ospfv3 lsdb
Command: show ospfv3 lsdb

                Router LSA (Area 0.0.0.0)
Link State ID  ADV Router      Age  Seq#           Link
0.0.0.0        2.2.2.2          696  0x80000003    0

                Link LSA (Interface System)
Link State ID  ADV Router      Age  Seq#           Prefix
0.0.0.1        2.2.2.2          696  0x80000003    1

                Intra-Area-Prefix LSA (Area 0.0.0.0)
Link State ID  ADV Router      Age  Seq#           Ref LSA Type
0.0.0.1        2.2.2.2          684  0x80000004    0x2001

Total Entries: 3

DGS-3627:admin# show ospfv3 lsdb type rtrlink
Command: show ospfv3 lsdb type rtrlink

LS Age: 782
LS Type: Router-LSA
Link State ID: 0.0.0.0
Advertising Router: 2.2.2.2
LS Seq Number: 0x80000003
Checksum: 0xED3A
Length: 24
Flags: 0x0: - - - -
Options: 0x13: - R - - E V6

Total Entries: 1

DGS-3627:admin#
```

show ospfv3 neighbor

Purpose	Used to display OSPFv3 neighbor information.
Syntax	show ospfv3 neighbor {<neighbor_id> ipif <ipif_name 12>}
Description	This command is used to display OSPFv3 neighbor information.
Parameters	<i>neighbor_id</i> - Specify the ID of the neighbor. If none of the parameters are set, all neighbors will be displayed. <i>ipif</i> - Specify the interface where the neighbor is built. If none of the parameters are set, all neighbors will be displayed.
Restrictions	None.

Example usage:

To display OSPFv3 neighbor:

```
DGS-3627:admin# show ospfv3 neighbor
Command: show ospfv3 neighbor

Router ID of      Interface      Neighbor Neighbor
Neighbor          Name           Priority State
-----
10.10.10.10      System        1         Full
20.20.20.20      ip1           10        Full

Total Entries: 2

DGS-3627:admin# show ospfv3 neighbor 10.10.10.10 ipif System
Command: show ospfv3 neighbor 10.10.10.10 ipif System

Neighbor ID: 10.10.10.10           Interface Name: System
Neighbor Options: 19               Neighbor Priority: 255
Neighbor State: Full               State Changes: 6 times
Interface ID: 1

Total Entries: 1

DGS-3627:admin#
```

show ospfv3 virtual_neighbor

Purpose	Used to display OSPFv3 virtual neighbor information.
Syntax	show ospfv3 virtual_neighbor {<area_id> <neighbor_id>}
Description	This command is used to display OSPFv3 virtual neighbor information.
Parameters	<p><area_id> - Specify the transit area where the virtual neighbor is built. If none of the parameters are set, all virtual neighbors will be displayed.</p> <p><neighbor_id> - Specify the ID of the virtual neighbor. If none of the parameters are set, all virtual neighbors will be displayed.</p>
Restrictions	None.

Example usage:

To display OSPFv3 virtual neighbor:

```
DGS-3627:admin# show ospfv3 virtual_neighbor
Command: show ospfv3 virtual_neighbor

Transit      Router ID Of      Virtual Neighbor
Area ID      Virtual Neighbor  State
-----
1.1.1.1      30.30.30.30      Full

Total Entries: 1

DGS-3627:admin# show ospfv3 virtual_neighbor 6.6.6.6 20.20.20.20
Command: show ospfv3 virtual_neighbor 6.6.6.6 20.20.20.20

Transit Area ID: 1.1.1.1
Virtual Neighbor ID: 30.30.30.30
Virtual Neighbor Options: 19
Virtual Neighbor State: Full           State Changes: 9 times

Total Entries: 1

DGS-3627:admin#
```

config ospfv3

Purpose	Used to configure OSPFv3 interface.
Syntax	config ospfv3 [ipif <ipif_name 12> all] {area <area_id> priority <value 0-255> hello_interval <sec 1-65535> dead_interval <sec 1-65535> instance <value 0-255> metric <value 1-65535> state [enable disable] passive [enable disable]}(1)
Description	This command is used to configure OSPFv3 interface.
Parameters	<p><i>ipif</i> - Configure one OSPFv3 interface.</p> <p><i>all</i> - Configure all OSPFv3 interfaces.</p> <p><i>area</i> - A 32-bit number in the form of an IPv4 address that uniquely identifies the OSPFv3 area in the OSPFv3 domain.</p> <p><i>priority</i> - The priority used in the election of the Designated Router (DR). It is a number between 0 and 255. Its default value is 1.</p> <p><i>hello_interval</i> - Allows the specification of the interval between the transmission of OSPFv3 Hello packets, in seconds. Between 1 and 65535 seconds can be specified. The Hello Interval, Dead Interval should be the same for all routers on the same link. Its default value is 10.</p> <p><i>dead_interval</i> - Allows the specification of the length of time between the receipt of Hello packets from a neighbor router before the selected area declares that router down. An interval between 1 and 65535 seconds can be specified. The Dead Interval must be evenly divisible by the Hello Interval. Its default value is 40.</p> <p><i>instance</i> - The instance ID of the interface. Its default value is 0.</p> <p><i>metric</i> - This field allows the entry of a number between 1 and 65,535 that is representative of the OSPFv3 cost of reaching the selected OSPFv3 interface. Its default value is 1.</p> <p><i>passive</i> - The user may select Active or Passive for this OSPFv3 interface. Active interfaces actively advertise OSPFv3 to routers on other Intranets that are not part of this specific OSPFv3 group. Passive interface will not advertise to any other routers than those within its OSPFv3 intranet. When this field is disabled, it denotes an active interface. Its default setting is Disabled.</p> <p><i>state</i> - Used to enable or disable this interface to run OSPFv3. Its default value is Disabled.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure OSPFv3 interface:

```
DGS-3627:admin# config ospfv3 ipif System area 0.0.0.0 priority 100 hello_interval 20
dead_interval 60 instance 1 metric 20 state enable passive disable
Command: config ospfv3 ipif System area 0.0.0.0 priority 100 hello_interval 20
dead_interval 60 instance 1 metric 20 state enable passive disable

Success.

DGS-3627:admin#
```

create ospfv3 virtual_link

Purpose	Used to create an OSPFv3 virtual link.
Syntax	create ospfv3 virtual_link <area_id> <neighbor_id> {hello_interval <sec 1-65535> dead_interval <sec 1-65535> instance <value 0-255>}
Description	This command is used to create an OSPFv3 virtual link.
Parameters	<p><i><area_id></i> - A 32-bit number in the form of an IPv4 address that uniquely identifies the OSPFv3 area in the OSPFv3 domain. This area is the transit area where the virtual link is built.</p> <p><i><neighbor_id></i> - A 32-bit number in the form of an IPv4 address that uniquely identifies the OSPFv3 virtual neighbor in the OSPFv3 domain.</p> <p><i>hello_interval</i> - Allows the specification of the interval between the transmission of OSPFv3 Hello packets, in seconds. Between 1 and 65535 seconds can be specified. The Hello Interval, Dead Interval should be the same for all routers on the same link. Its default value is 10.</p> <p><i>dead_interval</i> - Allows the specification of the length of time between the receipt of Hello packets from a neighbor router before the selected area declares that router down. An interval between 1 and 65535 seconds can be specified. The Dead Interval must be evenly divisible by the Hello Interval. Its default value is 60.</p> <p><i>instance</i> - The instance ID on the virtual link. Its default value is 0.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create OSPFv3 virtual link:

```
DGS-3627:admin# create ospfv3 virtual_link 1.1.1.1 60.60.60.60
Command: create ospfv3 virtual_link 1.1.1.1 60.60.60.60

Success.

DGS-3627:admin#
```

config ospfv3 virtual_link

Purpose	Used to configure an OSPFv3 virtual link.
Syntax	config ospfv3 virtual_link <area_id> <neighbor_id> {hello_interval <sec 1-65535> dead_interval <sec 1-65535> instance <value 0-255>}(1)
Description	This command is used to configure an OSPFv3 virtual link.
Parameters	<p><i><area_id></i> - A 32-bit number in the form of an IPv4 address that uniquely identifies the OSPFv3 area in the OSPFv3 domain. This area is the transit area where the virtual link is built.</p>

config ospfv3 virtual_link

<neighbor_id> - A 32-bit number in the form of an IPv4 address that uniquely identifies the OSPFv3 virtual neighbor in the OSPFv3 domain.

hello_interval - Allows the specification of the interval between the transmission of OSPFv3 Hello packets, in seconds. Between 1 and 65535 seconds can be specified. The Hello Interval, Dead Interval should be the same for all routers on the same link. Its default value is 10.

dead_interval - Allows the specification of the length of time between the receipt of Hello packets from a neighbor router before the selected area declares that router down. An interval between 1 and 65535 seconds can be specified. The Dead Interval must be evenly divisible by the Hello Interval. Its default value is 60.

instance - The instance ID on the virtual link. Its default value is 0.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To configure an OSPFv3 virtual link:

```
DGS-3627:admin# config ospfv3 virtual_link 1.1.1.1 60.60.60.60 hello_interval 20
dead_interval 80 instance 1
Command: config ospfv3 virtual_link 1.1.1.1 60.60.60.60 hello_interval 20 dead_interval
80 instance 1

Success.

DGS-3627:admin#
```

delete ospfv3 virtual_link

Purpose	Used to delete an OSPFv3 virtual link.
Syntax	delete ospfv3 virtual_link <area_id> <neighbor_id>
Description	This command is used to delete an OSPFv3 virtual link.
Parameters	<p><i><area_id></i> - A 32-bit number in the form of an IPv4 address that uniquely identifies the OSPFv3 area in the OSPFv3 domain. This area is the transit area where the virtual link is built.</p> <p><i><neighbor_id></i> - A 32-bit number in the form of an IPv4 address that uniquely identifies the OSPFv3 virtual neighbor in the OSPFv3 domain.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an OSPFv3 virtual link:

```
DGS-3627:admin# delete ospfv3 virtual_link 1.1.1.1 60.60.60.60
Command: delete ospfv3 virtual_link 1.1.1.1 60.60.60.60

Success.

DGS-3627:admin#
```

show ospfv3 virtual_link

Purpose	Used to display OSPFv3 virtual link configurations.
---------	---

show ospfv3 virtual_link

Syntax	show ospfv3 virtual_link {<area_id> <neighbor_id>}
Description	This command is used to display OSPFv3 virtual link configuration. If no parameters are set, all virtual links will be displayed.
Parameters	<p><area_id> - A 32-bit number in the form of an IPv4 address that uniquely identifies the OSPFv3 area in the OSPFv3 domain. This area is the transit area where the virtual link is built.</p> <p><neighbor_id> - A 32-bit number in the form of an IPv4 address that uniquely identifies the OSPFv3 virtual neighbor in the OSPFv3 domain.</p>
Restrictions	None.

Example usage:

To display OSPFv3 virtual link:

```
DGS-3627:admin# show ospfv3 virtual_link
```

```
Command: show ospfv3 virtual_link
```

Virtual Interface Configuration

Transit Area ID	Virtual Neighbor Router	Hello Interval	Dead Interval	Instance ID	Link Status
1.1.1.1	60.60.60.60	10	60	0	DOWN
1.1.1.1	70.70.70.70	10	60	0	DOWN

```
Total Entries: 2
```

```
DGS-3627:admin# show ospfv3 virtual_link 1.1.1.1 60.60.60.60
```

```
Command: show ospfv3 virtual_link 1.1.1.1 60.60.60.60
```

```
Transit Area ID: 1.1.1.1           Virtual Neighbor Router ID: 60.60.60.60
Hello Interval: 10                 Dead Interval: 60
Transmit Delay: 1                  Retransmit Time: 5
Instance ID: 0
Virtual Link Status: DOWN
```

```
Total Entries: 1
```

```
DGS-3627:admin#
```

OSPF COMMANDS

The OSPF commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config ospf router_id	<ipaddr>
enable ospf	
disable ospf	
show ospf	{[ipif <ipif_name 12> all]}
create ospf area	<area_id> type [normal [stub nssa {translate [enable disable]}] {stub_summary [enable disable] metric <value 0-65535>}]
delete ospf area	<area_id>
config ospf area	<area_id> type [normal [stub nssa {translate [enable disable]}] {stub_summary [enable disable] metric <value 0-65535>}]
show ospf area	{<area_id>}
create ospf host_route	<ipaddr> {area <area_id> metric <value 1-65535>}
delete ospf host_route	<ipaddr>
config ospf host_route	<ipaddr> {area <area_id> metric <value 1-65535>}(1)
show ospf host_route	{<ipaddr>}
create ospf aggregation	<area_id> <network_address> lsdb_type [summary {advertise [enable disable]} nssa_ext {advertise [enable disable]}]
delete ospf aggregation	<area_id> <network_address> lsdb_type [summary nssa_ext]
config ospf aggregation	<area_id> <network_address> lsdb_type [summary {advertise [enable disable]} nssa_ext {advertise [enable disable]}]
show ospf aggregation	{<area_id>}
show ospf lsdb	{area <area_id> advertise_router <ipaddr> type [rtrlink netlink summary assummary asexmlink nssa_ext]}
show ospf neighbor	{<ipaddr>}
show ospf virtual_neighbor	{<area_id> <neighbor_id>}
config ospf ipif	[ipif <ipif_name 12> all] {area <area_id> priority <value> hello_interval <sec 1-65535> dead_interval <sec 1-65535> authentication [none simple <password 8> md5 <key_id 1-255>] metric <value 1-65535> state [enable disable] passive [enable disable]}(1)
create ospf virtual_link	<area_id> <neighbor_id> {hello_interval <sec 1-65535> dead_interval <sec 1-65535> authentication [none simple <password 8> md5 <key_id 1-255>]}
config ospf virtual_link	<area_id> <neighbor_id> {hello_interval <sec 1-65535> dead_interval <sec 1-65535> authentication [none simple <password 8> md5 <key_id 1-255>]}(1)
delete ospf virtual_link	<area_id> <neighbor_id>
show ospf virtual_link	{<area_id> <neighbor_id>}

Each command is listed, in detail, in the following sections.

config ospf router_id

Purpose	Used to configure the OSPF router ID.
Syntax	config ospf router_id <ipaddr>
Description	This command is used to configure the OSPF router ID.
Parameters	<ipaddr> – The IP address of the OSPF router.
Restrictions	Only Administrator and Operator-level users can issue this command.

Usage example

To configure the OSPF router ID:

```
DGS-3627:admin# config ospf router_id 10.48.74.122
Command: config ospf router_id 10.48.74.122

Success.

DGS-3627:admin#
```

enable ospf

Purpose	Used to enable OSPF on the Switch.
Syntax	enable ospf
Description	This command, in combination with the disable ospf command below, is used to enable and disable OSPF on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Usage example

To enable OSPF on the Switch:

```
DGS-3627:admin# enable ospf
Command: enable ospf

Success.

DGS-3627:admin#
```

disable ospf

Purpose	Used to disable OSPF on the Switch.
Syntax	disable ospf
Description	This command, in combination with the enable ospf command above, is used to enable and disable OSPF on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Usage example

To disable OSPF on the Switch:

```
DGS-3627:admin# disable ospf
Command: disable ospf

Success.

DGS-3627:admin#
```

show ospf

Purpose	Used to display the current OSPF state on the Switch.
Syntax	show ospf {[<i>ipif</i> < <i>ipif_name</i> 12> all]}
Description	This command will display the current state of OSPF on the Switch, divided into the following categories: <ul style="list-style-type: none">General OSPF settingsOSPF Interface settingsOSPF Area settingsOSPF Virtual Interface settingsOSPF Area Aggregation settingsOSPF Host Route settings
Parameters	<i>ipif</i> – Specify the IP interface here.
Restrictions	None.

Example usage:

To show OSPF state:

DGS-3627:admin# show ospf

Command: show ospf

OSPF Router ID : 10.90.90.90 (Auto selected)

State : Disabled

OSPF Interface Settings

Interface	IP Address	Area ID	State	Link Status	Metric
System	10.90.90.90/8	0.0.0.0	Disabled	Link Up	1

Total Entries : 1

OSPF Area Settings

Area ID	Type	Stub	Import Summary	LSA	Stub Default	Cost	Translate
0.0.0.0	Normal	None			None		None

Total Entries : 1

CTRL+C **ESC** **q** Quit **SPACE** **n** Next Page **Enter** Next Entry **a** All

create ospf area

Purpose	Used to create an OSPF area.
Syntax	create ospf area <area_id> type [normal [stub nssa {translate [enable disable]}] {stub_summary [enable disable] metric <value 0-65535>}]
Description	This command is used to create an OSPF area and configure its settings.
Parameters	<p><area_id> – The OSPF area ID. The user may enter a 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain.</p> <p>type – The OSPF area mode of operation – the user has three choices to choose from to define the area created here.</p> <ul style="list-style-type: none"> normal – Choosing this parameter will define the OSPF area created here as a normal area. stub – Choosing this parameter will define the OSPF area created here as a stub area. nssa – Choosing this parameter will define the OSPF area created here as an NSSA (Not So Stubby Area) area. <ul style="list-style-type: none"> translate [enable disable] – Enable this parameter to translate Type-7 LSAs into Type-5 LSAs, so that they can be distributed outside of the NSSA. The default is Disabled. This field can only be configured if <i>nssa</i> is chosen in the <i>type</i> field. <p>stub_summary [enable disable] – Enables or disables the OSPF area to import summary LSA advertisements.</p> <p>metric <value 0-65535> – The OSPF area cost between 0 and 65535. 0 denotes that the value will be automatically assigned. The default setting is 0. For NSSA areas, the metric field determines the cost of traffic entering the NSSA area.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create an OSPF area:

```
DGS-3627:admin# create ospf area 10.48.74.122 type normal
Command: create ospf area 10.48.74.122 type normal

Success.

DGS-3627:admin#
```

To create an OSPF NSSA area:

```
DGS-3627:admin# create ospf area 11.1.1.1 type nssa translate enable metric 5
stub_summary enable
Command: create ospf area 11.1.1.1 type nssa translate enable metric 5 stub_summary
enable

Success.

DGS-3627:admin#
```

delete ospf area

Purpose	Used to delete an OSPF area.
Syntax	delete ospf area <area_id>
Description	This command is used to delete an OSPF area.
Parameters	<area_id> – A 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an OSPF area:

```
DGS-3627:admin# delete ospf area 10.48.74.122
Command: delete ospf area 10.48.74.122

Success.

DGS-3627:admin#
```

config ospf area

Purpose	Used to configure an OSPF area's settings.
Syntax	config ospf area <area_id> type [normal [stub nssa {translate [enable disable]}] {stub_summary [enable disable] metric <value 0-65535>}]
Description	This command is used to configure an OSPF area's settings.
Parameters	<p><area_id> – The OSPF area ID. The user may enter a 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain.</p> <p>type – The OSPF area mode of operation – the user has three choices to choose from to define the area configured here.</p> <ul style="list-style-type: none"> • <i>normal</i> – Choosing this parameter will define the OSPF area configured here as a normal area. • <i>stub</i> – Choosing this parameter will define the OSPF area configured here as a stub area.

config ospf area

- *nssa* – Choosing this parameter will define the OSPF area configured here as an NSSA (Not So Stubby Area) area.
 - *translate [enable | disable]* – Enable this parameter to translate Type-7 LSAs into Type-5 LSAs, so that they can be distributed outside of the NSSA. The default is Disabled. This field can only be configured if *nssa* is chosen in the type field.

stub_summary [enable | disable] – Allows the OSPF area import of LSA advertisements to be enabled or disabled.

metric <value 0-65535> – The OSPF area cost between 0 and 65535. 0 denotes that the value will be automatically assigned. The default setting is 0. For NSSA areas, the metric field determines the cost of traffic entering the NSSA area.

Restrictions

Only Administrator and Operator-level users can issue this command.

Usage example

To configure an OSPF area's settings:

```
DGS-3627:admin# config ospf area 10.48.74.122 type stub stub_summary enable metric 1
Command: config ospf area 10.48.74.122 type stub stub_summary enable metric 1
```

Success.

```
DGS-3627:admin#
```

show ospf area

Purpose	Used to display an OSPF area's configuration.
Syntax	show ospf area {<area_id>}
Description	This command will display the current OSPF area configuration.
Parameters	<i><area_id></i> – A 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain.
Restrictions	None.

Usage example

To display an OSPF area's settings:

```
DGS-3627:admin# show ospf area
Command: show ospf area
```

OSPF Area Settings

Area ID	Type	Stub	Import	Summary	LSA	Stub	Default	Cost	Translate
0.0.0.0	Normal	None				None			None

Total Entries : 1

```
DGS-3627:admin#
```

create ospf host_route

Purpose	Used to configure OSPF host route settings.
Syntax	create ospf host_route <ipaddr> {area <area_id> metric <value 1-65535>}
Description	This command is used to configure the OSPF host route settings.
Parameters	<p><ipaddr> – The host's IP address.</p> <p><area_id> – A 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain.</p> <p>metric <value 1-65535> – A metric between 1 and 65535, which will be advertised.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Usage example

To configure the OSPF host route settings:

```
DGS-3627:admin# create ospf host_route 10.48.74.122 area 10.1.1.1 metric 2
Command: create ospf host_route 10.48.74.122 area 10.1.1.1 metric 2
```

Success.

```
DGS-3627:admin#
```

delete ospf host_route

Purpose	Used to delete an OSPF host route.
Syntax	delete ospf host_route <ipaddr>
Description	This command is used to delete an OSPF host route.
Parameters	<ipaddr> – The IP address of the OSPF host.
Restrictions	Only Administrator and Operator-level users can issue this command.

Usage example

To delete an OSPF host route:

```
DGS-3627:admin# delete ospf host_route 10.48.74.122
Command: delete ospf host_route 10.48.74.122
```

Success.

```
DGS-3627:admin#
```

config ospf host_route

Purpose	Used to configure OSPF host route settings.
Syntax	config ospf host_route <ipaddr> {area <area_id> metric <value 1-65535>}(1)
Description	This command is used to configure an OSPF host route settings.
Parameters	<p><ipaddr> – The IP address of the host.</p> <p><area_id> – A 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain.</p> <p><value> – A metric between 1 and 65535 that will be advertised for the route.</p>

config ospf host_route

Restrictions Only Administrator and Operator-level users can issue this command.

Usage example

To configure an OSPF host route:

```
DGS-3627:admin# config ospf host_route 10.48.74.122 area 10.1.1.1 metric 2
Command: config ospf host_route 10.48.74.122 area 10.1.1.1 metric 2

Success.

DGS-3627:admin#
```

show ospf host_route

Purpose	Used to display the current OSPF host route table.
Syntax	show ospf host_route {<ipaddr>}
Description	This command will display the current OSPF host route table.
Parameters	<ipaddr> – The IP address of the host.
Restrictions	None.

Example usage:

To display the current OSPF host route table:

```
DGS-3627:admin# show ospf host_route
Command: show ospf host_route

OSPF Host Route Settings

Host Address      Metric Area ID
-----
10.48.73.21      2      10.1.1.1

Total Entries : 1

DGS-3627:admin#
```

create ospf aggregation

Purpose	Used to configure OSPF area aggregation settings.
Syntax	create ospf aggregation <area_id> <network_address> lsdb_type [summary {advertise [enable disable]} nssa_ext {advertise [enable disable]}]
Description	This command is used to create an OSPF area aggregation.
Parameters	<p><area_id> – A 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain.</p> <p><network_address> – The 32-bit number in the form of an IP address that uniquely identifies the network that corresponds to the OSPF Area.</p> <p>lsdb_type – The type of address aggregation. The user has two choices for the LSDB type:</p> <ul style="list-style-type: none"> • <i>summary</i> – Choosing this LSDB type will summarize routes that are entering the OSPF area by redistribution.

create ospf aggregation

- *advertise [enable | disable]* – Allows for the advertisement trigger to be enabled or disabled.
- *nssa_ext* – Choosing this LSDB type will summarize routes that are entering the OSPF NSSA from an external source.
 - *advertise [enable | disable]* – Allows for the advertisement trigger to be enabled or disabled.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To create an OSPF area aggregation:

```
DGS-3627:admin# create ospf aggregation 10.1.1.1 10.48.76.122/16 lsdb_type summary
advertise enable
Command: create ospf aggregation 10.1.1.1 10.48.76.122/16 lsdb_type summary advertise
enable

Success.

DGS-3627:admin#
```

delete ospf aggregation

Purpose	Used to delete an OSPF area aggregation configuration.
Syntax	delete ospf aggregation <area_id> <network_address> lsdb_type [summary nssa_ext]
Description	This command is used to delete an OSPF area aggregation configuration.
Parameters	<p><i><area_id></i> – A 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain.</p> <p><i><network_address></i> – The 32-bit number in the form of an IP address that uniquely identifies the network that corresponds to the OSPF Area.</p> <p><i>lsdb_type</i> – Specifies the type of address aggregation to be deleted. Choose either <i>summary</i> or <i>nssa_ext</i>.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Usage example

To delete the OSPF area aggregation settings:

```
DGS-3627:admin# delete ospf aggregation 10.1.1.1 10.48.76.122/16 lsdb_type summary
Command: delete ospf aggregation 10.1.1.1 10.48.76..122/16 lsdb_type summary

Success.

DGS-3627:admin#
```

config ospf aggregation

Purpose	Used to configure the OSPF area aggregation settings.
Syntax	config ospf aggregation <area_id> <network_address> lsdb_type [summary {advertise [enable disable]} nssa_ext {advertise [enable disable]}]
Description	This command is used to configure the OSPF area aggregation settings.

config ospf aggregation

Parameters	<p><i><area_id></i> – A 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain.</p> <p><i><network_address></i> – The 32-bit number in the form of an IP address that uniquely identifies the network that corresponds to the OSPF Area.</p> <p><i>lsdb_type</i> – The type of address aggregation. The user has two choices for the LSDB type:</p> <ul style="list-style-type: none"> • <i>summary</i> – Choosing this LSDB type will summarize routes that are entering the OSPF area by redistribution. <ul style="list-style-type: none"> • <i>advertise [enable disable]</i> – Allows for the advertisement trigger to be enabled or disabled. • <i>nssa_ext</i> – Choosing this LSDB type will summarize routes that are entering the OSPF NSSA from an external source. <ul style="list-style-type: none"> • <i>advertise [enable disable]</i> – Allows for the advertisement trigger to be enabled or disabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Usage example

To configure the OSPF area aggregation settings:

```
DGS-3627:admin# config ospf aggregation 10.1.1.1 10.48.76.122/16 lsdb_type summary
advertise enable
Command: config ospf aggregation 10.1.1.1 10.48.76.122/16 lsdb_type summary advertise
enable

Success.

DGS-3627:admin#
```

show ospf aggregation

Purpose	Used to display the current OSPF area aggregation settings.
Syntax	show ospf aggregation {<area_id>}
Description	This command will display the current OSPF area aggregation settings.
Parameters	<i><area_id></i> – Enter this parameter to view this table by a specific OSPF area ID.
Restrictions	None.

Example usage:

To display OSPF area aggregation settings:

```
DGS-3627:admin# show ospf aggregation
Command: show ospf aggregation

OSPF Area Aggregation Settings

Area ID          Aggregated          LSDB          Advertise
Network Address  Type
-----
10.1.1.1         10.0.0.0/8         Summary      Enabled
244.0.0.6        11.0.0.0/8         NSSA-Ext     Enabled

Total Entries: 2

DGS-3627:admin#
```

show ospf lsdb

Purpose	Used to display the OSPF Link State Database (LSDB).
Syntax	show ospf lsdb {area_id <area_id> advertise_router <ipaddr> type [rtrlink netlink summary asummary asexmlink nssa_ext]}
Description	This command will display the current OSPF Link State Database (LSDB).
Parameters	<i>area_id <area_id></i> – A 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain. <i>advertise_router <ipaddr></i> – The router ID of the advertising router. <i>type [rtrlink netlink summary asummary asexmlink nssa_ext]</i> – The type of link.
Restrictions	None.



NOTE: When this command displays a "*" (a star symbol) in the OSPF LSDB table for the area_id or the Cost, this is interpreted as "no area ID" for external LSAs, and as "no cost given" for the advertised link.

Example usage:

To display the link state database of OSPF:

```
DGS-3627:admin# show ospf lsdb
Command: show ospf lsdb

Area          LSDB          Advertising          Link State          Cost          Sequence
ID            Type          Router ID           ID
-----
0.0.0.0       RTRLink       50.48.75.73         50.48.75.73        *             0x80000002
0.0.0.0       Summary       50.48.75.73         10.0.0.0/8         1             0x80000001
1.0.0.0       RTRLink       50.48.75.73         50.48.75.73        *             0x80000001
1.0.0.0       Summary       50.48.75.73         40.0.0.0/8         1             0x80000001
1.0.0.0       Summary       50.48.75.73         50.0.0.0/8         1             0x80000001
*             ASExtLink     50.48.75.73         1.2.0.0/16         20            0x80000001

Total Entries: 5

DGS-3627:admin#
```

show ospf neighbor

Purpose	Used to display the current OSPF neighbor router table.
Syntax	show ospf neighbor {<ipaddr>}
Description	This command will display the current OSPF neighbor router table.
Parameters	<ipaddr> – The IP address of the neighbor router.
Restrictions	None.

Usage example

To display the current OSPF neighbor router table:

```
DGS-3627:admin# show ospf neighbor
Command: show ospf neighbor

IP Address of      Router ID of      Neighbor Neighbor
Neighbor           Neighbor         Priority State
-----
10.48.74.122      10.2.2.2         1    Initial

Total Entries: 1

DGS-3627:admin#
```

show ospf virtual_neighbor

Purpose	Used to display the current OSPF virtual neighbor router table.
Syntax	show ospf virtual_neighbor {<area_id> <neighbor id>}
Description	This command will display the current OSPF virtual neighbor router table.
Parameters	<area_id> – A 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain. <neighbor_id> – The OSPF router ID for the neighbor. This is a 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the remote area's Area Border Router.
Restrictions	None.

Usage example

To display the current OSPF virtual neighbor table:

```
DGS-3627:admin# show ospf virtual_neighbor
Command: show ospf virtual_neighbor

Transit           Router ID of      IP Address of      Virtual Neighbor
Area ID           Virtual Neighbor  Virtual Neighbor  State
-----
10.1.1.1          10.2.3.4         10.48.74.111     Exchange

Total Entries : 1

DGS-3627:admin#
```

config ospf ipif

Purpose	Used to configure the OSPF interface settings.
Syntax	config ospf [ipif <ipif_name 12> all] {area <area_id> priority <value> hello_interval <sec 1-65535> dead_interval <sec 1-65535> authentication [none simple <password 8> md5 <key_id 1-255>] metric <value 1-65535> state [enable disable] passive [enable disable]}(1)
Description	This command is used to configure the OSPF interface settings.
Parameters	<p><ipif_name 12> – The name of the IP interface.</p> <p>all - All IP interfaces.</p> <p>area <area_id> – A 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain.</p> <p>priority <value> – The priority used in the election of the Designated Router (DR). A number between 0 and 255.</p> <p>hello_interval <sec 1-65535> – Allows the specification of the interval between the transmission of OSPF Hello packets, in seconds. Between 1 and 65535 seconds can be specified. The Hello Interval, Dead Interval, Authorization Type, and Authorization Key should be the same for all routers on the same network.</p> <p>dead_interval <sec 1-65535> – Allows the specification of the length of time between the receipt of Hello packets from a neighbor router before the selected area declares that router down. An interval between 1 and 65535 seconds can be specified. The Dead Interval must be evenly divisible by the Hello Interval.</p> <p>authentication – Enter the type of authentication preferred. The user may choose between:</p> <ul style="list-style-type: none"> • none – Choosing this parameter will require no authentication. • simple <password 8> – Choosing this parameter will set a simple authentication which includes a case-sensitive password of no more than 8 characters. • md5 <key_id 1-255> – Choosing this parameter will set authentication based on md5 encryption. A previously configured MD5 key ID (1 to 255) is required. <p>metric <value 1-65535> – This field allows the entry of a number between 1 and 65,535 that is representative of the OSPF cost of reaching the selected OSPF interface. The default metric is 1.</p> <p>state [enable disable] – Used to enable or disable this function.</p> <p>passive [enable disable] – The user may select Active or Passive for this OSPF interface. Active interfaces actively advertise OSPF to routers on other Intranets that are not part of this specific OSPF group. Passive interface will not advertise to any other routers than those within its OSPF intranet. When this field is disabled, it denotes an active interface. The default setting is <i>disable</i>. (active)</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Usage example

To configure OSPF interface settings:

```
DGS-3627:admin# config ospf ipif System priority 2 hello_interval 15 metric 2 state enable
Command: config ospf ipif System priority 2 hello_interval 15 metric 2 state enable

Success.

DGS-3627:admin#
```

show ospf ipif

Purpose	Used to display the current OSPF interface settings for the specified interface name.
Syntax	show ospf ipif {[ipif <ipif_name 12> all]}

show ospf ipif

Description	This command will display the current OSPF interface settings for the specified interface name.
Parameters	<i><ipif_name 12></i> – The IP interface name for which to display the current OSPF interface settings. <i>all</i> – Choosing this parameter will display the OSPF settings for all IP interfaces on the Switch.
Restrictions	None.

Example usage:

To display the current OSPF interface settings, for a specific OSPF interface:

```
DGS-3627:admin# show ospf ipif System
Command: show ospf ipif System

Interface Name: System                IP Address: 172.18.70.105/21 (Link Up)
Network Medium Type: BROADCAST       Metric: 1
Area ID: 0.0.0.0                     Administrative State: Disabled
Priority: 1                           DR State: DOWN
DR Address: None                      Backup DR Address: None
Hello Interval: 10                   Dead Interval: 40
Transmit Delay: 1                    Retransmit Time: 5
Authentication: None

Passive Mode: Disabled
Total Entries: 1

DGS-3627:admin#
```

show ospf all

Purpose	Used to display the current OSPF settings of all the OSPF interfaces on the Switch.
Syntax	show ospf all
Description	This command will display the current OSPF settings for all OSPF interfaces on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the current OSPF interface settings, for all OSPF interfaces on the Switch:

```
DGS-3627:admin# show ospf all
```

```
Command: show ospf all
```

```
Interface Name: System                IP Address: 10.90.90.90/8 (Link Up)
Network Medium Type: BROADCAST        Metric: 1
Area ID: 0.0.0.0                      Administrative State: Disabled
Priority: 1                             DR State: DOWN
DR Address: None                       Backup DR Address: None
Hello Interval: 10                     Dead Interval: 40
Transmit Delay: 1                      Retransmit Time: 5
Authentication: None
```

```
Total Entries : 1
```

```
DGS-3627:admin#
```

create ospf virtual_link

Purpose	Used to create an OSPF virtual interface.
Syntax	create ospf virtual_link <area_id> <neighbor_id> {hello_interval <sec 1-65535> dead_interval <sec 1-65535> authentication [none simple <password 8> md5 <key_id 1-255>]}
Description	This command is used to create an OSPF virtual interface.
Parameters	<p><i><area_id></i> – A 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain.</p> <p><i><neighbor_id></i> – The OSPF router ID for the remote area. This is a 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the remote area's Area Border Router. The router ID of the neighbor router.</p> <p><i>hello_interval <sec 1-65535></i> – Allows the specification of the interval between the transmission of OSPF Hello packets, in seconds. Between 1 and 65535 seconds can be specified. The Hello Interval, Dead Interval, Authorization Type, and Authorization Key should be the same for all routers on the same network.</p> <p><i>dead_interval <sec 1-65535></i> – Allows the specification of the length of time between the receipt of Hello packets from a neighbor router before the selected area declares that router down. An interval between 1 and 65535 seconds can be specified. The Dead Interval must be evenly divisible by the Hello Interval.</p> <p><i>authentication</i> – Enter the type of authentication preferred. The user may choose between:</p> <ul style="list-style-type: none"> • <i>none</i> – Choosing this parameter will require no authentication. • <i>simple <password 8></i> – Choosing this parameter will set a simple authentication which includes a case-sensitive password of no more than 8 characters. • <i>md5 <key_id 1-255></i> – Choosing this parameter will set authentication based on md5 encryption. A previously configured MD5 key ID (1 to 255) is required.
Restrictions	Only Administrator and Operator-level users can issue this command.

Usage example

To create an OSPF virtual interface:

```
DGS-3627:admin# create ospf virtual_link 10.1.1.2 20.1.1.1 hello_interval 10
```

```
Command: create ospf virtual_link 10.1.1.2 20.1.1.1 hello_interval 10
```

```
Success.
```

```
DGS-3627:admin#
```

config ospf virtual_link

Purpose	Used to configure the OSPF virtual interface settings.
Syntax	config ospf virtual_link <area_id> <neighbor_id> {hello_interval <sec 1-65535> dead_interval <sec 1-65535> authentication [none simple <password 8> md5 <key_id 1-255>]}(1)
Description	This command is used to configure the OSPF virtual interface settings.
Parameters	<p><i><area_id></i> – A 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain.</p> <p><i><neighbor_id></i> – The OSPF router ID for the remote area. This is a 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the remote area's Area Border Router.</p> <p><i>hello_interval <sec 1-65535></i> – Allows the specification of the interval between the transmission of OSPF Hello packets, in seconds. Between 1 and 65535 seconds can be specified. The Hello Interval, Dead Interval, Authorization Type, and Authorization Key should be the same for all routers on the same network.</p> <p><i>dead_interval <sec 1-65535></i> – Allows the specification of the length of time between the receipt of Hello packets from a neighbor router before the selected area declares that router down. An interval between 1 and 65535 seconds can be specified. The Dead Interval must be evenly divisible by the Hello Interval.</p> <p><i>authentication</i> – Enter the type of authentication preferred. The user may choose between:</p> <ul style="list-style-type: none"> • <i>none</i> – Choosing this parameter will require no authentication. • <i>simple <password 8></i> – Choosing this parameter will set a simple authentication which includes a case-sensitive password of no more than 8 characters. • <i>md5 <key_id 1-255></i> – Choosing this parameter will set authentication based on md5 encryption. A previously configured MD5 key ID (1 to 255) is required.
Restrictions	Only Administrator and Operator-level users can issue this command.

Usage example

To configure the OSPF virtual interface settings:

```
DGS-3627:admin# config ospf virtual_link 10.1.1.2 20.1.1.1 hello_interval 10
Command: config ospf virtual_link 10.1.1.2 20.1.1.1 hello_interval 10

Success.

DGS-3627:admin#
```

delete ospf virtual_link

Purpose	Used to delete an OSPF virtual interface.
Syntax	delete ospf virtual_link <area_id> <neighbor_id>
Description	This command will delete an OSPF virtual interface from the Switch.
Parameters	<p><i><area_id></i> – A 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain.</p> <p><i><neighbor_id></i> – The OSPF router ID for the remote area. This is a 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the remote area's Area Border Router. The router ID of the neighbor router.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an OSPF virtual interface from the Switch:

```
DGS-3627:admin# delete ospf virtual_link 10.1.1.2 20.1.1.1
Command: delete ospf virtual_link 10.1.1.2 20.1.1.1

Success.

DGS-3627:admin#
```

show ospf virtual_link

Purpose	Used to display the current OSPF virtual interface configuration.
Syntax	show ospf virtual_link {<area_id> <neighbor_id>}
Description	This command will display the current OSPF virtual interface configuration.
Parameters	<p><area_id> – A 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the OSPF area in the OSPF domain.</p> <p><neighbor_id> – The OSPF router ID for the remote area. This is a 32-bit number in the form of an IP address (xxx.xxx.xxx.xxx) that uniquely identifies the remote area's Area Border Router. This is the router ID of the neighbor router.</p>
Restrictions	None.

Example usage:

To display the current OSPF virtual interface configuration:

```
DGS-3627:admin# show ospf virtual_link
Command: show ospf virtual_link

Virtual Interface Configuration

Transit      Virtual      Hello      Dead      Authentication  Link
Area ID      Neighbor Router Interval Interval          Status
-----
10.0.0.0      20.0.0.0      10         60         None            DOWN

Total Entries: 1

DGS-3627:admin#
```


OSPF DEBUG ENHANCEMENT COMMANDS

The OSPF Debug Enhancement commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
debug ospf show flag	
debug ospf neighbor_state_change state	[enable disable]
debug ospf interface_state_change	{dr_bdr_selection} state [enable disable]
debug ospf lsa	{all originating installing receiving flooding} state [enable disable]
debug ospf packet	{all receiving sending} state [enable disable]
debug ospf retransmission state	[enable disable]
debug ospf spf	{all intra inter extern} state [enable disable]
debug ospf route state	[enable disable]
debug ospf route redistribution state	[enable disable]
debug ospf route virtual_link state	[enable disable]
debug ospf route state	[enable disable]
debug ospf timer state	[enable disable]
debug ospf show counter	{packet neighbor spf}
debug ospf clear counter	{packet neighbor spf}
debug ospf show request_list	
debug ospf show redistribution	
debug ospf show summary_list	
debug ospf show detail	[rt_link net_link summary_link external_link type7_link]
debug ospf timer state	[enable disable]
debug ospf log state	[enable disable]
debug ospf show log state	
debug ospf state	[enable disable]

Each command is listed, in detail, in the following sections.

debug ospf show flag

Purpose	Used to display the OSPF debug flag setting.
Syntax	debug ospf show flag
Description	This command is used to display the OSPF debug flag setting.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To show the current OSPF debug flag setting:

```
DGS-3627:admin# debug ospf show flag
Command: debug ospf show flag
```

Current OSPF Flags Setting:

```
Neighbor State Change
Interface State Change
LSA Originating
LSA Operating
LSA Receiving
LSA Flooding
Packet Receiving
Packet Sending
Retransmission
Timer
DR Selection
Route
Redistribution
Virtual Link
SPF Intra
SPF Inter
SPF Extern
```

```
DGS-3627:admin#
```

debug ospf neighbor_state_change

Purpose	Used to enable or disable debug information flags about neighbor state change.
Syntax	debug ospf neighbor_state_change state [enable disable]
Description	This command is used to enable or disable debug information flags about neighbor state change.
Parameters	<i>state</i> - The state of the OSPF neighbor state change debug.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable OSPF neighbor state change debug:

```
DGS-3627:admin# debug ospf neighbor_state_change state enable
Command: debug ospf neighbor_state_change state enable
```

Success.

```
DGS-3627:admin#
```

debug ospf interface_state_change

Purpose	Used to enable or disable debug information flags about interface state change.
Syntax	debug ospf interface_state_change {dr_bdr_selection} state [enable disable]
Description	This command is used to enable or disable debug information flags about interface state

debug ospf interface_state_change

	change.
Parameters	<i>dr_bdr_selection</i> - Used to include or exclude debug information for DR/BDR selection. <i>state</i> - The state of the OSPF interface state change debug.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable OSPF interface state change debug:

```
DGS-3627:admin# debug ospf interface_state_change state enable
Command: debug ospf interface_state_change state enable

Success.

DGS-3627:admin#
```

debug ospf lsa

Purpose	Used to enable or disable debug information flags about LSA.
Syntax	debug ospf lsa {all originating installing receiving flooding} state [enable disable]
Description	This command is used to enable or disable debug information flags about LSA.
Parameters	<i>all</i> - Set all LSA debug flags. <i>originating</i> - Set LSA originating debug flag. <i>installing</i> - Set LSA installing debug flag. <i>receiving</i> - Set LSA receiving debug flag. <i>flooding</i> - Set LSA flooding debug flag. <i>state</i> - The state of the designated debug flag.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable all OSPF LSA debug flags:

```
DGS-3627:admin# debug ospf lsa all state enable
Command: debug ospf lsa all state enable

Success.

DGS-3627:admin#
```

debug ospf packet

Purpose	Used to enable or disable debug information flags about packets, including receiving and sending.
Syntax	debug ospf packet {all receiving sending} state [enable disable]
Description	This command is used to enable or disable debug information flags about packets, including receiving and sending.
Parameters	<i>all</i> - Set all packet debug flags. <i>receiving</i> - Set packet receiving debug flag.

debug ospf packet

	<i>sending</i> - Set packet sending debug flag.
	<i>state</i> - The state of the designated debug flag.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable all OSPF packet debug flags:

```
DGS-3627:admin# debug ospf packet all state enable
Command: debug ospf packet all state enable
```

Success.

```
DGS-3627:admin#
```

debug ospf retransmission

Purpose	Used to enable or disable debug information flags about retransmission.
Syntax	debug ospf retransmission state [enable disable]
Description	This command is used to enable or disable debug information flags about retransmission.
Parameters	<i>state</i> - The state of the OSPF retransmission debug flag.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable all OSPF retransmission debug flags:

```
DGS-3627:admin# debug ospf retransmission state enable
Command: debug ospf retransmission state enable
```

Success.

```
DGS-3627:admin#
```

debug ospf spf

Purpose	Used to enable or disable debug information flags about SPF calculation, including intra-area, inter-area, and AS external.
Syntax	debug ospf spf {all intra inter extern} state [enable disable]
Description	This command is used to enable or disable debug information flags about SPF calculation, including intra-area, inter-area, and AS external.
Parameters	<i>all</i> - Set all SPF debug flags. <i>intra</i> - Set intra-area SPF debug flag. <i>inter</i> - Set inter-area SPF debug flag. <i>extern</i> - Set AS external SPF debug flag. <i>state</i> - The state of the designated debug flag.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable all OSPF SPF debug flags:

```
DGS-3627:admin# debug ospf spf all state enable
Command: debug ospf spf all state enable

Success.

DGS-3627:admin#
```

debug ospf route

Purpose	Used to enable or disable debug information flags about OSPF route adding, modifying, and deleting.
Syntax	debug ospf route state [enable disable]
Description	This command is used to enable or disable debug information flags about OSPF route adding, modifying, and deleting.
Parameters	<i>state</i> - The state of OSPF route debug flag.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable all OSPF route calculating debug flags:

```
DGS-3627:admin# debug ospf route state enable
Command: debug ospf route state enable

Success.

DGS-3627:admin#
```

debug ospf redistribution

Purpose	Used to enable or disable debug information flags about importing other routing protocol routes into OSPF.
Syntax	debug ospf route redistribution state [enable disable]
Description	This command is used to enable or disable debug information flags about importing other routing protocol routes into OSPF.
Parameters	<i>state</i> - The state of OSPF redistribution debug.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable all OSPF route redistribution debug flags:

```
DGS-3627:admin# debug ospf redistribution state enable
Command: debug ospf redistribution state enable

Success.

DGS-3627:admin#
```

debug ospf virtual_link

Purpose	Used to enable or disable debug information flags about virtual link.
Syntax	debug ospf route virtual_link state [enable disable]
Description	This command is used to enable or disable debug information flags about virtual link.
Parameters	<i>state</i> - The state of the OSPF virtual link debug flag.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable all OSPF virtual link debug flags:

```
DGS-3627:admin# debug ospf virtual_link state enable
Command: debug ospf virtual_link state enable

Success.

DGS-3627:admin#
```

debug ospf route state

Purpose	Used to enable or disable debug information flags about OSPF route adding, modifying, and deleting.
Syntax	debug ospf route state [enable disable]
Description	This command is used to enable or disable debug information flags about OSPF route adding, modifying, and deleting.
Parameters	<i>state</i> - The state of OSPF route debug flag.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable all OSPF route calculating debug flags:

```
DGS-3627:admin# debug ospf route state enable
Command: debug ospf route state enable

Success.

DGS-3627:admin#
```

debug ospf timer state

Purpose	Used to enable or disable debug information flags for the OSPF timer.
Syntax	debug ospf timer state [enable disable]
Description	This command is used to enable or disable debug information flags for the OSPF timer.
Parameters	<i>state</i> - The state of the OSPF timer debug flag.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable the OSPF timer debug flag:

```
DGS-3627:admin# debug ospf timer state enable
Command: debug ospf timer state enable

Success.

DGS-3627:admin#
```

debug ospf show counter

Purpose	Used to display OSPF statistic counters.
Syntax	debug ospf show counter {packet neighbor spf}
Description	This command is used to display OSPF statistic counters.
Parameters	<i>packet</i> - To display the OSPF packet counter. <i>neighbor</i> - To display the OSPF neighbor event counter. <i>spf</i> - To display the OSPF SPF event counter. If the parameter is not specified, all OSPF counters will be displayed.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To show all OSPF statistic counters:

```
DGS-3627:admin# debug ospf show counter
Command: debug ospf show counter

OSPF Debug Statistic Counters
Packet Receiving:
  Total   : 30
  Hello   : 30
  DD      : 0
  LSR     : 0
  LSU     : 0
  LSAck   : 0
  Drop    : 0
  Auth Fail : 0

Packet Sending:
  Total   : 59
  Hello   : 59
  DD      : 0
  LSR     : 0
  LSU     : 0
  LSAck   : 0

Neighbor State:
  Change  : 0
  SeqMismatch : 0

SPF Calculation:
  Intra   : 0
  Inter   : 0
  Extern  : 0

DGS-3627:admin#
```

debug ospf clear counter

Purpose	Used to reset OSPF statistic counters.
Syntax	debug ospf clear counter {packet neighbor spf}
Description	This command is used to reset OSPF statistic counters.
Parameters	<i>packet</i> - To reset the OSPF packet counter. <i>neighbor</i> - To reset the OSPF neighbor event counter. <i>spf</i> - To reset the OSPF SPF event counter. If the parameter is not specified, all OSPF counters will be cleared.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To clear all OSPF statistic counters:

```
DGS-3627:admin# debug ospf clear counter
Command: debug ospf clear counter
```

Success.

```
DGS-3627:admin#
```

debug ospf show request_list

Purpose	Used to display the current internal OSPF request list. This command can be used if one or more OSPF neighbors remain in "Loading" state.
Syntax	debug ospf show request_list
Description	This command is used to display the current internal OSPF request list.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display the current OSPF request list:

```
DGS-3627:admin# debug ospf show request_list
Command: debug ospf show request_list
```

OSPF Request List:

```
*Area 0.0.0.0:
Circuit: 1.1.1.1
Neighbor: 90.2.0.1 IP: 1.1.1.2
  LSID: 192.194.134.0 RTID: 90.2.0.1
  LSID: 192.194.135.0 RTID: 90.2.0.1
  LSID: 192.194.136.0 RTID: 90.2.0.1
  LSID: 192.194.137.0 RTID: 90.2.0.1
  LSID: 192.194.138.0 RTID: 90.2.0.1
```

```
DGS-3627:admin#
```


debug ospf show redistribution

Purpose	Used to display the current internal OSPF redistribute list. This command can be used if the external route advertising is not correct.
Syntax	debug ospf show redistribution
Description	This command is used to display the current internal OSPF redistribute list.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display the current OSPF redistribution list:

```
DGS-3627:admin# debug ospf show redistribution
```

```
Command: debug ospf show redistribution
```

```
OSPF Redistribution List:
```

IP	Nexthop	State	Type	Tag
1.1.1.0/24	0.0.0.0	ON	2	0.0.0.0

```
OSPF ASE Table:
```

IP	Nexthop	State	Type	Tag
1.1.1.0/24	0.0.0.0	ON	2	0.0.0.0

```
DGS-3627:admin#
```

debug ospf show summary_list

Purpose	It is used to display the current internal OSPF summary list. This command can be used if one or more OSPF neighbors state stay at ExStart or Exchange.
Syntax	debug ospf show summary_list
Description	This command is used to display the current internal OSPF summary list.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display the current OSPF summary list:

```

DGS-3627:admin# debug ospf show summary_list
Command: debug ospf show summary_list

OSPF Summary List:

Area 0.0.0.0:
Circuit: 1.1.1.1
Neighbor: 90.2.0.1 IP: 1.1.1.2
LSID: 1.1.1.1 RTID: 1.1.1.1

Circuit: 2.2.2.1

Circuit: 10.1.1.6

DGS-3627:admin#

```

debug ospf show detail

Purpose	It is used to display LSAs with detail information. This command can be used if the route calculation is not correct.
Syntax	debug ospf show detail [rt_link net_link summary_link external_link type7_link]
Description	This command is used to display LSAs with detail information.
Parameters	<i>rt_link</i> - Display all Router LSAs with detail information. <i>net_link</i> - Display all Network LSAs with detail information. <i>summary_link</i> - Display all Summary LSAs with detail information. <i>external_link</i> - Display all AS external LSAs with detail information. <i>type7_link</i> - Display all type-7 LSAs with detail information.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display current OSPF router link LSA detail information:

```
DGS-3627:admin# debug ospf show detail rt_link
Command: debug ospf show detail rt_link

OSPF Phase2 RT Link:

=====
AREA 0.0.0.0:
Router LSA:
Link-State ID: 1.1.1.1
Advertising Router: 1.1.1.1
LS Age: 10 Seconds
Options: 0x2
.... ...0 = 0 Bit Isn't Set
.... ..1. = E: ExternalRoutingCapability
.... .0.. = MC: NOT Multicast Capable
.... 0... = N/P: NSSA Bit
...0 .... = EA: Not Support Rcv And Fwd EA_LSA
..0. .... = DC: Not Support Handling Of Demand Circuits
.0.. .... = O: O Bit Isn't Set
0... .... = 7 Bit Isn't Set
LS Sequence Number: 0x80000002
Length: 36
Flags: 0x0
.... ...0 = B: Not Area Border Router
.... ..0. = E: Not AS Boundary Router
.... .0.. = V: Not Virtual Link Endpoint
Number Of Links: 1
Type: Transit      ID: 10.90.90.123      Data: 10.90.90.91      Metric: 1
Internal Field:
Del_flag: 0x0  I_ref_count: 0  Seq: 0x80000002  Csum: 0xd81d
Rxtime: 5  Txttime: 0  Orgage: 0
Current Time: 15

DGS-3627:admin#
```

To display current OSPF network LSA detail information:

```
DGS-3627:admin# debug ospf show detail net_link
Command: debug ospf show detail net_link

OSPF Phase2 NET Link:

=====
AREA 0.0.0.0:
Network LSA:
Link-State ID: 10.90.90.123
Netmask: 255.0.0.0
Advertising Router: 10.90.90.91
LS Age: 109 Seconds
Options: 0x2
.... ...0 = 0 Bit Isn't Set
.... ..1. = E: ExternalRoutingCapability
.... .0.. = MC: NOT Multicast Capable
.... 0... = N/P: NSSA Bit
...0 .... = EA: Not Support Rcv And Fwd EA_LSA
..0. .... = DC: Not Support Handling Of Demand Circuits
.0.. .... = O: O Bit Isn't Set
0... .... = 7 Bit Isn't Set
LS Sequence Number: 0x80000001
Length: 32
Attached Router: 10.90.90.91
Attached Router: 1.1.1.1
Internal Field:
Del_flag: 0x0 I_ref_count: 0 Seq: 0x80000001 Csum: 0x4e99
Rxtime: 4 Txttime: 4 Orgage: 1
Current Time: 112

DGS-3627:admin#
```

To display current OSPF summary LSA detail information:

```
DGS-3627:admin# debug ospf show detail summary_link
Command: debug ospf show detail summary_link

OSPF Phase2 Summary Link:

=====
AREA 0.0.0.0:
  Summary LSA:
  Link-State ID: 20.1.1.0
  Advertising Router: 10.90.90.91
  LS Age: 10 Seconds
  Options: 0x2
  .... ...0 = 0 Bit Isn't Set
  .... ..1. = E: ExternalRoutingCapability
  .... .0.. = MC: NOT Multicast Capable
  .... 0... = N/P: NSSA Bit
  ...0 .... = EA: Not Support Rcv And Fwd EA_LSA
  ..0. .... = DC: Not Support Handling Of Demand Circuits
  .0.. .... = O: O Bit Isn't Set
  0... .... = 7 Bit Isn't Set
  LS Sequence Number: 0x80000001
  Length: 28
  Netmask: 255.255.255.0
  Metric: 1
  Internal Field:
  Del_flag: 0x0 I_ref_count: 0 Seq: 0x80000001 Csum: 0x8f9c
  Rxtime: 246 Txttime: 246 Orgage: 1
  Current Time: 255

DGS-3627:admin#
```

To display current OSPF external LSA detail information:

```
DGS-3627:admin# debug ospf show detail external_link
Command: debug ospf show detail external_link

OSPF Phase2 External Link:

=====
AREA 0.0.0.0:

AS-External LSA:
Link-State ID: 192.168.205.0
Advertising Router: 1.1.1.1
LS Age: 10 Seconds
Options: 0x2
.... ...0 = 0 Bit Isn't Set
.... ..1. = E: ExternalRoutingCapability
.... .0.. = MC: NOT Multicast Capable
.... 0... = N/P: NSSA Bit
...0 .... = EA: Not Support Rcv And Fwd EA_LSA
..0. .... = DC: Not Support Handling Of Demand Circuits
.0.. .... = O: O Bit Isn't Set
0... .... = 7 Bit Isn't Set
LS Sequence Number: 0x80000001
Length: 36
Netmask: 255.255.255.0
Metric: 20
Forwarding Address: 10.90.90.101
External Route Tag: 0
Internal Field:
Del_flag: 0x0 I_ref_count: 0 Seq: 0x80000001 Csum: 0xd08e
Rxtime: 384 Txtime: 0 Orgage: 0
Current Time: 394

DGS-3627:admin#
```

To display current OSPF Type-7 LSA detail information:

```
DGS-3627:admin# debug ospf show detail type7_link
Command: debug ospf show detail type7_link

OSPF Phase2 NSSA-External Link:

=====
AREA 0.0.0.1:

NSSA-External LSA:
Link-State ID: 0.0.0.0
Advertising Router: 10.90.90.91
LS Age: 855 Seconds
Options: 0x2
.... ...0 = 0 Bit Isn't Set
.... ..1. = E: ExternalRoutingCapability
.... .0.. = MC: NOT Multicast Capable
.... 0... = N/P: NSSA Bit
...0 .... = EA: Not Support Rcv And Fwd EA_LSA
..0. .... = DC: Not Support Handling Of Demand Circuits
.0.. .... = O: O Bit Isn't Set
0... .... = 7 Bit Isn't Set
LS Sequence Number: 0x80000002
Length: 36
Netmask: 0.0.0.0
Metric: 0
Forwarding Address: 0.0.0.0
External Route Tag: 0
Internal Field:
Del_flag: 0x0 I_ref_count: 0 Seq: 0x80000002 Csum: 0x77be
Rxtime: 2301 Txtime: 0 Orgage: 0
Current Time: 3156

DGS-3627:admin#
```

debug ospf timer

Purpose	Used to enable or disable debug information flags for the OSPF timer.
Syntax	debug ospf timer state [enable disable]
Description	This command is used to enable or disable debug information flags for the OSPF timer.
Parameters	<i>state</i> - The state of the OSPF timer debug flag.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable the OSPF timer debug flag:

```
DGS-3627:admin# debug ospf timer state enable
Command: debug ospf timer state enable

Success.

DGS-3627:admin#
```

debug ospf log state

Purpose	Used to enable or disable the debug OSPF log.
Syntax	debug ospf log state [enable disable]
Description	This command is used to enable or disable the debug OSPF log.
Parameters	<i>state</i> - The state of the OSPF debug log.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable the OSPF debug log:

```
DGS-3627:admin# debug ospf log state enable
Command: debug ospf log state enable

Success.

DGS-3627:admin#
```

debug ospf show log state

Purpose	Used to display the OSPF debug log state.
Syntax	debug ospf show log state
Description	This command is used to display the OSPF debug log state.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display the debug OSPF log state:

```
DGS-3627:admin# debug ospf show log state
Command: debug ospf show log state

  OSPF Log State : Enabled

DGS-3627:admin#
```

debug ospf state

Purpose	Used to set the OSPF debug global state.
Syntax	debug ospf state [enable disable]
Description	This command is used to set the OSPF debug global state.
Parameters	<i>enable</i> – Specify to enable the OSPF debug global state. <i>disable</i> - Specify to disable the OSPF debug global state.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable the OSPF debug global state:


```
DGS-3627:admin# debug ospf state enable
```

```
Command: debug ospf state enable
```

```
Success.
```

```
DGS-3627:admin# debug ospf show flag
```

```
Command: debug ospf show flag
```

```
Current OSPF Flags Setting:
```

```
Neighbor State Change
```

```
DGS-3627:admin#
```

PASSWORD ENCRYPTION COMMANDS

The Password Encryption commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
enable password encryption	
disable password encryption	
create account	[admin operator] user] <username 15>
config account	<username> {encrypt [plain_text sha_1] <password>}
show account	
delete account	<username>

Each command is listed, in detail, in the following sections.

enable password encryption

Purpose	Used to create user accounts.
Syntax	enable password encryption
Description	The user account configuration information will be stored in the configuration file, and can be applied to the system later. If the password encryption is enabled, the password will be in encrypted form.
Parameters	None.
Restrictions	Only Administrator can issue this command.

Example usage:

To enable the password encryption:

```
DGS-3627:admin# enable password encryption
Command: enable password encryption

Success.

DGS-3627:admin#
```

disable password encryption

Purpose	Used to create user accounts
Syntax	disable password encryption
Description	The user account configuration information will be stored in the configuration file, and can be applied to the system later. When password encryption is disabled, if the user specifies the password in plain text form, the password will be in plain text form. However, if the user specifies the password in encrypted form, or if the password has been converted to encrypted form by the last enable password encryption command, the password will still be in the encrypted form. It can not be

config account

Purpose	Used to configure user accounts.
Syntax	config account <username> {encrypt [plain_text sha_1] <password>}
Description	<p>When the password information is not specified in the command, the system will prompt the user to input the password interactively. For this case, the user can only input the plain text password.</p> <p>If the password is present in the command, the user can select to input the password in the plain text form or in the encrypted form. The encryption algorithm is based on SHA-1.</p>
Parameters	<p><i><username></i> - Name of the account. The account must already be defined.</p> <p><i>plain_text</i> - Select to specify the password in plain text form.</p> <p><i>sha_1</i> - Select to specify the password in the SHA-1 encrypted form.</p> <p><i><password></i> - The password for the user account. The length for of password in plain-text form and in encrypted form are different. For the plain-text form, passwords must have a minimum of 0 character and can have a maximum of 15 characters. For the encrypted form password, the length is fixed to 35 bytes long. The password is case-sensitive.</p>
Restrictions	Only Administrator can issue this command.

Example usage:

To configure the user password of “dlink” account:

```
DGS-3627:admin# config account dlink
Command: config account dlink

Enter a old password:****
Enter a case-sensitive new password:****
Enter the new password again for confirmation:****
Success.

DGS-3627:admin#
```

To configure the user password of “dlink” account:

```
DGS-3627:admin# config account administrator
Command: config account administrator encrypt sha_1 *@&cRDtpNCeBiq15KOQsKVyrA0sAiCIZQwq
Success.

DGS-3627:admin#
```

show account

Purpose	Used to display user accounts.
Syntax	show account
Description	The show account command displays user accounts that have been created.
Parameters	None.
Restrictions	Only Administrator can issue this command.

Example usage:

To display the accounts that have been created:

```

DGS-3627:admin# show account
Command: show account

Current Accounts:
Username          Access Level
-----          -
System           User
dlink            Admin

Total Entries : 2

DGS-3627:admin#

```

delete account

Purpose	Used to delete an existing account.
Syntax	delete account <username>
Description	The delete account command deletes an existing account.
Parameters	<username> - Name of the user who will be deleted.
Restrictions	Only Administrator can issue this command.

Example usage:

To delete the user account "System":

```

DGS-3627:admin# delete account System
Command: delete account System

Success.

DGS-3627:admin#

```

PING COMMANDS

The Ping commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
ping	[<ipaddr> <domain_name 255>] {times <value 1-255> timeout <sec 1-99> source_ip <ipaddr>}
ping6	<ipv6addr> {times <value 1-255> size <value 1-6000> timeout <sec 1-99> source_ip <ipv6addr>}
enable broadcast_ping_reply	
disable broadcast_ping_reply	
show broadcast_ping_reply	

Each command is listed, in detail, in the following sections.

ping

Purpose	Used to test the connectivity between network devices.
Syntax	ping [<ipaddr> <domain_name 255>] {times <value 1-255> timeout <sec 1-99> source_ip <ipaddr>}
Description	The ping command sends Internet Control Message Protocol (ICMP) echo messages to a remote IP address. The remote IP address will then “echo” or return the message. This is used to confirm connectivity between the switch and the remote device.
Parameters	<p><i>ipaddr</i> - Specify the IP address of the host.</p> <p><i>domain_name</i> - Specify the domain name of the host.</p> <p><i>times</i> - The number of individual ICMP echo messages to be sent. A value of 0 will send an infinite number of ICMP echo messages. The maximum value is 255. The default is 0, indicating infinity. Press "CTRL+C" to terminate the ping test.</p> <p><i>timeout</i> - Specify the time-out period while waiting for a response from the remote device. A value of 1 to 99 seconds can be specified. The default is 1 second.</p> <p><i>source_ip</i> - Specify the source IP address of the ping packets. If specified, , this IP address will be used as the packets' source IP address that ping sends to the remote host.</p>
Restrictions	None.

Example usage:

To send ICMP echo message to “10.51.17.1” for 4 times:

```
DGS-3627:admin# ping 10.51.17.1 times 4
Command: ping 10.51.17.1 times 4

Reply from 10.51.17.1, time<10ms
Reply from 10.51.17.1, time<10ms
Reply from 10.51.17.1, time<10ms
Reply from 10.51.17.1, time<10ms

Ping Statistics for 10.51.17.1
Packets: Sent =4, Received =4, Lost =0

DGS-3627:admin#
```

To use the host domain name for the ping command to test the network connectivity. When the 4th response has been received, press “CTRL+C” to terminate the ping:

```
DGS-3627:admin# ping www.dlink.com
Command: ping www.dlink.com

Reply from 207.232.83.10, time<10ms
Reply from 207.232.83.10, time<10ms
Reply from 207.232.83.10, time<10ms
Reply from 207.232.83.10, time<10ms

Ping Statistics for 207.232.83.10
Packets: Sent =4, Received =4, Lost =0

DGS-3627:admin#
```

To send ICMP echo message with source IP address “10.51.17.8” to “10.51.17.2” for 3 times (the Switch’s IP address is 10.51.17.8):

```
DGS-3627:admin# ping 10.51.17.2 times 3 source_ip 10.51.17.8
Command: ping 10.51.17.2 times 3 source_ip 10.51.17.8

Reply from 10.51.17.2, time<10ms
Reply from 10.51.17.2, time<10ms
Reply from 10.51.17.2, time<10ms

Ping Statistics for 10.51.17.2
Packets: Sent =3, Received =3, Lost =0

DGS-3627:admin#
```

ping6

Purpose	Used to test the IPv6 connectivity between network devices.
Syntax	ping6 <ipv6addr> {times <value 1-255> size <value 1-6000> timeout <sec 1-99> source_ip <ipv6addr>}
Description	The ping6 command sends IPv6 Internet Control Message Protocol (ICMP) echo messages to a remote IPv6 address. The remote IPv6 address will then “echo” or return the message. This is used to confirm the IPv6 connectivity between the switch and the remote device.
Parameters	<ipv6addr> - Specify the IPv6 address of the host. times - Specify the number of individual ICMP echo messages to be sent. A value of 0 will send an infinite ICMP echo messages. The maximum value is 255. The default is 0, indicating infinity. Press "CTRL+C" to terminate the ping test.

ping6

size - Specify the size of the test packet.

timeout - Specify the time-out period while waiting for a response from the remote device. A value of 1 to 10 seconds can be specified. The default is 1 second.

source_ip - Specify the source IPv6 address of the ping packets. If specified, , the IPv6 address will be used as the packets' source IPv6 address that ping6 sends to the remote host.

Restrictions

None.

Example usage:

To send ICMP echo message to "3000::1" for 4 times:

```
DGS-3627:admin# ping6 3000::1 times 4
Command: ping6 3000::1 times 4

Reply from 3000::1, bytes=200, time<10ms
Reply from 3000::1, bytes=200, time<10ms
Reply from 3000::1, bytes=200, time<10ms
Reply from 3000::1, bytes=200, time<10ms

Ping Statistics for 3000::1
Packets: Sent =4, Received =4, Lost =0

DGS-3627:admin#
```

To send ICMP echo message with source IPV6 address "3000::11" to "3000::1" for 3 times (the Switch's IP address are 3000::11 and 3000::10):

```
DGS-3627:admin# ping6 3000::1 times 3 source_ip 3000::11
Command: ping6 3000::1 times 3 source_ip 3000::11

Reply from 3000::1, bytes=200, time<10ms
Reply from 3000::1, bytes=200, time<10ms
Reply from 3000::1, bytes=200, time<10ms

Ping Statistics for 3000::1
Packets: Sent =3, Received =3, Lost =0

DGS-3627:admin#
```

enable broadcast_ping_reply

Purpose	Used to enable the broadcast ping reply state.
Syntax	enable broadcast_ping_reply
Description	The device will reply to the broadcast ping request.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the broadcast ping reply state:


```
DGS-3627:admin# enable broadcast_ping_reply
Command: enable broadcast_ping_reply

Success.

DGS-3627:admin#
```

disable broadcast_ping_reply

Purpose	Used to disable the broadcast ping reply state.
Syntax	disable broadcast_ping_reply
Description	The device won't reply to the broadcast ping request.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the broadcast ping reply state:

```
DGS-3627:admin# disable broadcast_ping_reply
Command: disable broadcast_ping_reply

Success.

DGS-3627:admin#
```

show broadcast_ping_reply

Purpose	Used to show the broadcast ping reply state.
Syntax	show broadcast_ping_reply
Description	Show the device broadcast ping reply state.
Parameters	None.
Restrictions	None.

Example usage:

To show the broadcast ping reply state:

```
DGS-3627:admin# show broadcast_ping_reply
Command: show broadcast_ping_reply

Broadcast Ping Reply State: Enabled

DGS-3627:admin#
```

POLICY ROUTE COMMANDS

Policy Based routing is a method used by the Switch to give specified devices a cleaner path to the Internet. Used in conjunction with the Access Profile feature, the Switch will identify traffic originating from a specified IP address and forward it on to a next hop router that has a less congested connection to the Internet than the normal routing scheme of your network.

The steps needed to set up policy-based routing on the switch are as follows:

- Create an access profile using the **create access_profile** command which specifies information that will identify the device to be given a policy route.
- Modify the rule regarding this access profile using the **config access_profile** command. (Remember not to add the deny parameter to this rule, or packets will be dropped and the policy route will not take effect.)
- Name the policy route to be used by configuring the **create policy_route** command.
- Bind the access profile (profile_id) and its rule (access_id) to this policy route using the **config policy_route** command. This command must also be used to add the next hop IP address of the device that will be connected directly to the gateway router. When the time is ready to deploy the policy route, the administrator must enable this function here as well (state [enable | disable]).

Once completed, the Switch will identify the device to be given a policy route using the access profile function, recognize that it has a Policy Based route, and then forward the information on to the specified next hop router, that will, in turn, relay packets to the gateway router. Thus, the new, cleaner path to the Internet has been formed.

The Policy Route commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create policy_route	name <policyroute_name 32>
config policy_route	name <policyroute_name 32> acl profile_id <value 1-14> access_id <value 1-128> nexthop <ipaddr> state [enable disable]
delete policy_route	name <policyroute_name 32>
show policy_route	

Each command is listed, in detail, in the following sections.

create policy_route

Purpose	Used to create a name to identify a policy route.
Syntax	create policy_route name <policyroute_name 32>
Description	This command is used to create a policy route name which will identify the policy route.
Parameters	<i>name <policyroute_name 32></i> – Enter an alphanumeric name of no more than 32 characters to identify this policy route.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create the policy route name “manager”:

```
DGS-3627:admin# create policy_route name manager
Command: create policy_route name manager

Success.

DGS-3627:admin#
```

config policy_route

Purpose	Used to configure the parameters to set the policy route on the Switch.
Syntax	config policy_route name <policyroute_name 32> acl profile_id <value 1-14> access_id <value 1-128> nexthop <ipaddr> state [enable disable]
Description	This command is used to configure the policy route settings for a policy route created with the create policy_route command. The administrator must have previously created an access profile with an accompanying access rule using the create access_profile profile_id and config access_profile profile_id mentioned previously in this manual. The next hop router IP address must also be specified using this command.
Parameters	<p><i>name <policyroute_name 32></i> – Enter an alphanumeric name of no more than 32 characters which identifies this policy route.</p> <p><i>acl</i> – This parameter is used to denote the access profile that will be used with this command, by identifying the following parameters:</p> <ul style="list-style-type: none"> <i>profile_id <value 1-14></i> – Enter the ID number of the previously created access profile that is to be associated with this policy route. <i>access_id <value 1-128></i> – Enter the previously created access ID that has been created in conjunction with the access profile ID mentioned previously, that is to be associated with this policy route. <p><i>nexthop <ipaddr></i> – Enter the IP address of the next hop router that will be connected to the gateway router. This field must be set or no policy routing will take place.</p> <p><i>state [enable disable]</i> – Used to enable or disable this policy route on the Switch.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the policy route name “manager”:

```
DGS-3627:admin# config policy_route name manager acl profile_id 1 access_id 2 nexthop
10.2.2.2 state enable
Command: config policy_route name manager acl profile_id 1 access_id 2 nexthop 10.2.2.2
state enable

Success.

DGS-3627:admin#
```

delete policy_route

Purpose	Used to delete a policy route setting.
Syntax	delete policy_route name <policyroute_name 32>
Description	This command is used to delete a policy route setting.
Parameters	<i>name <policyroute_name 32></i> – Enter an alphanumeric name of no more than 32 characters to identify this policy route to be deleted.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the policy route name “manager”:

```
DGS-3627:admin# delete policy_route name manager
Command: delete policy_route name manager

Success.

DGS-3627:admin#
```

show policy_route

Purpose	Used to display policy route settings.
Syntax	show policy_route
Description	This command is used to display policy route settings.
Parameters	None.
Restrictions	None.

Example usage:

To display the policy route settings:

```
DGS-3627:admin# show policy_route
Command: show policy_route

Policy Routing Table
-----
Name                               Profile ID  Access ID  Next Hop      State
-----
manager                             1           1          10.3.3.3      Enabled

Total Entries: 1

DGS-3627:admin#
```

PORT SECURITY COMMANDS

The primary purpose of port security function is to restrict the access to a switch port to a number of authorized users. If an unauthorized user tries to access a port-security enabled port, the system will block the access by dropping its packet.

The Port Security commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config port_security ports	[<portlist> all] {admin_state [enable disable] max_learning_addr <max_lock_no 0-64> lock_address_mode [Permanent DeleteOnTimeout DeleteOnReset]}(1)
delete port_security_entry vlan_name	<vlan_name 32> port <port> mac_address <macaddr>
clear port_security_entry port	<portlist>
show port_security	{ports <portlist>}

Each command is listed, in detail, in the following sections.

config port_security

Purpose	This command is used to set the port level port security setting.
Syntax	config port_security ports [<portlist> all] {admin_state [enable disable] max_learning_addr <max_lock_no 0-64> lock_address_mode [permanent delete ontimeout deleteonreset]}(1)
Description	This command configures admin state, maximum learning address and lock address mode. There are four levels of limitations on the learned entry number, for the entire system, for a port, for a VLAN, and for specific VLAN on a port. If any limitation is exceeded, the new entry will be discarded.
Parameters	<p><i>portlist</i> - Specifies a range of ports to be configured.</p> <p><i>all</i> - Specifies that all ports will be configured.</p> <p><i>admin_state</i> - Specifies to enable/disable the port security function on the port. By default, the setting is disabled.</p> <p><i>max_learning_addr</i> - Specifies the maximum of port security entries that can be learned on this port. If the value is set to 0, it means that no user can get authorized by port security function on this port. If the setting is smaller than the number of current learned entries on the port, the command will be rejected. The default value is 1.</p> <p><i>lock_address_mode</i> - Indicates the mode of locking address. The default mode is deleteonreset.</p> <p><i>Permanent</i> - The address will never be deleted unless the user removes it manually or the VLAN of the entry is removed or the port is removed from the VLAN, or port security is disabled on the port where the address resides..</p> <p><i>DeleteOnTimeout</i> - This entry will be removed if it's idle for the ageing time.</p> <p><i>DeleteOnReset</i> - This address will be removed if the switch is reset or reboots. The cases under which the permanent entries are deleted also apply to the deleteonreset entries,</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To config port security setting:

```
DGS-3627:admin# config port_security ports 1:6 admin_state enable max_learning_addr 10
lock_address_mode Permanent
Command: config port_security ports 1:6 admin_state enable max_learning_addr 10
lock_address_mode Permanent

Success.

DGS-3627:admin#
```

delete port_security_entry vlan_name

Purpose	Used to delete a port security entry.
Syntax	delete port_security_entry vlan_name <vlan_name 32> port <port> mac_address <macaddr>
Description	Used to delete a port security entry.
Parameters	<i><vlan_name></i> - Specifies the VLAN by VLAN name. <i>port</i> - Specifies a range of ports to be configured <i>mac_address</i> - Specifies the MAC address of the entry.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete a default route from the routing table:

```
DGS-3627:admin#delete port_security_entry vlan_name default port 1 mac_address 00-01-30-
10-2C-C7
Command: delete port_security_entry vlan_name default port 1 mac_address 00-01-30-10-2C-
C7

DGS-3627:admin#
```

clear port_security_entry

Purpose	Used to clear the MAC entries learned by the port security function.
Syntax	clear port_security_entry port <portlist>
Description	Used to clear the MAC entries learned by the port security function.
Parameters	<i><portlist></i> - Specifies a range of ports to be configured. The port-security entries learned on the specified port will be cleared.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To clear port security entry by port(s):

```
DGS-3627:admin# clear port_security_entry port 1:6
Command: clear port_security_entry port 1:6

Success.

DGS-3627:admin#
```

show port_security

Purpose	This command is to used to display port security configuration.
Syntax	show port_security {ports <portlist>}
Description	The show port_security command displays the port security related information.
Parameters	<portlist> - Specifies a range of ports to show their configuration.
Restrictions	None.

Example usage:

To display the port security configuration:

```
DGS-3627:admin# show port_security
Command: show port_security
```

Port	Admin State	Max. Learning Addr.	Lock Address Mode
-----	-----	-----	-----
1:1	Disabled	1	DeleteOnReset
1:2	Disabled	1	DeleteOnReset
1:3	Disabled	1	DeleteOnReset
1:4	Disabled	1	DeleteOnReset
1:5	Disabled	1	DeleteOnReset
1:6	Disabled	1	DeleteOnReset

PROTOCOL INDEPENDENT MULTICAST (PIM) COMMANDS

PIM or Protocol Independent Multicast is a method of forwarding traffic to multicast groups over the network using any pre-existing unicast routing protocol, such as RIP or OSPF, set on routers within a multicast network. The xStack® DGS-3600 Series supports three types of PIM, Dense Mode (PIM-DM), Sparse Mode (PIM-SM), and Sparse and Dense Mode (PIM-SM-DM).

PIM-SM

PIM-SM or Protocol Independent Multicast – Sparse Mode is a method of forwarding multicast traffic over the network only to multicast routers who actually request this information. Unlike most multicast routing protocols which flood the network with multicast packets, PIM-SM will forward traffic to routers who are explicitly a part of the multicast group through the use of a Rendezvous Point (RP). This RP will take all requests from PIM-SM enabled routers, analyze the information and then returns multicast information it receives from the source, to requesting routers within its configured network. Through this method, a distribution tree is created, with the RP as the root. This distribution tree holds all PIM-SM enabled routers within which information collected from these router is stored by the RP.

Two other types of routers also exist with the PIM-SM configuration. When many routers are a part of a multiple access network, a Designated Router (DR) will be elected. The DR's primary function is to send Join/Prune messages to the RP. The router with the highest priority on the LAN will be selected as the DR. If there is a tie for the highest priority, the router with the higher IP address will be chosen.

The third type of router created in the PIM-SM configuration is the Boot Strap Router (BSR). The goal of the Boot Strap Router is to collect and relay RP information to PIM-SM enabled routers on the LAN. Although the RP can be statically set, the BSR mechanism can also determine the RP. Multiple Candidate BSRs (C-BSR) can be set on the network but only one BSR will be elected to process RP information. If it is not explicitly apparent which C-BSR is to be the BSR, all C-BSRs will emit Boot Strap Messages (BSM) out on the PIM-SM enabled network to determine which C-BSR has the higher priority and once determined, will be elected as the BSR. Once determined, the BSR will collect RP data emanating from candidate RPs on the PIM-SM network, compile it and then send it out on the land using periodic Boot Strap Messages (BSM). All PIM-SM Routers will get the RP information from the Boot Strap Mechanism and then store it in their database.

Discovering and Joining the Multicast Group

Although Hello packets discover PIM-SM routers, these routers can only join or be “pruned” from a multicast group through the use of Join/Prune Messages exchanged between the DR and RP. Join/Prune Messages are packets relayed between routers that effectively state which interfaces are, or are not to be receiving multicast data. These messages can be configured for their frequency to be sent out on the network and are only valid to routers if a Hello packet has first been received. A Hello packet will simply state that the router is present and ready to become a part of the RP's distribution tree. Once a router has accepted a member of the IGMP group and it is PIM-SM enabled, the interested router will then send an explicit Join/Prune message to the RP, which will in turn route multicast data from the source to the interested router, resulting in a unidirectional distribution tree for the group. Multicast packets are then sent out to all nodes on this tree. Once a prune message has been received for a router that is a member of the RP's distribution tree, the router will drop the interface from its distribution tree.

Distribution Trees

Two types of distribution trees can exist within the PIM-SM protocol, a Rendezvous-Point Tree (RPT) and a Shortest Path Tree (SPT). The RP will send out specific multicast data that it receives from the source to all outgoing interfaces enabled to receive multicast data. Yet, once a router has determined the location of its source, an SPT can be created, eliminating hops between the source and the destination, such as the RP. This can be configured by the switch administrator by setting the multicast data rate threshold. Once the threshold has been passed, the data path will switch to the SPT. Therefore, a closer link can be created between the source and destination, eliminating hops previously used and shortening the time a multicast packet is sent from the source to its final destination.

Register and Register Suppression Messages

Multicast sources do not always join the intended receiver group. The first hop router (DR) can send multicast data without being the member of a group or having a designated source, which essentially means it has no information about how to relay this information to the RP distribution tree. This problem is alleviated through Register and Register-Stop messages. The first multicast packet received by the DR is encapsulated and sent on to the RP which in turn removes the encapsulation and sends the packet on down the RP distribution tree. When the route has been established, a SPT can be created to directly connect routers to the source, or the multicast traffic flow can begin, traveling from the DR to the RP. When the latter occurs, the same packet may be sent twice, one type encapsulated, one not. The RP will detect this flaw and then return a Register Suppression message to the DR requesting it to discontinue sending encapsulated packets.

Assert Messages

At times on the PIM-SM enabled network, parallel paths are created from source to receiver, meaning some receivers will receive the same multicast packets twice. To improve this situation, Assert messages are sent from the receiving device to both multicast sources to determine which single router will send the receiver the necessary multicast data. The source with the shortest metric (hop count) will be elected as the primary multicast source. This metric value is included within the Assert message.

PIM-DM

The Protocol Independent Multicast - Dense Mode (PIM-DM) protocol should be used in networks with a low delay (low latency) and high bandwidth as PIM-DM is optimized to guarantee delivery of multicast packets, not to reduce overhead.

The PIM-DM multicast routing protocol assumes that all downstream routers want to receive multicast messages and relies upon explicit prune messages from downstream routers to remove branches from the multicast delivery tree that do not contain multicast group members.

PIM-DM has no explicit 'join' messages. It relies upon periodic flooding of multicast messages to all interfaces and then either waiting for a timer to expire (the Join/Prune Interval) or for the downstream routers to transmit explicit 'prune' messages indicating that there are no multicast members on their respective branches. PIM-DM then removes these branches ('prunes' them) from the multicast delivery tree.

Because a member of a pruned branch of a multicast delivery tree may want to join a multicast delivery group (at some point in the future), the protocol periodically removes the 'prune' information from its database and floods multicast messages to all interfaces on that branch. The interval for removing 'prune' information is the Join/Prune Interval.

The Protocol Independent Multicast (PIM) commands in the Command Line Interface (CLI) are listed below, along with their appropriate parameters, in the following table.

Command	Parameters
enable pim	
disable pim	
config pim	[[ipif <ipif_name 12> all] {hello <sec 1-18724> jp_interval <sec 1-18724> state [enable disable] mode [dm sm sm-dm] dr_priority <unit 0 – 4294967294>} register_probe_time <value 1-127> register_suppression_time <value 3-255>]
create pim crp group	<network_address> rp <ipif_name 12>
delete pim crp group	<network_address>
config pim crp	{holdtime <value 0-255> priority <value 0-255> wildcard_prefix_cnt [0 1]}
create pim static_rp group	<network_address> rp <ipaddr>
delete pim static_rp group	<network_address>
show pim static_rp	
config pim last_hop_spt_switchover	[never immediately]
show pim rpset	
show pim crp	
config pim cbsr	[ipif <ipif_name 12> {priority [-1 <value 0-255>]} hash_masklen <value 0-32> bootstrap_period <value 1-255>]
show pim cbsr	{ipif <ipif_name 12>}
show pim	{ipif <ipif_name 12>}
show pim neighbor	{ipif <ipif_name 12> ipaddress <network_address>}
show pim ipmroute	
create pim register_checksum_include_data rp_address	<ipaddr>
delete pim register_checksum_include_data rp_address	<ipaddr>
show pim register_checksum_include_data_rp_list	

Each command is listed, in detail, in the following sections.

enable pim

Purpose	Used to enable the PIM function on the Switch.
Syntax	enable pim
Description	This command will enable PIM for the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable PIM as previously configured on the Switch:

```
DGS-3627:admin# enable pim
Command: enable pim

Success.

DGS-3627:admin#
```

disable pim

Purpose	Used to disable PIM function on the Switch.
Syntax	disable pim
Description	This command will disable PIM for the Switch. Any previously configured PIM settings will remain unchanged and may be enabled at a later time with the enable pim command.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable PIM on the Switch:

```
DGS-3627:admin# disable pim
Command: disable pim

Success.

DGS-3627:admin#
```

config pim

Purpose	Used to configure the parameters for the PIM protocol.
Syntax	config pim [[<i>ipif</i> < <i>ipif_name</i> 12> <i>all</i>] { <i>hello</i> < <i>sec</i> 1-18724> <i>jp_interval</i> < <i>sec</i> 1-18724> <i>state</i> [<i>enable</i> <i>disable</i>] <i>mode</i> [<i>dm</i> <i>sm</i> <i>sm-dm</i>] <i>dr_priority</i> < <i>unit</i> 0 – 4294967294>} <i>register_probe_time</i> < <i>value</i> 1-127> <i>register_suppression_time</i> < <i>value</i> 3-255>]
Description	This command will configure the general settings for the PIM protocol per IP interface, including choice of PIM mode, Designated Router priority and various timers.
Parameters	<p><i>ipif</i> <<i>ipif_name</i> 12> – Enter an IP interface for which to configure the PIM settings. This name cannot exceed 12 alphanumeric characters.</p> <p><i>all</i> – Select this parameter to configure PIM settings for all IP interfaces on the Switch.</p> <p><i>hello</i> <<i>sec</i> 1-18724> – Used to set the interval time between the sending of Hello Packets from this IP interface to neighboring routers one hop away. These Hello packets are used to discover other PIM enabled routers and state their priority as the Designated Router (DR) on the PIM enabled network. The user may state an interval time between 1 and 18724 seconds with a default interval time of 30 seconds.</p> <p><i>jp_interval</i> <<i>sec</i> 1-18724> – This field will set the interval time between the sending of Join/Prune packets stating which multicast groups are to join the PIM enabled network and which are to be removed or “pruned” from that group. The user may state an interval time between 1 and 18724 seconds with a default interval time of 60 seconds.</p> <p><i>state</i> [<i>enable</i> <i>disable</i>] – Used to enable or disable PIM for this IP interface. The default is Disabled.</p> <p><i>mode</i> [<i>dm</i> <i>sm</i> <i>sm-dm</i>] – Used to select the type of PIM protocol to use, Sparse Mode (SM), Dense Mode (DM), or Sparse-Dense Mode (SM-DM). The default setting is DM.</p> <p><i>dr_priority</i> <<i>unsigned_int</i> 0 – 4294967294> – Enter the priority of this IP interface to become the Designated Router for the multiple access network. The user may enter a DR priority between 0 and 4,294,967,294 with a default setting of 1.</p> <p><i>register_probe_time</i> <<i>value</i> 1-127> – Configure this field to set a time to send a probe message from the DR to the RP before the Register Suppression time expires. The user may configure a time between 1 and 127 seconds with a default setting of 5 seconds.</p> <p><i>register_suppression_time</i> <<i>value</i> 3-255> – The user may set an interval time between 3 and 255 with a default setting of 60 seconds for the sending of register suppression time packets.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the PIM settings for an IP interface:

```
DGS-3627:admin# config pim ipif Zira hello 60 jp_interval 60 state enable mode sm
Command: config pim ipif Zira hello 60 jp_interval 60 state enable mode sm
```

Success.

```
DGS-3627:admin#
```



NOTE: If not, the configure value can apply to protocol, and the administrator will be presented with a prompt message.

NOTE: The administrator should ensure the Register Probe time value less than the half of the Register Suppression time value.

create pim crp

Purpose	To enable the Switch to become a candidate to be the Rendezvous Point (RP).
Syntax	create pim crp group <network_address> rp <ipif_name 12>
Description	This command will set the parameters for the switch to become a candidate RP. This command is for PIM-SM configurations only.
Parameters	<i>group <network_address></i> – Enter the multicast group address for this switch to become a Candidate RP. This address must be a class D address. <i>rp <ipif_name 12></i> – Enter the name of the PIM-SM enabled interface the switch administrator wishes to become the CRP for this group.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create an IP interface to become a Candidate RP on the Switch:

```
DGS-3627:admin# create pim crp group 231.0.0.1/32 rp Zira
Command: create pim crp group 231.0.0.1/32 rp Zira

Success.

DGS-3627:admin#
```

delete pim crp

Purpose	To disable the Switch in becoming a possible candidate to be the Rendezvous Point (RP).
Syntax	delete pim crp group <network_address>
Description	This command remove the switch's status of Candidate RP. This command is for PIM-SM configurations only.
Parameters	<i>group <network_address></i> – Enter the multicast group address for this switch to be removed from being a Candidate RP. This address must be a class D address.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an IP interface from becoming a Candidate RP on the Switch:

```
DGS-3627:admin# delete pim crp group 231.0.0.1/32
Command: delete pim crp group 231.0.0.1/32

Success.

DGS-3627:admin#
```

config pim crp

Purpose	To configure the Candidate RP settings that will determine the RP.
Syntax	config pim crp {holdtime <value 0-255> priority <value 0-255> wildcard_prefix_cnt [0 1]}
Description	This command will configure parameters regarding the Candidate RP on the Switch, including hold time, priority and wildcard prefix count. This command is for PIM-SM configurations only.
Parameters	<p><i>holdtime <value 0-255></i> – This field is used to set the time Candidate RP (CRP) advertisements are valid on the PIM-SM enabled network. If CRP advertisements are not received by the BSR within this time frame, the CRP is removed from the list of candidates. The user may set a time between 0 and 255 seconds with a default setting of 150 seconds. An entry of 0 will send out one advertisement that states to the BSR that it should be immediately removed from CRP status on the PIM-SM network.</p> <p><i>priority <value 0-255></i> – Enter a priority value to determine which CRP will become the RP for the distribution tree. This priority value will be included in the router's CRP advertisements. A lower value means a higher priority, yet, if there is a tie for the highest priority, the router having the higher IP address will become the RP. The user may set a priority between 0 and 255 with a default setting of 192.</p> <p><i>wildcard_prefix_cnt [0 1]</i> – The user may set the Prefix Count value of the wildcard group address here by choosing a value between 0 and 1 with a default setting of 0.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the Candidate RP settings:

```
DGS-3627:admin# config pim crp holdtime 150 priority 2 wildcard_prefix_cnt 0
Command: config pim crp holdtime 150 priority 2 wildcard_prefix_cnt 0

Success.

DGS-3627:admin#
```

create pim static_rp

Purpose	Used to enter the multicast group IP address used in identifying the Rendezvous Point (RP).
Syntax	create pim static_rp group <network_address> rp <ipaddr>
Description	This command will enter the multicast group IP address which will be used to identify the RP. This entry must be a class D IP address. This command is for PIM-SM configurations only.
Parameters	<p><i>group <network_address></i> – Enter the multicast group IP address used in determining the Static RP. This address must be a class D IP address.</p> <p><i>rp <ipaddr></i> – Enter the IP address of the RP the switch administrator wishes to become the Static RP for this group.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create the settings to determine a static RP:

```
DGS-3627:admin# create pim static_rp group 231.0.0.1/32 rp 11.1.1.1
Command: create pim static_rp group 231.0.0.1/32 rp 11.1.1.1

Success.

DGS-3627:admin#
```

delete pim static_rp

Purpose	To remove the multicast group IP address used in identifying the Rendezvous Point (RP).
Syntax	delete pim static_rp group <network_address>
Description	This command will remove the multicast group IP address used in identifying the Rendezvous Point (RP). This command is for PIM-SM configurations only.
Parameters	<i>group <network_address></i> – Enter the multicast group IP address used in identifying the Rendezvous Point (RP). This address must be a class D address.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To remove a static RP:

```
DGS-3627:admin# delete pim static_rp group 231.0.0.1/32
Command: delete pim static_rp group 231.0.0.1/32

Success.

DGS-3627:admin#
```

show pim static_rp

Purpose	To show the Static Rendezvous Point (RP) settings.
Syntax	show pim static_rp
Description	This command will display the Static Rendezvous Point (RP) settings. This command is for PIM-SM configurations only.
Parameters	None.
Restrictions	None.

Example usage:

To display the static RP settings as configured for the multiple access network:

```
DGS-3627:admin# show pim static_rp
```

```
Command: show pim static_rp
```

PIM Static RP Table

Group	RP Address
224.0.0.0/4	11.1.1.254
239.0.0.1/32	31.1.1.1
239.0.0.2/32	31.1.1.12
239.0.0.3/32	31.1.1.123

```
Total entries: 4
```

```
DGS-3627:admin#
```

config pim last_hop_spt_switchover

Purpose	Used to choose the switchover mode on the last hop router.
Syntax	config pim last_hop_spt_switchover [never immediately]
Description	This command will configure the need to change the last hop router's distribution tree to a SPT. The last hop router will always receive data from the shared tree unless this command is changed to immediately and then the router will always receive multicast data from the shortest path tree. This command is for PIM-SM configurations only.
Parameters	<i>never</i> – Using this command will configure the router to always receive multicast data from the shared tree. <i>immediately</i> – Using this command will configure the router to always receive multicast data from the shortest path tree.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the last hop router to immediately switch to SPT:

```
DGS-3627:admin# config pim last_hop_spt_switchover immediately
```

```
Command: config pim last_hop_spt_switchover immediately
```

```
Success.
```

```
DGS-3627:admin#
```

show pim rpset

Purpose	Used to display the RP Set of the Switch.
Syntax	show pim rpset
Description	This command will display the information regarding the RP Set learned by the BSR and statically configured by the user. This command is for PIM-SM configurations only.
Parameters	None.
Restrictions	None.

Example usage:

To view the RP Set information:


```
DGS-3627:admin# show pim rpset
```

```
Command: show pim rpset
```

PIM RP-Set Table

```
Bootstrap Router: 12.43.51.81
```

Group Address	RP Address	Holdtime	Expired Time	Type
224.0.0.0/4	31.43.51.81	150	107	Dynamic

```
Total Entries: 1
```

```
DGS-3627:admin#
```

show pim crp

Purpose	Used to display the Candidate RP settings on the Switch, along with CRP parameters configured for the Switch.
Syntax	show pim crp
Description	This command will display the settings for Candidate RPs that are accessible to the switch. This command is for PIM-SM configurations only.
Parameters	None.
Restrictions	None.

Example usage:

To view the CRP settings:

```
DGS-3627:admin# show pim crp
```

```
Command: show pim crp
```

PIM Candidate-RP Table

```
C-RP Holdtime           : 150
C-RP Priority            : 2
C-RP Wildcard Prefix Count : 0
```

Group	Interface
224.0.0.0/4	Zira

```
Total Entries: 1
```

```
DGS-3627:admin#
```

config pim cbsr

Purpose	Used to configure the settings for the Candidate Bootstrap Router and the priority of the selected IP interface to become the Boot Strap Router (BSR) for the PIM-SM network domain.
Syntax	config pim cbsr [ipif <ipif_name 12> {priority [-1 value 0-255>]} hash_masklen <value 0-32> bootstrap_period <value 1-255>]
Description	This command will configure the settings for the Candidate BSR. The Boot Strap Router holds the information which determines which router on the network is to be elected as the RP for the multicast group and then to distribute RP information to other PIM-SM enabled routers. This command is for PIM-SM configurations only.
Parameters	<p><i>ipif <ipif_name 12></i> – Enter the ipif name of the interface to become the CBSR.</p> <p><i>priority [-1 value 0-255>]</i> – Used to state the Priority of this IP Interface to become the BSR. The user may select a priority between -1 and 255. An entry of -1 states that the interface will be disabled to be the BSR.</p> <p><i>hash_masklen <value 0-32></i> – Enter a hash mask length, which will be used with the IP address of the candidate RP and the multicast group address, to calculate the hash algorithm used by the router to determine which CRP on the PIM-SM enabled network will be the RP. The user may select a length between 0 and 32 with a default setting of 30. This parameter must be configured separately from the ipif settings of this command. See the examples below for a better understanding.</p> <p><i>bootstrap_period <value 1-255></i> – Enter a time period between 1 and 255 to determine the interval the Switch will send out Boot Strap Messages (BSM) to the PIM enabled network. The default setting is 60 seconds. This parameter must be configured separately from the ipif settings of this command. See the examples below for a better understanding.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the settings for an IP interface to become a CBSR:

```
DGS-3627:admin# config pim cbsr ipif Zira priority 4
Command: config pim cbsr ipif Zira priority 4

Success.

DGS-3627:admin#
```

Example usage:

To configure the hash mask length for the CBSR:

```
DGS-3627:admin# config pim cbsr hash_masklen 30
Command: config pim cbsr hash_masklen 30

Success.

DGS-3627:admin#
```

Example usage:

To configure the bootstrap period for the CBSR:

```
DGS-3627:admin# config pim cbsr bootstrap_period 60
Command: config pim cbsr bootstrap_period 60

Success.

DGS-3627:admin#
```

show pim cbsr

Purpose	Used to display the Candidate BSR settings of the switch, along with CBSR parameters configured for the Switch.
Syntax	show pim cbsr {ipif <ipif_name12>}
Description	This command will display the settings for Candidate BSRs that are accessible to the switch. This command is for PIM-SM configurations only.
Parameters	<ipif_name 12> – Enter the name of the IP interface for which to display settings. Entering no name will display all CBSRs.
Restrictions	None.

Example usage:

To view the CBSR settings:

```
DGS-3627:admin# show pim cbsr
Command: show pim cbsr

PIM Candidate-BSR Table

C-BSR Hash Mask Len           : 30
C-BSR Bootstrap Period        : 2

Interface           IP Address           Priority
-----
Zira                 11.1.1.1/8           4
System              10.53.13.30/8        -1 (Disabled)

Total Entries: 2

DGS-3627:admin#
```

show pim

Purpose	Used to display the PIM settings, along with PIM parameters configured for the Switch.
Syntax	show pim {ipif <ipif_name12>}
Description	This command will display the settings for the PIM function that are accessible to the switch.
Parameters	<ipif_name 12> – Enter the name of the IP address for which to display settings. Entering no name will display all PIM IP interfaces.
Restrictions	None.

Example usage:

To view the PIM settings:

```
DGS-3627:admin# show pim
Command: show pim

PIM Global State           : Enabled
Last Hop SPT Switchover    : Never
Register Probe Time        : 5
Register Suppression Time  : 60

PIM Interface Table

Interface   IP Address      Designated   Hello   J/P
           IP Address      Router       Interval Interval Mode   State
-----
System     10.90.90.90/8   10.90.90.90  30     60    DM   Disabled

Total Entries: 1
DGS-3627:admin#
```

show pim neighbor

Purpose	Used to display PIM neighbors of the Switch.
Syntax	show pim neighbor {ipif <ipif_name12> ipaddress <network_address>}
Description	This command will display the PIM neighbor table for the Switch.
Parameters	<p><i><ipif_name 12></i> – Enter the name of the IP interface for which to display PIM information regarding PIM neighbors.</p> <p><i>ipaddress <network_address></i> – Enter the IP address of a PIM neighbor for which to display information.</p> <p>Adding no parameters to this command will display all PIM neighbors that probed the Switch.</p>
Restrictions	None.

Example usage:

To view the PIM neighbors:

```
DGS-3627:admin# show pim neighbor
Command: show pim neighbor

PIM Neighbor Address Table

Interface Name      Neighbor Address      Expired Time
-----
n10                 10.20.6.251          79

Total Entries: 1
DGS-3627:admin#
```

show pim ipmroute

Purpose	Used to display the PIM IP Multicast Route Table on the Switch.
Syntax	show pim ipmroute
Description	This command will display the PIM IP Multicast Route Table on the Switch. This command is for PIM-SM configurations only.
Parameters	None.
Restrictions	None.

Example usage:

To view the PIM routes:

```
DGS-3627:admin# show pim ipmroute
```

```
Command: show pim ipmroute
```

PIM IP Multicast Route Table

UA = Upstream AssertTimer

AM = Assert Metric

AMPref = Assert MetricPref

ARB = Assert RPTBit

Group Address	Source Address	UA	AM	AMPref	ARB	Flag	Type
224.0.1.1	31.43.51.81/32	0	0	0	0	RPT	(*G)
224.0.1.24	10.54.81.250/32	0	0	0	0	SPT	(S,G)
224.0.1.24	10.55.68.64/32	0	0	0	0	SPT	(S,G)
224.0.1.24	31.43.51.81/32	0	0	0	0	RPT	(*G)
229.55.150.208	10.6.51.1/32	0	0	0	0	SPT	(S,G)
229.55.150.208	10.38.45.151/32	0	0	0	0	SPT	(S,G)
229.55.150.208	10.38.45.192/32	0	0	0	0	SPT	(S,G)
229.55.150.208	10.50.93.100/32	0	0	0	0	SPT	(S,G)
229.55.150.208	10.51.16.1/32	0	0	0	0	SPT	(S,G)
229.55.150.208	10.59.23.10/32	0	0	0	0	SPT	(S,G)
229.55.150.208	31.43.51.81/32	0	0	0	0	RPT	(*G)
239.192.0.1	31.43.51.81/32	0	0	0	0	RPT	(*G)

Total Entries: 12

```
DGS-3627:admin#
```

create pim register_checksum_include_data

Purpose	Used to set the RPs that the Switch will send Register packets to and create checksums to be included with the data in Registered packets.
Syntax	create pim register_checksum_include_data rp_address <ipaddr>
Description	This command will set the RPs that the Switch will send Register packets to and create checksums to be included with the data in Registered packets. This command is for PIM-SM configurations only.
Parameters	<i>rp_address <ipaddr></i> – Enter the IP address of the RP that will verify checksums included with Registered packets.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create an RP to which the Switch will send Register packets to and create checksums to be included with the data in Registered packets:

```
DGS-3627:admin# create pim register_checksum_include_data rp_address 11.1.1.1
Command: create pim register_checksum_include_data rp_address 11.1.1.1

Success.

DGS-3627:admin#
```

delete pim register_checksum_include_data

Purpose	Used to disable the RPs that the Switch will send Register packets to and create checksums to be included with the data in Registered packets.
Syntax	delete pim register_checksum_include_data rp_address <ipaddr>
Description	This command will disable the RPs that the Switch will send Register packets to and create checksums to be included with the data in Registered packets. This command is for PIM-SM configurations only.
Parameters	<i>rp_address <ipaddr></i> – Enter the IP address of the RP that will discontinue sending Register packets to and create checksums to be included with the data in Registered packets.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete RPs that the Switch will send Register packets to and create checksums to be included with the data in Registered packets:

```
DGS-3627:admin# delete pim register_checksum_include_data rp_address 11.1.1.1
Command: delete pim register_checksum_include_data rp_address 11.1.1.1

Success.

DGS-3627:admin#
```

show pim register_checksum_include_data_rp_list

Purpose	Used to display RPs that the Switch will send Register packets to and create checksums to be included with the data in Registered packets.
Syntax	show pim register_checksum_include_data_rp_list
Description	This command will display RPs that the Switch will send Register packets to and create checksums to be included with the data in Registered packets. This command is for PIM-SM configurations only.
Parameters	None.
Restrictions	None.

Example usage:

To show the RPs that the Switch will send Register packets to and create checksums to be included with the data in Registered packets:

```
DGS-3627:admin# show pim register_checksum_include_data_rp_list
Command: show pim register_checksum_include_data_rp_list
PIM Register Checksum Include Data
RP Address
-----
11.1.1.1

Total Entries: 1

DGS-3627:admin#
```

PROTOCOL VLAN GROUP COMMANDS

For bridges that implement Port-and-Protocol-based VLAN classification, the VID associated with an Untagged or Priority-tagged Frame is determined based on the Port of arrival of the frame into the bridge and on the protocol identifier of the frame. If there is no protocol VLAN configured on the ingress port, all the untagged packets incoming on the port will be classified into PVID VLAN. This classification mechanism requires defining the protocol groups which specified frame type and protocol value to match for. A protocol group can be bound to a port and given a VLAN ID. If the incoming untagged packet matches the protocol group the VLAN ID will be assigned. A port can bind with multiple protocol groups. This allows untagged packets be classified into different VLANs based on packet content. The same protocol group can be assigned to multiple ports with different VLAN ID assigned, i.e. the same protocol can be given different VLAN ID through binding to different ports.

The Protocol VLAN Group commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
create dot1v_protocol_group	group_id <id>
config dot1v_protocol_group	group_id <id> [add delete] protocol [ethernet_2 ieee802.3_snap ieee802.3_llc] <protocol_value>
delete dot1v_protocol_group	group_id <id>
show dot1v_protocol_group	{group_id <id>}
config port dot1v	ports [<portlist> all] [add protocol_group group_id <id> [vlan <vlan_name 32> vlanid <vlanid>] delete protocol_group [group_id <id> all]]
show port dot1v	{ports <portlist>}

Each command is listed, in detail, in the following sections.

create dot1v_protocol_group

Purpose	Used to create a protocol group.
Syntax	create dot1v_protocol_group group_id <id>
Description	This command will create a protocol group. This group is to be configured using the config dot1v_protocol_group command where users may set the parameters for this group. After being configured, this group may be attached to a port or range of ports using the config port dot1v command.
Parameters	<i>group_id <id></i> – Enter an integer from 1 to 16 to identify the protocol VLAN group being created here.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a protocol group:


```
DGS-3627:admin# create dot1v_protocol_group group_id 1
Command: create dot1v_protocol_group group_id 1

Success.

DGS-3627:admin#
```

config dot1v_protocol_group

Purpose	Used to configure the parameters for a protocol VLAN group.
Syntax	config dot1v_protocol_group group_id <id> [add delete] protocol [ethernet_2 ieee802.3_snap ieee802.3_llc] <protocol_value>
Description	This command will configure a protocol template for a group. Users may set the frame type to be added or deleted, along with the appropriate <i>protocol_value</i> in hexadecimal form. After being configured, this group may be attached to a port or range of ports using the config port dot1v command.
Parameters	<p><i>group_id <id></i> – Enter an integer from 1 to 16 to identify the protocol VLAN group being configured here.</p> <p><i>add delete</i> – Choose whether to add or delete the protocol to this group. This protocol is identified using the following <i>protocol</i> parameter.</p> <p><i>protocol</i> – Choose the appropriate frame type to be added to this group. This frame type will be identified by the switch by examining the packet header of incoming packets and matching it to the <i>protocol_value</i> stated here. This frame type must be followed by the correct <i>protocol_value</i>. The user has three choices:</p> <ul style="list-style-type: none"> • <i>ethernet_2</i> – Choose this parameter if you wish this protocol group to employ the Ethernet2 frame type. This frame type is identified by the 16-bit (2 octet) IEEE802.3 type field in the packet header, which is to be stated using the following <i>protocol_value</i>. • <i>ieee802.3_snap</i> – Choose this parameter if you wish this protocol group to employ the Sub Network Access Protocol (SNAP) frame type. This frame type is identified by the 16-bit (2 octet) IEEE802.3 type field in the packet header, which is to be stated using the following <i>protocol_value</i>. • <i>ieee802.3_llc</i> – Choose this parameter if you wish this protocol group to employ the Link Logical Control (LLC) frame type. This frame type is identified by the 2-octet IEEE802.3 Link Service Access Point (LSAP) pair field in the packet header, which is to be stated using the following <i>protocol_value</i>. The first octet defines the Destination Service Access Point value and the second octet is the Source Service Access Point (SSAP) value. <p><i><protocol_value></i> – Enter the corresponding protocol value of the protocol identified in the previous field. This value must be stated in a hexadecimal form.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure a protocol template:

```
DGS-3627:admin# config dot1v_protocol_group group_id 1 add protocol ethernet_2 86DD
Command: config dot1v_protocol_group group_id 1 add protocol ethernet_2 86DD

Success.

DGS-3627:admin#
```

delete dot1v_protocol_group

Purpose	Used to delete a protocol VLAN group.
Syntax	delete dot1v_protocol_group group_id <id>
Description	This command will delete a protocol VLAN group.
Parameters	<i>group_id <id></i> – Enter an integer from 1 to 16 to identify the protocol VLAN group being deleted here.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete a protocol VLAN group:

```
DGS-3627:admin# delete dot1v_protocol_group group_id 1
Command: delete dot1v_protocol_group group_id 1

Success.

DGS-3627:admin#
```

show dot1v_protocol_group

Purpose	Used to display the configurations for a protocol VLAN group.
Syntax	show dot1v_protocol_group {group_id <id>}
Description	This command will display the configurations of a protocol VLAN group.
Parameters	<i>group_id <id></i> – Enter an integer from 1 to 16 to identify the protocol VLAN group to be displayed. Entering this command without the <i>group_id</i> parameter will display the configurations for all configured protocol VLAN groups.
Restrictions	None.

Example usage:

To display the configurations for a protocol VLAN group:

```
DGS-3627:admin# show dot1v_protocol_group group_id 1
Command: show dot1v_protocol_group group_id 1

Protocol Group ID      Frame Type      Protocol Value
-----
1                      EthernetII     86DD

Total Entries: 1

DGS-3627:admin#
```

config port dot1v

Purpose	Used to bind a VLAN with a protocol template on one or more ports.
Syntax	config port dot1v ports [<portlist> all] [add protocol_group group_id <id> [vlan <vlan_name 32> vlanid <vlanid>] delete protocol_group [group_id <id> all]]
Description	This command will bind a VLAN with a protocol template on one or more ports. When an ingress untagged packet is identified by the <i>protocol_value</i> stated using the config dot1v_protocol_group command, the switch will assign a pre-configured VLAN and a priority for these ingress untagged packets in order to properly reach their destination.
Parameters	<p><i>ports</i> – Use this parameter to specify ports.</p> <ul style="list-style-type: none"> <i><portlist></i> – Use this parameter to assign a port or group of ports. <i>all</i> – Use this parameter to specify all ports on the system. <p><i>add protocol_group group_id <id></i> – Enter an integer from 1 to 16 to identify the protocol VLAN group being assigned to the ports or range of ports configured in the previous field.</p> <p><i>vlan</i> – Use this parameter bind a VLAN with a specific protocol template using either of the following parameters:</p> <ul style="list-style-type: none"> <i>vlan_name 32</i> – Identify the VLAN name for which to add a tag to ingress untagged packets. <i>vlanid</i> – Identify the VID for which to add a tag to ingress untagged packets. <p><i>delete protocol_group</i> – Use this parameter to remove this protocol VLAN group's association with the ports stated in this command, by using the following parameters:</p> <ul style="list-style-type: none"> <i>group_id <id></i> – Enter this parameter with its corresponding group number, to remove this pre-defined protocol group from the ports specified here. <i>all</i> – Use this parameter to remove all protocol VLAN groups from the ports specified in this command.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To bind a VLAN with a protocol template:

```
DGS-3627:admin# config port dot1v ports 1:6-1:8 add protocol_group group_id 1 vlan
building1
Command: config port dot1v ports 1:6-1:8 add protocol_group group_id 1 vlan building1

Success.

DGS-3627:admin#
```

show port dot1v

Purpose	Used to display the bound protocol template on a specific port or ports.
Syntax	show port dot1v {ports <portlist>}
Description	This command will display the protocol VLAN group and VLAN for individual ports.
Parameters	<i>ports <portlist></i> – Enter the port or group of ports for which to display the protocol VLAN group settings. Entering this command without this parameter will display all ports and their corresponding protocol VLAN group settings.
Restrictions	None.

Example usage:

To configure the ports for a protocol VLAN group:

```
DGS-3627:admin# show port dot1v ports 1:6-1:8
```

```
Command: show port dot1v ports 1:6-1:8
```

```
Port: 1:6
```

Protocol Group ID	VLAN Name
-----	-----
1	building1

```
Port: 1:7
```

Protocol Group ID	VLAN Name
-----	-----
1	building1

```
Port: 1:8
```

Protocol Group ID	VLAN Name
-----	-----
1	building1

```
Total Entries: 3
```

```
DGS-3627:admin#
```

QUALITY OF SERVICE (QOS) COMMANDS

The Switch supports 802.1p priority queuing. The Switch has seven configurable priority queues. These priority queues are numbered from 6 (Class 6) — the highest priority queue — to 0 (Class 0) — the lowest priority queue. The eight priority tags specified in IEEE 802.1p (p0 to p7) are mapped to the Switch's priority queues as follows:

- Priority 0 is assigned to the Switch's Q2 queue.
- Priority 1 is assigned to the Switch's Q0 queue.
- Priority 2 is assigned to the Switch's Q1 queue.
- Priority 3 is assigned to the Switch's Q3 queue.
- Priority 4 is assigned to the Switch's Q4 queue.
- Priority 5 is assigned to the Switch's Q5 queue.
- Priority 6 is assigned to the Switch's Q6 queue.
- Priority 7 is assigned to the Switch's Q6 queue.

Priority scheduling is implemented by the priority queues stated above. The Switch will empty the eight hardware priority queues in order, beginning with the highest priority queue, 6, to the lowest priority queue, 0. Each hardware queue will transmit all of the packets in its buffer before permitting the next lower priority to transmit its packets. When the lowest hardware priority queue has finished transmitting all of its packets, the highest hardware priority queue will begin transmitting any packets it may have received.



NOTICE: The Switch contains eight classes of service for each port on the Switch. One of these classes is reserved for internal use on the Switch and therefore is not configurable. All references in the following section regarding classes of service will refer to only the seven classes of service that may be used and configured by the Switch's Administrator.

The Quality of Service (QoS) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config bandwidth_control	[<portlist> all] {rx_rate [no_limit <value 64-10000000>] tx_rate [no_limit <value 64-10000000>]}
show bandwidth_control	{<portlist>}
config scheduling	{ports [<portlist> all]} <class_id 0-6> [max_packet <value 0-15>]
config scheduling_mechanism	{ports [<portlist> all]} [strict weight_fair]
show scheduling	{<portlist>}
show scheduling_mechanism	{<portlist>}
config 802.1p user_priority	{ports [<portlist> all]} <priority 0-7> <class_id 0-6>
show 802.1p user_priority	{<portlist>}
config 802.1p default_priority	[<portlist> all] <priority 0-7>
show 802.1p default_priority	{<portlist>}
enable hol_prevention	
disable hol_prevention	
show hol_prevention	
config per_queue bandwidth_control	{ports [<portlist> all]} <cos_id_list 0-6> {{min_rate [no_limit <value 64-10000000 >]} max_rate [no_limit <value 64-10000000 >]}(1)
show per_queue bandwidth_control	{<portlist>}
enable cpu_rx_rate_control	{<class_id 0-2>}
disable cpu_rx_rate_control	{<class_id 0-2>}
show cpu_rx_rate_control	

Each command is listed, in detail, in the following sections.

config bandwidth_control

Purpose	Use to configure the port bandwidth limit control.
Syntax	config bandwidth_control [<portlist> all] {rx_rate [no_limit <value 64-10000000>] tx_rate [no_limit <value 64-10000000>]}
Description	This command sets the maximum limit for port bandwidth.
Parameters	<p><i>portlist</i> - Specifies the range of ports to be configured.</p> <p><i>rx_rate</i> - Specifies the limitations to apply to the receive data rate.</p> <p><i>no_limit</i> - Indicates there is no limit on the amount of bandwidth that can be received on the configured ports.</p> <p>An integer value from 64 to 10000000 sets the maximum limit in Kbits/sec. The actual bandwidth will be an adjusted value based on the user specified bandwidth. The actual limit may be equal to the user specified limit, but will not exceed it. The actual limit recognized by the device, will be displayed when the command is executed. Actual rate = (inputted rate/ minimum granularity) * minimal granularity</p> <p><i>tx_rate</i> - Specifies the limitation applied to the transmit data rate.</p> <p><i>no_limit</i> - Indicates that there is no limit on the port TX bandwidth.</p> <p>An integer value from 64 to 10000000 sets a maximum limit in Kbits/sec. The actual bandwidth will be an adjusted value based on the user specified bandwidth. The actual limit may be equal to the user specified limit, but will not exceed it. The actual limit recognized by the device, will be displayed when the command is executed. Actual rate = (inputted rate/</p>

config bandwidth_control

	minimum granularity) * minimal granularity
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the transmit bandwidth rate on port 1:1-1:10 to be 100 Kbits/sec:

```
DGS-3627:admin# config bandwidth_control 1:1-1:10 tx_rate 100
Command: config bandwidth_control 1:1-1:10 tx_rate 100
```

The setting value is not an integer multiple of granularity 64. The closest value 64 is chosen.

Success.

```
DGS-3627:admin#
```

show bandwidth_control

Purpose	Used to display the port bandwidth control table.
Syntax	show bandwidth_control {<portlist>}
Description	The show bandwidth_control command displays the port bandwidth configuration. The bandwidth can also be assigned by the RADIUS server through the authentication process. If the RADIUS server has assigned the bandwidth, then the RADIUS-assigned bandwidth will be the effective bandwidth. The authentication with the RADIUS server can be either per port or per user. For per-user authentication, there may be multiple bandwidth control values assigned when there are multiple users attached to the specific port. In this case, the largest assigned bandwidth value will be applied to the effective bandwidth for this specific port. Note that only devices that support MAC-based VLANs can provide per user authentication.
Parameters	<i>portlist</i> - Specifies a range of ports to be displayed. If no parameter is specified, the system will display all ports bandwidth configurations.
Restrictions	None.

Example usage:

To display port bandwidth control table for ports 1:1-1:10:

```
DGS-3627:admin# show bandwidth_control 1:1-1:10
```

```
Command: show bandwidth_control 1:1-1:10
```

Bandwidth Control Table

Port	RX Rate (Kbit/sec)	TX Rate (Kbit/sec)	Effective RX (Kbit/sec)	Effective TX (Kbit/sec)
1:1	no_limit	64	-	128
1:2	no_limit	64	-	-
1:3	no_limit	64	64	64
1:4	no_limit	64	64	64
1:5	no_limit	64	-	-
1:6	no_limit	64	64	64
1:7	no_limit	64	-	-
1:8	no_limit	64	-	-
1:9	no_limit	64	-	-
1:10	no_limit	64	-	-

```
DGS-3627:admin#
```

config scheduling

Purpose	Used to configure the traffic scheduling mechanism for each CoS queue.
Syntax	config scheduling {ports [<portlist> all]} <class_id 0-6> [max_packet <value 0-15>]
Description	Used to configure the traffic scheduling mechanism for each CoS queue.
Parameters	<p><i>ports <portlist></i> - Specifies the range of ports to be configured.</p> <p><i>all</i> - To set all ports in the system, you may use the "all" parameter. If no parameter is specified, the system will set all ports.</p> <p><i>class_id</i> - This specifies the n+1 hardware priority queues that the config scheduling command will apply to. The four hardware priority queues are identified by a number □ from 0 to n □ with the 0 queue being the lowest priority. The determination of n is project dependent.</p> <p><i>max_packet</i> - Specifies the maximum number of packets that the hardware priority queue, specified above, will be allowed to transmit before allowing the next lowest priority queue to transmit its packets. A value between 0 and m can be specified. Determination of m is project dependent.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the traffic scheduling on CoS queue 1, with a weight value of 15, on port 1:10:

```
DGS-3627:admin# config scheduling ports 1:10 1 max_packet 15
```

```
Command: config scheduling ports 1:10 1 max_packet 15
```

```
Success.
```

```
DGS-3627:admin#
```

config scheduling_mechanism

Purpose	Used to configure the traffic scheduling mechanism for each CoS queue.
Syntax	config scheduling_mechanism {ports [<portlist> all]} [strict weight_fair]

config scheduling_mechanism

Description	There are two sets of commands that the project can be choose to implement. If the project only supports the scheduling mechanism to be set globally, the portlist parameter will not be supported. This command is used to specify how the switch handles packets in priority queues.
Parameters	<i>ports</i> <portlist> - Specifies a range of ports to be configured. <i>all</i> - To set all ports in the system, you may use the "all" parameter. If no parameter is specified, the system will set all ports. <i>strict</i> - All queues will operate in strict mode. <i>weight_fair</i> - Each queue will operate based on their settings.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the traffic scheduling mechanism for the CoS queue on port 1:1:

```
DGS-3627:admin# config scheduling_mechanism ports 1:1 strict
Command: config scheduling_mechanism ports 1:1 strict
```

Success.

```
DGS-3627:admin#
```

show scheduling

Purpose	Used to display the current traffic scheduling parameters.
Syntax	show scheduling {<portlist>}
Description	The show scheduling command displays the current traffic scheduling parameters in use on the Switch.
Parameters	<i>portlist</i> - Specifies the range of ports to be displayed. If portlist is not specified, for the projects that support the per-port scheduling configure, system will display all ports' scheduling configurations, for those projects that only support the global scheduling settings, this command will display the global setting only.
Restrictions	None.

Example usage:

To display the traffic scheduling parameters for each CoS queue on port 1:1 (take eight hardware priority queues for example):

```
DGS-3627:admin#show scheduling 1:1
```

```
Command: show scheduling 1:1
```

```
QOS Output Scheduling On Port: 1:1
```

```
Class ID  MAX. Packets
```

```
-----  -----
```

```
Class-0   1
Class-1   2
Class-2   3
Class-3   4
Class-4   5
Class-5   6
Class-6   7
```

```
DGS-3627:admin#
```

show scheduling_mechanism

Purpose	Used to show the traffic scheduling mechanism.
Syntax	show scheduling_mechanism { <portlist> }
Description	The show scheduling_mechanism command displays the traffic scheduling mechanism.
Parameters	<i>portlist</i> - Specifies a range of ports to be displayed. If no portlist is specified, for the projects that support the per-port scheduling mechanism configure, system will display all ports' scheduling mechanism configurations, for those projects that only support the global scheduling mechanism settings, this command will display the global setting only.
Restrictions	None.

Example usage:

To show the scheduling mechanism for all ports:

```
DGS-3627:admin#show scheduling_mechanism 1:1
```

```
Command: show scheduling_mechanism 1:1
```

```
Port  Mode
-----  -----
1:1   strict
```

```
DGS-3627:admin#
```

config 802.1p user_priority

Purpose	Used to map the 802.1p user priority of an incoming packet to one of the eight hardware queues available on the Switch.
Syntax	config 802.1p user_priority { ports [<portlist> all]} <priority 0-7> <class_id 0-6>
Description	The config 802.1p user_priority command is used when you want to configure the way that the switch will map an incoming packet, based on its 802.1p user priority, to one of the available hardware priority queues on the switch.
Parameters	<i>ports <portlist></i> - Specifies the range of ports to be configured. <i>all</i> - To set all ports in the system, you may use the "all" parameter. If no parameter is specified, the system will set all ports. <i>priority</i> - The 802.1p user priority you want to associate the <class_id> (the number of the hardware queue) with.

config 802.1p user_priority

class_id - The number of the switch's hardware priority queue. The switch has 7 hardware priority queues available. They are numbered between 0 (the lowest priority) and 6 (the highest priority).

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To configure an 802.1p user priority of 1 and a class_ID of 3 on port 1:1:

```
DGS-3627:admin# config 802.1p user_priority ports 1:1 1 3
Command: config 802.1p user_priority ports 1:1 1 3
```

Success.

```
DGS-3627:admin#
```

show 802.1p user_priority

Purpose Used to display the 802.1p user priority.

Syntax **show 802.1p user_priority {<portlist>}**

Description The show 802.1p user_priority command displays 802.1p user priority for ports.

Parameters *portlist* - Specifies the range of ports to be displayed.
If no portlist is specified, this command will display the 802.1p user priority for all ports.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

In the case of Project only support global configuration, display the 802.1p user priority:

```
DGS-3627:admin#show 802.1p user_priority 1:1
```

```
Command: show 802.1p user_priority 1:1
```

```
QOS Class of Traffic
```

```
Port 1:1
```

```
Priority-0 -> <Class-2>
```

```
Priority-1 -> <Class-0>
```

```
Priority-2 -> <Class-1>
```

```
Priority-3 -> <Class-3>
```

```
Priority-4 -> <Class-4>
```

```
Priority-5 -> <Class-5>
```

```
Priority-6 -> <Class-6>
```

```
Priority-7 -> <Class-6>
```

```
DGS-3627:admin#
```

config 802.1p default_priority

Purpose Used to configure the 802.1p default priority settings on the Switch. If an untagged packet is received by the Switch, the priority configured with this command will be written to the packet's priority field.

Syntax **config 802.1p default_priority [<portlist> | all] <priority 0-7>**

Description The configure 802.1p default_priority command allows you to specify default priority handling of untagged packets received by the Switch. The priority value entered with this command

config 802.1p default_priority

Parameters	<p>will be used to determine the hardware priority queues that the packet will be forwarded to.</p> <p><i>portlist</i> - This specifies the range of ports, which require the default priority settings configured on. That is, the range of ports which receive all untagged packets will be assigned the priority specified below. The port list is specified by listing the lowest switch number and the beginning port number on that switch, separated by a colon. Then the highest switch number, and the highest port number of the range (also separated by a colon) are specified. The beginning and end of the port list range are separated by a dash. For example:</p> <p>1:3 - Specifies switch number 1, port 3.</p> <p>2:4 - Specifies switch number 2, port 4.</p> <p>1:3-2:4 - Specifies all of the ports between switch 1, port 3 and switch 2, port 4, in numerical order.</p> <p><i>all</i> - Specifies that the command will apply to all ports on the switch.</p> <p><i>priority</i> - The priority value (0 to 7) assigned to untagged packets received by the switch or a range of ports on the switch.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure an 802.1p default priority settings of 5 on all Switch ports:

```
DGS-3627:admin# config 802.1p default_priority all 5
Command: config 802.1p default_priority all 5

Success.

DGS-3627:admin#
```

show 802.1p default_priority

Purpose	Used to display the current default priority settings on the Switch.
Syntax	show 802.1p default_priority { <portlist> }
Description	<p>The command displays the current configured default priority settings on the switch.</p> <p>The default priority can also be assigned by the RADIUS server through the authentication process. Authentication with the RADIUS server can be either per port or per user. For per port authentication, the priority assigned by the RADIUS server will be the default priority of the effective port. For per user authentication, the priority assigned by RADIUS will not be the effective port default priority, as the will priority associated with MAC address will be assigned. Note that only devices supporting MAC-based VLANs can provide per user authentication.</p>
Parameters	<p><i>portlist</i> - Specifies the range of ports to be displayed.</p> <p>If no parameter is specified, all ports with an 802.1p default priority will be displayed.</p>
Restrictions	None.

Example usage:

To display the 802.1p default priority on ports 1:1-1:10:

```
DGS-3627:admin# show 802.1p default_priority 1:1-1:10
```

```
Command: show 802.1p default_priority 1:1-1:10
```

Port	Priority	Effective Priority
----	-----	-----
1:1	5	5
1:2	5	5
1:3	5	5
1:4	5	5
1:5	5	5
1:6	5	5
1:7	5	5
1:8	5	5
1:9	5	5
1:10	5	5

```
DGS-3627:admin#
```

enable hol_prevention

Purpose	Used to enable HOL prevention.
Syntax	enable hol_prevention
Description	The enable hol_prevention command enables head of line prevention on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable HOL prevention on the switch:

```
DGS-3627:admin# enable hol_prevention
```

```
Command: enable hol_prevention
```

```
Success.
```

```
DGS-3627:admin#
```

disable hol_prevention

Purpose	Used to disable HOL prevention.
Syntax	disable hol_prevention
Description	The command disables head of line prevention on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable HOL prevention on the Switch:

```
DGS-3627:admin# disable hol_prevention
```

```
Command: disable hol_prevention
```

```
Success.
```

```
DGS-3627:admin#
```

show hol_prevention

Purpose	Use to show the HOL prevention state.
Syntax	show hol_prevention
Description	The show hol_prevention command displays the head of line prevention state on the switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the HOL prevention state on the switch:

```
DGS-3627:admin# show hol_prevention
```

```
Command: show hol_prevention
```

```
Device HOL Prevention State: Enabled
```

```
DGS-3627:admin#
```

config per_queue bandwidth_control

Purpose	Used to configure the queue bandwidth control for each port.
Syntax	config per_queue bandwidth_control {ports [<portlist> all]} <cos_id_list 0-6> {{min_rate [no_limit <value 64-10000000>]} max_rate [no_limit <value 64-10000000>]}(1)
Description	<p>The config per_queue bandwidth_control command sets the bandwidth control for each specific queue on specified ports.</p> <p>min_rate specifies the minimum guaranteed bandwidth. Specifying no limit for the minimum rate means that bandwidth will not be guaranteed.</p> <p>max_rate limits the bandwidth. When specified, packets transmitted from the queue will not exceed the specified limit even if extra bandwidth is available.</p> <p>The specification of min_rate and max_rate are effective regardless of whether the queue is operating in strict mode or in WRR mode.</p>
Parameters	<p><i>ports <portlist></i> - Specifies a range of ports to be configured.</p> <p><i>all</i> - To set all ports in the system, you may use the “all” parameter. If no parameter is specified, the system will set all ports.</p> <p><i><cos_id_list 0-6></i> - Specifies a list of priority queues. The priority queue number is ranged from 0 to 6.</p> <p><i>min_rate</i> - Specifies that one of the parameters below (no_limit or 64-10000000) will be applied to the minimum rate, which the above specified class will be allowed to receive packets at.</p> <p><i>no_limit</i> - Specifies that there will be no limit on the rate of packets received by the class specified above.</p> <p><i><value 64-10000000></i> - Specifies the packet limit, in Kbps, that the above ports will be allowed to receive.</p>

config per_queue bandwidth_control

If the specified rate does not have multiple of minimum granularity, the rate will be adjusted:
Actual rate = (inputted rate/ minimum granularity) * minimal granularity.

max_rate - Specifies that one of the parameters below (*no_limit* or 64-10000000) will be applied to the maximum rate that the class specified above will be allowed to transmit packets at.

no_limit - Specifies that there will be no limit on the rate of packets received by the above specified class.

<value 64-10000000> - Specifies the packet limit, in Kbps, that the above ports will be allowed to receive.

If the specified rate does not have multiple of minimum granularity, the rate will be adjusted:
Actual rate = (inputted rate/ minimum granularity) * minimal granularity.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the minimum rate to be 130 and the maximum rate to be 100000 on CoS bandwidth queue 1 for ports 1:1-1:10:

```
DGS-3627:admin# config per_queue bandwidth_control ports 1:1-1:10 1 min_rate 130 max_rate 100000
Command: config per_queue bandwidth_control ports 1:1-1:10 1 min_rate 130 max_rate 100000

Success.

DGS-3627:admin#
```

show per_queue bandwidth_control

Purpose	Used to display the per queue bandwidth control settings for each port.
Syntax	show per_queue bandwidth_control {<portlist>}
Description	Used to display the per queue bandwidth control settings.
Parameters	<i>portlist</i> - Specifies the range of ports to be displayed. If no parameter is specified, the system will display the CoS bandwidth configuration for all ports.
Restrictions	None.

Example usage:

To display the per queue bandwidth control table for port 1:10:

```
DGS-3627:admin# show per_queue bandwidth_control 1:10
```

```
Command: show per_queue bandwidth_control 1:10
```

```
Queue Bandwidth Control Table On Port: 1:10
```

Queue	Min_Rate (64Kbit/sec)	Max_Rate (64Kbit/sec)
0	640	no_limit
1	640	no_limit
2	640	no_limit
3	640	no_limit
4	640	no_limit
5	no_limit	no_limit
6	no_limit	no_limit

```
DGS-3627:admin#
```

enable cpu_rx_rate_control

Purpose	Used to set CPU receiving rate as predefined limit.
Syntax	enable cpu_rx_rate_control {<class_id 0-2>}
Description	Used to set CPU receiving rate as predefined limit.
Parameters	<class_id 0-2> - Specifies which class of service to set. If not specified, all classes in the range will be set.
Restrictions	Only Administrator users can issue this command.

Example usage:

To set CPU receiving rate as predefined limit:

```
DGS-3627:admin# enable cpu_rx_rate_control
```

```
Command: enable cpu_rx_rate_control
```

```
Success.
```

```
DGS-3627:admin#
```

disable cpu_rx_rate_control

Purpose	Used to set CPU receiving rate as no limit.
Syntax	disable cpu_rx_rate_control {<class_id 0-2>}
Description	Used to set CPU receiving rate as no limit.
Parameters	<class_id 0-2> - Specifies which class of service to set. If not specified, all classes in the range will be set.
Restrictions	Only Administrator users can issue this command.

Example usage:

To set CPU receiving rate as no limit:


```
DGS-3627:admin# disable cpu_rx_rate_control
Command: enable cpu_rx_rate_control

Success.

DGS-3627:admin#
```

show cpu_rx_rate_control

Purpose	Used to show current settings of CPU receiving rate control.
Syntax	show cpu_rx_rate_control
Description	Used to show current settings of CPU receiving rate control.
Parameters	None.
Restrictions	None.

Example usage:

To show current settings of CPU receiving rate control:

```
DGS-3627:admin# show cpu_rx_rate_control
Command: show cpu_rx_rate_control

Cos  Rate Control
---  -
  0  Enabled
  1  Enabled
  2  Enabled

DGS-3627:admin#
```

REMOTE COPY PROTOCOL (RCP) COMMANDS

RCP is a UNIX Remote Shell service which allows files to be copied between a server and client. RCP is an application that operates above the TCP protocols, and uses port number 514 as the TCP destination port.

The RCP application uses client server architecture and the client can be any machine running the RCP client application.

A Switch that supports the RCP client allows users to copy firmware images, configurations and log files between the Switch and RCP Server.

Switches that do not support a file system should still be able to run an RCP client to copy firmware images, configurations and logs between the switch and RCP server.

The Remote Copy Protocol (RCP) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config rcp server	{ipaddress <ipaddr> username <username 15>}
config rcp server clear	[ipaddr username both]
show rcp server	
download firmware_fromRCP	[[username <username 15>] {<ipaddr>} src_file <path_filename 64> rcp:<string 128>] {unit [<unit_id 1-12> all]} {dest_file <pathname 64>} {boot_up}
upload firmware_toRCP	[[username <username 15>]{<ipaddr>} dest_file <path_filename 64> rcp:<string 128>] {src_file <pathname 64>}
download cfg_fromRCP	[[username <username 15>] {<ipaddr>} src_file <path_filename 64> rcp:<string 128>] {dest_file <pathname 64>}
upload cfg_toRCP	[[username <username 15>]{<ipaddr>} dest_file <path_filename 64> rcp:<string 128>] {src_file <pathname 64>} {[include exclude begin] <filter_string 80> {<filter_string 80>{<filter_string 80>}} {[include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>}} {[include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>}}}]}
upload log_toRCP	[[username <username 15>]{<ipaddr>} dest_file <path_filename 64> rcp:<string 128>]
upload attack_log_toRCP	[[username <username 15>]{<ipaddr>} dest_file <path_filename 64> rcp:<string 128>] {unit <unit_id 1-12>}

Each command is listed, in detail, in the following sections.

config rcp server

Purpose	Configure the global RCP server information.
Syntax	config rcp server {ipaddress <ipaddr> username <username 15>}
Description	This command is used to configure the global RCP server information. This global RCP Server setting can be used when the Server or remote user name is not specified. ONLY one RCP server can be configured for each system. If a user does not specify the RCP Server in the CLI command, and the global RCP Server was not configured, the Switch will ask the user to input the Server IP address or remote user name while executing the RCP commands.
Parameters	<i>ipaddress</i> - The IP address of the global RCP Server. By default, the server is unspecified.

config rcp server

username - The remote user name for logging into the global RCP Server. By default, the global server's remote user name is unspecified.

both - Both the RCP Server IP address and remote user name.

Restrictions

Only Administrator level users can issue this command.

Example usage:

To configure the global RCP Server:

```
DGS-3627:admin# config rcp server ipaddress 172.18.212.106 username rcp_user
```

```
Command: config rcp server ipaddress 172.18.212.106 username rcp_user
```

Success.

```
DGS-3627:admin#
```

config rcp server clear

Purpose

This command is used to clear the RCP global server information.

Syntax

config rcp server clear [ipaddr | username | both]

Description

This command is used to configure the global RCP server information. This global RCP Server setting can be used when the Server or remote user name is not specified.

ONLY one RCP server can be configured for each system.

If a user does not specify the RCP Server in the CLI command, and the global RCP Server was not configured, the Switch will ask the user to input the Server IP address or remote user name while executing the RCP commands.

Parameters

ipaddress - The IP address of the global RCP Server. By default, the server is unspecified.

username - The remote user name for logging into the global RCP Server. By default, the global server's remote user name is unspecified.

both - Both the RCP Server IP address and remote user name.

Restrictions

Only Administrator level users can issue this command.

Example usage:

To configure the global RCP Server:

```
DGS-3627:admin# config rcp server clear username
```

```
Command: config rcp server clear username
```

Success.

```
DGS-3627:admin# config rcp server clear both
```

```
Command: config rcp server clear both
```

Success.

```
DGS-3627:admin#
```

show rcp server

Purpose

Used to display the global RCP server configured on the switch.

show rcp server

Syntax	show rcp server
Description	This command displays the global RCP server information.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display the global RCP Server configuration:

```
DGS-3627:admin# show rcp server
Command: show rcp server
RCP Server Address      : 172.18.64.43
RCP Server Username     : tld2
DGS-3627:admin#
```

download firmware_fromRCP

Purpose	This command is used to download the firmware from the RCP server.
Syntax	download firmware_fromRCP [{ username <username 15> } {<ipaddr>} src_file <path_filename 64> [rcp: <string 128>] { unit [<unit_id 1-12> all]} { dest_file <pathname 64>} { boot_up }
Description	This command is used to download a firmware image file from an RCP server.
Parameters	<p><i>username</i> - The remote user name on the RCP Server.</p> <p><i>ipaddr</i> - The IP address of the RCP server.</p> <p><i>path_filename</i> - The pathname specifies the pathname on the RCP server or local.</p> <p>Note: If user specifies the relative file path, the path search strategy is depending on the server system. For some system, will search the current user working directory firstly, then the environment paths.</p> <p><i>unit</i> - Specifies which unit on the stacking system. If it is not specified, it refers to the master unit.</p> <p><i>all</i> - When all is specified, the boot_up firmware image on all units will be updated.</p> <p><i>boot_up</i> - Specifies it as a boot up file.</p> <p><i>rcp:</i> <string 128> - Syntax: rcp: username@ipaddr/directory/filename Example for FULL path: user_name@10.1.1.1/home/user_name/desxxxx.had Example for relative path: user_name@10.1.1.1./desxxxx.had Example for omitted user name in rcp string: 10.1.1.1./desxxxx.had.</p> <p>Note: No SPACE in the whole <string>.</p>
Restrictions	Only Administrator level users can issue this command.

Example usage:

To download firmware from RCP:

```
DGS-3627:admin# download firmware_fromRCP username rcp_user 172.18.212.106 src_file
/home/DGS-3627.had
Command: download firmware_fromRCP username rcp_user 172.18.212.106 src_file /home/DGS-
3627.had

Connecting to server..... Done.
Download firmware..... Done. Do not power off!
Please wait, programming flash..... Done.
Saving current settings to NV-RAM..... Done.

DGS-3627:admin#
```

To download firmware form RCP using string:

```
DGS-3627:admin# download firmware_fromRCP rcp: rcp_user@10.1.1.1/home/rcp_user/DGS-
3627.had
Command: download firmware_fromRCP rcp: rcp_user@10.1.1.1/home/rcp_user/DGS-3627.had

Connecting to server..... Done.
Download firmware..... Done. Do not power off!
Please wait, programming flash..... Done.
Saving current settings to NV-RAM..... Done.

DGS-3627:admin#
```

To download firmware from RCP Server using rcp string without user name specified, and global RCP Server was not configured:

```
DGS-3627:admin# download firmware_fromRCP rcp: 10.1.1.1.DGS-3627.had
Command: download firmware_fromRCP rcp: 10.1.1.1 DGS-3627.had

Using RCP Server Username : rcp_user

Connecting to server..... Done.
Download firmware..... Done. Do not power off!
Please wait, programming flash..... Done.
Saving current settings to NV-RAM..... Done.

DGS-3627:admin#
```

To download firmware from RCP using string on file system supported device:

```
DGS-3627:admin# download firmware_fromRCP rcp: rcp_user@172.18.212.106 /home/DGS-3627.had
dest_file RUN26B18.had boot_up

Command: download firmware_fromRCP rcp: rcp_user@172.18.212.106 /home/DGS-3627.had
dest_file RUN26B18.had boot_up

Connecting to server..... Done.
Download firmware..... Done. Do not power off!
Please wait, programming flash..... Done.
Saving current settings to NV-RAM..... Done.
Please wait, the switch is rebooting...
```

To download firmware from RCP using global configured server:

```
DGS-3627:admin# download firmware_fromRCP src_file /home/DGS-3627.had dest_file
RUN26B18.had boot_up

Command: download firmware_fromRCP src_file /home/DGS-3627.had dest_file RUN26B18.had
boot_up

Using RCP Server IP: 172.18.212.106
Using RCP Server Username : rcp_user

Connecting to server..... Done.
Download firmware..... Done. Do not power off!
Please wait, programming flash..... Done.
Saving current settings to NV-RAM..... Done.
Please wait, the switch is rebooting...

DGS-3627:admin#
```

To download firmware from RCP without specifies the RCP Server and remote user:

```
DGS-3627:admin# download firmware_fromRCP src_file /home/DGS-3627.had dest_file
RUN26B18.had boot_up

Command: download firmware_fromRCP src_file /home/DGS-3627.had dest_file RUN26B18.had
boot_up

No RCP Server IP Configured.
Would you like to specify a RCP Server IP? (N) 172.18.211.106
No RCP Server Username Configured
Would you like to specify a RCP Server Username? (N) rcp_user

Connecting to server..... Done.
Download firmware..... Done. Do not power off!
Please wait, programming flash..... Done.
Saving current settings to NV-RAM..... Done.
Please wait, the switch is rebooting...

DGS-3627:admin#
```

To download firmware from RCP without specifies the RCP Server and remote user, and the global RCP server was not configured:

```
DGS-3627:admin# download firmware_fromRCP src_file DGS-3627.had dest_file RUN26B18.had
Command: download firmware_fromRCP src_file DGS-3627.had dest_file RUN26B18.had

No RCP Server IP configured.
Would you like to specify a RCP Server IP?(N)

RCP: copy file aborted!
Fail!

DGS-3627:admin#
```

To download DGS-3627.had from Global RCP Server and save with default file path & name:

```
DGS-3627:admin# download firmware_fromRCP src_file DGS-3627.had
```

```
Command: download firmware_fromRCP src_file DGS-3627.had
```

```
Using RCP Server IP: 172.18.212.106
```

```
Using RCP Server Username : rcp_user
```

```
Connecting to server..... Done.
Download firmware..... Done. Do not power off!
Please wait, programming flash..... Done.
Saving current settings to NV-RAM..... Done.
```

```
DGS-3627:admin#
```

upload firmware_toRCP

Purpose	Upload firmware from device to RCP server.
Syntax	upload firmware_toRCP [{ username <username 15>}{<ipaddr>} dest_file <path_filename 64> [rcp:<string 128>] {src_file <pathname 64>}
Description	This command is used to upload firmware from the device to the RCP server.
Parameters	<p><i>username</i> - The remote user name on RCP Server.</p> <p><i>ipaddr</i> - The IP address of the RCP server.</p> <p><i>path_filename</i> - The pathname specifies the pathname on the RCP server or local RCP client.</p> <p>Note: If a user specifies the relative file path, the path search strategy will depend on the server system. For some systems, the current user working directory will be searched first followed by the environment path.</p> <p><i>rcp: <string 128></i> - Syntax: rcp: username@ipaddr/directory/filename Example for FULL path: user_name@10.1.1.1/home/user_name/desxxxx.had Example for relative path: user_name@10.1.1.1./desxxxx.had</p> <p>Note: No SPACE in the whole <string>.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To upload firmware to an RCP Server and rename the image file to DGS-3627-uploaded.had:

```
DGS-3627:admin# upload firmware_toRCP username rcp_user 172.18.212.106 dest_file
```

```
/home/DGS-3627-uploaded.had unit 1 image_id 2
```

```
Command: upload firmware_toRCP username rcp_user 172.18.212.106 dest_file /home/DGS-3627-uploaded.had
```

```
Connecting to server..... Done.
```

```
Upload firmware..... Done.
```

```
DGS-3627:admin#
```

To upload firmware from a single image device to an RCP server using an RCP string:

```
DGS-3627:admin# upload firmware_toRCP rcp: rcp_user@10.1.1.1/home/rcp_user/DGS-3627-
uploaded.had
Command: upload firmware_toRCP rcp: rcp_user@10.1.1.1/home/rcp_user/ DGS-3627-
uploaded.had

Connecting to server..... Done.
Upload firmware..... Done.

DGS-3627:admin#
```

To upload firmware on a switch that supports a file system:

```
DGS-3627:admin# upload firmware_toRCP rcp: rcp_user@172.18.212.106 DGS-3627-R26B18.had
src_file RUN26B18.had

Command: upload firmware_toRCP rcp: rcp_user@172.18.212.106 DGS-3627-R26B18.had src_file
RUN26B18.had

Connecting to server..... Done.
Upload firmware..... Done.

DGS-3627:4#
```

download cfg_fromRCP

Purpose	Download configuration file from the RCP server.
Syntax	download cfg_fromRCP [{ username <username 15>} {<ipaddr>} src_file <path_filename 64> [rcp:<string 128>] {dest_file <pathname 64>}]
Description	This command is used to download a configuration file from an RCP server.
Parameters	<p><i>username</i> - The remote user name on the RCP Server.</p> <p><i>ipaddr</i> - The IP address of the RCP server.</p> <p><i>path_filename</i> - The pathname specifies the pathname on the RCP server or local RCP client.</p> <p>Note: If a user specifies the relative file path, the path search strategy will depend on the server system. For some systems, the current user working directory will be searched first, followed by the environment paths.</p> <p><i>rcp:</i> <string 128> - Syntax: rcp: username@ipaddr/directory/filename</p> <p>Example for FULL path: user_name@10.1.1.1/home/user_name/desxxxx.had</p> <p>Example for relative path: user_name@10.1.1.1./desxxxx.had</p> <p>Note: No SPACE in the whole <string>.</p>
Restrictions	Only Administrator level users can issue this command.

Example usage:

To download a configuration file from an RCP server:


```
DGS-3627:admin# download cfg_fromRCP username rcp_user 172.18.212.106 src_file
/home/DGS-3627.cfg
Command: download cfg_fromRCP username rcp_user 172.18.212.106 src_file /home/DGS-
3627.cfg

Connecting to server..... Done.
Download configuration..... Done.

DGS-3627:admin#
```

To download a configuration using an RCP string:

```
DGS-3627:admin# download cfg_fromRCP rcp: rcp_user@172.18.212.106/home/DGS-3627.cfg
Command: download cfg_fromRCP rcp: rcp_user@172.18.212.106/home/DGS-3627.cfg

Connecting to server..... Done.
Download configuration..... Done.

DGS-3627:admin#
```

To download configuration on a device that supports a file system:

```
DGS-3627:admin# download cfg_fromRCP rcp: rcp_user@172.18.212.106/home/rcp_user/DGS-
3627.cfg dest_file bone_switch.cfg
Command: download cfg_fromRCP rcp: rcp_user@172.18.212.106/home/rcp_user/DGS-3627.cfg
dest_file bone_switch.cfg

Connecting to server..... Done.
Download configuration..... Done.

DGS-3627:admin#
```

upload cfg_toRCP

Purpose	Upload a configuration file from the device to an RCP server.
Syntax	<code>upload cfg_toRCP [{ username <username 15>}{<ipaddr>} dest_file <path_filename 64> [rcp:<string 128>] {src_file <pathname 64>} {[include exclude begin] <filter_string 80> {<filter_string 80>{<filter_string 80>}} {[include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>}} {[include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>}}}]}</code>
Description	This command is used to upload a configuration file from the device to an RCP server. If the remote filename is not specified, the default file name will be modelname-image-id.
Parameters	<p><i>username</i> - The remote user name on the RCP Server.</p> <p><i>ipaddr</i> - The IP address of the RCP server.</p> <p><i>path_filename</i> - The pathname specifies the pathname on the RCP server or local RCP client.</p> <p>Note: If a user specifies the relative file path, the path search strategy will depend on the server system. For some systems, the current user working directory will be searched first, followed by the environment paths. Note:</p> <p>If a user only specifies the <i>path_filename</i> parameter, only the current device configuration will be uploaded.</p> <p><i>rcp: <string 128></i> - Syntax: <code>rcp: username@ipaddr/directory/filename</code> Example for FULL path: <code>user_name@10.1.1.1/home/user_name/desxxxx.had</code> Example for relative path: <code>user_name@10.1.1.1./desxxxx.had</code></p>

upload cfg_toRCP

Note: No SPACES are allowed in the whole <string>.

filter_string - A filter string is enclosed by the “symbol. Therefore, the filter string itself cannot contain the “character. The filter string is case sensitive.

Restrictions

Only Administrator level users can issue this command.

Example usage:

To upload the configuration from a single-config device to an RCP server:

```
DGS-3627:admin# upload cfg_toRCP username rcp_user 172.18.212.104 dest_file /home/DGS-3627.cfg
Command: upload cfg_toRCP username rcp_user 172.18.212.104 dest_file /home/DGS-3627.cfg

Connecting to server..... Done.
Upload Configuration..... Done.

DGS-3627:admin#
```

To upload the configuration from a file system supported device to an RCP Server:

```
DGS-3627:admin# upload cfg_toRCP username rcp_user 172.18.212.104 dest_file /home/rcp_user/bone_switch.cfg src_file c:\DGS-3627.cfg
Command: upload cfg_toRCP username rcp_user 172.18.212.104 dest_file /home/rcp_user/bone_switch.cfg src_file c:\DGS-3627.cfg

Connecting to server..... Done.
Upload Configuration..... Done.

DGS-3627:admin#
```

upload log_toRCP

Purpose	Upload a log file from the device to an RCP server.
Syntax	upload log_toRCP [{ username <username 15>}{<ipaddr>} dest_file <path_filename 64> [rcp:<string 128>]
Description	This command is used to upload a system log file from the device to an RCP server. If a destination file is not specified the file name will be modelname-slog.
Parameters	<p><i>username</i> - The remote user name on the RCP Server.</p> <p><i>ipaddr</i> - The IP address of the RCP server.</p> <p><i>path_filename</i> - The pathname specifies the pathname on the RCP server or local RCP client.</p> <p>Note: If a user specifies the relative file path, the path search strategy will depend on the server system. For some systems, the current user working directory will be searched first, followed by the environment paths.</p> <p><i>rcp:</i> <string 128> - Syntax: rcp: username@ipaddr/directory/filename</p> <p>Example for FULL path: user_name@10.1.1.1/home/user_name/desxxxx.had</p> <p>Example for relative path: user_name@10.1.1.1./desxxxx.had</p> <p>Note: No SPACES are allowed in the whole <string>.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To upload the log from the device to an RCP server:

```
DGS-3627:admin# upload log_toRCP username rcp_user 172.18.212.104 dest_file /home/DGS-XXXX.log
Command: upload log_toRCP username rcp_user 172.18.212.104 dest_file /home/DGS-3627.log

Connecting to server... Done.
Upload log..... Done.

DGS-3627:admin#
```

To upload log from the device to an RCP server using an RCP string:

```
DGS-3627:admin# upload log_toRCP rcp: rcp_user@172.18.212.104/home/DGS-XXXX.log
Command: upload log_toRCP rcp: rcp_user@172.18.212.104/home/DGS-3627.log

Connecting to server..... Done.
Upload configuration..... Done.

DGS-3627:admin#
```

upload attack_log_toRCP

Purpose	Upload attack log file from the device to an RCP server.
Syntax	upload attack_log_toRCP [{ username <username 15>}{<ipaddr>} dest_file <path_filename 64> [rcp:<string 128>] {unit <unit_id 1-12>}
Description	This command is used to upload the system attack log file from the device to an RCP server.
Parameters	<p><i>username</i> - The remote user name on the RCP Server.</p> <p><i>ipaddr</i> - The IP address of the RCP server.</p> <p><i>path_filename</i> - The pathname specifies the pathname on the RCP server or local RCP client.</p> <p>Note: If a user specifies the relative file path, the path search strategy will depend on the server system. For some systems, the current user working directory will be searched first, followed by the environment paths</p> <p>Note: If a user only specifies the path_filename parameter for the RCP server, it will upload the master attack log file.</p> <p><i>unit</i> - Specifies which unit on the stacking system. If not specified, it refers to the master unit.</p> <p><i>rcp: <string 128></i> - Syntax: rcp: username@ipaddr/directory/filename Example for FULL path: user_name@10.1.1.1/home/user_name/desxxxx.had Example for relative path: user_name@10.1.1.1./desxxxx.had</p> <p>Note: No SPACES allowed in the whole <string>.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To upload the attack log from the device to an RCP server:

```
DGS-3627:admin# upload attack_log_toRCP username rcp_user 172.18.212.104 dest_file
/home/DGS-XXXX.alog unit 2
Command: upload attack_log_toRCP username rcp_user 172.18.212.104 dest_file /home/DGS-
XXXX.alog unit 2

Connecting to server...Done.
Upload attack log.....Done.

DGS-3627:admin#
```

To upload the attack log from the device to an RCP server using an RCP string:

```
DGS-3627:admin# upload attack_log_toRCP rcp: rcp_user@172.18.212.104/home/DGS-XXXX.alog
Command: upload attack_log_toRCP rcp: rcp_user@172.18.212.104/home/DGS-XXXX.alog

Connecting to server..... Done.
Upload attack log..... Done.

DGS-3627:admin#
```

To upload the attack log from a device that supports a file system to an RCP Server:

```
DGS-3627:admin# upload attack_log_toRCP rcp: 172.18.212.104./DGS-XXXX.log src_file
c:\attsys.log
Command: upload attack_log_toRCP rcp: 172.18.212.104./DGS-XXXX.log src_file c:\attsys.log

No RCP Username configured.
Would you like to specify a RCP Username?(N) : rcp_user

Connecting to server... Done.
Upload attack log..... Done.

DGS-3627:admin#
```

REMOTE SWITCHED PORT ANALYZER (RSPAN) COMMANDS

The Remote Switched Port Analyzer (RSPAN) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
enable rspan	
disable rspan	
create rspan vlan	[vlan_name <vlan_name> vlan_id <value 1-4094>]
delete rspan vlan	[vlan_name <vlan_name> vlan_id <value 1-4094>]
config rspan vlan	[vlan_name <vlan_name> vlan_id <vlanid 1-4094>] source { [mirror_group_id <value 1-4> [add delete] ports <portlist> [rx tx both]]}
config rspan vlan	[vlan_name <vlan_name> vlan_id <vlanid 1-4094>] redirect [add delete] port <port>
show rspan	{[vlan_name <vlan_name> vlan_id <vlanid 1-4094>]}

Each command is listed, in detail, in the following sections.

enable rspan

Purpose	Used to enable the RSPAN globally.
Syntax	enable rspan
Description	<p>This command controls the RSPAN function.</p> <p>The purpose of the RSPAN function is to mirror packets to a remote switch.</p> <p>A packet travels from the switch where the monitored packet is received, passing through the intermediate switch, and then to the switch where the sniffer is attached. The first switch is also named the source switch.</p> <p>To make the RSPAN function work, the RSPAN VLAN source setting must be configured on the source switch. For the intermediate and the last switch, the RSPAN VLAN redirect setting must be configured.</p> <p>Note: RSPAN VLAN mirroring will only work when RSPAN is enabled (when one RSPAN VLAN has been configured with a source port).</p> <p>The RSPAN redirect function will work when RSPAN is enabled and at least one RSPAN VLAN has been configured with redirect ports.</p>
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Configure RSPAN state to enable:

```
DGS-3627:admin# enable rspan
Command: enable rspan

Success.

DGS-3627:admin#
```

disable rspan

Purpose	Used to disable the RSPAN globally.
Syntax	disable rspan
Description	This command controls the RSPAN function.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Configure RSPAN state to disabled:

```
DGS-3627:admin# disable rspan
Command: disable rspan

Success.

DGS-3627:admin#
```

create rspan vlan

Purpose	Used to create an RSPAN VLAN.
Syntax	create rspan vlan [vlan_name <vlan_name> vlan_id <value 1-4094>]
Description	This command is used to create the RSPAN VLAN. Up to 16 RSPAN VLANs can be created.
Parameters	<i>vlan_name</i> - Create the RSPAN VLAN by VLAN name. <i>vlan_id</i> - Create the RSPAN VLAN by VLAN ID.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create an RSPAN VLAN entry by VLAN name "v2":

```
DGS-3627:admin# create rspan vlan vlan_name v2
Command: create rspan vlan vlan_name v2

Success.

DGS-3627:admin#
```

To create an RSPAN VLAN entry by VLAN ID "3":

```
DGS-3627:admin# create rspan vlan vlan_id 3
Command: create rspan vlan vlan_id 3

Success.

DGS-3627:admin#
```

delete rspan vlan

Purpose	Used to delete an RSPAN VLAN.
Syntax	delete rspan vlan [vlan_name <vlan_name> vlan_id <value 1-4094>]
Description	This command is used to delete RSPAN VLANs.
Parameters	<i> vlan_name </i> - Delete RSPAN VLAN by VLAN name. <i> vlan_id </i> - Delete RSPAN VLAN by VLAN ID.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an RSPAN VLAN entry by VLAN name “v2”:

```
DGS-3627:admin# delete rspan vlan vlan_name v2
Command: delete rspan vlan vlan_name v2
Success.

DGS-3627:admin#
```

To delete an RSPAN VLAN entry by VLAN ID “3”:

```
DGS-3627:admin# delete rspan vlan vlan_id 3
Command: delete rspan vlan vlan_id 3
Success.

DGS-3627:admin#
```

config rspan vlan source

Purpose	Used by the source switch to configure the source setting for the RSPAN VLAN.
Syntax	config rspan vlan [vlan_name <vlan_name> vlan_id <vlanid 1-4094>] source { [mirror_group_id <value 1-4> [add delete] ports <portlist> [rx tx both]]}
Description	This command configures the source setting for the RSPAN VLAN on the source switch.
Parameters	<i> vlan </i> - See below: <i> vlan_name </i> - Specify the RSPAN VLAN by VLAN name. <i> vlan_id </i> - Specify the RSPAN VLAN by VLAN ID. <i> source </i> - If the ports are not specified by this command, the source of RSPAN will come from the source specified by the mirror command or the flow-based source specified by an ACL. If no parameter is specified for source, it deletes the configured source parameters. <i> add </i> - Add source ports. <i> delete </i> - Delete source ports. <i> ports <portlist> </i> - Specify source portlist to add to or delete from the RSPAN source <i> rx </i> - Only monitor ingress packets.

config rspan vlan source

tx - Only monitor egress packets.

both - Monitor both ingress and egress packets.

mirror_group_id - The mirror group identify that specify which mirror session used for RSPAN source function.

If the mirror group is not specified when configuring the mirror ports, the mirror group 1 will be the default group.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To configure an RSPAN source entry without source target port:

```
DGS-3627:admin#config rspan vlan vlan_name vlan2 source add ports 2-5 rx
```

```
Command:config rspan vlan vlan_name vlan2 source add ports 2-5 rx
```

Success.

```
DGS-3627:admin#
```

To configure an RSPAN source entry for per flow RSPAN, without any source ports:

```
DGS-3627:admin#config rspan vlan vlan_id 2 source
```

```
Command:config rspan vlan vlan_id 2 source
```

Success.

```
DGS-3627:admin#
```

To configure an RSPAN entry on a source with mirror group ID:

```
DGS-3627:admin#config rspan vlan vlan_id 2 source mirror_group_id 3
```

```
Command:config rspan vlan vlan_id 2 source mirror_group_id 3
```

Success.

```
DGS-3627:admin#
```

config rspan vlan redirect

Purpose Used by the intermediate or last switch to configure the output port for the RSPAN mirrored packet.

Syntax **config rspan vlan [vlan_name <vlan_name> | vlan_id <vlanid 1-4094>] redirect [add | delete] port <port>**

Description This command is used by the intermediate or last switch to configure the output port of the RSPAN VLAN packets.

The redirect command makes sure that the RSPAN VLAN packets can egress to the redirect ports. In addition, to this redirect command, the VLAN setting must be correctly configured to make the RSPAN VLAN work correctly. That is, for the intermediate switch, the redirect port must be tagged member port of RSPAN VLAN. For the last switch, the redirect port must be either be a tagged member port or an untagged member port of the RSPAN VLAN based on the users' requirements. If untagged membership is specified, the RSPAN VLAN tag will be removed.

config rspan vlan redirect

The redirect function will only work when RSPAN is enabled.
 Multiple RSPAN VLANs can be configured with the redirect setting at the same time.
 A RSPAN VLAN can be configured with the source setting and the redirect setting at the same time.

Parameters

vlan - See below:

vlan_name - Specify the RSPAN VLAN by VLAN name.

vlan_id - Specify the RSPAN VLAN by VLAN ID.

redirect - Specify output portlist for the RSPAN VLAN packets. If the redirect port is a Link Aggregation port, there will perform the Link Aggregation behavior for RSPAN packets.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To add or delete redirect ports for special RSPAN VLAN on intermediate or destination switch:

```
DGS-3627:admin# config rspan vlan vlan_name vlan2 redirect add ports 18
Command: config rspan vlan vlan_name vlan2 redirect add ports 18
```

Success.

```
DGS-3627:admin#
```

show rspan

Purpose	Used to display RSPAN configuration.
Syntax	show rspan {[vlan_name <vlan_name> vlan_id <vlanid 1-4094>]}
Description	This command displays the RSPAN configuration.
Parameters	<i>vlan_name</i> - Specify the RSPAN VLAN by VLAN name <i>vlan_id</i> - Specify the RSPAN VLAN by VLAN ID.
Restrictions	None.

Example usage:

Display the specific settings:

```
DGS-3627:admin# show rspan vlan_id 63
Command: show rspan vlan_id 63
RSPAN : Enabled
```

```
RSPAN VLAN ID : 63
-----
Mirror Group ID : 1
Target Port      : 1:1
Source Ports
RX               : 1:2-1:5
TX               : 1:2-1:5
Redirect Ports   : 1:9
```

```
Total RSPAN VLAN : 1
DGS-3627:admin#
```

Display all settings:

```
DGS-3627:admin# show rspan
Command: show rspan

RSPAN: Enabled

RSPAN VLAN ID: 1
-----
Mirror Group ID   : 1
Target Port       : 1:1
Source Ports
                  RX:
                  TX:

RSPAN VLAN ID: 2
-----
Redirect Ports    : 1:6

RSPAN VLAN ID: 3
-----
Redirect Ports    : 1:6

Total RSPAN VLAN :3
DGS-3627:admin#
```

RIPNG COMMANDS

The RIPng commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
enable ripng	
disable ripng	
show ripng	{ipif <ipif_name 12>}
config ripng	{method [no_horizon split_horizon poison_reverse] update <sec 5-65535> expire <sec 1-65535> garbage_collection <sec 1-65535>}(1)
config ripng ipif	[<ipif_name 12> all] {metric <value 1-15> state [enable disable] }(1)
debug ripng state	[enable disable]
debug ripng show flag	
debug ripng flag	[[interface packet [all rx tx] route](1) all] state [enable disable]

Each command is listed, in detail, in the following sections.

enable ripng

Purpose	This command is used to enable RIPng globally for the Switch.
Syntax	enable ripng
Description	This command is used to enable RIPng globally for the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable RIPng globally:

```
DGS-3627:admin# enable ripng
Command: enable ripng

Success.

DGS-3627:admin#
```

disable ripng

Purpose	This command is used to disable RIPng globally for the Switch.
Syntax	disable ripng
Description	This command is used to disable RIPng globally on the Switch. The default setting is disabled.
Parameters	None.

disable ripng

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To disable RIPng globally:

```
DGS-3627:admin# disable ripng
Command: disable ripng

Success.

DGS-3627:admin#
```

show ripng

Purpose	This command is used to display the RIPng state on all or specified interfaces.
Syntax	show ripng {ipif <ipif_name 12>}
Description	This command displays the RIPng state on all or specified interfaces.
Parameters	<i>ipif</i> - Specify that the RIPng configuration will be displayed on a specific interface.
Restrictions	None.

Example usage:

To display RIPng configurations:

```
DGS-3627:admin# show ripng
Command: show ripng

Global State           : Disabled
Method                 : Poison Reverse
Update Time            : 30 seconds
Expire Time             : 180 seconds
Garbage Collection Time : 120 seconds

Interface              State              Metric
-----
int8                   Disabled          1
int14                  Disabled          1

Total Entries : 2

DGS-3627:admin#
```

config ripng

Purpose	This command is used to configure the RIPng algorithm and timer.
Syntax	config ripng {method [no_horizon split_horizon poison_reverse] update <sec 5-65535> expire <sec 1-65535> garbage_collection <sec 1-65535>}(1)
Description	This command is used to specify the RIPng method and timer.
Parameters	<i>update</i> - The value (in seconds) of the update timer. <i>expire</i> - The interval (in seconds) when the update expires.

config ripng

garbage_collection - The value (in seconds) of the garbage-collection timer.
method - See below:
 no_horizon - Configured to not use any horizon.
 split_horizon - Configured to use basic split horizon. This is the default setting.
 poison_reverse - Configured to use split horizon with poison reverse.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the RIPng method as poison reverse:

```
DGS-3627:admin# config ripng method poison_reverse
```

```
Command: config ripng method poison_reverse
```

```
Success.
```

```
DGS-3627:admin#
```

config ripng ipif

Purpose	This command is used to specify the RIPng state and metric value for one or all interfaces
Syntax	config ripng ipif [-ipif_name 12> all] {metric <value 1-15> state [enable disable] }(1)
Description	This command is used to specify the RIPng state or metric value for one or all interfaces.
Parameters	<i>all</i> - Specify that settings will be applied to all IP interfaces. <i>metric</i> - The cost value of an interface. The RIPng route that was learned from the interface will add this value as a new route metric. The default value is 1. <i>state</i> - Enable or disable the RIPng state on the specific IP interface. If the state is disabled, then RIPng packets will not be transmitted or received by the interface. The default setting is disabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the RIPng interface state:

```
DGS-3627:admin# config ripng ipif System state enable
```

```
Command: config ripng ipif System state enable
```

```
Success.
```

```
DGS-3627:admin#
```

debug ripng state

Purpose	This command is used to enable or disable the RIPng debug state globally.
Syntax	debug ripng state [enable disable]
Description	This command is used to enable or disable RIPng debug globally.
Parameters	<i>state</i> - The state of the RIPng debug. The default setting is disabled. <i>enable</i> - Enable RIPng debug. <i>disable</i> - Disable RIPng debug.

debug ripng state

Restrictions	Only Administrator and Operator-level users can issue this command.
--------------	---

Example usage:

To enable RIPng debug globally:

```
DGS-3627:admin# debug ripng state enable
Command: debug ripng state enable

Success.

DGS-3627:admin#
```

debug ripng show flag

Purpose	This command is used to display the RIPng debug flag setting.
Syntax	debug ripng show flag
Description	Used to display the RIPng debug flag setting.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show the current RIPng debug flag setting:

```
DGS-3627:admin# debug ripng show flag
Command: debug ripng show flag

Current Enabled RIPng Flags:
Interface State Change
Packet Receiving
Packet Sending
Route

DGS-3627:admin#
```

debug ripng flag

Purpose	This command is used to enable or disable the RIPng debug flag .
Syntax	debug ripng flag [{interface packet [all rx tx] route}(1) all] state [enable disable]
Description	Used to enable or disable the RIPng debug flag.
Parameters	<i>interface</i> - The state of the RIPng interface debug. The default setting is disabled. <i>packet</i> - See below: <i>all</i> - Set all packets with debug flags. <i>rx</i> - Set inbound packets with debug flag. <i>tx</i> - Set outbound packets with debug flag. <i>route</i> - The state of the RIPng route debug. The default setting is disabled. <i>all</i> - Set all debug flags. <i>state</i> - See below: <i>enable</i> - Enable the designated flags.

debug ripng flag

disable - Disable the designated flags.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the ripng interface debug:

```
DGS-3627:admin# debug ripng interface state enable
```

```
Command: debug ripng interface state enable
```

```
Success.
```

```
DGS-3627:admin#
```

After enabling RIPng on an interface, the following information may appear when the interface state changes:

```
The RIPng interface System has changed the link state to down.
```

ROUTING INFORMATION PROTOCOL (RIP) COMMANDS

The Routing Information Protocol (RIP) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config rip	[ipif <ipif_name 12> all] {authentication [enable <password 16> disable] tx_mode [disable v1_only v1_compatible v2_only] rx_mode [v1_only v2_only v1_or_v2 disable] state [enable disable]}
enable rip	
disable rip	
show rip	{ipif <ipif_name 12>}

Each command is listed, in detail, in the following sections.

config rip

Purpose	Used to configure RIP on the Switch.
Syntax	config rip [ipif <ipif_name 12> all] {authentication [enable <password 16> disable] tx_mode [disable v1_only v1_compatible v2_only] rx_mode [v1_only v2_only v1_or_v2 disable] state [enable disable]}
Description	This command is used to configure RIP on the Switch.
Parameters	<p><ipif_name 12> – The name of the IP interface.</p> <p>all – To configure all RIP receiving mode for all IP interfaces.</p> <p>authentication [enable disable] – Enables or disables authentication for RIP on the Switch.</p> <ul style="list-style-type: none"> <password 16> – Allows the specification of a case-sensitive password. <p>tx_mode – Determines how received RIP packets will be interpreted – as RIP version <i>V1 only</i>, <i>V2 Only</i>, or <i>V1 Compatible (V1 and V2)</i>. This entry specifies which version of the RIP protocol will be used to transfer RIP packets. The disabled entry prevents the reception of RIP packets.</p> <ul style="list-style-type: none"> disable – Prevents the transmission of RIP packets. v1_only – Specifies that only RIP v1 packets will be transmitted. v1_compatible – Specifies that only RIP v1 compatible packets will be transmitted. v2_only – Specifies that only RIP v2 packets will be transmitted. <p>rx_mode – Determines how received RIP packets will be interpreted – as RIP version <i>V1 only</i>, <i>V2 Only</i>, or <i>V1 or V2</i>. This entry specifies which version of the RIP protocol will be used to receive RIP packets. The disabled entry prevents the reception of RIP packets.</p> <ul style="list-style-type: none"> v1_only – Specifies that only RIP v1 packets will be received. v2_only – Specifies that only RIP v2 packets will be received. v1_or_v2 – Specifies that only RIP v1 or v2 packets will be received. <p>state [enable disable] – Allows RIP to be enabled and disabled on the Switch.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To change the RIP receive mode for the IP interface System:


```
DGS-3627:admin# config rip ipif System rx_mode v1_only
Command: config rip ipif System rx_mode v1_only

Success.

DGS-3627:admin#
```

enable rip

Purpose	Used to enable RIP.
Syntax	enable rip
Description	This command is used to enable RIP on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example Usage:

To enable RIP:

```
DGS-3627:admin# enable rip
Command: enable rip

Success.

DGS-3627:admin#
```

disable rip

Purpose	Used to disable RIP.
Syntax	disable rip
Description	This command is used to disable RIP on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable RIP:

```
DGS-3627:admin# disable rip
Command: disable rip

Success.

DGS-3627:admin#
```

show rip

Purpose	Used to display the RIP configuration and statistics for the Switch.
Syntax	show rip {ipif <ipif_name 12>}
Description	This command will display the RIP configuration and statistics for a given IP interface or for all IP interfaces.
Parameters	<i>ipif <ipif_name 12></i> – The name of the IP interface for which to display the RIP configuration and settings. If this parameter is not specified, the show rip command will display the global RIP configuration for the Switch.
Restrictions	None.

Example usage:

To display RIP configuration:

```
DGS-3627:admin# show rip
Command: show rip

RIP Global State : Disabled

RIP Interface Settings

Interface      IP Address      TX Mode    RX Mode      Authen-      State
-----
System        10.90.90.90/8   Disabled   Disabled     Disabled     Disabled

Total Entries : 1
DGS-3627:admin#
```

Example usage:

To display RIP configurations by IP interface:

```
DGS-3627:admin# show rip ipif System
Command: show rip ipif System

RIP Interface Settings

Interface Name: System                IP Address: 10.53.13.33/8 (Link Up)
Interface Metric: 1                   Administrative State: Disabled
TX Mode: V2 Only                       RX Mode: V1 or V2
Authentication: Disabled

Total Entries: 1

DGS-3627:admin#
```

SAFEGUARD ENGINE COMMANDS

Periodically, malicious hosts on the network will attack the Switch by utilizing packet flooding (ARP Storm) or other methods. These attacks may increase the CPU utilization beyond its capability. To alleviate this problem, the Safeguard Engine function was added to the Switch's software.

The Safeguard Engine can help the overall operability of the Switch by minimizing the workload of the Switch while the attack is ongoing, thus making it capable to forward essential packets over its network in a limited bandwidth. When the Switch either (a) receives too many packets to process or (b) exerts too much memory, it will enter an Exhausted mode.

When in this mode, the Switch will perform the following tasks to minimize the CPU usage:

- It will limit bandwidth of receiving ARP packets. The user may implement this in two ways, by using the **config safeguard_engine** command.
 - When strict is chosen, the Switch will stop receiving ARP packets not destined for the Switch. This will eliminate all unnecessary ARP packets while allowing the essential ARP packets to pass through to the Switch's CPU.
 - When fuzzy is chosen, the Switch will minimize the ARP packet bandwidth received by the switch by adjusting the bandwidth for all ARP packets, whether destined for the Switch or not. The Switch uses an internal algorithm to filter ARP packets through, with a higher percentage set aside for ARP packets destined for the Switch.
- It will limit the bandwidth of IP packets received by the Switch. The user may implement this in two ways, by using the **config safeguard_engine** command.
 - When strict is chosen, the Switch will stop receiving all unnecessary broadcast IP packets, even if the high CPU utilization is not caused by the high reception rate of broadcast IP packets.
 - When fuzzy is chosen, the Switch will minimize the IP packet bandwidth received by the Switch by adjusting the bandwidth for all IP packets, by setting a acceptable bandwidth for both unicast and broadcast IP packets. The Switch uses an internal algorithm to filter IP packets through while adjusting the bandwidth dynamically.

IP packets may also be limited by the Switch by configuring only certain IP addresses to be accepted. This method can be accomplished through the CPU Interface Filtering mechanism explained in the previous section. Once the user configures these acceptable IP addresses, other packets containing different IP addresses will be dropped by the Switch, thus limiting the bandwidth of IP packets. To keep the process moving fast, be sure not to add many conditions on which to accept these acceptable IP addresses and their packets, this limiting the CPU utilization.

Once in Exhausted mode, the packet flow will decrease by half of the level that caused the Switch to enter Exhausted mode. After the packet flow has stabilized, the rate will initially increase by 25% and then return to a normal packet flow.



NOTICE: When the Safeguard Engine is enabled, the Switch will allot bandwidth to various traffic flows (ARP, IP) using the FFP (Fast Filter Processor) metering table to control the CPU utilization and limit traffic. This may limit the speed of routing traffic over the network.

The Safeguard Engine commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config safeguard_engine	{state [enable disable] utilization {rising <value 20-100> falling <value 20-100>} trap_log [enable disable] mode [strict fuzzy]}
show safeguard_engine	

Each command is listed, in detail, in the following sections.

config safeguard_engine

Purpose	To config ARP storm control for system.
Syntax	config safeguard_engine {state [enable disable] utilization {rising <value 20-100> falling <value 20-100>} trap_log [enable disable] mode [strict fuzzy]}
Description	Use this command to configure Safeguard Engine to minimize the effects of an ARP storm.
Parameters	<p><i>state [enable disable]</i> – Select the running state of the Safeguard Engine function as enable or disable.</p> <p><i>utilization</i> – Select this option to trigger the Safeguard Engine function to enable based on the following determinates:</p> <ul style="list-style-type: none"> <i>rising <value 20-100></i> – The user can set a percentage value of the rising CPU utilization which will trigger the Safeguard Engine function. Once the CPU utilization rises to this percentage, the Safeguard Engine mechanism will initiate. <i>falling <value 20-100></i> – The user can set a percentage value of the falling CPU utilization which will trigger the Safeguard Engine function to cease. Once the CPU utilization falls to this percentage, the Safeguard Engine mechanism will shut down. <p><i>trap_log [enable disable]</i> – Choose whether to enable or disable the sending of messages to the device's SNMP agent and switch log once the Safeguard Engine has been activated by a high CPU utilization rate.</p> <p><i>mode</i> - Used to select the type of Safeguard Engine to be activated by the Switch when the CPU utilization reaches a high rate. The user may select:</p> <ul style="list-style-type: none"> <i>strict</i> – If selected, this function will stop accepting all ARP packets not intended for the Switch, and will stop receiving all unnecessary broadcast IP packets, until the storm has subsided. <i>fuzzy</i> – If selected, this function will instruct the Switch to minimize the IP and ARP traffic flow to the CPU by dynamically allotting an even bandwidth to all traffic flows.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the safeguard engine for the Switch:

```
DGS-3627:admin# config safeguard_engine state enable utilization rising 45
Command: config safeguard_engine state enable utilization rising 45

Success.

DGS-3627:admin#
```

show safeguard_engine

Purpose	Used to display current Safeguard Engine settings.
Syntax	show safeguard_engine
Description	This will list the current status and type of the Safeguard Engine settings currently configured.
Parameters	None.
Restrictions	None.

Example usage:

To display the safeguard engine status:

```
DGS-3627:admin# show safeguard_engine
Command: show safeguard_engine

Safeguard Engine State      : Disabled
Safeguard Engine Current Status : Normal Mode
=====
CPU Utilization Information:
Rising Threshold           : 30%
Falling Threshold          : 20%
Trap/Log State             : Disabled
Mode                       : Fuzzy

DGS-3627:admin#
```

SECURE SHELL (SSH) COMMANDS

The steps required to use the Secure Shell (SSH) protocol for secure communication between a remote PC (the SSH Client) and the Switch (the SSH Server), are as follows:

- Create a user account with admin-level access using the **create account admin <username> <password>** command. This is identical to creating any other admin-level user account on the Switch, including specifying a password. This password is used to login to the Switch, once secure communication has been established using the SSH protocol.
- Configure the user account to use a specified authorization method to identify users that are allowed to establish SSH connections with the Switch using the **config ssh user** command. There are three choices as to the method SSH will use to authorize the user, and they are password, publickey and hostbased.
- Configure the encryption algorithm that SSH will use to encrypt and decrypt messages sent between the SSH Client and the SSH Server.
- Finally, enable SSH on the Switch using the **enable ssh** command.

After following the above steps, you can configure an SSH Client on the remote PC and manage the Switch using secure, in-band communication.

The Secure Shell (SSH) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config ssh algorithm	[3DES AES128 AES192 AES256 Arcfour blowfish cast128 twofish128 twofish192 twofish256 MD5 SHA1 RSA DSS] [enable disable]
show ssh algorithm	
config ssh authmode	[password publickey hostbased] [enable disable]
show ssh authmode	
config ssh user	<username 15> authmode [hostbased [hostname <domain_name 32> hostname_IP <domain_name 32> <ipaddr>] password publickey]
show ssh user authmode	
config ssh server	{maxsession <int 1-8> contimeout <sec 120-600> authfail {<int 2-20> rekey [10min 30min 60min never] port < tcp_port_number 1-65535>}
enable ssh	
disable ssh	
show ssh server	

Each command is listed, in detail, in the following sections.

config ssh algorithm

Purpose	Used to config ssh server algorithm.
Syntax	config ssh algorithm [3DES AES128 AES192 AES256 Arcfour blowfish cast128 twofish128 twofish192 twofish256 MD5 SHA1 RSA DSS] [enable disable]
Description	The config ssh algorithm command config the ssh service algorithm.

config ssh algorithm

Parameters	<p><i>3DES</i> - Specify ssh server encryption algorithm.</p> <p><i>blowfish</i> - Specify ssh server encryption algorithm.</p> <p><i>AES(128,192,256)</i> - Specify ssh server encryption algorithm.</p> <p><i>arcfour</i> - Specify ssh server encryption algorithm.</p> <p><i>cast128</i> - Specify ssh server encryption algorithm.</p> <p><i>twofish(128,192,256)</i> - Specify ssh server encryption algorithm.</p> <p><i>MD5</i> - Specify ssh server data integrity algorithm.</p> <p><i>SHA1</i> - Specify ssh server data integrity algorithm.</p> <p><i>DSS</i> - Specify ssh server public key algorithm.</p> <p><i>RSA</i> - Specify ssh server public key algorithm.</p> <p><i>enable</i> - Specify to enable the algorithm.</p> <p><i>disable</i> - Specify to disable the algorithm.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable ssh server public key algorithm:

```
DGS-3627:admin# config ssh algorithm DSS enable RSA enable
Command: config ssh algorithm DSS enable RSA enable
```

Success.

```
DGS-3627:admin#
```

show ssh algorithm

Purpose	Used to show ssh server algorithm.
Syntax	show ssh algorithm
Description	The show ssh algorithm command show the ssh service algorithm.
Parameters	None.
Restrictions	None.

Example usage:

To show server algorithm:

```
DGS-3627:admin# show ssh algorithm
```

```
Command: show ssh algorithm
```

Encryption Algorithm

```
3DES          : Enabled
AES128        : Enabled
AES192        : Enabled
AES256        : Enabled
Arcfour       : Enabled
Blowfish      : Enabled
Cast128       : Enabled
Twofish128   : Enabled
Twofish192   : Enabled
Twofish256   : Enabled
MD5           : Enabled
SHA1          : Enabled
RSA           : Enabled
DSS           : Enabled
```

```
DGS-3627:admin#
```

config ssh authmode

Purpose	Used to update user authentication for ssh configuration.
Syntax	config ssh authmode [password publickey hostbased] [enable disable]
Description	The config ssh user command update the ssh user information.
Parameters	<i>password</i> - Specifies user authentication method. <i>publickey</i> - Specifies user authentication method. <i>hostbased</i> - Specifies user authentication method. <i>enable</i> - Enable user authentication method. <i>disable</i> - Disable user authentication method.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To config user authentication method:

```
DGS-3627:admin# config ssh authmode publickey enable
```

```
Command: config ssh authmode publickey enable
```

```
Success.
```

```
DGS-3627:admin#
```

show ssh authmode

Purpose	Used to show user authentication method.
Syntax	show ssh authmode
Description	The show ssh authmode command show the user authentication method.
Parameters	None.
Restrictions	None.

Example usage:

To show user authentication method:

```
DGS-3627:admin# show ssh authmode
Command: show ssh authmode

The SSH authmode
Password : Enabled
Publickey : Enabled
Hostbased : Enabled

DGS-3627:admin#
```

config ssh user

Purpose	Used to update user information for ssh configuration.
Syntax	config ssh user <username 15> authmode [hostbased [hostname <domain_name 32> hostname_IP <domain_name 32> <ipaddr>] password publickey]
Description	The config ssh user command update the ssh user information.
Parameters	<p><i>username</i> - Specifies the User name.</p> <p><i>publickey</i> - Specifies user authentication method.</p> <p><i>password</i> - Specifies user authentication method.</p> <p><i>hostbased</i> - Specifies user authentication method.</p> <p><i>hostname</i> - Specifies host domain name.</p> <p><i>hostname_ip</i> - Specifies host domain name and ipaddress.</p> <p><i>domain_name</i> - Specifies host name if configuration hostbased mode.</p> <p><i>ipaddr</i> - Specifies host ip address if configuring hostbased mode.</p>
Restrictions	Only Administrator level users can issue this command.

Example usage:

To update user "test" authmode:

```
DGS-3627:admin# config ssh user test publickey
Command: config ssh user test publickey

Success.

DGS-3627:admin#
```

show ssh user authmode

Purpose	Used to show ssh user information.
Syntax	show ssh user authmode
Description	The show ssh user command show the ssh user information.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To show user information about ssh configuration:

```
DGS-3627:admin# show ssh user authmode
```

```
Command: show ssh user authmode
```

Current Accounts

```
Username      Authenticaiton
```

```
-----
```

```
test         publickey
```

```
Total Entries : 1
```

```
DGS-3627:admin#
```

config ssh server

Purpose	Used to configure the SSH server.
Syntax	config ssh server {maxsession <int 1-8> contimeout <sec 120-600> authfail {<int 2-20> rekey [10min 30min 60min never] port < tcp_port_number 1-65535>}
Description	The config ssh server command config the SSH server general information.
Parameters	<p><i>maxsession</i> - Specifies ssh server max session at the same time.</p> <p><i>contimeout</i> - Specifies ssh server connection timeout.</p> <p><i>authfail</i> - Specifies user max fail attempts.</p> <p><i>10/30/60 min</i> - Specifies time to re-generate session key.</p> <p><i>never</i> - Do not re-generate session key.</p> <p><i>port</i> - Specifies the TCP port used to communication between ssh client and server. The default value is 22.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To config ssh server maxsession is 3:

```
DGS-3627:admin# config ssh server maxsession 3
```

```
Command: config ssh server maxsession 3
```

```
Success.
```

```
DGS-3627:admin#
```

enable ssh

Purpose	Used to enable the SSH server.
Syntax	enable ssh
Description	The enable ssh command enables ssh server services. When enabling ssh, telnet will be disabled.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the SSH server:

```
DGS-3627:admin# enable ssh
Command: enable ssh

Success.

DGS-3627:admin#
```

disable ssh

Purpose	Used to disable the SSH server service.
Syntax	disable ssh
Description	The disable ssh command disables ssh server services.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the SSH server service:

```
DGS-3627:admin# disable ssh
Command: disable ssh

Success.

DGS-3627:admin#
```

show ssh server

Purpose	Used to show the SSH server.
Syntax	show ssh server
Description	The show ssh server command show the ssh server general information.
Parameters	None.
Restrictions	None.

Example usage:

To show the SSH server:

```
DGS-3627:admin# show ssh server
Command: show ssh server

The SSH server configuration
max Session           : 3
Connection timeout    : 300
Authfail attempts     : 2
Rekey timeout         : 60min
TCP Port Number       : 23

DGS-3627:admin#
```

SECURE SOCKETS LAYER (SSL) COMMANDS

Secure Sockets Layer or SSL is a security feature that will provide a secure communication path between a host and client through the use of authentication, digital signatures and encryption. These security functions are implemented through the use of a ciphersuite, which is a security string that determines the exact cryptographic parameters, specific encryption algorithms and key sizes to be used for an authentication session and consists of three levels:

- **Key Exchange:** The first part of the ciphersuite string specifies the public key algorithm to be used. This Switch utilizes the Rivest Shamir Adleman (RSA) public key algorithm and the Digital Signature Algorithm (DSA), specified here as the DHE_DSS Diffie-Hellman (DHE) public key algorithm. This is the first authentication process between client and host as they “exchange keys” in looking for a match and therefore authentication to be accepted to negotiate encryptions on the following level.
- **Encryption:** The second part of the ciphersuite that includes the encryption used for encrypting the messages sent between client and host. The Switch supports two types of cryptology algorithms:
 - Stream Ciphers – There are two types of stream ciphers on the Switch, RC4 with 40-bit keys and RC4 with 128-bit keys. These keys are used to encrypt messages and need to be consistent between client and host for optimal use.
 - CBC Block Ciphers – CBC refers to Cipher Block Chaining, which means that a portion of the previously encrypted block of encrypted text is used in the encryption of the current block. The Switch supports the 3DES_EDE encryption code defined by the Data Encryption Standard (DES) to create the encrypted text.
- **Hash Algorithm:** This part of the ciphersuite allows the user to choose a message digest function which will determine a Message Authentication Code. This Message Authentication Code will be encrypted with a sent message to provide integrity and prevent against replay attacks. The Switch supports two hash algorithms, MD5 (Message Digest 5) and SHA (Secure Hash Algorithm).

These three parameters are uniquely assembled in four choices on the Switch to create a three layered encryption code for secure communication between the server and the host. The user may implement any one or combination of the ciphersuites available, yet different ciphersuites will affect the security level and the performance of the secured connection. The information included in the ciphersuites is not included with the Switch and requires downloading from a third source in a file form called a *certificate*. This function of the Switch cannot be executed without the presence and implementation of the certificate file and can be downloaded to the Switch by utilizing a TFTP server. The Switch supports SSLv3 and TLSv1. Other versions of SSL may not be compatible with this Switch and may cause problems upon authentication and transfer of messages from client to host.

Command	Parameters
enable ssl	{ciphersuite {RSA_with_RC4_128_MD5 RSA_with_3DES_EDE_CBC_SHA DHE_DSS_with_3DES_EDE_CBC_SHA RSA_EXPORT_with_RC4_40_MD5}}
disable ssl	{ciphersuite {RSA_with_RC4_128_MD5 RSA_with_3DES_EDE_CBC_SHA DHE_DSS_with_3DES_EDE_CBC_SHA RSA_EXPORT_with_RC4_40_MD5}}
config ssl cachetimeout	<value 60-86400>
show ssl	{certificate}
show ssl cachetimeout	
download ssl certificate	<ipaddr> certfilename <path_filename 64> keyfilename <path_filename 64>

Each command is listed, in detail, in the following sections.

enable ssl

Purpose	To enable the SSL function on the Switch.
Syntax	enable ssl {ciphersuite {RSA_with_RC4_128_MD5 RSA_with_3DES_EDE_CBC_SHA DHE_DSS_with_3DES_EDE_CBC_SHA RSA_EXPORT_with_RC4_40_MD5}}
Description	This command will enable SSL on the Switch by implementing any one or combination of listed ciphersuites on the Switch. Entering this command without a parameter will enable the SSL status on the Switch. Enabling SSL will disable the web-manager on the Switch.
Parameters	<p><i>ciphersuite</i> – A security string that determines the exact cryptographic parameters, specific encryption algorithms and key sizes to be used for an authentication session. The user may choose any combination of the following:</p> <ul style="list-style-type: none"> • <i>RSA_with_RC4_128_MD5</i> – This ciphersuite combines the RSA key exchange, stream cipher RC4 encryption with 128-bit keys and the MD5 Hash Algorithm. • <i>RSA_with_3DES_EDE_CBC_SHA</i> – This ciphersuite combines the RSA key exchange, CBC Block Cipher 3DES_EDE encryption and the SHA Hash Algorithm. • <i>DHE_DSS_with_3DES_EDE_CBC_SHA</i> – This ciphersuite combines the DSA Diffie Hellman key exchange, CBC Block Cipher 3DES_EDE encryption and SHA Hash Algorithm. • <i>RSA_EXPORT_with_RC4_40_MD5</i> – This ciphersuite combines the RSA Export key exchange, stream cipher RC4 encryption with 40-bit keys. <p>The ciphersuites are enabled by default on the Switch, yet the SSL status is disabled by default. Enabling SSL with a ciphersuite will not enable the SSL status on the Switch.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable SSL on the Switch for all ciphersuites:

```
DGS-3627:admin# enable ssl
Command:enable ssl
```

Note: Web will be disabled if SSL is enabled.
Success.

```
DGS-3627:admin#
```



NOTE: Enabling SSL on the Switch will enable all ciphersuites. To utilize a particular ciphersuite, the user must eliminate other ciphersuites by using the disable ssl command along with the appropriate ciphersuites.



NOTE: Enabling the SSL function on the Switch will disable the port for the web manager (port 80). To log on to the web based manager, the entry of your URL must begin with https://. (ex. https://10.90.90.90)

disable ssl

Purpose	To disable the SSL function on the Switch.
Syntax	disable ssl {ciphersuite {RSA_with_RC4_128_MD5 RSA_with_3DES_EDE_CBC_SHA DHE_DSS_with_3DES_EDE_CBC_SHA RSA_EXPORT_with_RC4_40_MD5}}
Description	This command will disable SSL on the Switch and can be used to disable any one or combination of listed ciphersuites on the Switch.
Parameters	<p><i>ciphersuite</i> – A security string that determines the exact cryptographic parameters, specific encryption algorithms and key sizes to be used for an authentication session. The user may choose any combination of the following:</p> <ul style="list-style-type: none"> • <i>RSA_with_RC4_128_MD5</i> – This ciphersuite combines the RSA key exchange, stream cipher RC4 encryption with 128-bit keys and the MD5 Hash Algorithm. • <i>RSA_with_3DES_EDE_CBC_SHA</i> – This ciphersuite combines the RSA key exchange, CBC Block Cipher 3DES_EDE encryption and the SHA Hash Algorithm. • <i>DHE_DSS_with_3DES_EDE_CBC_SHA</i> – This ciphersuite combines the DSA Diffie Hellman key exchange, CBC Block Cipher 3DES_EDE encryption and SHA Hash Algorithm. • <i>RSA_EXPORT_with_RC4_40_MD5</i> – This ciphersuite combines the RSA Export key exchange, stream cipher RC4 encryption with 40-bit keys.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the SSL status on the Switch:

```
DGS-3627:admin# disable ssl
```

```
Command: disable ssl
```

```
Success.
```

```
DGS-3627:admin#
```

To disable ciphersuite RSA_EXPORT_with_RC4_40_MD5 only:

```
DGS-3627:admin# disable ssl ciphersuite RSA_EXPORT_with_RC4_40_MD5
```

```
Command: disable ssl ciphersuite RSA_EXPORT_with_RC4_40_MD5
```

```
Success.
```

```
DGS-3627:admin#
```

config ssl cachetimeout

Purpose	Used to configure the SSL cache timeout.
Syntax	config ssl cachetimeout <value 60-86400>
Description	This command will set the time between a new key exchange between a client and a host using the SSL function. A new SSL session is established every time the client and host go through a key exchange. Specifying a longer timeout will allow the SSL session to reuse the master key on future connections with that particular host, therefore speeding up the negotiation process.
Parameters	<i><value 60-86400></i> – Enter a timeout value between 60 and 86400 seconds to specify the total time an SSL key exchange ID stays valid before the SSL module will require a new, full SSL negotiation for connection. The default cache timeout is 600 seconds
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set the SSL cachetimeout for 7200 seconds:

```
DGS-3627:admin# config ssl cachetimeout 7200
Command: config ssl cachetimeout 7200

Success.

DGS-3627:admin#
```

show ssl cachetimeout

Purpose	Used to show the SSL cache timeout.
Syntax	show ssl cachetimeout
Description	Entering this command will allow the user to view the SSL cache timeout currently implemented on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To view the SSL cache timeout on the Switch:

```
DGS-3627:admin# show ssl cachetimeout
Command: show ssl cachetimeout

Cache timeout is 600 second(s).

DGS-3627:admin#
```

show ssl

Purpose	Used to view the SSL status and the certificate file status on the Switch.
Syntax	show ssl {certificate}
Description	This command is used to view the SSL status on the Switch.
Parameters	<i>{certificate}</i> – Use this parameter to display the SSL certificate file information currently implemented on the Switch.
Restrictions	None.

Example usage:

To view the SSL status on the Switch:

```
DGS-3627:admin# show ssl
Command: show ssl

SSL status           Disabled
RSA_WITH_RC4_128_MD5 Enabled
RSA_WITH_3DES_EDE_CBC_SHA Enabled
DHE_DSS_WITH_3DES_EDE_CBC_SHA Enabled
RSA_EXPORT_WITH_RC4_40_MD5 Enabled

DGS-3627:admin#
```

Example usage:

To view certificate file information on the Switch:

```
DGS-3627:admin# show ssl certificate
Command: show ssl certificate

Loaded with RSA Certificate!

DGS-3627:admin#
```

download ssl certificate

Purpose	Used to download a certificate file for the SSL function on the Switch.
Syntax	download ssl certificate <ipaddr> certfilename <path_filename 64> keyfilename <path_filename 64>
Description	This command is used to download a certificate file for the SSL function on the Switch from a TFTP server. The certificate file is a data record used for authenticating devices on the network. It contains information on the owner, keys for authentication and digital signatures. Both the server and the client must have consistent certificate files for optimal use of the SSL function. The Switch only supports certificate files with .der file extensions.
Parameters	<p><i><ipaddr></i> – Enter the IP address of the TFTP server.</p> <p><i>certfilename <path_filename 64></i> – Enter the path and the filename of the certificate file you wish to download.</p> <p><i>keyfilename <path_filename 64></i> – Enter the path and the filename of the key exchange file you wish to download.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To download a certificate file and key file to the Switch:

```
DGS-3627:admin# download ssl certificate 10.53.13.94 certfilename c:/cert.der keyfilename
c:/pkey.der
Command: download ssl certificate 10.53.13.94 certfilename c:/cert.der keyfilename
c:/pkey.der

Certificate Loaded Successfully!

DGS-3627:admin#
```


SFLOW COMMANDS

sFlow is a feature that allows users to monitor network traffic running through the switch to identify network problems through packet sampling and packet counter information of the Switch. The Switch itself is the sFlow agent where packet data is retrieved and sent to an sFlow Analyzer where it can be scrutinized and utilized to resolve the problem.

The Switch can configure the settings for the sFlow Analyzer but the remote sFlow Analyzer device must have an sFlow utility running on it to retrieve and analyze the data it receives from the sFlow agent.

The Switch will take sample packets from the normal running traffic of the Switch based on a sampling interval configured by the user. Once this information has been gathered by the switch, it is packaged into a packet called an sFlow datagram, which is then sent to the sFlow Analyzer for analysis.

The sFlow commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create sflow flow_sampler	ports [<portlist> all] analyzer_server_id < value 1-4> {rate <value 0-65535> tx_rate <value 0-65535> maxheadersize <value 18-256>}
config sflow flow_sampler	ports [<portlist> all] {rate <value 0-65535> tx_rate <value 0-65535> maxheadersize < value 18-256 >}(1)
delete sflow flow_sampler	ports [<portlist> all]
create sflow counter_poller	ports [<portlist> all] analyzer_server_id < value 1-4> {interval [disable <sec 20-120>]}
config sflow counter_poller	ports [<portlist> all] interval [disable <sec 20-120>]
delete sflow counter_poller	ports [<portlist> all]
create sflow analyzer_server	< value 1-4 > owner<name 16> {timeout [<sec 1-2000000> infinite] collectoraddress [<ipaddr> <ipv6addr>] collectorport <udp_port_number 1-65535> maxdatagramsize < value m-n>}
config sflow analyzer_server	< value 1-4 > {timeout [<sec 1-2000000 > infinity] collectoraddress [<ipaddr> <ipv6addr>] collectorport <udp_port_number 1-65535> maxdatagramsize < value 300-1400 >}(1)
delete sflow analyzer_server	< value 1-4 >
enable sflow	
disable sflow	
show sflow	
show sflow flow_sampler	
show sflow counter_poller	
show sflow analyzer_server	

Each command is listed, in detail, in the following sections.

create sflow flow_sampler

Purpose Used to create the sFlow flow_sampler.

create sflow flow_sampler

Syntax	create sflow flow_sampler ports [<portlist> all] analyzer_server_id <value 1-4> {rate <value 0-65535> tx_rate <value 0-65535> maxheadersize <value 18-256>
Description	Used to create the sFlow flow_sampler. By configuring the sampling function for a port, a sample packet received by this port will be encapsulated and forwarded to analyzer server at the specified interval.
Parameters	<p><i>ports</i> - Specifies the list of ports to be configured.</p> <p><i>analyzer_server_id</i> - Specifies the ID of a server analyzer where the packet will be forwarded.</p> <p><i>rate</i> - The sampling rate for packet Rx sampling.</p> <p><i>tx_rate</i> - The sampling rate for packet Tx sampling.</p> <p><i>maxheadersize</i> - The maximum number of leading bytes in the packet which has been sampled that will be encapsulated and forwarded to the server. If not specified, the default value is 128</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Create sFlow flow sampler:

```
DGS-3627:admin# create sflow flow_sampler ports 1 analyzer_server_id 1 rate 1
maxheadersize 18
Command: create sflow flow_sampler ports 1 analyzer_server_id 1 rate 1 maxheadersize 18

Success.

DGS-3627:admin#
```

config sflow flow_sampler

Purpose	Used to config the sFlow flow_sampler parameters.
Syntax	config sflow flow_sampler ports [<portlist> all] {rate <value 0-65535> tx_rate <value 0-65535> maxheadersize <value 18-256>}(1)
Description	Configures the sFlow flow sampler parameters. In order to change the analyzer_server_id, first delete the flow_sampler and create a new one.
Parameters	<p><i>ports</i> - Specifies the list of ports to be configured.</p> <p><i>rate</i> - The sampling rate for packet Rx sampling.</p> <p><i>tx_rate</i> - The sampling rate for packet Tx sampling.</p> <p><i>maxheadersize</i> - The maximum number of leading bytes in the packet which has been sampled that will be encapsulated and forwarded to the server. If not specified, the default value is 128.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Configure the sFlow sampler the rate of port 1 to be 0:

```
DGS-3627:admin# config sflow flow_sampler ports 1 rate 0 tx_rate 1
Command: config sflow flow_sampler ports 1 rate 0 tx_rate 1

Success.

DGS-3627:admin#
```

delete sflow flow_sampler

Purpose	Used to delete the sFlow flow_sampler.
Syntax	delete sflow flow_sampler ports [<portlist> all]
Description	Used to delete the sFlow flow_sampler.
Parameters	<i>ports</i> - Specifies the list of ports to be configured.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Delete the sFlow sampler port 1:

```
DGS-3627:admin# delete sflow flow_sampler ports 1
Command: delete sflow flow_sampler ports 1

Success.

DGS-3627:admin#
```

create sflow counter_poller

Purpose	Used to create the sFlow counter_poller:
Syntax	create sflow counter_poller ports [<portlist> all] analyzer_server_id <value 1-4> {interval [disable <sec 20-120>]}
Description	This command is used to create the sFlow counter poller. The poller function instructs the switch to forward statistics counter information with respect to a port. The counters are RFC 2233 counters.
Parameters	<i>analyzer_server_id</i> - The analyzer_server_id is the id of a analyzer_server, <i>interval</i> - The maximum number of seconds between successive statistic counters information. If set to 0, the counter-poller is disabled. If interval is not specified, its default value is 0.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Create sFlow counter poller, which sample port 1 to analyzer server 1:

```
DGS-3627:admin# create sflow counter_poller ports 1 analyzer_server_id 1
Command: create sflow counter_poller ports 1 analyzer_server_id 1

Success.

DGS-3627:admin#
```

config sflow counter_poller

Purpose	Used to config the sFlow counter_poller parameters.
Syntax	config sflow counter_poller ports [<portlist> all] interval [disable <sec 20-120>]
Description	This command is used to configure the sFlow counter_poller parameters. If the user wants the change the analyzer_server_id, he needs to delete the counter_poller and creates a new one.

config sflow counter_poller

Parameters	<i>interval</i> - The maximum number of seconds between successive samples of the counters. If set to 0, the counter-sample is disabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Configure the interval of sFlow counter poller port 1 to be 0:

```
DGS-3627:admin# config sflow counter_poller ports 1 interval disable
Command: config sflow counter_poller ports 1 interval disable
```

Success.

```
DGS-3627:admin#
```

delete sflow counter_poller

Purpose	Used to delete the sFlow counter poller.
Syntax	delete sflow counter_poller ports [<portlist> all]
Description	Delete the sFlow counter_poller from the specified port.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Delete sFlow counter poller on port 1:

```
DGS-3627:admin# delete sflow counter_poller ports 1
Command: delete sflow counter_poller ports 1
```

Success.

```
DGS-3627:admin#
```

create sflow analyzer_server

Purpose	Used to create the analyzer server.
Syntax	create sflow analyzer_server < value 1-4 > owner<name 16> {timeout [<sec m-n> infinite] collectoraddress [<ipaddr> <ipv6addr>] collectorport <udp_port_number 1-65535> maxdatagramsize < value m-n>}
Description	Creates the analyzer_server. You can specify more than one analyzer_server with the same IP address but with different UDP port numbers. You can have up to four unique combinations of IP address and UDP port number.
Parameters	<p><i>owner</i> - The entity making use of this sFlow analyzer_server. When owner is set or modified, the timeout value will become 400 automatically.</p> <p><i>timeout</i> - The length of time before the server is timed out. When the analyzer_server times out, all of the flow_samplers and counter_pollers associated with this analyzer_server will be deleted. If not specified, its default value is 400.</p> <p><i>collectoraddress</i> - The IP address of the analyzer_server. If this is set to 0 or not specified, the IPv4 address is 0.0.0.0 and the entry is not active.</p> <p><i>collectorport</i> - The destination UDP port for sending the sFlow datagrams. If not specified, the default value is 6364.</p>

create sflow analyzer_server

maxdatagramsize - The maximum number of data bytes that can be packed in a single sample datagram. If not specified, the default value is 1400.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To create the analyzer_server:

```
DGS-3627:admin# create sflow analyzer_server 2 owner monitor timeout infinite collect
oraddress 10.0.0.1 collectorport 65524 maxdatagramsize 300
```

```
Command: create sflow analyzer_server 2 owner monitor timeout infinite collector
address 10.0.0.1 collectorport 65524 maxdatagramsize 300
```

Success.

```
DGS-3627:admin#
```

config sflow analyzer_server

Purpose Used to config the analyzer server information.

Syntax **config sflow analyzer_server <value 1-4> {timeout [<sec 1-2000000 > | infinity] | collectoraddress [<ipaddr> | <ipv6addr>] | collectorport <udp_port_number 1-65535> | maxdatagramsize < value 300-1400 >}(1)**

Description Configures the receiver information. You can specify more than one collector with the same IP address if the UDP port numbers are unique.

Parameters *timeout* - The time (in seconds) remaining before the sample is released and stops sampling. When the analyzer_server times out, all of the flow_samplers and counter_pollers associated with this analyzer_server will be deleted.

collectoraddress - The IP address of the server.

If not specified or set a 0 address, sFlow packets will not be sent to this server.

collectorport - The destination port for sending sFlow datagrams

maxdatagramsize - The maximum number of data bytes that can be packed in a single sample datagram.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

Configure the sFlow analyzer server to be 10.90.90.90:

```
DGS-3627:admin# config sflow analyzer_server 1 collectoraddress 10.90.90.90
```

```
Command: config sflow analyzer_server 1 collectoraddress 10.90.90.90
```

Success.

```
DGS-3627:admin#
```

delete sflow_analyzer_server

Purpose Used to delete the analyzer_server.

Syntax **delete sflow analyzer_server < value 1-4 >**

Description Used to delete the analyzer_server.

delete sflow_analyzer_server

Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the analyzer_server:

```
DGS-3627:admin# delete sflow analyzer_server 1
Command: delete sflow analyzer_server 1
```

Success.

```
DGS-3627:admin#
```

enable sflow

Purpose	Used to enable the sFlow function.
Syntax	enable sflow
Description	Enable the sFlow function.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Enable sFlow:

```
DGS-3627:admin# enable sflow
Command: enable sflow
```

Success.

```
DGS-3627:admin#
```

disable sflow

Purpose	Used to disable the sFlow function.
Syntax	disable sflow
Description	Disable the sFlow function.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the sFlow function:

```
DGS-3627:admin# disable sflow
Command: disable sflow

Success.

DGS-3627:admin#
```

show sflow

Purpose	Show the sFlow information.
Syntax	show sflow
Description	This command is used to show the sFlow information. sFlow Address: The IPv4 address associated with this agent. sFlow AddressV6: The IPv6 address associated with this agent. sFlow State: The current state of the sFlow agent.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show the sFlow information:

```
DGS-3627:admin# show sflow
Command: show sflow

sFlow Version      : V5
sFlow Address      : 10.90.90.90
sFlow AddressV6    : FE80::285:43FF:FE26:3101
sFlow State        : Enabled

DGS-3627:admin#
```

show sflow flow_sampler

Purpose	Used to display the sFlow flow_sampler information of ports which have been created.
Syntax	show sflow flow_sampler
Description	This command is used to show the sFlow flow_sampler configured for ports. The actual value rate is 256 times the displayed rate value. There are two types of rates. The Configured Rate is configured by the user. In order to limit the number of packets sent to the CPU when the rate of traffic to the CPU is high, the sampling rate will be decreased. This is specified as the active rate.
Parameters	None.
Restrictions	None.

Example usage:

To show the sFlow flow_sampler information of ports which have been created:

DGS-3627:admin# show sflow flow_sampler

Command: show sflow flow_sampler

Port	Analyzer Server ID	Configured Rx Rate	Configured Tx Rate	Active Rx Rate	Active Tx Rate	Max Header Size
10	1	1	2	0	0	20

Total Entries: 1

DGS-3627:admin#

show sflow flow_poller

Purpose	Used to display the sFlow counter_poller information of ports which have been created.
Syntax	show sflow counter_poller
Description	This command is used to show the sFlow counter_pollers which have been configured for port.
Parameters	None.
Restrictions	None.

Example usage:

To show the sFlow counter_poller information of ports which have been created:

DGS-3627:admin# show sflow counter_poller

Command: show sflow counter_poller

Port	Analyzer Server ID	Polling Interval (secs)
1	1	disable

Total Entries: 1

DGS-3627:admin#

show sflow analyzer_server

Purpose	Used to display the sFlow analyzer server information.
Syntax	show sflow analyzer_server
Description	This command is used to show the sFlow analyzer_server information. The Timeout field specifies the time configured by user. The Current Countdown Time is the current time remaining before the server timeout.
Parameters	None.
Restrictions	None.

Example usage:

To show the sFlow flow_sampler information of ports which have been created:


```
DGS-3627:admin# show sflow analyzer_server
```

```
Command: show sflow analyzer_server
```

```
sFlow Analyzer_server Information
```

```
-----
```

```
Server ID           : 1  
Owner               : 1  
Timeout             : Infinite  
Current Countdown Time : Infinite  
Collector Address   : 10.0.0.1  
Collector Port      : 655  
Max Datagram Size  : 301
```

```
Total Entries: 1
```

```
DGS-3627:admin#
```

SIMPLE NETWORK MANAGEMENT PROTOCOL (SNMP) COMMANDS

The Simple Network Management Protocol (SNMP) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create snmp community	<community_string 32> view <view_name 32> [read_only read_write]
delete snmp community	<community_string 32>
show snmp community	{ <community_string 32> }
create snmp user	<user_name 32> <groupname 32> {encrypted [by_password auth [md5 <auth_password 8-16 > sha <auth_password 8-20 >] priv [none des <priv_password 8-16>] by_key auth [md5 <auth_key 32-32> sha <auth_key 40-40>] priv [none des <priv_key 32-32>]]}
delete snmp user	<user_name 32>
show snmp user	
create snmp group	<groupname 32> [v1 v2c v3 [noauth_nopriv auth_nopriv auth_priv]] {read_view <view_name 32> write_view <view_name 32> notify_view <view_name 32>}
delete snmp group	<groupname 32>
show snmp groups	
create snmp view	<view_name 32> <oid> view_type [included excluded]
delete snmp view	<view_name 32> [all <oid>]
show snmp view	{<view_name 32>}
create snmp	[host <ipaddr> v6host <ipv6addr>] [v1 v2c v3 [noauth_nopriv auth_nopriv auth_priv]] <auth_string 32>
delete snmp	[host <ipaddr> v6host <ipv6addr>]
show snmp host	{ <ipaddr> }
show snmp v6host	{ <ipv6addr> }
config snmp engineID	<snmp_engineID 10-64>
show snmp engineID	

Each command is listed, in detail, in the following sections.

create snmp community view

Purpose	Use an SNMP community string to define the relationship between the SNMP manager and the agent. The community string acts like a password to permit access to the agent on the switch. You can specify one or more of the following characteristics associated with the string:
---------	---

create snmp community view

	<p>An access list of IP addresses of the SNMP managers that are permitted to use the community string to gain access to the agent.</p> <p>A MIB view, which defines the subset of all MIB objects accessible to the given community. Read and write or read-only permission for the MIB objects accessible to the community.</p>
Syntax	create snmp community <community_string 32> view <view_name 32> [read_only read_write]
Description	The create snmp community command is used to creates an SNMP community string. This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.
Parameters	<p><i><community_string 32></i> - Community string. Max string length is 32. The acceptable chars for community string are the same as a general octet string, except that '#' is not accepted.</p> <p><i>view</i> - A MIB view name.</p> <p><i>[read_only read_write]</i> - Read and write or read-only permission. Allows the user using the above community string to have read only or read and write access to the switch's SNMP agent.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a read-only level SNMP community "System" with a "CommunityView" view:

```
DGS-3627:admin# create snmp community System view CommunityView read_only
Command: create snmp community System view CommunityView read_only
```

Success.

```
DGS-3627:admin#
```

show snmp community

Purpose	This command is used to display the community string configurations.
Syntax	show snmp community { <community_string> }
Description	The show snmp community command displays the community string configurations. Note: This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.
Parameters	<p><i>community_string</i> - Community string.</p> <p>If not specify community string , all community string information will be displayed.</p>
Restrictions	None.

Example usage:

To display SNMP community:

```
DGS-3627:admin# show snmp community
Command: show snmp community

SNMP Community Table
Community Name          View Name              Access Right
-----
private                 CommunityView          read_write
public                  CommunityView          read_only

Total Entries : 2

DGS-3627:admin#
```

create snmp user

Purpose	This command is used to create a new user to an SNMP group originated by this command.
Syntax	create snmp user <username 32> <groupname 32> {encrypted [by_password auth [md5 <auth_password 8-16 > sha <auth_password 8-20 >] priv [none des <priv_password 8-16>] by_key auth [md5 <auth_key 32-32> sha <auth_key 40-40>] priv [none des <priv_key 32-32>]]}
Description	The create snmp user command creates a new user to an SNMP group originated by this command. User can chose input authentication and privacy by password or by key. Note: This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.
Parameters	<i>username</i> - The name of the user on the host that connects to the agent. The range is 1 to 32. <i>groupname</i> - The name of the group to which the user is associated. The range is 1 to 32. <i>encrypted</i> - Specifies whether the password appears in encrypted format. <i>by_password</i> - Indicate input password for authentication and privacy. <i>by_key</i> - Indicate input key for authentication and privacy. <i>auth</i> - Initiates an authentication level setting session. The options are md5 and sha. <i>md5</i> - The HMAC-MD5-96 authentication level. <i>sha</i> - The HMAC-SHA-96 authentication level. <i>auth_password</i> - An authentication string used by MD5 or SHA1. <i>priv_password</i> - A privacy string used by DES. <i>auth_key</i> - An authentication key used by MD5 or SHA1, it is hex string type. <i>priv_key</i> - A privacy key used by DES, it is hex string type.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a SNMP user "user123" with group "group123":

```
DGS-3627:admin# create snmp user user123 group123 encrypted by_password auth md5
12345678 priv des 12345678
Command: create snmp user user123 group123 encrypted by_password auth md5
12345678 priv des 12345678

Success.

DGS-3627:admin#
```

delete snmp user

Purpose	This command is used to remove a user from an SNMP group and delete the associated group in SNMP group.
Syntax	delete snmp user <username 32>
Description	The delete snmp user command removes a user from a SNMP group and deletes the associated group in SNMP group. Note: This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.
Parameters	<username32> - The name of the user on the host that connects to the agent. The range is 1 to 32.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete a SNMP user "user123":

```
DGS-3627:admin# delete snmp user user123
Command: delete snmp user user123

Success.

DGS-3627:admin#
```

show snmp user

Purpose	This command is used to display information on each SNMP username in the group username table.
Syntax	show snmp user
Description	The show snmp user command displays information on each SNMP username in the group username table. Note: This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.
Parameters	None.
Restrictions	None.

Example usage:

To show SNMP user:

```
DGS-3627:admin# show snmp user
Command: show snmp user

Username                               Group Name                               VerAuthPriv
-----                               -
initial                                 initial                                 V3 NoneNone
user123                                 group123                               V3 MD5 DES

Total Entries : 2

DGS-3627:admin#
```

create snmp group

Purpose	This command is used to create a new SNMP group, or a table that maps SNMP users to
---------	---

create snmp group

	SNMP views.
Syntax	create snmp group <groupname 32> [v1 v2c v3 [noauth_nopriv auth_nopriv auth_priv]] {read_view <view_name 32> write_view <view_name 32> notify_view <view_name 32>}
Description	The create snmp group command creates a new SNMP group. Note: This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.
Parameters	<i>groupname</i> - The name of the group. <i>v1</i> - The least secure of the possible security models. <i>v2c</i> - The second least secure of the possible security models. <i>v3</i> - The most secure of the possible. Specifies authentication of a packet. <i>noauth_nopriv</i> - Neither support packet authentication nor encrypting. <i>auth_nopriv</i> - Support packet authentication. <i>auth_priv</i> - Support packet authentication and encrypting. <i>view_name</i> - View name.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create SNMP group "group123":

```
DGS-3627:admin# create snmp group group123 v3 auth_priv read_view CommunityView w
rite_view CommunityView notify_view CommunityView
Command: create snmp group group123 v3 auth_priv read_view CommunityView write_v
iew CommunityView notify_view CommunityView

Success.

DGS-3627:admin#
```

delete snmp group

Purpose	This command is used to remove a SNMP group.
Syntax	delete snmp group <groupname 32>
Description	The delete snmp group command removes a SNMP group. Note: This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.
Parameters	<i><groupname 32></i> - The name of the group will be deleted.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete SNMP group "group123":

```
DGS-3627:admin# delete snmp group group123
Command: delete snmp group group123

Success.

DGS-3627:admin#
```

show snmp groups

Purpose	This command is used to display the names of groups on the switch and the security model, level, the status of the different views.
Syntax	show snmp groups
Description	The show snmp groups command displays the names of groups on the switch and the security model, level, the status of the different views. Note: This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.
Parameters	None.
Restrictions	None.

Example usage:

To show SNMP groups:

```
DGS-3627:admin# show snmp groups
```

```
Command: show snmp groups
```

```
Vacm Access Table Settings
```

```
Group Name : public
ReadView Name : CommunityView
WriteView Name :
Notify View Name : CommunityView
Security Model : SNMPv1
Security Level : NoAuthNoPriv
```

```
Group Name : public
ReadView Name : CommunityView
WriteView Name :
Notify View Name : CommunityView
Security Model : SNMPv2
Security Level : NoAuthNoPriv
```

```
Group Name : initial
ReadView Name : restricted
WriteView Name :
Notify View Name : restricted
Security Model : SNMPv3
Security Level : NoAuthNoPriv
```

```
Group Name : private
ReadView Name : CommunityView
WriteView Name : CommunityView
Notify View Name : CommunityView
Security Model : SNMPv1
Security Level : NoAuthNoPriv
```

```
Group Name : private
ReadView Name : CommunityView
WriteView Name : CommunityView
Notify View Name : CommunityView
Security Model : SNMPv2
Security Level : NoAuthNoPriv
```

```
Group Name : group123
ReadView Name : view123
WriteView Name : view123
Notify View Name : view123
Security Model : SNMPv3
Security Level : authPriv
```

```
Group Name : ReadGroup
ReadView Name : CommunityView
WriteView Name :
Notify View Name : CommunityView
Security Model : SNMPv1
Security Level : NoAuthNoPriv
```

```
Group Name : ReadGroup
ReadView Name : CommunityView
WriteView Name :
Notify View Name : CommunityView
Security Model : SNMPv2
```



```

Securiy Level      : NoAuthNoPriv

Group   Name      : WriteGroup
ReadView Name     : CommunityView
WriteView Name    : CommunityView
Notify View Name  : CommunityView
Securiy Model     : SNMPv1
Securiy Level     : NoAuthNoPriv

Group   Name      : WriteGroup
ReadView Name     : CommunityView
WriteView Name    : CommunityView
Notify View Name  : CommunityView
Securiy Model     : SNMPv2
Securiy Level     : NoAuthNoPriv

Total Entries: 10

DGS-3627:admin#
    
```

create snmp view

Purpose	This command is used to assign views to community strings to limit which MIB objects an SNMP manager can access.
Syntax	create snmp view <view_name 32> <oid> view_type [included excluded]
Description	The create snmp view command assigns views to community strings to limit which MIB objects an SNMP manager can access. Note: This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.
Parameters	<i>view_name</i> - View name to be created. <i>oid</i> - Object-Identified tree, MIB tree. <i>view_type</i> - Specify the access type of the MIB tree in this view. <i>included</i> - Includes for this view. <i>excluded</i> - Excluded for this view.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create SNMP view "view123":

```

DGS-3627:admin# create snmp view view123 1.3.6 view_type included
Command: create snmp view view123 1.3.6 view_type included

Success.

DGS-3627:admin#
    
```

delete snmp view

Purpose	This command is used to remove a view record.
Syntax	delete snmp view <view_name 32> [all <oid>]
Description	The delete snmp view command removes a view record. Note: This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.
Parameters	<i>view_name</i> - View name to be deleted.

delete snmp view

all - All view record.

oid - Object-Identified tree, MIB tree.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To delete SNMP view "view123":

```
DGS-3627:admin# delete snmp view view123 all
```

```
Command: delete snmp view view123 all
```

```
Success.
```

```
DGS-3627:admin#
```

show snmp view

Purpose

This command is used to display the SNMP view record.

Syntax

show snmp view {<view_name 32>}

Description

The show snmp view command displays the SNMP view record.

Parameters

view_name - View name of the user who likes to show.

Restrictions

None.

Example usage:

To show SNMP view:

```
DGS-3627:admin# show snmp view
```

```
Command: show snmp view
```

```
Vacm View Table Settings
```

View Name	Subtree	View Type
view123	1.3.6	Included
restricted	1.3.6.1.2.1.1	Included
restricted	1.3.6.1.2.1.11	Included
restricted	1.3.6.1.6.3.10.2.1	Included
restricted	1.3.6.1.6.3.11.2.1	Included
restricted	1.3.6.1.6.3.15.1.1	Included
CommunityView	1	Included
CommunityView	1.3.6.1.6.3	Excluded
CommunityView	1.3.6.1.6.3.1	Included

```
Total Entries: 9
```

```
DGS-3627:admin#
```

create snmp host

Purpose

This command is used to create a recipient of an SNMP trap operation.

Syntax

create snmp [host <ipaddr> | v6host <ipv6addr>] [v1 | v2c | v3 [noauth_nopriv | auth_nopriv | auth_priv]] <auth_string 32>

create snmp host

Description	The create snmp host command creates a recipient of an SNMP operation. Note: This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.
Parameters	<p><ipaddr> - The IP address of the recipient for which the traps are targeted.</p> <p><ipv6addr> - Specifies the IPv6 host address to which the trap packet will be sent.</p> <p>v1 - The least secure of the possible security models.</p> <p>v2c - The second least secure of the possible security models.</p> <p>v3 - The most secure of the possible.</p> <p> noauth_nopriv - Neither support packet authentication nor encrypting.</p> <p> auth_nopriv - Support packet authentication.</p> <p> auth_priv - Support packet authentication and encrypting.</p> <p><auth_string 32> - Authentication string. If the v1 or v2 is specified, the auth_string presents the community string, and it must be one of the entries in community table. If the v3 is specified, the auth_string presents the user name, and it must be one of the entries in the user table.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create SNMP host "10.0.0.1" with community string "public":

```
DGS-3627:admin# create snmp host 10.0.0.1 v1 public
Command: create snmp host 10.0.0.1 v1 public

Success.

DGS-3627:admin#
```

To create SNMP host "3FFE::51" with community string "public":

```
DGS-3627:admin# create snmp v6host 3FFE::51 v1 public
Command: create snmp v6host 3FFE::51 v1 public

Success.

DGS-3627:admin#
```

To create SNMP host "3FFE::4" with user name "user123":

```
DGS-3627:admin# create snmp v6host 3FFE::4 v3 auth_nopriv user123
Command: create snmp v6host 3FFE::4 v3 auth_nopriv user123

Success.

DGS-3627:admin#
```

delete snmp host

Purpose	This command is used to delete a recipient of an SNMP trap operation.
Syntax	delete snmp [host <ipaddr> v6host <ipv6addr>]
Description	The delete snmp host command deletes a recipient of an SNMP trap operation. Note: This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.

delete snmp host

Parameters	<i>host</i> - The IP address of the recipient for which the traps are targeted. <i>v6host</i> - Specifies the IPv6 host address.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete SNMP host "10.0.0.1":

```
DGS-3627:admin# delete snmp host 10.0.0.1
Command: delete snmp host 10.0.0.1

Success.

DGS-3627:admin#
```

show snmp host

Purpose	This command is used to display the recipient for which the traps are targeted.
Syntax	show snmp host { <ipaddr> }
Description	The show snmp host command displays the recipient for which the traps are targeted. Note: This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.
Parameters	<i>host</i> - The IP address of the recipient for which the traps are targeted. If no parameter specified, all SNMP hosts will be displayed.
Restrictions	None.

Example usage:

To show SNMP host:

```
DGS-3627:admin# show snmp host
Command: show snmp host

SNMP Host Table
Host IP Address  SNMP Version      Community Name / SNMPv3 User Name
-----
10.90.90.3      V3 noauthnopriv  initial
10.90.90.2      V2c               private
10.90.90.1      V1                public
10.90.90.4      V3 authnopriv    user123
10.90.90.5      V3 authpriv      user234

Total Entries : 5

DGS-3627:admin#
```

show snmp v6host

Purpose	This command is used to display the recipient for which the traps are targeted.
Syntax	show snmp v6host { <ipv6addr> }
Description	The show snmp v6host command displays the recipient for which the traps are targeted.

show snmp v6host

	Note: This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.
Parameters	<i>v6host</i> - Specifies the IPv6 host address. If no parameter specified, all SNMP hosts will be displayed.
Restrictions	None.

Example usage:

To show SNMP host:

```
DGS-3627:admin# show snmp v6host
Command: show snmp v6host

SNMP Host Table
-----
Host IPv6 Address : 3FFE::3
SNMP Version      : V3 na/np
Community Name/SNMPv3 User Name : initial

Host IPv6 Address : 3FFE::2
SNMP Version      : V2c
Community Name/SNMPv3 User Name : private

Host IPv6 Address : 3FFE::1
SNMP Version      : V1
Community Name/SNMPv3 User Name : public

Host IPv6 Address : 3FFE::3
SNMP Version      : V3 a/np
Community Name/SNMPv3 User Name : user123

Host IPv6 Address : 3FFE::3
SNMP Version      : V3 a/ p
Community Name/SNMPv3 User Name : user234

Total Entries: 5

DGS-3627:admin#
```

config snmp engineID

Purpose	This command is used to configure a identifier for the SNMP engine on the switch.
Syntax	config snmp engineID <snmp_engineID>
Description	The config snmp engineID command configures an identifier for the SNMP engine on the switch. Associated with each SNMP entity is a unique engineID. Note: This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.
Parameters	<i>snmp_engineID</i> - Identify for the SNMP engine on the switch. It is octet string type. It accepts the hex number directly.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure SNMP engine ID to "1023457890":

```
DGS-3627:admin# config snmp engineID 1023457890
Command: config snmp engineID 1023457890

Success.

DGS-3627:admin#
```

show snmp engineID

Purpose	This command is used to display the identification of the SNMP engine on the switch.
Syntax	show snmp engineID
Description	The show snmp engineID command displays the identification of the SNMP engine on the switch. The default value is suggested in RFC2271. The very first bit is 1, and the first four octets are set to the binary equivalent of the agent's SNMP management private enterprise number as assigned by IANA, D_Link is 171. The fifth octet is 03 to indicates the rest is the MAC address of this device. The 6th –11th octets is MAC address. Note: This is SNMPv3 command, if it is used; All SNMPv1/v2 commands are not necessary.
Parameters	None.
Restrictions	None.

Example usage:

To show SNMP engine ID:

```
DGS-3627:admin# show snmp engineID
Command: show snmp engineID

SNMP Engine ID : 1023457890

DGS-3627:admin#
```

STACKING COMMANDS

Stacking protocol is a special communication mechanism between devices. It is responsible for allowing multiple devices to combine together, working in the same configuration. To users, these devices work as a whole.

Stacking devices can provide more network bandwidth and reliability for users. A device down will not influence other devices in the same stacking topology.

The Stacking commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config stacking_mode	[disable enable]
show stacking_mode	
config box_priority current_box_id	<value 1-12> priority <value 1-63>
config box_id current_box_id	<value 1-12> new_box_id [auto <value 1- 12>
show stack_information	
show stack_device	
config stacking force_master_role state	[enable disable]

Each command is listed, in detail, in the following sections.

config stacking_mode

Purpose	Used to configure the stacking mode.
Syntax	config stacking_mode [disable enable]
Description	The config stacking_mode command configures the state of the stacking function. By default stacking mode is disabled. Administrators need to specifically configure the stacking mode to make the switch stackable. The user can only change the stacking mode when the Switch is operating in standalone mode.
Parameters	<i>stacking_mode</i> - Used to enable or disable the switch's stacking capability.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable stacking mode:

```
DGS-3627:admin# config stacking_mode enable
Command: config stacking_mode enable
```

```
Changing the stacking mode may cause the device to restart. Do you still want to
continue?(y/n) y
Please wait, the switch is rebooting...
```

show stacking_mode

Purpose	Used to display the current stacking mode.
Syntax	show stacking_mode
Description	The show stacking_mode command displays the current stacking mode.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To display the stacking mode:

```
DGS-3627:admin# show stacking_mode
Command: show stacking_mode

Stacking mode   : Enabled

DGS-3627:admin#
```

config box_priority

Purpose	Used to configure the box priority of the switch.
Syntax	config box_priority current_box_id <value 1-12> priority <value 1-63>
Description	The config box_priority command configures the box priority of the switch, which determines the box that will become the master. A lower number means a higher priority. The new priority will take effect after the user reboots the switch.
Parameters	<i>current_box_id</i> - Specifies the switch being configured. The range is 1-12. For example, for the DGS34xx series the ID is 12; for the DGS36xx series the priority is 8. <i>priority</i> - Specifies the priority assigned to the box, with a lower number meaning a higher priority. The range is 1-63.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the box priority of the Switch to have an ID of 1 and a priority value of 1:

```
DGS-3627:admin# config box_priority current_box_id 1 priority 1
Command: config box_priority current_box_id 1 priority 1

Success.

DGS-3627:admin#
```

config box_id

Purpose	Used to configure the box ID. Users can use this command to reassign box IDs.
Syntax	config box_id current_box_id <value 1-12 > new_box_id [auto <value 1- 12>]
Description	The config box_id command configures the box ID. By default, the box ID is automatically assigned by the system based topology election results. Administrators can assign box IDs statically. The new box ID will take effect after the unit reboots. Each unit in the Switch stack must have a unique box ID. If there are duplicate IDs, the stack system will not stack properly.

config box_id

Parameters	<p><i>current_box_id</i> - Specifies the switch being configured. The parameter range is 1-12. For example, for the DGS34xx series the ID is 12; for the DGS36xx series the ID is 8.</p> <p><i>new_box_id</i> - Specifies the new ID that will be assigned to the box. The parameter range is 1-12.</p> <p><i>auto</i> - Allows the box ID to be assigned automatically by the stack system. The new box ID will take effect after the next reboot.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the Switch that has a current box ID of 1 to have an automatic ID assigned by the Switch:

```
DGS-3627:admin# config box_id current_box_id 1 new_box_id auto
Command: config box_id current_box_id 1 new_box_id auto
```

Success.

```
DGS-3627:admin#
```

show stack_information

Purpose	Used to display the stack information.
Syntax	show stack_information
Description	The show stack_information command displays stacking information.
Parameters	None.
Restrictions	None.

Example usage:

To display the stack information:

DGS-3627:admin# show stack_information

Command: show stack_information

Topology :Duplex_Chain
 My Box ID :3
 Master ID :3
 Box Count :1
 Force Master Role: Enable

Box ID	User Set	Type	Exist	Prio- rity	MAC	Prom Version	Runtime Version	H/W Version
1	-	DGS-3627	No					
2	-	NOT_EXIST	No					
3	User	DGS-3627	Exist	0	00-00-11-33-66-33	1.00.B007	2.00.B033	A1
4	-	NOT_EXIST	No					
5	-	NOT_EXIST	No					
6	-	NOT_EXIST	No					
7	-	NOT_EXIST	No					
8	-	NOT_EXIST	No					

DGS-3627:admin#

show stack_device

Purpose	Used to display information about the devices in the stack.
Syntax	show stack_device
Description	The show stack_device command displays stack device information.
Parameters	None.
Restrictions	None.

Example usage:

To display the stack device information:

DGS-3627:admin# show stack_device

Command: show stack_device

Box ID	Box Type	H/W Version	Serial Number
1	DGS-3627	0A1	1234567890123
3	DGS-3627	0A1	2345678901234

DGS-3627:admin#

config stacking force_master_role

Purpose	This command is used to configure the stacking force master role state.
Syntax	config stacking force_master_role state [enable disable]
Description	This command is used to ensure the master role is unchanged when new device add to

config stacking force_master_role

	current stacking topology. If the state is enabled, the master's priority will become zero after the stacking has stabilized.
Parameters	<i>force_master_role</i> - Used to enable or disable the switch's Stacking Force Master Role state. The default setting is disabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the stacking force master role state:

```
DGS-3627:admin# config stacking force_master_role state enable
Command: config stacking force_master_role state enable
```

Success.

```
DGS-3627:admin#
```

STATIC MAC-BASED VLAN COMMANDS

The Static MAC-Based VLAN commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

For bridges that implement MAC-based VLAN classification, the VID associated with an Untagged or Priority-tagged Frame is determined based on the source MAC address. The each entry of VLAN_MAC table specifies a relationship for a source MAC address with a VLAN. If the source MAC address of ingress untagged or priority-tagged frame is match with the entry, the VLAN of the frame will be assigned according VLAN assignment rule in the entry.

Command	Parameters
create mac_based_vlan mac_address	<macaddr> vlan [<vlan_name 32> vlanid <vlanid 1-4094>]
delete mac_based_vlan	[mac_address <macaddr> all]
show mac_based_vlan	{mac_address <macaddr> [vlan <vlan_name 32>]}

Each command is listed, in detail, in the following sections.

create mac_based_vlan

Purpose	Used to create a static mac-based vlan entry.
Syntax	create mac_based_vlan mac_address <macaddr> [vlan <vlan_name 32> vlanid <vlanid 1-4094>]
Description	<p>The user can use this command to create a static mac-based VLAN entry.</p> <p>When a static mac_based_vlan entry is created for a user, the traffic from this user will be able to be serviced under the specified VLAN regardless of the authentication function operated on this port.</p> <p>There is a global limitation of the maximum entries supported for the static mac-based entry. It is 1024.</p>
Parameters	<p><i>mac_address</i> – The MAC address.</p> <p><i>vlan</i> – The VLAN to be associated with the MAC address.</p> <p><i>vlanid</i> - The VLAN ID to be associated with the MAC address.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage

To create mab_local:

```
DGS-3627:admin# create mac_based_vlan mac_address 00-00-00-00-00-01 vlan default
Command: create mac_based_vlan mac_address 00-00-00-00-00-01 vlan default

Success.

DGS-3627:admin#
```

delete mac_based_vlan

Purpose	Used to delete the static MAC-based VLAN entry.
Syntax	delete mac_based_vlan [mac_address <macaddr> all]
Description	Use this command to delete a database entry. If the mac_address and vlan is not specified, all static entries associated with the port will be removed.
Parameters	<i>mac_address</i> – The MAC address.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage

To delete a static mac-based-vlan entry:

```
DGS-3627:admin# delete mac_based_vlan mac_address 00-00-00-00-00-01 vlan default
Command: delete mac_based_vlan mac mac_address 00-00-00-00-00-01 vlan default

Success.

DGS-3627:admin#
```

show mac_based_vlan

Purpose	Used to show the static or dynamic MAC-based VLAN entry.
Syntax	show mac_based_vlan {mac_address <macaddr> [vlan <vlan_name 32>]}
Description	User can use this command to display the static or dynamic MAC-Based VLAN entry.
Parameters	<i>mac_address</i> – Specifies the entry that you would like to display. <i>vlan</i> – Specifies the VLAN to be associated with the MAC address that you would like to display.
Restrictions	None.

Example usage

To display the static MAC-based VLAN entry:

```
DGS-3627:admin# show mac_based_vlan
Command: show mac_based_vlan

MAC Address          VLAN      Status      Type
-----
00-80-e0-14-a7-57    200       Active      Static
00-80-c2-33-c3-45    200       Inactive    Mac based access control
00-80-c2-33-c3-45    300       Active      JWAC
00-80-c2-33-c3-90    400       Active      WAC
00-a2-44-17-32-98    500       Active      Multiple Authentication
00-a2-44-17-32-97    500       Active      802.1x
Total Entries : 6

DGS-3627:admin#
```

STATIC MULTICAST ROUTE COMMANDS

The static multicast route commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

IP multicast static routes are used to configure static RPF check paths that don't depend on the unicast route table. The main goal of IP multicast static routes is to let multicast traffic diverge from unicast traffic.

Command	Parameters
create ipmroute	<network_address> rpf_address [<ipaddr> null]
delete ipmroute	[<network_address> all]
show ipmroute	{ <network_address> }

Each command is listed, in detail, in the following sections.

create ipmroute

Purpose	Used to create an ip multicast static route configuration entry.
Syntax	create ipmroute <network_address> rpf_address [<ipaddr> null]
Description	Normally, when a IP multicast packet is received, the source IP address of the packet is used to do the RPF check. When an RPF network is configured for network, and the source IP address of the received IP multicast packet matches this network, the RPF network will be used to do RPF check.
Parameters	<p><i>network_address</i> – If the source IP address of the received IP multicast packet matches this network, the RPF network is used to do RPF check.</p> <p><i>ipaddr</i> – If it specifies a ip address, if the source IP address of the received IP multicast packet match <i>network_address</i>, <i>ipaddr</i> will be used to check whether packet receive from legal upstream interface. If it is set to null, it means that if the source IP address in the received IP multicast packet match <i>network_address</i>, RPF check will always fail.</p>
Restrictions	Only Administrator and Operator-level users can issue this command. Current, static multicast routes only support PIM environment.

Usage example:

To create an IP multicast static route entry:

```
DGS-3627:admin# create ipmroute 10.0.0.9/8 rpf_address 20.1.1.1
Command: create ipmroute 10.0.0.9/8 rpf_address 20.1.1.1

Success.

DGS-3627:admin#
```

delete ipmroute

Purpose	Used to delete an IP multicast static route configuration entry.
Syntax	delete ipmroute [<network_address> all]

delete ipmroute

Description	Deletes an IP multicast static route configuration entry.
Parameters	<i>network_address</i> – The entry corresponds to the specified network to be deleted. <i>all</i> – All configured entries will be removed.
Restrictions	Only Administrator and Operator-level users can issue this command.

Usage example:

To delete an IP multicast static route entry:

```
DGS-3627:admin# delete ipmroute 10.0.0.9/8
Command: delete ipmroute 10.0.0.9/8

Success.

DGS-3627:admin#
```

show ipmroute

Purpose	Used to display an IP multicast static route configuration entry.
Syntax	show ipmroute { <network_address>}
Description	The show ipmroute command displays the RPF check entry to a source IP address range.
Parameters	<i>network_address</i> – The network address that will be used, if the IP multicast packet received matches it, the RPF address configured will be used to do the RPF check.
Restrictions	None.

Usage example:

To display an IP multicast static route entry:

```
DGS-3627:admin# show ipmroute 10.0.0.0/8
Command: show ipmroute 10.0.0.0/8

Index      Source IP Address      RPF IP Address
-----
1          10.0.0.0/8            20.1.1.1

Total Entries : 1

DGS-3627:admin#
```

SUBNET VLAN COMMANDS

The Subnet VLAN commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create subnet_vlan	[network <network_address> ipv6network <ipv6networkaddr>] [vlan <vlan_name 32> vlanid <vlanid 1-4094>] {priority <value 0-7>}
delete subnet_vlan	[network <network_address> ipv6network <ipv6networkaddr>] vlan <vlan_name 32> vlanid <vidlist> all]
show subnet_vlan	{[network<network_address> ipv6network <ipv6networkaddr>] vlan <vlan_name 32> vlanid <vidlist>]}
config vlan_precedence ports	<portlist> [mac_based_vlan subnet_vlan]
show vlan_precedence ports	{<portlist>}

Each command is listed, in detail, in the following sections.

create subnet_vlan

Purpose	Use this command to create a subnet VLAN entry.
Syntax	create subnet_vlan [network <network_address> ipv6network <ipv6networkaddr>] [vlan <vlan_name 32> vlanid <vlanid 1-4094>] {priority <value 0-7>}
Description	The user can use this command to create a subnet VLAN entry. A subnet VLAN entry is an IP subnet-based VLAN classification rule. If an untagged or priority-tagged IP packet is received on a port, its source IP address will be used to match the subnet VLAN entries. If the source IP is in the subnet of an entry, the packet will be classified to the VLAN defined for this subnet.
Parameters	<i>network</i> - To specify an IPv4 network address. The format is ipaddress/prefix length. <i>ipv6network</i> - To specify an IPv6 network address. The format is ipaddress/prefix length. The prefix length of IPv6 network address shall not be greater than 64. <i>vlan</i> - The vlan to be associated with the subnet. You can specify a vlan name or vlan ID. The vlan must be existed static vlan. <i>priority</i> - The priority to be associated with the subnet. Its range is 0-7.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

This example shows how to create a subnet VLAN entry:

```
DGS-3627:admin# create subnet_vlan network 172.168.1.0/24 vlan v2 priority 2
Command: create subnet_vlan network 172.168.1.0/24 vlan v2 priority 2

Success.

DGS-3627:admin#
```


This example shows how to create an IPv6 subnet VLAN entry:

```
DGS-3627:admin# create subnet_vlan ipv6network FE80::/64 vlan v2 priority 2
Command: create subnet_vlan ipv6network FE80::/64 vlan v2 priority 2

Success.

DGS-3627:admin#
```

delete subnet_vlan

Purpose	Use this command to delete subnet vlan entry.
Syntax	delete subnet_vlan [network <network_address> ipv6network <ipv6networkaddr>] vlan <vlan_name 32> vlanid <vidlist> all]
Description	This command is used to delete subnet vlan entry from switch. You can delete subnet vlan entry by IP subnet or vlan, or delete all subnet vlan entries.
Parameters	<p><i>network</i> - To specify an IPv4 network address or IPv6 network address. The format is ipaddress / prefix length.</p> <p><i>ipv6network</i> - To specify an IPv6 network address. The format is ipaddress / prefix length. The prefix length of IPv6 network address shall not be greater than 64.</p> <p><i>vlan</i> - If specify the vlan, all subnet vlan entries that associated with this vlan will be deleted.</p> <p><i>vidlist</i> - Specifies a list of VLANs by VLAN ID.</p> <p><i>all</i> - If specify all, all subnet vlan entries will be deleted.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

This example shows how to delete a subnet VLAN entry:

```
DGS-3627:admin# delete subnet_vlan network 172.168.1.0/24
Command:delete subnet_vlan network 172.168.1.0/24

Success.

DGS-3627:admin#
```

This example shows how to delete all subnet VLAN entries:

```
DGS-3627:admin# delete subnet_vlan all
Command:delete subnet_vlan all

Success.

DGS-3627:admin#
```

show subnet_vlan

Purpose	Use this command to display subnet vlan entry information.
Syntax	show subnet_vlan {[network<network_address> ipv6network <ipv6networkaddr>] vlan <vlan_name 32> vlanid <vidlist>}]
Description	This command is used to display subnet vlan entry information.
Parameters	<i>network</i> - To specify an IPv4 network address. If network address is not specified, all subnet

show subnet_vlan

VLAN entries will be displayed.

ipv6network - To specify an IPv6 network address. If network address is not specified, all subnet VLAN entries will be displayed.

vlan - If specify the vlan, all subnet vlan entries that associated with this vlan will be displayed. If no parameter is specified, all subnet vlan entries will be displayed.

vidlist - Specifies a list of VLANs by VLAN ID.

Restrictions

None.

Example usage:

This example shows how to show a specified subnet VLAN entry:

```
DGS-3627:admin# show subnet_vlan network 172.168.1.0/24
Command:show subnet_vlan network 172.168.1.0/24
```

IP Address/Subnet Mask	VLAN	Priority
172.168.1.0/255.255.255.0	10	2

```
DGS-3627:admin#
```

This example shows how to display a specified IPv6 subnet VLAN entry:

```
DGS-3627:admin# show subnet_vlan ipv6network FE80::/64
Command: show subnet_vlan ipv6network FE80::/64
```

IP Address/Subnet Mask	VLAN	Priority
fe80::/64	10	2

```
DGS-3627:admin#
```

This example shows how to show all subnet VLAN entries:

```
DGS-3627:admin# show subnet_vlan
Command:show subnet_vlan
```

IP Address/Subnet Mask	VLAN	Priority
172.168.1.0/255.255.255.0	10	2
172.18.211.0/255.255.255.0	20	3
fe80::/64	10	2

Total Entries : 3

```
DGS-3627:admin#
```

config vlan_precedence ports

Purpose

Use this command to configure the vlan classification precedence.

Syntax

config vlan_precedence ports <portlist> [mac_based_vlan | subnet_vlan]

Description

This command is used to configure vlan classification precedence on each port.

You can specify the order of MAC-based VLAN classification and subnet VLAN classification.

If a port's VLAN classification is MAC-based precedence, MAC-based VLAN classification

config vlan_precedence ports

	will process at first. If MAC-based VLAN classification fails, the subnet VLAN classification will be executed. If a port's VLAN classification is subnet VLAN precedence, the subnet VLAN classification will process at first. If subnet VLAN classification fails, the MAC-based VLAN classification will be executed.
Parameters	<i>portlist</i> - A range of ports to configure. <i>mac_based_vlan</i> - If the parameter is specified, the MAC-based VLAN classification is precedence than subnet VLAN classification. <i>subnet_vlan</i> - If the parameter is specified, the subnet VLAN classification is precedence than MAC-based VLAN classification.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

This example shows how to configure subnet VLAN classification precedence on port 1:

```
DGS-3627:admin# config vlan_precedence 1 subnet_vlan
Command: config vlan_precedence 1 subnet_vlan

Success.

DGS-3627:admin#
```

show vlan_precedence ports

Purpose	Use this command to show vlan classification precedence.
Syntax	show vlan_precedence ports {<portlist>}
Description	This command is used to show vlan classification precedence.
Parameters	<i>portlist</i> - A range of ports will display. If no parameters is specified, all ports vlan classification precedence will display.
Restrictions	None.

Example usage:

This example shows how to display VLAN classification precedence on ports 1-3::

```
DGS-3627:admin# show vlan_precedence ports 1-3
Command: show vlan_precedence ports 1-3

Port      VLAN Precedence
----      -
1         MAC-Based VLAN
2         Subnet VLAN
3         MAC-Based VLAN

DGS-3627:admin#
```

SUPER VLAN COMMANDS

The Super VLAN commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create super_vlan	[<vlan_name 32> vlanid <vlanid 1-4094>] {sub_vlan <vidlist>}
config super_vlan	[<vlan_name 32 > vlanid <vlanid 1-4094>] [add delete] sub_vlan <vidlist>
delete super_vlan	[<vlan_name 32 > vlanid <vlanid 1-4094>]
config sub_vlan	[<vlan_name 32> vlanid <vlanid 1-4094>] [add delete] ip_range <ipaddr> to <ipaddr>
show super_vlan	{{<vlan_name 32 > vlanid <vlanid 1-4094>}}
show sub_vlan	{{<vlan_name 32 > vlanid <vidlist>}}

Each command is listed, in detail, in the following sections.

create super vlan

Purpose	This command is used to create a super VLAN.
Syntax	create super_vlan [<vlan_name 32> vlanid <vlanid 1-4094>] {sub_vlan <vidlist>}
Description	<p>This command is used to create a super VLAN. The specified VLAN must be an 802.1Q VLAN. If the specified VLAN is inexistent, the operation will not be success.</p> <p>NOTE:</p> <p>If you specify the super VLAN name, the VLAN must be an existent 802.1Q VLAN. L3 route protocol, VRRP, multicast protocol and IPV6 protocol cannot run on super VLAN interface.</p> <p>Super VLAN is used to aggregate multi sub VLANs in the same IP subnet. Sub-VLAN is a L2 separate broadcast domain. The super VLAN cannot have any physical member port; hosts reside in sub VLANs.</p> <p>Once an IP interface is bound to a super VLAN, the proxy ARP will enable automatically on the interface for communication between its sub VLANs.</p> <p>If an IP interface is bound to a super VLAN, it cannot bind to other VLANs.</p> <p>A super VLAN cannot be sub VLAN of other super VLANs.</p>
Parameters	<p><vlan_name 32> - Specify the name of the super VLAN. The VLAN name must be an existed 802.1Q VLAN.</p> <p>vlanid <vlanid 1-4094> - Specify the VLAN ID of the super VLAN.</p> <p>sub_vlan <vidlist> - Specify the sub VLANs of the super VLAN. By default, a new created super VLAN has not sub VLAN configured.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create super VLAN 10:

```
DGS-3627:admin# create super_vlan vlanid 10
Command: create super_vlan vlanid 10

Success.

DGS-3627:admin#
```

config super vlan

Purpose	This command is used to configure a super VLAN.
Syntax	config super_vlan [<vlan_name 32 > vlanid <vlanid 1-4094>] [add delete] sub_vlan <vidlist>
Description	This command is used to configure the sub VLANs of a super VLAN. A sub VLAN only can belong to one super VLAN and you cannot bind an IP interface on it. The maximum sub VLAN number of a super VLAN is 80.
Parameters	<vlan_name 32> - Specify the super VLAN name vlanid <vlanid 1-4094> - Specify the super VLAN ID add sub_vlan <vidlist> - Specify the sub VLAN ID list to add to the super VLAN. The sub VLAN shall be an 802.1Q VLAN. delete sub_vlan <vidlist> - Specify the sub VLAN ID list to delete from the super VLAN.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To add sub VLAN 2-4 into super VLAN 10:

```
DGS-3627:admin# config super_vlan 10 add sub_vlan 2-4
Command: config super_vlan 10 add sub_vlan 2-4

Success.

DGS-3627:admin#
```

delete super vlan

Purpose	This command is used to delete a super VLAN.
Syntax	delete super_vlan [<vlan_name 32 > vlanid <vlanid 1-4094>]
Description	This command is used to delete a super VLAN. NOTE: The VLAN will not be deleted really by this command. It is only no longer used as super VLAN.
Parameters	<vlan_name 32> - Specify the super VLAN name. vlanid <vlanid 1-4094> - Specify the super VLAN ID.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the super VLAN by specify the VLAN ID 10:

```
DGS-3627:admin# delete super_vlan vlanid 10
```

```
Command: delete super_vlan vlanid 10
```

```
Success.
```

```
DGS-3627:admin#
```

config sub_vlan

Purpose	This command is used to configure the IP range of the sub VLAN.
Syntax	config sub_vlan [<vlan_name 32> vlanid <vlanid 1-4094>] [add delete] ip_range <ipaddr> to <ipaddr>
Description	<p>This command is used to configure the IP range of the sub VLAN.</p> <p>A sub VLAN can has one or more IP ranges. Configuring IP range of sub VLAN can reduce the ARP traffic in the super VLAN.</p> <p>Sub VLAN mapping to IP range is 1 to n. That is multiple IP (ranges) is allowed to map to one sub VLANs.</p> <p>One IP can not map to multiple sub VLANs, if one IP map to multiple VLAN it may cause traffic forwarding to wrong VLAN.</p> <p>For example, if the IP range of a sub VLAN is 10.1.1.1-10.1.1.3, once the L3 switch received an ARP request whose target IP is 10.1.1.2 from the sub VLAN, the switch know the target IP in the sub VLAN and it does not send proxy ARP request to other sub VLANs.</p>
Parameters	<p><vlan_name 32> - Specify the sub VLAN name. The VLAN name must be an existent VLAN name.</p> <p>vlanid <vlanid 1-4094> - Specify the sub VLAN ID</p> <p>add ip_range <ipaddr> - Specify the IP range of the sub VLAN.</p> <p>delete ip_range <ipaddr> - Specify the IP range no longer belong to the sub VLAN</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure IP range of sub VLAN 1 to 10.1.1.1-10.1.1.3:

```
DGS-3627:admin# config sub_vlan vlanid 1 add ip_range 10.1.1.1 to 10.1.1.3
```

```
Command: config sub_vlan vlanid 1 add ip_range 10.1.1.1 to 10.1.1.3
```

```
Success.
```

```
DGS-3627:admin#
```

show super_vlan

Purpose	This command is used to show super VLAN.
Syntax	show super_vlan [{ <vlan_name 32 > vlanid <vlanid 1-4094> }]
Description	<p>This command is used to show super VLAN. The information includes:</p> <p>Super VLAN ID</p> <p>Super VLAN name</p> <p>IP subnet of the super VLAN associated interface.</p> <p>Status: if any sub VLAN of the super VLAN has linkup member port, the super VLAN is active. Otherwise, the super VLAN is inactive.</p> <p>Sub VLAN set of the super VLAN.</p>
Parameters	<vlan_name 32> - Specify the super VLAN name.

show super vlan

vlanid <*vlanid 1-4094*> - Specify the super VLAN ID.
If not specified the super VLAN, show all super VLANs.

Restrictions None.

Example usage:

To show super VLAN:

```
DGS-3627:admin# show super_vlan
Command: show super_vlan
```

```
Super VID      : 10
VLAN Name     : VLAN10
IP subnet     : 10.1.0.0/16
Status        : Active
Sub VID       : 2-4, 7, 9
Total Entries : 1
```

```
DGS-3627:admin#
```

show sub vlan

Purpose This command is used to show sub VLAN.

Syntax **show sub_vlan** {[<*vlan_name 32* > | *vlanid* <*vidlist*>]}

Description This command is used to show sub VLAN.
The "Active" and "Inactive" status means if any ports link up in the sub vlan.

Parameters <*vlan_name 32*> - Specify the sub VLAN name
vlanid <*vlanid 1-4094*> - Specify the sub VLAN ID list
If not specified the sub VLAN, show all sub VLANs.

Restrictions None.

Example usage:

To show all sub VLAN:

```
DGS-3627:admin# show sub_vlan
Command: show sub_vlan
```

Sub VID	Status	Super VID	IP Range
-----	-----	-----	-----
1	Active	10	10.1.1.1-10.1.1.10 10.1.2.1-10.1.2.20
2	Active	10	10.1.3.0-10.1.3.100
3	Inactive	10	10.1.4.0-10.1.4.255
4	Active	20	
5	Inactive	20	

```
Total Entries: 5
```

```
DGS-3627:admin#
```

SWITCH PORT COMMANDS

The switch port commands in the Command Line Interface (CLI) are listed (with the appropriate parameters) in the following table.

Command	Parameters
config ports	[<portlist> all] {medium_type [fiber copper]} { speed[auto {capability_advertised {10_half 10_full 100_half 100_full 1000_full } } 10_half 10_full 100_half 100_full 1000_full {[master slave]}] auto_negotiation restart_an flow_control [enable disable] learning [enable disable] state [enable disable] [description <desc 1-32> clear_description]}
show ports	{<portlist>} {[description err_disabled auto_negotiation details media_type]}

Each command is listed, in detail, in the following sections.

config ports

Purpose	Used to configure the Switch's Ethernet port settings.
Syntax	config ports [<portlist> all] {medium_type [fiber copper]} { speed[auto {capability_advertised {10_half 10_full 100_half 100_full 1000_full } } 10_half 10_full 100_half 100_full 1000_full {[master slave]}] auto_negotiation restart_an [flow_control [enable disable] learning [enable disable] state [enable disable] [description <desc 1-32> clear_description]}
Description	This command allows for the configuration of the Switch's Ethernet ports. Only the ports listed in the <portlist> will be affected.
Parameters	<p><i>all</i> – Configure all ports on the Switch.</p> <p><portlist> – Specifies a port or range of ports to be configured. The beginning and end of the port list range are separated by a dash.</p> <p><i>medium_type</i> [fiber copper] – This applies only to the Combo ports. If configuring the Combo ports this defines the type of transport medium used.</p> <p><i>speed</i> – Allows the user to adjust the speed for a port or range of ports. The user has a choice of the following:</p> <ul style="list-style-type: none"> • <i>auto</i> – Enables auto-negotiation for the specified range of ports. • [10 100 1000] – Configures the speed in Mbps for the specified range of ports. Gigabit ports are statically set to 1000 and cannot be set to slower speeds. • [half full] – Configures the specified range of ports as either full-duplex or half-duplex. • [master slave] – The master setting (1000M/Full_M) will allow the port to advertise capabilities related to duplex, speed and physical layer type. The master setting will also determine the master and slave relationship between the two connected physical layers. This relationship is necessary for establishing the timing control between the two physical layers. The timing control is set on a master physical layer by a local source. The slave setting (1000M/Full_S) uses loop timing, where the timing comes from a data stream received from the master. If one connection is set for 1000M/Full_M, the other side of the connection must be set for 1000M/Full_S. Any other configuration will result in a link down status for both ports. <p><i>flow_control</i> [enable disable] – Enable or disable flow control for the specified ports.</p> <p><i>learning</i> [enable disable] – Enables or disables the MAC address learning on the specified range of ports.</p> <p><i>state</i> [enable disable] – Enables or disables the specified range of ports. If the specific ports are in an error-disabled state configuring their state to enable will recover these ports from disabled to enabled state.</p> <p><i>description</i> <desc 1-32> – Enter an alphanumeric string of no more than 32 characters to describe a selected port interface.</p> <p><i>clear_description</i> – Enter this command to clear the port description of the selected port(s).</p>
Restrictions	Only Administrator and Operator-level users can issue this command.



NOTE: Gigabit Ethernet ports are statically set to 1 Gbps, and their speed cannot be modified. The DGS-3600 series fiber ports only support 1000M_full.

Example usage:

To configure the speed of ports 1 to 3 of unit 1 to be 10 Mbps, full duplex, with learning, state and flow control enabled:

```
DGS-3627:admin# config ports 1:1-1:3 speed 10_full learning enable state enable
flow_control enable
Command: config ports 1:1-1:3 speed 10_full learning enable state enable flow_control
enable

Success.

DGS-3627:admin#
```

To configure the speed of ports 1 to 3 of unit 1 to be auto, capability advertised with half duplex and full duplex ports:

```
DGS-3627:admin# config ports 1:1-1:3 speed auto capability_advertised 10_half 10_full
Command: config ports 1:1-1:3 speed auto capability_advertised 10_half 10_full

Success.

DGS-3627:admin#
```

show ports

Purpose	Used to display the current configuration of a range of ports.
Syntax	show ports {<portlist>} [{description err_disabled auto_negotiation details media_type}]
Description	This command is used to display the current configuration of a range of ports.
Parameters	<p><i><portlist></i> – Specifies a port or range of ports to be displayed. The beginning and end of the port list range are separated by a dash.</p> <p><i>{description}</i> – Adding this parameter to the show ports command indicates that a previously entered port description will be included in the display.</p> <p><i>err_disabled</i> – Choosing this parameter will display ports that have been disconnected due to an error on the port, such as a Loopback Detection.</p> <p><i>auto_negotiation</i> – Choosing this parameter will display the port auto-negotiation information in the display.</p> <p><i>details</i> - Displays the port detailed information</p> <p><i>media_type</i> - Displays port transceiver type.</p>
Restrictions	None.

Example usage:

To display the configuration of all ports on a switch:

DGS-3627:admin# show ports

Command: show ports

Port	Port State	Settings Speed/Duplex/FlowCtrl	Connection Speed/Duplex/FlowCtrl	Address Learning
1:1	Enabled	Auto/Disabled	Link Down	Enabled
1:2	Enabled	Auto/Disabled	Link Down	Enabled
1:3	Enabled	Auto/Disabled	Link Down	Enabled
1:4	Enabled	Auto/Disabled	Link Down	Enabled
1:5	Enabled	Auto/Disabled	Link Down	Enabled
1:6	Enabled	Auto/Disabled	Link Down	Enabled
1:7	Enabled	Auto/Disabled	Link Down	Enabled
1:8	Enabled	Auto/Disabled	Link Down	Enabled
1:9	Enabled	Auto/Disabled	Link Down	Enabled
1:10	Enabled	Auto/Disabled	Link Down	Enabled
1:11	Enabled	Auto/Disabled	Link Down	Enabled
1:12	Enabled	Auto/Disabled	Link Down	Enabled
1:13	Enabled	Auto/Disabled	Link Down	Enabled
1:14	Enabled	Auto/Disabled	Link Down	Enabled
1:15	Enabled	Auto/Disabled	Link Down	Enabled
1:16	Enabled	Auto/Disabled	Link Down	Enabled
1:17	Enabled	Auto/Disabled	Link Down	Enabled
1:18	Enabled	Auto/Disabled	Link Down	Enabled
1:19	Enabled	Auto/Disabled	Link Down	Enabled

CTRL+C **ESC** **q** Quit **SPACE** **n** Next Page **p** Previous Page **r** Refresh

To display the configuration of all ports on the Switch, with a description:

DGS-3627:admin# show ports description

Command: show ports description

Port	Port State	Settings Speed/Duplex/FlowCtrl	Connection Speed/Duplex/FlowCtrl	Address Learning
1:1	Enabled	Auto/Disabled	Link Down	Enabled
	Description:			
1:2	Enabled	Auto/Disabled	Link Down	Enabled
	Description:			
1:3	Enabled	Auto/Disabled	Link Down	Enabled
	Description:			
1:4	Enabled	Auto/Disabled	Link Down	Enabled
	Description:			
1:5	Enabled	Auto/Disabled	Link Down	Enabled
	Description:			
1:6	Enabled	Auto/Disabled	Link Down	Enabled
	Description:			
1:7	Enabled	Auto/Disabled	Link Down	Enabled
	Description:			
1:8	Enabled	Auto/Disabled	Link Down	Enabled
	Description:			
1:9	Enabled	Auto/Disabled	Link Down	Enabled
	Description:			

CTRL+C **ESC** **q** Quit **SPACE** **n** Next Page **p** Previous Page **r** Refresh

To display the Error Disabled ports:

```
DGS-3627:admin# show ports err_disabled
Command : show ports err_disabled

Port      Port      Connection status      Reason
-----  -
1:2       Enabled   Err-disabled           Storm control
          Desc: Port 2
1:8       Enabled   Err-disabled           Storm control
          Desc: Port 8

DGS-3627:admin#
```

To display the Error Disabled ports:

```
DGS-3627:admin# show ports err_disabled
Command : show ports err_disabled

Port      Port      Connection status      Reason
-----  -
1:2       Enabled   Err-disabled           Storm control
          Desc: Port 2
1:8       Enabled   Err-disabled           Storm control
          Desc: Port 8

DGS-3627:admin#
```

To display the auto_negotiation ports:

```
DGS-3627:admin# show ports 1:1-1:3 auto_negotiation
Command: show ports 1:1-1:3 auto_negotiation

Port : 1:1
-----
Auto Negotiation      : Enabled
Capability Bits       : 1000M_Full
Capability Advertised Bits : 1000M_Full
Capability Received Bits  :

Port : 1:2
-----
Auto Negotiation      : Enabled
Capability Bits       : 1000M_Full
Capability Advertised Bits : 1000M_Full
Capability Received Bits  :

Port : 1:3
-----
Auto Negotiation      : Enabled
Capability Bits       : 1000M_Full
Capability Advertised Bits : 1000M_Full
Capability Received Bits  :

DGS-3627:admin#
```


SYSLOG OR TRAP SOURCE-INTERFACE COMMANDS

The syslog or trap source-interface function is used for selecting a fixed interface as the source interface to send syslog or trap message. It also provides a mechanism to select a certain IP address from the specified interface as the source address to send the message. The servers beyond different networks receive the syslog or trap message always come from a fixed source IP address, it is helpful to use the source IP address to identify the switch.

The Syslog or Trap Source-Interface commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config syslog source_ipif	[<ipif_name> {<ipaddr>} none]
show syslog source_ipif	
config trap source_ipif	[<ipif_name> {<ipaddr> <ipv6addr>} none]
show trap source_ipif	

Each command is listed, in detail, in the following sections.

config syslog source_ipif

Purpose	Configure syslog source IP interface.
Syntax	config syslog source_ipif [<ipif_name> {<ipaddr>} none]
Description	This command is used to configure syslog source IP interface.
Parameters	<p><i>ipif_name</i> - IP interface name. If only specify this parameter, the least IPv4 address and the smallest IPv6 address of ipif_name will be used as source IP addresses.</p> <p><i>none</i> - For clear the configured source IP interface.</p> <p><i>ipaddr</i> - Specify the IPv4 address.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Configure syslog source IP interface:

```
DGS-3627:admin# config syslog source_ipif ipif3 14.0.0.5
Command: config syslog source_ipif ipif3 14.0.0.5

Success

DGS-3627:admin#
```

To clear the configured source IP interface for syslog:

```
DGS-3627:admin# config syslog source_ipif none
Command: config syslog source_ipif none

Success

DGS-3627:admin#
```

show syslog source_ipif

Purpose	Show syslog source IP interface.
Syntax	show syslog source_ipif
Description	This command is used to display the syslog source IP interface.
Parameters	None.
Restrictions	None.

Example usage:

Show syslog source IP interface:

```
DGS-3627:admin# show syslog source_ipif
Command: show syslog source_ipif
```

Syslog Source IP Interface Configuration:

```
IP Interface           : ipif3
IPv4 Address           : 14.0.0.3
```

```
DGS-3627:admin#
```

config trap source_ipif

Purpose	Configure trap source IP interface.
Syntax	config trap source_ipif [<ipif_name> {<ipaddr> <ipv6addr>} none]
Description	This command is used to configure trap source IP interface.
Parameters	<i>ipif_name</i> - IP interface name. If only specify this parameter, the least IPv4 address and the smallest IPv6 address of ipif_name will be used as source IP addresses. <i>none</i> - For clearing the configured source IP interface. <i>ipaddr</i> - IPv4 address. <i>ipv6addr</i> - IPv6 address.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Configure trap source IP interface:

```
DGS-3627:admin# config trap source_ipif inter4
Command: config trap source_ipif inter4
```

Success

```
DGS-3627:admin#
```

To clear the configured trap source IP interface:

```
DGS-3627:admin# config trap source_ipif none
Command: config trap source_ipif none

Success

DGS-3627:admin#
```

show trap source_ipif

Purpose	Show trap source IP interface.
Syntax	show trap source_ipif
Description	This command is used to display the trap source IP interface.
Parameters	None.
Restrictions	None.

Example usage:

Show trap source IP interface:

```
DGS-3627:admin# show trap source_ipif
Command: show trap source_ipif

Trap Source IP Interface Configuration:

IP Interface           : ipif4
IPv4 Address           : None
IPv6 address           : 3000::52

DGS-3627:admin#
```


SYSTEM LOG COMMANDS

The System Log commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
clear log	
show log	{[index <value_list> severity {emergency alert critical error warning notice informational debug <level_list 0-7>}]}
enable syslog	
disable syslog	
show syslog	
config syslog host	<index 1-4> [severity [emergency alert critical error warning notice informational debug all <level 0-7>] facility [local0 local1 local2 local3 local4 local5 local6 local7] udp_port <udp_port_number> ipaddress <ipaddr> state [enable disable]]
create syslog host	<index 1-4> {severity [emergency alert critical error warning notice informational debug] all <level 0-7>] facility [local0 local1 local2 local3 local4 local5 local6 local7] udp_port <udp_port_number> ipaddress<ipaddr> state [enable disable]}
delete syslog host	[<index 1-4> all]
show syslog host	{<index 1-4>}
config log_save_timing	[time_interval <min 1-65535> on_demand log_trigger]
show log_save_timing	
show attack_log	{unit <unit_id 1-12>} {index <value_list>}
clear attack_log	{unit <unit_id 1-12> all}
upload attack_log_toTFTP	[<ipaddr> <ipv6addr> <domain_name 255>] dest_file <path_filename 64> {unit <unit_id 1-12>}
upload attack_log_toRCP	[[username <username 15>] {<ipaddr>} dest_file <path_filename 64> rcp: <string 128>] {unit <unit_id 1-12>}
config system_severity	[trap log all] [emergency alert critical error warning notice information debug <level 0-7>]
show system_severity	

Each command is listed, in detail, in the following sections.

clear log

Purpose	Used to clear the switch's history log.
Syntax	clear log
Description	This command clears the switch's history log.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To clear the switch's history log:

```
DGS-3627:admin# clear log
Command: clear log

Success.

DGS-3627:admin#
```

show log

Purpose	Used to display the switch's history log.
Syntax	show log {[<i>index</i> < <i>value_list</i> > <i>severity</i> { <i>emergency</i> <i>alert</i> <i>critical</i> <i>error</i> <i>warning</i> <i>notice</i> <i>informational</i> <i>debug</i> [<i><level_list 0-7></i>]}]}
Description	This command displays the switch's history log. When the log is empty, the prompt message "Log is empty." will be displayed.
Parameters	<i>index</i> - The show log command will display the history log between the log number of X and Y. For example, showing log index 1-5 will display the history log from 1 to 5. If no parameter is specified, all history log entries will be displayed. <i>severity</i> <i>emergency</i> Severity level 0 <i>alert</i> Severity level 1 <i>critical</i> Severity level 2 <i>error</i> Severity level 3 <i>warning</i> Severity level 4 <i>notice</i> Severity level 5 <i>informational</i> Severity level 6 <i>debug</i> Severity level 7 <i>level_list</i> - Specifies a list of severity levels to be displayed. If there is more than one severity level, please separate them by comma. The level number is from 0 to 7.
Restrictions	None.

Example usage:

To display the switch's history log:

```
DGS-3627:admin# show log index 1-3
Command: show log index 1-3

Index Date          Time             Level   Log Text
-----
3      2008-10-17 15:00:14 INFO(1) Successful login through Console (Username: Anonymous)
2      2008-10-17 10:50:36 WARN(3) Console session timed out (Username: Anonymous)
1      2008-10-16 15:19:17 CRIT(5) SNMP request received from 10.0.0.27 with invalid
community string!

DGS-3627:admin#
```

enable syslog

Purpose	Used to enable the sending of syslog messages.
Syntax	enable syslog

enable syslog

Description	This command enables the sending of syslog messages.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the sending of syslog messages:

```
DGS-3627:admin# enable syslog
Command: enable syslog

Success.

DGS-3627:admin#
```

disable syslog

Purpose	Used to disable the sending of syslog messages.
Syntax	disable syslog
Description	This command disables the sending of syslog messages.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the sending of syslog messages:

```
DGS-3627:admin# disable syslog
Command: disable syslog

Success.

DGS-3627:admin#
```

show syslog

Purpose	Used to display the syslog protocol global state.
Syntax	show syslog
Description	This command displays the syslog protocol global state.
Parameters	None.
Restrictions	None.

Example usage:

To display the syslog protocol global state:

```
DGS-3627:admin# show syslog
Command: show syslog

Syslog Global State: Enabled

DGS-3627:admin#
```

config syslog host

Purpose	Used to configure the syslog host configurations.																																								
Syntax	config syslog host <index 1-4> [severity [emergency alert critical error warning notice informational debug all <level 0-7>] facility [local0 local1 local2 local3 local4 local5 local6 local7] udp_port <udp_port_number> ipaddress <ipaddr> state [enable disable]]																																								
Description	<p>This command configures the syslog host configurations. The user can choose and report a specific level of messages to a specific host. When the user chooses a specific level for a specific host, messages which are at that severity level or higher will be reported to the specified host.</p> <p>When the specified host doesn't exist, the prompt message, "The entry does not exist." will be displayed and this configuration will fail.</p> <p>When the IP address is invalid, the prompt message, "Invalid IP address." will be displayed and this configuration will fail.</p> <p>The prompt message, "The IP address has already been configured." will be prompted to the user when configuring syslog hosts with "all" option and just assigning one IP address to those hosts. This configuration will fail.</p> <p>When the specified IP address already exists, the prompt message, "The host IP address already exists." will be displayed and this configuration will fail.</p>																																								
Parameters	<p><i>host</i> - The host index or all hosts.</p> <table border="0"> <tr> <td style="padding-right: 20px;"><i>severity</i> -</td> <td style="padding-right: 20px;"><i>emergency</i></td> <td>Severity level 0</td> </tr> <tr> <td></td> <td><i>alert</i></td> <td>Severity level 1</td> </tr> <tr> <td></td> <td><i>critical</i></td> <td>Severity level 2</td> </tr> <tr> <td></td> <td><i>error</i></td> <td>Severity level 3</td> </tr> <tr> <td></td> <td><i>warning</i></td> <td>Severity level 4</td> </tr> <tr> <td></td> <td><i>notice</i></td> <td>Severity level 5</td> </tr> <tr> <td></td> <td><i>informational</i></td> <td>Severity level 6</td> </tr> <tr> <td></td> <td><i>debug</i></td> <td>Severity level 7</td> </tr> </table> <p><i>facility</i> - Some of the operating system daemons and processes have been assigned facility values. Processes and daemons that have not been explicitly assigned a facility may use any of the "local use" facilities or they may use the "user-level" facility. Those facilities that have been designated are shown below. This facility setting will be put in the syslog packet when it is sent to a specific syslog server.</p> <table border="0"> <tr> <td style="padding-right: 20px;"><i>local0</i></td> <td>user-defined facility</td> </tr> <tr> <td><i>local1</i></td> <td>user-defined facility</td> </tr> <tr> <td><i>local2</i></td> <td>user-defined facility</td> </tr> <tr> <td><i>local3</i></td> <td>user-defined facility</td> </tr> <tr> <td><i>local4</i></td> <td>user-defined facility</td> </tr> <tr> <td><i>local5</i></td> <td>user-defined facility</td> </tr> <tr> <td><i>local6</i></td> <td>user-defined facility</td> </tr> <tr> <td><i>local7</i></td> <td>user-defined facility</td> </tr> </table> <p><i>udp_port</i> - The UDP port number.</p> <p><i>ipaddr</i> - Specify the IP address for the host.</p> <p><i>state</i> - The syslog protocol is used for the transmission of event notification messages across</p>	<i>severity</i> -	<i>emergency</i>	Severity level 0		<i>alert</i>	Severity level 1		<i>critical</i>	Severity level 2		<i>error</i>	Severity level 3		<i>warning</i>	Severity level 4		<i>notice</i>	Severity level 5		<i>informational</i>	Severity level 6		<i>debug</i>	Severity level 7	<i>local0</i>	user-defined facility	<i>local1</i>	user-defined facility	<i>local2</i>	user-defined facility	<i>local3</i>	user-defined facility	<i>local4</i>	user-defined facility	<i>local5</i>	user-defined facility	<i>local6</i>	user-defined facility	<i>local7</i>	user-defined facility
<i>severity</i> -	<i>emergency</i>	Severity level 0																																							
	<i>alert</i>	Severity level 1																																							
	<i>critical</i>	Severity level 2																																							
	<i>error</i>	Severity level 3																																							
	<i>warning</i>	Severity level 4																																							
	<i>notice</i>	Severity level 5																																							
	<i>informational</i>	Severity level 6																																							
	<i>debug</i>	Severity level 7																																							
<i>local0</i>	user-defined facility																																								
<i>local1</i>	user-defined facility																																								
<i>local2</i>	user-defined facility																																								
<i>local3</i>	user-defined facility																																								
<i>local4</i>	user-defined facility																																								
<i>local5</i>	user-defined facility																																								
<i>local6</i>	user-defined facility																																								
<i>local7</i>	user-defined facility																																								

config syslog host

	networks to a host. The option enables or disables the host to receive such messages.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure syslog host configuration:

```
DGS-3627:admin# config syslog host all severity all facility local0
Command: config syslog host all severity all facility local0

Success.

DGS-3627:admin#
```

create syslog host

Purpose	Used to create a new syslog host.																																							
Syntax	create syslog host <index 1-4> {severity [emergency alert critical error warning notice informational debug] all <level 0-7>} facility [local0 local1 local2 local3 local4 local5 local6 local7] udp_port <udp_port_number> ipaddress<ipaddr> state [enable disable]}																																							
Description	<p>This command creates a new syslog host. The user can choose and report specific levels of messages to a specific host. When the user chooses a specific level for a specific host, messages which are at that severity level or higher will be reported to that host.</p> <p>When the IP address is invalid, the prompt message, "Invalid IP address," will be displayed and this configuration will fail.</p> <p>When the specified IP address already exists, the prompt message, "The host IP address already exists," will be displayed and this configuration will fail.</p> <p>When the specified host already exists, the prompt message, "The entry already exists," will be displayed and this configuration will fail.</p>																																							
Parameters	<p><i>host</i> - The host index or all hosts</p> <table border="0"> <tr> <td><i>severity</i></td> <td><i>emergency</i></td> <td>Severity level 0</td> </tr> <tr> <td></td> <td><i>alert</i></td> <td>Severity level 1</td> </tr> <tr> <td></td> <td><i>critical</i></td> <td>Severity level 2</td> </tr> <tr> <td></td> <td><i>error</i></td> <td>Severity level 3</td> </tr> <tr> <td></td> <td><i>warning</i></td> <td>Severity level 4</td> </tr> <tr> <td></td> <td><i>notice</i></td> <td>Severity level 5</td> </tr> <tr> <td></td> <td><i>informational</i></td> <td>Severity level 6</td> </tr> <tr> <td></td> <td><i>debug</i></td> <td>Severity level 7</td> </tr> <tr> <td></td> <td><i>all</i></td> <td>Severity level All</td> </tr> </table> <p><i>facility</i> - Some of the operating system daemons and processes have been assigned facility values. Processes and daemons that have not been explicitly assigned a facility may use any of the "local use" facilities or they may use the "user-level" facility. The facilities that have been designated are shown below.</p> <table border="0"> <tr> <td><i>local0</i></td> <td>user-defined facility</td> </tr> <tr> <td><i>local1</i></td> <td>user-defined facility</td> </tr> <tr> <td><i>local2</i></td> <td>user-defined facility</td> </tr> <tr> <td><i>local3</i></td> <td>user-defined facility</td> </tr> <tr> <td><i>local4</i></td> <td>user-defined facility</td> </tr> <tr> <td><i>local5</i></td> <td>user-defined facility</td> </tr> </table>	<i>severity</i>	<i>emergency</i>	Severity level 0		<i>alert</i>	Severity level 1		<i>critical</i>	Severity level 2		<i>error</i>	Severity level 3		<i>warning</i>	Severity level 4		<i>notice</i>	Severity level 5		<i>informational</i>	Severity level 6		<i>debug</i>	Severity level 7		<i>all</i>	Severity level All	<i>local0</i>	user-defined facility	<i>local1</i>	user-defined facility	<i>local2</i>	user-defined facility	<i>local3</i>	user-defined facility	<i>local4</i>	user-defined facility	<i>local5</i>	user-defined facility
<i>severity</i>	<i>emergency</i>	Severity level 0																																						
	<i>alert</i>	Severity level 1																																						
	<i>critical</i>	Severity level 2																																						
	<i>error</i>	Severity level 3																																						
	<i>warning</i>	Severity level 4																																						
	<i>notice</i>	Severity level 5																																						
	<i>informational</i>	Severity level 6																																						
	<i>debug</i>	Severity level 7																																						
	<i>all</i>	Severity level All																																						
<i>local0</i>	user-defined facility																																							
<i>local1</i>	user-defined facility																																							
<i>local2</i>	user-defined facility																																							
<i>local3</i>	user-defined facility																																							
<i>local4</i>	user-defined facility																																							
<i>local5</i>	user-defined facility																																							

create syslog host

local6 user-defined facility

local7 user-defined facility

udp_port - The UDP port number.

state - The syslog protocol is used for the transmission of event notification messages across networks to a host. This option enables or disables the hosts that will receive such messages.

ipaddress – Specify the IP address used here.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To create a new syslog host:

```
DGS-3627:admin# create syslog host 1 ipaddress 10.90.90.1 severity all facility local0
Command: create syslog host 1 ipaddress 10.90.90.1 severity all facility local0
```

Success.

```
DGS-3627:admin#
```

delete syslog host

Purpose Used to delete the syslog host(s).

Syntax **delete syslog host [<index 1-4> | all]**

Description This command deletes the syslog host(s).

When the specified host doesn't exist, the prompt message, "The entry does not exist," will be displayed and this configuration will fail.

Parameters *host [<index 1-4> | all]* - Host index or all hosts.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To delete a syslog host:

```
DGS-3627:admin# delete syslog host 4
Command: delete syslog host 4
```

Success.

```
DGS-3627:admin#
```

show syslog host

Purpose Used to display syslog host configurations.

Syntax **show syslog host {<index 1-4>}**

Description This command displays the syslog host configurations.

Parameters *index* - The host index.

If no parameter is specified, all hosts will be displayed.

Restrictions None.

Example usage:

To display syslog host configurations:

```
DGS-3627:admin# show syslog host
```

```
Command: show syslog host
```

```
Syslog Global State: Enabled
```

Host Id	Host IP Address	Severity	Facility	UDP port	Status
1	172.18.70.97	All	Local5	514	Enabled

```
Total Entries : 1
```

```
DGS-3627:admin#
```

config log_save_timing

Purpose	Used to configure the method for saving the log.
Syntax	config log_save_timing [time_interval <min 1-65535> on_demand log_trigger]
Description	This command is used to set the method for saving the log.
Parameters	<p><i>time_interval</i> - Save log to flash every xxx minutes. (If no new log events occur in this period, don't save.)</p> <p><i>on_demand</i> - Save log to flash whenever the user enters the "save log" or "save all" command. The default setting is on_demand.</p> <p><i>log_trigger</i> - Save log to flash whenever a new log event arrives.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the method for saving a log as on demand:

```
DGS-3627:admin# config log_save_timing on_demand
```

```
Command: config log_save_timing on_demand
```

```
Success.
```

```
DGS-3627:admin#
```

show log_save_timing

Purpose	Used to show the method for saving the log.
Syntax	show log_save_timing
Description	To show the method for saving the log.
Parameters	None.
Restrictions	None.

Example usage:

To show the timing method used for saving the log:

```
DGS-3627:admin# show log_save_timing
```

```
Command: show log_save_timing
```

```
Saving log method: on_demand
```

```
DGS-3627:admin#
```

show attack_log

Purpose	Displays the attack log messages.
Syntax	show attack_log {unit <unit_id 1-n>} {index <value_list>}
Description	Displays the attack log messages. The attack log message refers to log messages driven by modules such as DOS and the IP-MAC-port binding module. This type of log message may generate a large amount of messages and quickly cause the system to run out of system log storage. Therefore, for this type of log messages only the first log that is generated each minute can be stored in the system log, with the rest of them being stored in a separate table named attack log. When the attack log is empty, the prompt message, "Log is empty," will be displayed.
Parameters	<i>unit</i> - The attack log messages on the specified unit will be displayed. If unit ID is specified, then this unit will be referred to as the master unit. <i>index</i> - The list of index numbers of the entries that need to be displayed. For example, show attack_log index 1-5 will display the attack log messages from 1 to 5. If no parameter is specified, all entries in the attack log will be displayed.
Restrictions	None.

Example usage:

To show dangerous messages on the master:

```
DGS-3627:admin# show attack_log index 1
```

```
Command: show attack_log index 1
```

```

Index      Date           Time           Level          Log Text
-----
1          2008-10-17 15:00:14 CRIT(2)      Land attack is blocked from (IP: 10.72.24.1
                                     Port: 7)

```

```
DGS-3627:admin#
```

clear attack_log

Purpose	Used to clear the attack log.
Syntax	clear attack_log {unit <unit_id 1-n> all}
Description	Used to clear the attack log.
Parameters	<i>unit</i> - The attack log messages on the specified unit will be cleared. If specified, this unit will be referred to as the master unit.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To clear the master's attack log:


```
DGS-3627:admin# clear attack_log
```

```
Command: clear attack_log
```

```
Success.
```

```
DGS-3627:admin#
```

upload attack_log_toTFTP

Purpose	Used to upload the attack log on a unit.
Syntax	upload attack_log_toTFTP [<ipaddr> <ipv6addr> <domain_name 255>] dest_file <path_filename 64> {unit <unit_id 1-12>}
Description	To upload the attack log stored on a unit.
Parameters	<p>When the attack log is empty, the prompt message, "Log is empty," will be displayed.</p> <p><i>unit</i> - The attack log messages on the specified unit will be uploaded to the TFTP server. If specified, this unit will be referred to as the master unit.</p> <p><ipaddr> - The IPv4 address of the TFTP server.</p> <p><ipv6addr> - The IPv6 address of the TFTP server.</p> <p><domain_name 255> - The domain name of the TFTP server.</p> <p><i>dest_file</i> - The destination file name.</p> <p><path_filename 64> - Specifies the path name on the TFTP server to hold the attack log.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To upload the master's dangerous log:

```
DGS-3627:admin# upload attack_log_toTFTP 10.90.90.1 dest_file c:\alert.txt
```

```
Command: upload attack_log_toTFTP 10.90.90.1 dest_file c:\alert.txt
```

```
Success.
```

```
DGS-3627:admin#
```

upload attack_log_toRCP

Purpose	Used to upload the attack log file from the device to an RCP server.
Syntax	upload attack_log_toRCP [{username <username 15>} {<ipaddr>}] dest_file <path_filename 64> rcp: <string 128>] {unit <unit_id 1-12>}
Description	This command is used to upload the attack log file from the device to an RCP server.
Parameters	<p><i>username</i> - The remote user name on the RCP Server.</p> <p><ipaddr> - The IPv4 address of the RCP server.</p> <p><i>path_filename</i> - The pathname specifies the pathname on the RCP server or local device.</p> <p>Note: If a user specifies the relative file path, the path search strategy will depend on the server system. For some systems, it will search the current user working directory first, and then search the environment paths.</p> <p><i>dest_file</i> - Specify the destination file here.</p> <p><i>rcp:</i> <string 128> - Syntax: rcp: username@ipaddr/directory/filename</p> <p>Example for FULL path: user_name@10.1.1.1/home/user_name/desxxxx.had</p> <p>Example for relative path: user_name@10.1.1.1./desxxxx.had</p>

upload attack_log_toRCP

Note: Do not use any blank spaces in the <string>.

unitid - The attack log messages on the specified unit will be uploaded to the RCP server. If specified, this unit will be referred to as the master unit.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To upload the attack log from the device to an RCP server:

```
DGS-3627:admin# upload attack_log_toRCP username rcp_user 172.18.212.104 /home/DGS-XXXX.log unit 2
Command: upload attack_log_toRCP username rcp_user 172.18.212.104 /home/DGS-XXXX.log unit 2

Connecting to server..... Done.
Upload Attack log..... Done.

DGS-3627:admin#
```

config system_severity

Purpose

This command is used to configure the severity level control for the system.

Syntax

config system_severity [trap | log | all] [emergency | alert | critical | error | warning | notice | information | debug | <level 0-7>]

Description

When the user chooses a specific level to log or trap, messages at that severity level or more will be logged or trapped to SNMP managers.

Parameters

trap - Specifies the severity level control for traps.
log - Specifies the severity level control for the log.
all - Specifies the severity level control for traps and the log.
emergency - Severity level 0.
alert - Severity level 1.
critical - Severity level 2.
error - Severity level 3.
warning - Severity level 4.
notice - Severity level 5.
information - Severity level 6.
debug - Severity level 7.
<level 0-7> - Enter the severity level here. This value must be between 0 and 7.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To configure severity level control as information level for trap:

```
DGS-3627:admin# config system_severity trap information
Command: config system_severity trap information

Success.

DGS-3627:admin#
```

show system_severity

Purpose	This command is used to display the severity level controls for the system.
Syntax	show system_severity
Description	This command is used to display the severity level controls for the system.
Parameters	None.
Restrictions	None.

Example usage:

To show severity level control for system:

```
DGS-3627:admin# show system_severity
Command: show system_severity

System Severity Trap : warning
System Severity Log  : information

DGS-3627:admin#
```

TECHNICAL SUPPORT COMMANDS

The Technical Support commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
show tech_support	
upload tech_support_toTFTP	<ipaddr> <path_filename 64>

Each command is listed, in detail, in the following sections.

show tech_support

Purpose	Used to show the information of technique's support.
Syntax	show tech_support
Description	<p>This command is especially used by the technical support personnel to dump the device overall operation information. The information is project dependent and includes the following information.</p> <ul style="list-style-type: none"> Basic System information system log Running configuration Layer 1 information Layer 2 information Layer 3 information Application OS status Controller's status <p>This command can be interrupted by Ctrl - C or ESC when it is executing.</p>
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To show the information of technique's support:

```

DGS-3627:admin# show tech_support
Command: show tech_support

#-----
#
#           DGS-3627 Gigabit Ethernet Switch
#           Technical Support Information
#
#           Firmware: Build 2.80.B31
#           Copyright(C) 2010 D-Link Corporation. All rights reserved.
#-----

***** Basic System Information *****

[SYS 2010-1-1 08:59:20]

Boot Time      : 8 Sep 2010 08:54:00
RTC Time       : 2010/09/08 08:59:20
Boot PROM Version : Build 1.10-B09
Firmware Version : Build 2.80.B31
Hardware Version  : 0A2G
MAC Address    : 00-01-02-03-04-05
MAC Address Number : 256
    
```

upload tech_support_toTFTP

Purpose	Used to upload the information of technique's support.
Syntax	upload tech_support_toTFTP <ipaddr> <path_filename 64>
Description	<p>The upload tech_support_toTFTP command is used to upload the information of technique's support to TFTP server. The information is project dependent and includes the following information.</p> <ul style="list-style-type: none"> Basic System information system log Running configuration Layer 1 information Layer 2 information Layer 3 information Application OS status Controller's status <p>This command can be interrupted by Ctrl - C or ESC when it is executing.</p>
Parameters	<p><i>ipaddr</i> - Specifies the IP address of TFTP server.</p> <p><i>path_filename</i> - Specifies the file name to store the information of technique's support in TFTP server. The max size of the file name is 64.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To upload the information of technique's support:

```
DGS-3627:admin# upload tech_support_to_TFTP 10.0.0.66 tech_report.txt
Command: upload tech_support_to_TFTP 10.0.0.66 tech_report.txt

Connecting to server..... Done.
Upload techsupport file..... Done.

Success.

DGS-3627:admin#
```

TELNET CLIENT COMMANDS

The Telnet Client commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
telnet	[<ipaddr> <domain_name 255>] {tcp_port(1) <value 0-65535>}

Each command is listed, in detail, in the following sections.

telnet

Purpose	Used to initiate a Telnet client session with a specific Telnet server.
Syntax	telnet [<ipaddr> <domain_name 255>] {tcp_port(1) <value 0-65535>}
Description	The Telnet command establishes a single Telnet client connection with a specified server. The parameters specified by the command will only be used for the establishment of this specific session. They will not affect the establishment of other sessions.
Parameters	<p><i>ipaddr</i> - The IP address of the Telnet server.</p> <p><i>domain_name</i> - Specify the domain name of the Telnet server.</p> <p><i>tcp_port</i> - Specifies the Telnet server port number to be connected. If not specified, the default port is 23.</p>
Restrictions	None.

Example usage:

Telnet to a Switch by specifying the IP address:

```
DGS-3627:admin# telnet 10.90.90.90
Command: telnet 10.90.90.90

DGS-3627 Fast Ethernet Switch Command Line Interface

Firmware: Build 1.01-B03
Copyright(C) 2006-2010 D-Link Corporation. All rights reserved.

UserName:
```

Telnet to a host by specifying the domain name and the server port:

```
DGS-3627:admin# telnet ctrl.iplanet.org tcp_port 2323
Command: telnet ctrl.iplanet.org tcp_port 2323

Login:
```

TFTP CLIENT COMMANDS

The TFTP Client commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
download firmware_fromTFTP	{[<ipaddr> <ipv6addr> <domain_name 255>] src_file <path_filename 64> {dest_file {[unit [<unitid 1-12> all]] <drive_id> <pathname 64> {boot_up}}}}
download cfg_fromTFTP	{[<ipaddr> <ipv6addr> <domain_name 255>] src_file <path_filename 64> {[dest_file {<drive_id> <pathname 64> increment}]}}
upload firmware_toTFTP	{[<ipaddr> <ipv6addr> <domain_name 255>] dest_file <path_filename 64> {src_file {<drive_id> <pathname 64>}}
upload cfg_toTFTP	{[<ipaddr> <ipv6addr> <domain_name 255>] dest_file <path_filename 64> {src_file {<drive_id> <pathname 64>} {[include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>}} {[include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>}} {[include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>}}}}}}
upload log_toTFTP	{[<ipaddr> <ipv6addr> <domain_name 255>] dest_file <path_filename 64>}
upload attack_log_toTFTP	[<ipaddr> <ipv6addr> <domain_name 255>] dest_file <path_filename 64> {unit <unit_id 1-12>}

Each command is listed, in detail, in the following sections.

download firmware_fromTFTP

Purpose	Used to download the firmware image from TFTP server.
Syntax	download firmware_fromTFTP {[<ipaddr> <ipv6addr> <domain_name 255>] src_file <path_filename 64> {dest_file {[unit [<unitid 1-12> all]] <drive_id> <pathname 64> {boot_up}}}}
Description	This command is used to download a firmware image file from the TFTP server.
Parameters	<p><i>ipaddr</i> - The IP address of the TFTP server.</p> <p><i>ipv6addr</i> - The IPV6 address of the TFTP server.</p> <p><i>domain_name</i> - The domain name of the TFTP server.</p> <p><i>src_file</i> - Used to identify the parameter "path_filename".</p> <p><i>dest_file</i> - Used to identify the parameter "path_filename".</p> <p><i>path_filename</i> - The pathname specifies the pathname on the TFTP server. It can be a relative pathname or an absolute pathname. The drive ID can be specified in this string.</p> <p><i>unit</i> - Specifies which unit on the stacking system. If it is not specified, it refers to the master unit.</p> <p><i>all</i> - When all is specified, the firmware image on all units will be updated.</p> <p><i>boot_up</i> - The result of downloading will depend on whether boot_up option is specified.</p> <p>Case 1: In case that the master unit provides file system and the slave unit does not provide file system, if boot_up is specified, then the file will be downloaded to the boot_up image on the slave. If boot_up is not specified, then the file will not be downloaded to this slave unit.</p> <p>Case 2: In case that the master unit does not provide file system and the slave unit provides file system, if boot_up is specified, then the file will be downloaded to the boot_up image on the slave unit. If boot_up is not specified, then the file will not be downloaded to this slave unit.</p>

download firmware_fromTFTP

Case 3: In case that the master unit and the slave unit both support or not support file system, the file will be downloaded to the specified file on the slave unit. If boot_up is specified, the downloaded file will be assigned as the boot_up image.

pathname - The pathname specifies an absolute pathname on the device file system. If pathname is not specified, it refers to the boot_up image.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To download firmware from TFTP:

```
DGS-3627:admin# download firmware_fromTFTP 10.54.71.1 src_file px.had
```

```
Command: download firmware_fromTFTP 10.54.71.1 src_file px.had
```

```
Connecting to server..... Done.
```

```
Download firmware..... Done. Do not power off!
```

```
Please wait, programming flash..... Done.
```

```
DGS-3627:admin#
```

download cfg_fromTFTP

Purpose Used to download configuration file from the TFTP server.

Syntax **download cfg_fromTFTP** {[<ipaddr> | <ipv6addr> | <domain_name 255>] **src_file** <path_filename 64> {[<dest_file {<drive_id>} <pathname 64> | increment]}

Description This command is used to download a configuration file from a TFTP server.

Parameters

- ipaddr* - The IP address of the TFTP server.
- ipv6addr* - The IPV6 address of the TFTP server.
- domain_name* - The domain name of the TFTP server.
- src_file* - Used to identify the parameter "path_filename".
- dest_file* - Used to identify the parameter "path_filename".
- path_filename* - The pathname specifies the pathname on the TFTP server. It can be a relative pathname or an absolute pathname.
- pathname* - The pathname specifies an absolute pathname on the device file system. If pathname is not specified, it refers to the boot_up configuration file.
- increment* - This argument is only required for system which does not have file system and only support one configuration file since the download of a configuration will automatically apply the setting to the system. If increment is specified, then the existing configuration will not be cleared before applying of the new configuration. If it is not specified, then the existing configuration will be cleared before applying of the new configuration.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To download configuration from TFTP:

```
DGS-3627:admin# download cfg_fromTFTP 10.54.71.1 src_file cfg01.txt
Command: download cfg_fromTFTP 10.54.71.1 src_file cfg01.txt

Connecting to server..... Done.
Download configuration..... Done.

DGS-3627:admin#
```

upload firmware_toTFTP

Purpose	Used to upload firmware from device to TFTP server.
Syntax	upload firmware_toTFTP {<ipaddr> <ipv6addr> <domain_name 255>} dest_file <path_filename 64> {src_file {<drive_id>} <pathname 64>}}
Description	This command is used to upload firmware from the device to the TFTP server.
Parameters	<p><i>ipaddr</i> - The IP address of the TFTP server.</p> <p><i>ipv6addr</i> - The IPV6 address of the TFTP server.</p> <p><i>domain_name</i> - The domain name of the TFTP server.</p> <p><i>src_file</i> - Used to identify the parameter “path_filename”.</p> <p><i>dest_file</i> - Used to identify the parameter “path_filename”.</p> <p><i>path_filename</i> - The pathname specifies the pathname on the TFTP server. It can be a relative pathname or an absolute pathname.</p> <p><i>pathname</i> - The pathname specifies an absolute pathname on the device file system. If pathname is not specified, it refers to the boot_up image.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To upload firmware from a file system device to a TFTP server:

```
DGS-3627:admin#upload firmware_toTFTP 10.1.1.1 dest_file D:\firmware.had 100b70.had
Command: upload firmware_toTFTP 10.1.1.1 dest_file D:\firmware.had 100b70.had

Connecting to server..... Done.
Upload firmware..... Done.

DGS-3627:admin#
```

upload cfg_toTFTP

Purpose	Used to upload a configuration file from device to TFTP server. This command is required to be supported when file system is not supported on device’s FLASH EPROM.
Syntax	upload cfg_toTFTP {<ipaddr> <ipv6addr> <domain_name 255>} dest_file <path_filename 64> {src_file {<drive_id>} <pathname 64>} {[include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>}} {[include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>}} {[include exclude begin] <filter_string 80> {<filter_string 80> {<filter_string 80>}}}}}}
Description	This command is used to upload a configuration file from the device to the TFTP server.
Parameters	<p><i>ipaddr</i> - The IP address of the TFTP server.</p> <p><i>ipv6addr</i> - The IPV6 address of the TFTP server.</p> <p><i>domain_name</i> - The domain name of the TFTP server.</p> <p><i>src_file</i> - Used to identify the parameter “path_filename”.</p> <p><i>dest_file</i> - Used to identify the parameter “path_filename”.</p> <p><i>path_filename</i> - The pathname specifies the pathname on the TFTP server. It can be a</p>

upload cfg_toTFTP

relative pathname or an absolute pathname.
pathname - The pathname specifies an absolute pathname on the device file system.
 If pathname is not specified, it refers to the boot_up CFG file.
filter_string - A filter string is enclosed by symbol. Thus, the filter string itself cannot contain the character. The filter string is case sensitive.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To upload configuration from TFTP:

```
DGS-3627:admin# upload cfg_toTFTP 10.48.74.121 dest_file C:\test
Command: upload cfg_toTFTP 10.48.74.121 dest_file C:\test

Connecting to server... Done.
Upload Configuration... Done.

DGS-3627:admin#
```

upload log_toTFTP

Purpose Used to upload a log file from device to TFTP server. This command is required to be supported when file system is not supported on device's FLASH EPROM.

Syntax **upload log_toTFTP { [<ipaddr> | <ipv6addr> | <domain_name 255>] dest_file <path_filename 64> }**

Description This command is used to upload a log file from device to TFTP server.

Parameters *ipaddr* - The IP address of the TFTP server.
ipv6addr - The IPV6 address of the TFTP server.
domain_name - The domain name of the TFTP server.
dest_file - Used to identify the parameter "path_filename".
path_filename - The pathname specifies the pathname on the TFTP server. It can be a relative pathname or an absolute pathname.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To upload a log file from TFTP server:

```
DGS-3627:admin# upload log_toTFTP 10.48.74.121 dest_file C:\LOG
Command: upload log_toTFTP 10.48.74.121 dest_file C:\LOG

Connecting to server... Done.
Upload log... Done.

DGS-3627:admin#
```

upload attack_log_toTFTP

Purpose Used to upload the attack log on a unit.

Syntax **upload attack_log_toTFTP [<ipaddr> | <ipv6addr> | <domain_name 255>] dest_file <path_filename 64> {unit <unit_id 1-12>}**

upload attack_log_toTFTP

Description	This command is used to upload the attack log on a unit.
Parameters	<i>ipaddr</i> - The IP address of the TFTP server. <i>ipv6addr</i> - The IPV6 address of the TFTP server. <i>domain_name</i> - The domain name of the TFTP server. <i>dest_file</i> - Used to identify the parameter "path_filename". <i>path_filename</i> - Specifies the path name on the TFTP server to hold the attack log. <i>unit</i> - The attack log messages on the specified unit will be uploaded to the TFTP server. If it is not specified, it refers to the master unit.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To upload the master's dangerous log:

```
DGS-3627:admin# upload attack_log 10.90.90.1 dest_file C:\alert.txt
Command: upload attack_log 10.90.90.1 dest_file C:\alert.txt

Success.

DGS-3627:admin#
```

TIME AND SNTP COMMANDS

The Simple Network Time Protocol (SNTP) (an adaptation of the Network Time Protocol (NTP)) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config sntp	{primary <ipaddr> secondary <ipaddr> poll-interval <int 30-99999>}
show sntp	
enable sntp	
disable sntp	
config time	<date ddmthyyyy> <time hh:mm:ss>
config time_zone	{operator [+ -] hour <gmt_hour 0-13> min <minute 0-59>}
config dst	[disable repeating {s_week <start_week 1-4,last> s_day <start_day sun-sat> s_mth <start_mth 1-12> s_time <start_time hh:mm> e_week <end_week 1-4,last> e-day <end_day sun-sat> e_mth <end_mth 1-12> e_time <end_time hh:mm> offset [30 60 90 120]} annual {s_date <start_date 1-31> s_mth <start_mth 1-12> s_time <start_time hh:mm> e_date <end_date 1-31> e_mth <end_mth 1-12> e_time <end_time hh:mm> offset [30 60 90 120]}]
show time	

Each command is listed, in detail, in the following sections.

config sntp

Purpose	Used to setup SNTP service.
Syntax	config sntp {primary <ipaddr> secondary <ipaddr> poll-interval <int 30-99999>}
Description	Use this command to configure SNTP service from an SNTP server. SNTP must be enabled for this command to function (See <i>enable sntp</i>).
Parameters	<p><i>primary</i> – This is the primary server the SNTP information will be taken from.</p> <ul style="list-style-type: none"> • <i><ipaddr></i> – The IP address of the primary server. <p><i>secondary</i> – This is the secondary server the SNTP information will be taken from in the event the primary server is unavailable.</p> <ul style="list-style-type: none"> • <i><ipaddr></i> – The IP address for the secondary server. <p><i>poll-interval <int 30-99999></i> – This is the interval between requests for updated SNTP information. The polling interval ranges from 30 to 99,999 seconds.</p>
Restrictions	Only Administrator and Operator-level users can issue this command. SNTP service must be enabled for this command to function (enable sntp).

Example usage:

To configure SNTP settings:

```
DGS-3627:admin# config sntp primary 10.1.1.1 secondary 10.1.1.2 poll-interval 30
Command: config sntp primary 10.1.1.1 secondary 10.1.1.2 poll-interval 30

Success.

DGS-3627:admin#
```

show sntp

Purpose	Used to display the SNTP information.
Syntax	show sntp
Description	This command will display SNTP settings information including the source IP address, time and poll interval.
Parameters	None.
Restrictions	None.

Example usage:

To display SNTP configuration information:

```
DGS-3627:admin# show sntp
Command: show sntp

Current Time Source      : System Clock
SNTP                     : Disabled
SNTP Primary Server     : 10.1.1.1
SNTP Secondary Server   : 10.1.1.2
SNTP Poll Interval      : 720 sec

DGS-3627:admin#
```

enable sntp

Purpose	To enable SNTP server support.
Syntax	enable sntp
Description	This will enable SNTP support. SNTP service must be separately configured (see config sntp). Enabling and configuring SNTP support will override any manually configured system time settings.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command. SNTP settings must be configured for SNTP to function (config sntp).

Example usage:

To enable the SNTP function:

```
DGS-3627:admin# enable sntp
Command: enable sntp

Success.

DGS-3627:admin#
```

disable sntp

Purpose	To disable SNTP server support.
Syntax	disable sntp
Description	This will disable SNTP support. SNTP service must be separately configured (see config sntp).
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example:

To disable SNTP support:

```
DGS-3627:admin# disable sntp
Command: disable sntp

Success.

DGS-3627:admin#
```

config time

Purpose	Used to manually configure system time and date settings.
Syntax	config time <date ddmthyyyy> <time hh:mm:ss>
Description	This will configure the system time and date settings. These will be overridden if SNTP is configured and enabled.
Parameters	<i>date</i> – Express the date using two numerical characters for the day of the month, three alphabetical characters for the name of the month, and four numerical characters for the year. For example: 03aug2003. <i>time</i> – Express the system time using the format hh:mm:ss, that is, two numerical characters each for the hour using a 24-hour clock, the minute and second. For example: 19:42:30.
Restrictions	Only Administrator and Operator-level users can issue this command. Manually configured system time and date settings are overridden if SNTP support is enabled.

Example usage:

To manually set system time and date settings:

```
DGS-3627:admin# config time 30jun2003 16:30:30
Command: config time 30jun2003 16:30:30

Success.

DGS-3627:admin#
```

config time_zone

Purpose	Used to determine the time zone used in order to adjust the system clock.
Syntax	config time_zone {operator [+ -] hour <gmt_hour 0-13> min <minute 0-59>}
Description	This will adjust system clock settings according to the time zone. Time zone settings will adjust SNTP information accordingly.
Parameters	<i>operator</i> – Choose to add (+) or subtract (-) time to adjust for time zone relative to GMT. <i>hour</i> – Select the number of hours different from GMT. <i>min</i> – Select the number of minutes difference added or subtracted to adjust the time zone.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure time zone settings:

```
DGS-3627:admin# config time_zone operator + hour 2 min 30
Command: config time_zone operator + hour 2 min 30
```

Success.

```
DGS-3627:admin#
```

config dst

Purpose	Used to enable and configure time adjustments to allow for the use of Daylight Savings Time (DST).
Syntax	config dst [disable repeating {s_week <start_week 1-4,last> s_day <start_day sun-sat> s_mth <start_mth 1-12> s_time start_time hh:mm> e_week <end_week 1-4,last> e_day <end_day sun-sat> e_mth <end_mth 1-12> e_time <end_time hh:mm> offset [30 60 90 120]} annual {s_date start_date 1-31> s_mth <start_mth 1-12> s_time <start_time hh:mm> e_date <end_date 1-31> e_mth <end_mth 1-12> e_time <end_time hh:mm> offset [30 60 90 120]}]
Description	DST can be enabled and configured using this command. When enabled this will adjust the system clock to comply with any DST requirement. DST adjustment effects system time for both manually configured time and time set using SNTP service.
Parameters	<i>disable</i> – Disable the DST seasonal time adjustment for the Switch. <i>repeating</i> – Using repeating mode will enable DST seasonal time adjustment. Repeating mode requires that the DST beginning and ending date be specified using a formula. For example, specify to begin DST on Saturday during the second week of April and end DST on Sunday during the last week of October. <i>annual</i> – Using annual mode will enable DST seasonal time adjustment. Annual mode requires that the DST beginning and ending date be specified concisely. For example, specify to begin DST on April 3 and end DST on October 14.

config dst

- s_week* – Configure the week of the month in which DST begins.
- <start_week 1-4,last>* – The number of the week during the month in which DST begins where 1 is the first week, 2 is the second week and so on, last is the last week of the month.
- e_week* – Configure the week of the month in which DST ends.
- *<end_week 1-4,last>* – The number of the week during the month in which DST ends where 1 is the first week, 2 is the second week and so on, last is the last week of the month.
- s_day* – Configure the day of the week in which DST begins.
- *<start_day sun-sat>* – The day of the week in which DST begins expressed using a three character abbreviation (sun, mon, tue, wed, thu, fri, sat)
- e_day* – Configure the day of the week in which DST ends.
- *<end_day sun-sat>* – The day of the week in which DST ends expressed using a three character abbreviation (sun, mon, tue, wed, thu, fri, sat)
- s_mth* – Configure the month in which DST begins.
- *<start_mth 1-12>* – The month to begin DST expressed as a number.
- e_mth* – Configure the month in which DST ends.
- *<end_mth 1-12>* – The month to end DST expressed as a number.
- s_time* – Configure the time of day to begin DST.
- *<start_time hh:mm>* - Time is expressed using a 24-hour clock, in hours and minutes.
- e_time* – Configure the time of day to end DST.
- *<end_time hh:mm>* – Time is expressed using a 24-hour clock, in hours and minutes.
- s_date* – Configure the specific date (day of the month) to begin DST.
- *<start_date 1-31>* – The start date is expressed numerically.
- e_date* – Configure the specific date (day of the month) to begin DST.
- *<end_date 1-31>* – The end date is expressed numerically.
- offset [30 | 60 | 90 | 120]* – Indicates number of minutes to add or to subtract during the summertime. The possible offset times are 30, 60, 90, and 120. The default value is 60.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To configure daylight savings time on the Switch:

```
DGS-3627:admin# config dst repeating s_week 2 s_day tue s_mth 4 s_time 15:00 e_week 2
e_day wed e_mth 10 e_time 15:30 offset 30
Command: config dst repeating s_week 2 s_day tue s_mth 4 s_time 15:00 e_week 2 e_day wed
e_mth 10 e_time 15:30 offset 30

Success.

DGS-3627:admin#
```

show time

Purpose	Used to display the current time settings and status.
Syntax	show time
Description	This will display system time and date configuration as well as display current system time.
Parameters	None.
Restrictions	None.

Example usage:

To show the time currently set on the Switch's System clock:

```
DGS-3627:admin# show time
Command: show time

Current Time Source   : System Clock
Boot Time             : 27 Nov 2008  09:33:16
Current Time         : 27 Nov 2008  16:17:45
Time Zone            : GMT +00:00
Daylight Saving Time : Disabled
  Offset in minutes  : 60
  Repeating          : From : Apr 1st  Sun 00:00
                    : To   : Oct last Sun 00:00
  Annual            : From : 29 Apr 00:00
                    : To   : 12 Oct 00:00

DGS-3627:admin#
```

TIME RANGE COMMANDS

The Time Range commands are used in conjunction with the Access Profile commands listed in the previous chapter to determine a starting point and an ending point, based on days of the week, when an Access Profile configuration will be enabled on the Switch. Once configured here, the time range are to be applied to an access profile rule using the **config access_profile profile_id** command.



NOTE: The Time Range commands are based on the time settings of the Switch. Make sure to configure the time for the Switch appropriately for these commands using commands listed in the Time and SNTP Commands chapter later in this manual.

The Time Range commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config time_range	<range_name 32> [hours start_time <time hh:mm:ss> end_time <time hh:mm:ss> weekdays <daylist> delete]
show time_range	

Each command is listed, in detail, in the following sections.

config time_range

Purpose	Used to configure a time range in which an access profile rule is to be enabled.
Syntax	config time_range <range_name 32> [hours start_time <time hh:mm:ss> end_time <time hh:mm:ss> weekdays <daylist> delete]
Description	This command is to be used in conjunction with an access profile rule to determine a period of time when an access profile and an associated rule are to be enabled on the Switch. Remember, this time range can only be applied to one period of time and also, it is based on the time set on the Switch.
Parameters	<p><i>range_name 32</i> – Enter a name of no more than 32 alphanumeric characters that will be used to identify this time range on the Switch. This range name will be used in the config access_profile profile_id command to identify the access profile and associated rule to be enabled for this time range.</p> <p><i>hours</i> – This parameter is used to set the time in the day that this time range is to be set using the following parameters:</p> <ul style="list-style-type: none"> <i>start_time <time hh:mm:ss></i> – Use this parameter to identify the starting time of the time range, in hours, minutes and seconds, based on the 24-hour time system. <i>end_time <time hh:mm:ss></i> – Use this parameter to identify the ending time of the time range, in hours, minutes and seconds, based on the 24-hour time system. <p><i>weekdays</i> – Use this parameter to determine the days of the week to set this time range.</p> <ul style="list-style-type: none"> <i><daylist></i> – The user may set the days of the week here to set this time range in the three letter format (mon, tue, wed...). To specify a day range, separate the daylist using a dash (mon-fri would mean Monday through Friday). To specify a list of days in a week, separate the daylist using a comma, with no spaces (mon,tue,fri would mean Monday, Tuesday and Friday). <p><i>delete</i> – Use this parameter to delete a previously configured time range from the system.</p>

config time_range

Restrictions	Only Administrator and Operator-level users can issue this command.
--------------	---

Example usage:

To configure the time range time1 to be between 6:30 a.m. and 9:40 p.m., Monday to Friday:

```
DGS-3627:admin# config time_range time1 hours start_time 6:30:00 end_time 21:40:00
weekdays mon-fri
Command: config time_range time1 hours start_time 6:30:00 end_time 21:40:00 weekdays mon-
fri

Success.

DGS-3627:admin#
```

show time_range

Purpose	To view the current configurations of the time range set on the Switch.
Syntax	show time_range
Description	This command is used to display the currently configured time range(s) set on the Switch.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To view the current time range settings.

```
DGS-3627:admin# show time_range
Command: show time_range

Time Range information
-----
Range name      : time1
Weekdays       : Mon, Tue, Wed, Thu, Fri
Start time      : 06:30:00
End time        : 21:40:00

Total entries: 1

DGS-3627:admin#
```

TRACE ROUTE COMMANDS

The Trace Route commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
traceroute	[<ipaddr> <domain_name 255>] {ttl <value 1-60> port <value 30000-64900> timeout <sec 1-65535> probe <value 1-9>}
traceroute6	<ipv6addr> {ttl <value 1-60> port <value 30000-64900> timeout <sec 1-65535> probe <value 1-9>}

Each command is listed, in detail, in the following sections.

traceroute

Purpose	This command is used to trace the routed path between the switch and a destination end station.
Syntax	traceroute [<ipaddr> <domain_name 255>] {ttl <value 1-60> port <value 30000-64900> timeout <sec 1-65535> probe <value 1-9>}
Description	To track the route of an IP packet, traceroute launches UDP probe packets with a small TTL (time to live) and then listens for an ICMP "time exceeded" reply from a gateway. Probes start with a TTL of one and increase by one until either an ICMP "port unreachable" is returned, indicating that the packet reached the host, or the maximum number of hops is exceeded. At each TTL setting, one probe packet is launched (the number can be changed by specifying the parameter "probe") and traceroute prints a line showing the round trip time and the address of the gateway of each probe, or time out of each probe. If there is no response within the 5 seconds timeout interval, an asterisk (*) is printed for that probe.
Parameters	<p><i>ipaddr</i> - IP address of the destination end station.</p> <p><i><domain_name 255></i> - The domain name of the destination end station.</p> <p><i>tll <value 1-60></i> - The time to live value of the trace route request. This is the maximum number of routers that a trace route packet can cross, while seeking the network path between two devices. The range for the TTL is 1 to 60 hops.</p> <p><i>port <value 30000–64900></i> - Specify the destination UDP port number. The UDP port range is from 30000 to 64900.</p> <p><i>timeout <sec 1-65535></i> - Define the timeout period while waiting for a response from the remote device. A value of 1 to 65535 seconds can be specified. The default is 5 seconds.</p> <p><i>probe <value 1-9></i> - Specify the number of probe packets for each TTL. The default is 1.</p> <p>Note: The probe will be terminated once the destination is reached.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To trace the routed path between the switch and 10.48.74.121:

```
DGS-3627:admin# traceroute 10.48.74.121 probe 3
Command: traceroute 10.48.74.121 probe 3

<10 ms      10.12.73.254
<10 ms      10.12.73.254
<10 ms      10.12.73.254
<10 ms      10.19.68.1
<10 ms      10.19.68.1
*           Request timed out.
<10 ms      10.48.74.121

Trace complete.
DGS-3627:admin#
```

To trace the routed path between the switch and intra.example.com:

```
DGS-3627:admin# traceroute intra.example.com timeout 10
Command: traceroute intra.example.com timeout 10

<10 ms      10.12.73.254
<10 ms      10.19.68.1
<10 ms      intra.example.com [10.48.74.100]

Trace complete.
DGS-3627:admin#
```

traceroute6

Purpose	This command is used to trace the IPv6 routed path between the switch and a destination end station.
Syntax	traceroute6 <ipv6addr> {ttl <value 1-60> port <value 30000-64900> timeout <sec 1-65535> probe <value 1-9>}
Description	To track the route of an IPv6 packet, traceroute6 launches UDP probe packets with a small TTL (time to live) and then listens for an ICMP "time exceeded" reply from a gateway. Probes start with a TTL of one and increase by one until either an ICMP "port unreachable" is returned, indicating that the packet reached the host, or the maximum number of hops is exceeded. At each TTL setting, one probe are launched (the number can be changed by specifying the parameter "probe") and traceroute prints a line showing the round trip time and the address of the gateway of each probe, or time out of each probe. If there is no response within the 5 seconds timeout interval, an asterisk (*) is printed for that probe.
Parameters	<p><i>ipv6addr</i> - IPv6 address of the destination end station.</p> <p><i>ttl <value 1-60></i> - The time to live value of the trace route request. This is the maximum number of routers that a trace route v6 packet can cross, while seeking the network path between two devices. The range for the TTL is 1 to 60 hops.</p> <p><i>port <value 30000-64900></i> - Specify the destination UDP port number. The UDP port range is from 30000 to 64900.</p> <p><i>timeout <sec 1-65535></i> - Define the timeout period while waiting for a response from the remote device. A value of 1 to 65535 seconds can be specified. The default is 5 seconds.</p> <p><i>probe <value 1-9></i> - Specify the number of probe packets for each hop. The default is 1.</p> <p>Note: The probe will be terminated once the destination is reached.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To trace the IPv6 routed path between the switch and 3000::1:

```
DGS-3627:admin# traceroute6 3000::1 probe 3
```

```
Command: traceroute6 3000::1 probe 3
```

```
<10 ms      1345:142::11
<10 ms      1345:142::11
<10 ms      1345:142::11
<10 ms      2011:14::100
<10 ms      2011:14::100
*           Request timed out.
<10 ms      3000::1
```

```
Trace complete.
```

```
DGS-3627:admin#
```

To trace the IPv6 routed path between the switch and 1210:100::11 with port 40000:

```
DGS-3627:admin# traceroute6 1210:100::11 port 40000
```

```
Command: traceroute6 1210:100::11 port 40000
```

```
<10 ms      3100::25
<10 ms      4130::100
<10 ms      1210:100::11
```

```
Trace complete.
```

```
DGS-3627:admin#
```

TRAFFIC CONTROL COMMANDS

On a computer network, packets such as Multicast packets and Broadcast packets continually flood the network as normal procedure. At times, this traffic may increase do to a malicious endstation on the network or a malfunctioning device, such as a faulty network card. Thus, switch throughput problems will arise and consequently affect the overall performance of the switch network. To help rectify this packet storm, the Switch will monitor and control the situation.

The packet storm is monitored to determine if too many packets are flooding the network, based on the threshold level provided by the user. Once a packet storm has been detected, the Switch will drop packets coming into the Switch until the storm has subsided. This method can be utilized by selecting the Drop option of the Action field in the window below. The Switch will also scan and monitor packets coming into the Switch by monitoring the Switch's chip counter. This method is only viable for Broadcast and Multicast storms because the chip only has counters for these two types of packets. Once a storm has been detected (that is, once the packet threshold set below has been exceeded), the Switch will shutdown the port to all incoming traffic with the exception of STP BPDU packets, for a time period specified using the Countdown field. If this field times out and the packet storm continues, the port will be placed in a Shutdown Forever mode which will produce a warning message to be sent to the Trap Receiver. Once in Shutdown Forever mode, the only method of recovering this port is to manually recoup it using the **Port Configuration** window in the **Administration** folder and selecting the disabled port and returning it to an Enabled status. To utilize this method of Storm Control, choose the Shutdown option of the Action field in the window below.

There are two modes used for packet storm control on the Switch, Drop mode and Shutdown mode. Drop mode is hardware-based (chip-based) and Shutdown mode is a function of software. The two modes are incompatible with each other, therefore it is necessary to determine which method is best suited to the network environment where it is used.

Drop mode

The Drop mode storm control function is used to configure three chip-based hardware tables for state and a single threshold value (threshold value is the same for all three tables). If the threshold value is exceeded on a port, the Switch will drop all packets on the port. In Drop mode, some parameters such as "time interval" and "count down," as well as the CLI command, "config traffic control auto_recover_time" are software-based functions and therefore not applicable for Drop mode traffic control.

Shutdown mode

Shutdown mode is a software-based storm control function. When shutdown mode is used, the state of the hardware tables used for Drop mode are set to disable. Shutdown mode does not support DLF storm control. All configurations except the port state are saved in the software table. The CPU receives the port state from the counter table (updated at 2 second intervals). If a counter is exceeded on a port, the CPU is shutdown. All packets, except BPDU packets, on the port are dropped. If the port remains in shutdown status for a configurable period (the count down value), the port enters shutdown forever status. The port link is down and remains disabled until either the configurable recover timer is timed out or the CLI command "config ports [<portlist> | all] state enable" is manually entered.

The Traffic Control commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config traffic control	[<portlist> all] {broadcast [enable disable] multicast [enable disable] [dlf unicast] [enable disable] action [drop shutdown] threshold <value 0-255000 > countdown [<min 0> <min 3-30> disable] time_interval <sec 5-600>}
config traffic trap	[none storm_occurred storm_cleared both]
show traffic control	{<portlist>}
config traffic control auto_recover_time	[<min 0> <min 1-65535>]
config traffic control_recover	[<portlist> all]

Each command is listed, in detail, in the following sections.

config traffic control

Purpose	Used to configure broadcast/multicast packet storm control. Shutdown mode is provided to monitor the traffic rate in addition to the storm control drop mode. If traffic rate is too high, this port will be shut down.
Syntax	config traffic control [<portlist> all] {broadcast [enable disable] multicast [enable disable] [dlf unicast] [enable disable] action [drop shutdown] threshold <value 0-255000 > countdown [<min 0> <min 3-30> disable] time_interval <sec 5-600>}
Description	The config traffic control command configures broadcast/multicast/DLF storm control.
Parameters	<p><i>portlist</i> - Used to specify a range of ports to be configured.</p> <p><i>broadcast</i> - Enable or disable broadcast storm control.</p> <p><i>multicast</i> - Enable or disable multicast storm control.</p> <p><i>dlf</i> - Enable or disable unknown packet storm control. (Supported for drop mode only)</p> <p><i>action</i> - One of the two options for action are specified for storm control, shutdown of drop mode. Shutdown mode is a function of software, drop mode is implemented by the chip. If shutdown mode is specified, it is necessary to configure values for the <i>back_off</i> and <i>time_interval</i> parameters.</p> <p><i>threshold</i> - The upper threshold, at which point the specified storm control is triggered. The <value>is the number of broadcast/multicast packets per second received by the switch that will trigger the storm traffic control measure. The threshold is expressed as PPS (packets per second) and must be an unsigned integer.</p> <p><i>time_interval</i> - The sampling interval of received packet counts. The possible value will be 5-600 seconds. The parameter is not applicable if “drop” (mode) is specified for the “action” parameter.</p> <p><i>countdown</i> - Timer for shutdown mode. If a port enters the shutdown Rx state and this timer runs out, port will be shutdown forever. The parameter is not applicable if “drop” (mode) is specified for the “action” parameter. Default is 0 minutes. 0 disables the forever state, meaning that the port will not enter the shut down forever state.</p> <p><i>disable</i> - Countdown is disable, the port directly shutdown when the switch detects storm.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the parameters so that the traffic control status is enabled on ports 1-12:

```
DGS-3627:admin# config traffic control 1-12 broadcast enable action shutdown threshold 1
countdown 5 time_interval 10
Command: config traffic control 1-12 broadcast enable action shutdown threshold 1
countdown 5 time_interval 10

Success.

DGS-3627:admin#
```

config traffic trap

Purpose	Used to configure trap modes.
Syntax	config traffic trap [none storm_occurred storm_cleared both]
Description	Occurred Mode: This trap is sent when a packet storm is detected by the packet storm mechanism. Cleared Mode: This trap is sent when the packet storm is cleared by the packet storm mechanism.
Parameters	<i>none</i> - No trap state is specified for storm control. <i>storm_occurred</i> - Occurred mode is enabled and cleared mode is disabled. <i>storm_cleared</i> - Occurred mode is disabled and cleared mode is enabled. <i>both</i> - Both occurred and cleared modes are enabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable both the occurred mode and cleared mode traffic control traps:

```
DGS-3627:admin# config traffic trap both
Command: config traffic trap both

Success.

DGS-3627:admin#
```

show traffic control

Purpose	Used to display the current traffic control settings.
Syntax	show traffic control { <portlist> }
Description	The show traffic control command displays the current traffic control settings.
Parameters	<i>portlist</i> - Used to specify the range of ports to be shown. If no parameter is specified, the system will display the packet storm control configuration for all ports.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To display the traffic control parameters for ports 1 to 10:

DGS-3627:admin# show traffic control 1-10

Command: show traffic control 1-10

Traffic Control Trap : [None]
 Traffic Control Auto Recover Time : 5 Minutes

Port	Thres hold	Broadcast Storm	Multicast Storm	Unicast Storm	Action	Count	Time down	Shutdown Interval Forever
1	1	Enabled	Disabled	Disabled	Shutdown	5	10	
2	1	Enabled	Disabled	Disabled	Shutdown	5	10	
3	1	Enabled	Disabled	Disabled	Shutdown	5	10	
4	1	Enabled	Disabled	Disabled	Shutdown	5	10	
5	1	Enabled	Disabled	Disabled	Shutdown	5	10	
6	1	Enabled	Disabled	Disabled	Shutdown	5	10	
7	1	Enabled	Disabled	Disabled	Shutdown	5	10	
8	1	Enabled	Disabled	Disabled	Shutdown	5	10	
9	1	Enabled	Disabled	Disabled	Shutdown	5	10	
10	1	Enabled	Disabled	Disabled	Shutdown	5	10	

DGS-3627:admin#

config traffic control auto_recover_time

Purpose	Used to configure the traffic auto recover time used to specify the time allowed for a port to recover from shutdown forever status.
Syntax	config traffic control auto_recover_time [<min 0> <min 1-65535>]
Description	Configure all ports' auto recover time from shutdown forever state.
Parameters	<i>minutes</i> - The time allowed for auto recovery from shutdown for a port. The default value is 0, so no auto recovery is possible; the port remains in shutdown forever mode. This requires manual entry of the CLI command "config ports [<portlist> all] state enable" to return the port to a forwarding state. The default value is 0, which means disable auto recover mode, shutdown forever.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the auto recover time to 5 minutes:

DGS-3627:admin# config traffic control auto_recover_time 5

Command: config traffic control auto_recover_time 5

Success.

DGS-3627:admin#

TRAFFIC SEGMENTATION COMMANDS

Traffic segmentation allows users to further sub-divide VLANs into smaller groups of ports that will help to reduce traffic on the VLAN. The VLAN rules take precedence, and then the traffic segmentation rules are applied.

Command	Parameters
config traffic_segmentation	[<portlist> all] forward_list [null all <portlist>]
show traffic_segmentation	{<portlist>}

Each command is listed, in detail, in the following sections.

config traffic_segmentation

Purpose	Used to configure traffic segmentation on the Switch.
Syntax	config traffic_segmentation [<portlist> all] forward_list [null all <portlist>]
Description	The config traffic_segmentation command is used to configure traffic segmentation on the Switch.
Parameters	<p><portlist> – Specifies a port or range of ports that will be configured for traffic segmentation. The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex: 1-3,7-9)</p> <p>forward_list – Specifies a range of ports that will receive forwarded frames from the ports specified in the portlist, above.</p> <ol style="list-style-type: none"> 1. <i>null</i> – No ports are specified. 2. <i>all</i> – All ports are specified. 3. <portlist> – Specifies a range of ports for the forwarding list. This list must be on the same Switch previously specified for traffic segmentation (i.e. following the <portlist> specified above for config traffic_segmentation). The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex:1-3,7-9)
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure ports 1 through 5 to be able to forward frames to port 6 through 10:

```
DGS-3627:admin# config traffic_segmentation 1-5 forward_list 6-10
Command: config traffic_segmentation 1-5 forward_list 6-10

Success.

DGS-3627:admin#
```

show traffic_segmentation

Purpose	Used to display the current traffic segmentation configuration on the Switch.
Syntax	show traffic_segmentation {<portlist>}
Description	The show traffic_segmentation command is used to display the current traffic segmentation configuration on the Switch.
Parameters	<i><portlist></i> – Specifies a port or range of ports for which the current traffic segmentation configuration on the Switch will be displayed. The beginning and end of the port list range are separated by a dash. Non-contiguous portlist entries are separated by a comma. (ex: 1-3,7-9)
Restrictions	The port lists for segmentation and the forward list must be on the same Switch.

Example usage:

To display the current traffic segmentation configuration on the Switch.

```
DGS-3627:admin# show traffic_segmentation
Command: show traffic_segmentation

Traffic Segmentation Table
Port Forward Portlist
-----
1:1 1:1-1:25
1:2 1:1-1:25
1:3 1:1-1:25
1:4 1:1-1:25
1:5 1:1-1:25
1:6 1:1-1:25
1:7 1:1-1:25
1:8 1:1-1:25
1:9 1:1-1:25
1:10 1:1-1:25
1:11 1:1-1:25
1:12 1:1-1:25
1:13 1:1-1:25
1:14 1:1-1:25
1:15 1:1-1:25
1:16 1:1-1:25
1:17 1:1-1:25
1:18 1:1-1:25
CTRL+C ESC q Quit SPACE n Next Page Enter Next Entry a All
```

TRUSTED HOST COMMANDS

Trusted Host is a security feature which denies an illegal network address to access the switch.

The Trusted Host commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create trusted_host	[<ipaddr> network <network_address>]
delete trusted_host	[ipaddr <ipaddr> network <network_address> all]
show trusted_host	

Each command is listed, in detail, in the following sections.

create trusted_host

Purpose	Used to create the trusted host.
Syntax	create trusted_host [<ipaddr> network <network_address>]
Description	The create trusted host command creates the trusted host. The switch allows you to specify up to three IP addresses that are allowed to manage the switch via in-band SNMP or Telnet based management software. These IP addresses must be members of the Management VLAN. If no IP addresses are specified, then there is nothing to prevent any IP address from accessing the switch, provided the user knows the Username and Password.
Parameters	When the access interface is not specified, the trusted host will be created for all interfaces. <i>ipaddr</i> - The IP address of the trusted host. <i>network</i> - The network address of the trusted network. The form of network address is xxx.xxx.xxx.xxx/y.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a trusted host:

```
DGS-3627:admin# create trusted_host 10.48.74.121
Command: create trusted_host 10.48.74.121

Success.

DGS-3627:admin#
```

delete trusted_host

Purpose	Used to delete a trusted host entry made using the create trusted_host command above.
Syntax	delete trusted_host [ipaddr <ipaddr> network <network_address> all]
Description	The delete trusted_host command is used to delete a trusted host entry made using the create trusted_host command above.

delete trusted_host

Parameters	<i>ipaddr</i> - The IP address of the trusted host. <i>network</i> - The network address of the trusted network. <i>all</i> - All trusted hosts will be deleted.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete the trusted host:

```
DGS-3627:admin# delete trusted_host 10.48.74.121
Command: delete trusted_host 10.48.74.121

Success.

DGS-3627:admin#
```

show trusted_host

Purpose	Used to display a list of trusted hosts entered on the switch using the create trusted_host command above.
Syntax	show trusted_host
Description	The show trusted host command displays the trusted hosts.
Parameters	None.
Restrictions	None.

Example usage:

To display a trusted host:

```
DGS-3627:admin# show trusted_host
Command: show trusted_host

Management Stations

IP Address
-----
10.48.93.100
10.51.17.1
10.50.95.90

Total Entries:3

DGS-3627:admin#
```

UNICAST ROUTE COMMANDS

Route Preference is a way for routers to select the best path when there are two or more different routes to the same destination from two different routing protocols. The majority of routing protocols are not compatible when used in conjunction with each other. This Switch supports and may be configured for many routing protocols, as a stand alone switch or more importantly, in utilizing the stacking function and Single IP Management of the Switch. Therefore the ability to exchange route information and select the best path is essential to optimal use of the Switch and its capabilities.

The first decision the Switch will make in selecting the best path is to consult the Route Preference Settings table of the Switch. This table can be viewed using the **show route preference** command, and it holds the list of possible routing protocols currently implemented in the Switch, along with a reliability value which determines which routing protocol will be the most dependable to route packets. Below is a list of the default route preferences set on the Switch.

Route Type	Validity Range	Default Value
Default	1-999	1
Local	0 – Permanently set on the Switch and not configurable.	0
Static	1 – 999	60
RIP	1 – 999	100
OSPF Intra	1 – 999	80
OSPF Inter	1 – 999	90
OSPF ExtT1	1 – 999	110
OSPF ExtT2	1 – 999	115
EBGP	1 – 999	70
IBGP	1 – 999	130

As shown above, Local will always be the first choice for routing purposes and the next most reliable path is Static due to the fact that its has the next lowest value. To set a higher reliability for a route, change its value to a number less than the value of a route preference that has a greater reliability value using the **config route preference** command. For example, if the user wishes to make RIP the most reliable route, the user can change its value to one that is less than the lowest value (Static - 60) or the user could change the other route values to more than 100.

The user should be aware of three points before configuring the route preference.

- No two route preference values can be the same. Entering the same route preference may cause the Switch to crash due to indecision by the Switch.
- If the user is not fully aware of all the features and functions of the routing protocols on the Switch, a change in the default route preference value may cause routing loops or black holes.
- After changing the route preference value for a specific routing protocol, that protocol needs to be restarted because the previously learned routes have been dropped from the Switch. The Switch must learn the routes again before the new settings can take affect.

The Unicast Route commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create iproute	[default <network_address>] [null0 <ipaddr> {<metric 1-65535>} {[primary backup weight <value 1-4>}]]
delete iproute	[default <network_address>] [null0 <ipaddr>]
show iproute	{[<network_address> <ipaddr>]} {[static rip ospf bgp hardware]}
config route preference	[static default rip ospfIntra ospfInter ospfExt1 ospfExt2 ebgp ibgp] <value 1-999>
show route preference	{[local static default rip ospf ospfIntra ospfInter ospfExt1 ospfExt2 ebgp ibgp]}
create route redistribute dst ospf	src [static rip bgp local] {mettype [1 2] metric <value 0-16777214>}
create route redistribute dst rip	src [local static bgp ospf [all internal external type_1 type_2 inter+e1 inter+e2]] {metric <value 0-16>}
create route redistribute dst bgp	src [static rip local ospf [all internal external type_1 type_2 inter+e1 inter+e2]] {metric <uint 0-4294967295> route_map <map_name 16>}
delete route redistribute	[dst [rip ospf bgp] src [rip static local ospf bgp]]
config route redistribute dst ospf	src [static rip bgp local] {mettype [1 2] metric <value 0-16777214>}(1)
config route redistribute dst rip	src [local static bgp ospf [all internal external type_1 type_2 inter+e1 inter+e2]] {metric <value 0-16>}
config route redistribute dst bgp	src [static rip local ospf [all internal external type_1 type_2 inter+e1 inter+e2]] {metric <uint 0-4294967295> [route_map <map_name 16> no_route_map]}
enable ecmp ospf	
disable ecmp ospf	
show route redistribute	{dst [rip ospf bgp] src [rip static local bgp ospf]}
config ecmp algorithm	{ip_destination [ip_source crc_low crc_high] tcp_udp_port}(1)
show ecmp	

Each command is listed, in detail, in the following sections.

create iproute

Purpose	Used to create an IP route entry to the switch's IP routing table.
Syntax	create iproute [default <network_address>] [null0 <ipaddr> {<metric 1-65535>} {[primary backup weight <value 1-4>}]]
Description	<p>Use this command to create an IP static route.</p> <p>Selecting "primary" or "backup" means the newly created route is a floating static route. Selecting "weight" means the newly created route is a static multipath route. Floating static route and static multipath route are mutually exclusive.</p> <p>If none of the following, "primary", "backup" or "weight," is selected, the static route will:</p> <ul style="list-style-type: none"> be primary if there is no primary route that has the same destination; be backup if there has been a primary route that has the same destination. fail to create if there have been a primary route and a backup route that have the same destination. fail to create if there has been one static multipath route that has the same destination.

create iproute

It will fail if a user wants to create a floating static route and there has been one static multipath route with the same destination.

It will fail if a user wants to create a static multipath route and there has been a floating static route, whether primary or backup.

Parameters

default - Create an IP default route (0.0.0.0/0).

network_address - The IP address and net mask of the destination of the route. The address and the mask can be set by the traditional format (for example, 10.1.2.3/255.0.0.0 or in CIDR format, 10.1.2.3/16).

null0 - Specify null interface as the next hop.

ipaddr - The IP address for the next hop router.

metric - The default setting is 1.

primary - Specify the route as the primary route to the destination.

backup - Specify the route as the backup route to the destination.

weight - Specify the route as the static multipath route. The default setting is 1.

One route's weight will determine its ratio when used by data packets forwarding to one destination.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To add a floating static route and a static multipath route:

```
DGS-3627:admin# create iproute 10.48.74.121/255.0.0.0 10.1.1.254 primary
```

```
Command: create iproute 10.48.74.121/8 10.1.1.254 primary
```

Success.

```
DGS-3627:admin# create iproute 11.53.73.131/8 10.1.2.11 weight 2
```

```
Command: create iproute 11.53.73.131/8 10.1.2.11 weight 2
```

Success.

```
DGS-3627:admin#
```

delete iproute default

Purpose

Used to delete an IP route entry from the switch's IP routing table.

Syntax

delete iproute [default | <network_address>] [null0 | <ipaddr>]

Description

Use this command to delete an IP static route.

Parameters

default - Deletes an IP default route (0.0.0.0/0).

network_address - The IP address and net mask of the destination of the route. The address and the mask can be set by the traditional format (for example, 10.1.2.3/255.0.0.0 or in CIDR format, 10.1.2.3/16).

null0 - Specify null interface as the next hop.

ipaddr - Specify the next hop IP address of the route need to be deleted.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To delete an IP static route:

```
DGS-3627:admin# delete iproute 10.48.74.121/255.0.0.0 10.1.1.254
```

```
Command: delete iproute 10.48.74.121/8 10.1.1.254
```

```
Success.
```

```
DGS-3627:admin#
```

show iproute

Purpose	Used to display the switch's current IP routing table.
Syntax	show iproute {[<network_address> <ipaddr>]} {[static rip ospf bgp hardware]}
Description	Use this command to display the switch's IP routing table.
Parameters	<p><i>network_address</i> - Specify the destination network address of the route to be displayed.</p> <p><i>ipaddr</i> - Specify the destination IP address of the route to be displayed. The longest prefix matched route will be displayed.</p> <p><i>static</i> - Specify to display only static routes. One static route may be active or inactive.</p> <p><i>rip</i> - Specify to display only RIP routes.</p> <p><i>ospf</i> - Specify to display only OSPF routes.</p> <p><i>bgp</i> - Specify to display only BGP routes.</p> <p><i>hardware</i> - Specify to display only the routes that have been written into the chip.</p>
Restrictions	None.

Example usage:

To display the contents of the IP routing table:

DGS-3627:admin# show iproute

Command: show iproute

Routing Table

IP Address/Netmask	Gateway	Interface	Cost	Protocol
10.1.1.0/24	0.0.0.0	System	1	Local
192.168.1.0/24	0.0.0.0	ip1	1	Local

Total Entries : 2

DGS-3627:admin# show iproute static

Command: show iproute static

Routing Table

IP Address/Netmask	Gateway	Cost	Protocol	Backup	Weight	Status
0.0.0.0/0	10.1.1.11	1	Default	Primary	None	Active
100.1.1.0/24	10.1.1.11	1	Static	Primary	None	Active
101.1.1.0/24	10.1.1.12	1	Static	Primary	None	Inactive

Total Entries : 3

DGS-3627:admin# show iproute hardware

Command: show iproute hardware

Routing Table

IP Address/Netmask	Gateway	Interface
0.0.0.0/0	10.1.1.11	ip1
10.1.1.0/24	0.0.0.0	System
100.1.1.0/24	10.1.1.11	ip1
192.168.1.0/24	10.1.1.11	ip1

Total Entries : 4

DGS-3627:admin#

config route preference

Purpose	Used to configure route type preference.
Syntax	config route preference [static default rip ospfIntra ospfInter ospfExt1 ospfExt2 ebgp ibgp] <value 1-999>
Description	Use this command to configure route preference. The route with smaller preference has higher priority. The preference for local routes is fixed to 0.
Parameters	<p><i>static</i> - Configure the preference of static route. The default value is 60.</p> <p><i>default</i> - Configure the preference of default route. The default value is 1.</p> <p><i>rip</i> - Configure the preference of RIP route. The default value is 100.</p> <p><i>ospfIntra</i> - Configure the preference of OSPF intra-area route. The default value is 80.</p> <p><i>ospfInter</i> - Configure the preference of OSPF inter-area route. The default value is 90.</p> <p><i>ospfExt1</i> - Configure the preference of OSPF external type-1 route. The default value is 110.</p>

config route preference

ospfExt2 - Configure the preference of OSPF external type-2 route. The default value is 115.
ebgp - Configure the preference of BGP AS-external route. The default value is 70.
ibgp - Configure the preference of BGP AS-internal route. The default value is 130.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To configure the route preference for static routes to 70:

```
DGS-3627:admin# config route preference static 70
Command: config route preference static 70
```

Success.

```
DGS-3627:admin#
```

show route preference

Purpose	Used to display the route preference of each route type.
Syntax	show route preference {[local static default rip ospf ospfIntra ospfInter ospfExt1 ospfExt2 ebgp ibgp]
Description	This command is used to display route preference setting.
Parameters	<i>local</i> - Display the preference of local route. <i>static</i> - Display the preference of static route. <i>default</i> - Display the preference of default route. <i>rip</i> - Display the preference of RIP route. <i>ospf</i> - Display the preference of all types of OSPF route. <i>ospfIntra</i> - Display the preference of OSPF intra-area route. <i>ospfInter</i> - Display the preference of OSPF inter-area route. <i>ospfExt1</i> - Display the preference of OSPF external type-1 route. <i>ospfExt2</i> - Display the preference of OSPF external type-2 route. <i>ebgp</i> - Display the preference of BGP AS-external route. <i>ibgp</i> - Display the preference of BGP AS-internal route.
Restrictions	None.

Example usage:

To display the route preference for all route types:

```
DGS-3627:admin# show route preference
```

```
Command: show route preference
```

Route Preference Settings

Protocol	Preference
RIP	100
Static	60
Default	1
Local	0
OSPF Intra	80
OSPF Inter	90
OSPF ExtT1	110
OSPF ExtT2	115
EBGP	70
IBGP	130

```
DGS-3627:admin#
```

create route redistribute dst ospf

Purpose	Used to redistribute routing information from other routing protocols to OSPF.
Syntax	create route redistribute dst ospf src [static rip local bgp] {mettype [1 2] metric <value 0-16777214>}
Description	This command is used to redistribute routing information from other routing protocols to OSPF.
Parameters	<p><i>dst</i> - Specify the target protocol.</p> <p><i>src</i> - Specify the source protocol.</p> <p><i>static</i> - To redistribute static routes to OSPF.</p> <p><i>local</i> - To redistribute the local routes to OSPF.</p> <p><i>rip</i> - To redistribute the RIP routes to OSPF.</p> <p><i>bgp</i> - To redistribute the BGP routes to OSPF.</p> <p><i>mettype</i> - Allows the selection of one of two methods for calculating the metric value. 1 calculates the metric (for other routing protocols to OSPF) by adding the destination's interface cost to the metric entered in the Metric field. 2 uses the metric entered in the Metric field without change. This field applies only when the destination field is OSPF. If the metric type is not specified, it will be type 2.</p> <p><i>metric</i> - Specifies the metric for the redistributed routes. The range is 0 to 16777214. If it is not specified or specified as 0, the redistributed routes will be associated with the default metric 20.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To add route redistribution to OSPF:

```
DGS-3627:admin# create route redistribute dst ospf src rip
```

```
Command: create route redistribute dst ospf src rip
```

```
Success.
```

```
DGS-3627:admin#
```

create route redistribute dst rip

Purpose	Used to redistribute routing information from other routing protocols to RIP.
Syntax	create route redistribute dst rip src [local static bgp ospf [all internal external type_1 type_2 inter+e1 inter+e2]] {metric <value 0-16>}
Description	This command is used to redistribute routing information from other routing protocols to RIP. When the metric is specified as 0, the metric in the original route will become the metric of the redistributing RIP routes transparently. If the metric of the original routes is greater than 16, the route will be not redistributed.
Parameters	<p><i>dst</i> - Specify the target protocol.</p> <p><i>src</i> - Specify the source protocol.</p> <p><i>static</i> - To redistribute static routes to RIP.</p> <p><i>local</i> - To redistribute local routes to RIP.</p> <p><i>bgp</i> - To redistribute BGP routes to RIP.</p> <p><i>ospf</i> - To redistribute OSPF routes to RIP.</p> <p><i>all</i> - To redistribute both OSPF AS-internal and OSPF AS-external routes to RIP.</p> <p><i>internal</i> - To redistribute only the OSPF AS-internal routes.</p> <p><i>external</i> - To redistribute only the OSPF AS-external routes, including type-1 and type-2 routes.</p> <p><i>type_1</i> - To redistribute only the OSPF AS-internal type-1 routes.</p> <p><i>type_2</i> - To redistribute only the OSPF AS-internal type-2 routes.</p> <p><i>inter+e1</i> - To redistribute only the OSPF AS-internal type-1 and OSPF AS-internal routes.</p> <p><i>inter+e2</i> - To redistribute only the OSPF AS-internal type-2 and OSPF AS-internal routes.</p> <p><i>metric</i> - Specifies the RIP route metric value for the redistributed routes. The valid value is 0 to 16. The default value is 0.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To add route redistribution settings:

```
DGS-3627:admin# create route redistribute dst rip src ospf all metric 2
```

```
Command: create route redistribute dst rip src ospf all metric 2
```

```
Success.
```

```
DGS-3627:admin#
```

create route redistribute dst bgp

Purpose	Used to redistribute routing information from other routing protocols to BGP.
Syntax	create route redistribute dst bgp src [static rip local ospf [all internal external type_1 type_2 inter+e1 inter+e2]] {metric <uint 0-4294967295> route_map <map_name 16>}
Description	This command is used to redistribute routing information from other routing protocols to BGP.
Parameters	<p><i>dst</i> - Specify the target protocol.</p> <p><i>src</i> - Specify the source protocol.</p> <p><i>static</i> - To redistribute static routes to BGP.</p> <p><i>local</i> - To redistribute local routes to BGP.</p> <p><i>rip</i> - To redistribute RIP routes to BGP.</p>

create route redistribute dst bgp

ospf - To redistribute OSPF routes to BGP.

all - To redistribute both OSPF AS-internal and OSPF AS-external routes to RIP.

internal - To redistribute only the OSPF AS-internal routes.

external - To redistribute only the OSPF AS-external routes, including type-1 and type-2 routes.

type_1 - To redistribute only the OSPF AS-internal type-1 routes.

type_2 - To redistribute only the OSPF AS-internal type-2 routes.

inter+e1 - To redistribute only the OSPF AS-internal type-1 and OSPF AS-internal routes.

inter+e2 - To redistribute only the OSPF AS-internal type-2 and OSPF AS-internal routes.

metric - Specify the BGP metric value for the redistributed routes. The range is 0 to 4294967295. The default value is 0.

route_map - Specify a route map which will be used as the criteria to determine whether to redistribute specific routes.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To add route redistribution settings:

```
DGS-3627:admin# create route redistribute dst bgp src ospf all metric 2
```

```
Command: create route redistribute dst bgp src ospf all metric 2
```

Success.

```
DGS-3627:admin#
```

delete route redistribute

Purpose Used to delete route redistribute configuration on the switch.

Syntax **delete route redistribute [dst [rip | ospf | bgp] src [rip | static | local | ospf | bgp]]**

Description This command is used to stop redistribution of routes from one source protocol to another destination protocol.

Parameters *dst* - Specify the target protocol.
src - Specify the source protocol.

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To delete route redistribution settings:

```
DGS-3627:admin# delete route redistribute dst rip src ospf
```

```
Command: delete route redistribute dst rip src ospf
```

Success.

```
DGS-3627:admin#
```


config route redistribute dst ospf

Purpose	Used to update the metric to be associated with the redistributed routes from a specific protocol to OSPF protocol.
Syntax	config route redistribute dst ospf src [static rip bgp local] {mettype [1 2] metric <value 0-16777214>}(1)
Description	This command updates the metric to be associated with the redistributed routes from a specific protocol to OSPF protocol.
Parameters	<p><i>dst</i> - Specify the target protocol.</p> <p><i>src</i> - Specify the source protocol.</p> <p><i>static</i> - To redistribute the static routes to OSPF.</p> <p><i>rip</i> - To redistribute RIP routes to OSPF</p> <p><i>bgp</i> - To redistribute BGP routes to OSPF</p> <p><i>local</i> - To redistribute the local routes to OSPF</p> <p><i>mettype</i> - Allows the selection of one of two methods for calculating the metric value. 1 calculates the metric (for other routing protocols to OSPF) by adding the destination's interface cost to the metric entered in the Metric field. 2 uses the metric entered in the Metric field without change. This field applies only when the destination field is OSPF. If the metric type is not specified, it will be type 2.</p> <p><i>metric</i> - Specifies the metric for the redistributed routes. The range is 0 to 16777214. If it is not specified or specified as 0, the redistributed routes will be associated with the default metric 20.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure route redistributions:

```
DGS-3627:admin# config route redistribute dst ospf src rip mettype 1 metric 2
Command: config route redistribute dst ospf src rip mettype 1 metric 2

Success.

DGS-3627:admin#
```

config route redistribute dst rip

Purpose	Used to update the metric to be associated with the redistributed routes from a specific protocol to RIP protocol.
Syntax	config route redistribute dst rip src [local static bgp ospf [all internal external type_1 type_2 inter+e1 inter+e2]] {metric <value 0-16>}
Description	This command is used to update the metric to be associated with the redistributed routes from a specific protocol to RIP protocol.
Parameters	<p><i>dst</i> - Specify the target protocol.</p> <p><i>src</i> - Specify the source protocol.</p> <p><i>static</i> - To redistribute static routes to RIP.</p> <p><i>local</i> - To redistribute local routes to RIP.</p> <p><i>bgp</i> - To redistribute BGP routes to RIP.</p> <p><i>ospf</i> - See below:</p> <p><i>all</i> - To redistribute both OSPF AS-internal and OSPF AS-external routes to RIP.</p> <p><i>internal</i> - To redistribute only the OSPF AS-internal routes.</p> <p><i>external</i> - To redistribute only the OSPF AS-external routes, including type-1 and type-2 routes.</p>

config route redistribute dst rip

type_1 - To redistribute only the OSPF AS-internal type-1 routes.
type_2 - To redistribute only the OSPF AS-internal type-2 routes.
inter+e1 - To redistribute only the OSPF AS-internal type-1 and OSPF AS-internal routes.
inter+e2 - To redistribute only the OSPF AS-internal type-2 and OSPF AS-internal routes.

metric - Specifies the RIP metric value for the redistributed routes. The valid value is 0 to 16.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To configure route redistributions:

```
DGS-3627:admin# config route redistribute dst rip src ospf internal
Command: config route redistribute dst rip src ospf internal
```

Success.

```
DGS-3627:admin#
```

config route redistribute dst bgp

Purpose

This command updates the metric to be associated with the redistributed routes from a specific protocol to BGP protocol.

Syntax

```
config route redistribute dst bgp src [static | rip | local | ospf [all | internal | external | type_1 | type_2 | inter+e1 | inter+e2]] {metric <uint 0-4294967295> | [route_map <map_name 16> | no_route_map]}
```

Description

This command is used to update the metric to be associated with the redistributed routes from a specific protocol to BGP protocol. If a user does not specify any one of the parameters of metric, route map and no route map, the configuration of metric and route map will be set to be the default value.

Parameters

dst - Specify the target protocol.

src - Specify the source protocol.

static - To redistribute static routes to BGP.

local - To redistribute local routes to BGP.

rip - To redistribute RIP routes to BGP.

ospf - See below:

all - To redistribute both OSPF AS-internal and OSPF AS-external routes to RIP.

internal - To redistribute only the OSPF AS-internal routes.

external - To redistribute only the OSPF AS-external routes, including type-1 and type-2 routes.

type_1 - To redistribute only the OSPF AS-internal type-1 routes.

type_2 - To redistribute only the OSPF AS-internal type-2 routes.

inter+e1 - To redistribute only the OSPF AS-internal type-1 and OSPF AS-internal routes.

inter+e2 - To redistribute only the OSPF AS-internal type-2 and OSPF AS-internal routes.

metric - Specifies the BGP metric value for the redistributed routes. The range is 0 to 4294967295. The default value is 0.

route_map - Specifies a route map which will be used as the criteria to determine whether to redistribute specific routes. The default setting is null.

no_router_map - Withdraw the route map setting.

config route redistribute dst bgp

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To add route redistribution settings:

```
DGS-3627:admin# config route redistribute dst bgp src ospf all metric 2
Command: config route redistribute dst bgp src ospf all metric 2

Success.

DGS-3627:admin#
```

show route redistribute

Purpose	Used to display the route redistribution settings on the switch.
Syntax	show route redistribute {dst [rip ospf bgp] src [rip static local bgp ospf]}
Description	This command is used to display the route redistributions settings.
Parameters	<p><i>dst</i> - Specify the target protocol.</p> <ul style="list-style-type: none"> <i>rip</i> - Display the redistribution with the target protocol RIP. <i>ospf</i> - Display the redistribution with the target protocol OSPF. <i>bgp</i> - Display the redistribution with the target protocol BGP. <p><i>src</i> - Specify the source protocol.</p> <ul style="list-style-type: none"> <i>rip</i> - Display the redistribution with the source protocol RIP. <i>static</i> - Display the redistribution with the source static. <i>local</i> - Display the redistribution with the source local. <i>ospf</i> - Display the redistribution with the source protocol OSPF. <i>bgp</i> - Display the redistribution with the source protocol BGP. <p>If no parameter is specified, the system will display all route redistributions.</p>
Restrictions	None.

Example usage:

To display route redistributions:

```
DGS-3627:admin# show route redistribute
Command: show route redistribute

Route Redistribution Settings

Source      Destination  Type      Metric      Routemap
Protocol    Protocol
-----
RIP         OSPF         Type-2    20          N/A
OSPF        BGP          All       100         routemap1

Total Entries : 2

DGS-3627:admin#
```

enable ecmp ospf

Purpose	This command is used to enable the ECMP route load-balancing algorithm.
Syntax	enable ecmp ospf
Description	This command is used to enable the ECMP route load-balancing algorithm.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable the ECMP route load-balancing algorithm:

```
DGS-3627:admin# enable ecmp ospf
Command: enable ecmp ospf

Success.

DGS-3627:admin#
```

disable ecmp ospf

Purpose	Used to disable the OSPF ECMP function.
Syntax	disable ecmp ospf
Description	This command is used to disable the OSPF ECMP function.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable OSPF ECMP function:

```
DGS-3627:admin# disable ecmp ospf
Command: disable ecmp ospf

Success.

DGS-3627:admin#
```

config ecmp algorithm

Purpose	Used to configure the ECMP route load-balancing algorithm.
Syntax	config ecmp algorithm {ip_destination [ip_source crc_low crc_high] tcp_udp_port}(1)
Description	This command is used to configure the ECMP route load-balancing algorithm. Thus, it is effective for ECMP routing. ECMP routing can be adopted either by OSPF dynamic routes or by static routes which are configured with equal weight.
Parameters	<p><i>ip_destination</i> - If set, the ecmp algorithm will include the destination IP. It is set by default.</p> <p><i>ip_source</i> - If set, the ecmp algorithm will include the the lower 5 bits of the source IP. This attribution is mutually exclusive with <i>crc_low</i> and <i>crc_high</i>. If it is set, <i>crc_low</i> and <i>crc_high</i> will be excluded. It is not set by default.</p> <p><i>crc_low</i> - If set, the ecmp algorithm will include the lower 5 bits of the CRC. This attribution is mutually exclusive with <i>crc_high</i> and <i>ip_source</i>. If it is set, <i>crc_high</i> and <i>ip_source</i> will be</p>

config ecmp algorithm

excluded. It is set by default.

crc_high - If set, the ecmp algorithm will include the upper 5 bits of the CRC. This attribution is mutually exclusive with *ip_source* and *crc_low*. If it is set, *crc_low* and *ip_source* will be excluded. It is not set by default.

tcp_udp_port - If set, the ecmp algorithm will include the TCP or UDP port. It is not set by default.

Restrictions

Only Administrator and Operator-level users can issue this command.

Example usage:

To set the ECMP hash algorithm:

```
DGS-3627:admin# config ecmp algorithm ip_destination ip_source
```

```
Command: config ecmp algorithm ip_destination ip_source
```

Success.

```
DGS-3627:admin#
```

show ecmp

Purpose	Used to display the ECMP route load-balancing algorithm.
Syntax	show ecmp
Description	This command is used to display the ECMP route load-balancing algorithm.
Parameters	None.
Restrictions	None.

Example usage:

To display the ECMP hash algorithm:

```
DGS-3627:admin# show ecmp
```

```
Command: show ecmp
```

```
ECMP For OSPF: Enabled
```

```
ECMP Load Balance Algorithm:
```

```
Destination IP: Used.
```

```
Source IP: Not Used.
```

```
CRC_Low: Used.
```

```
CRC_High: Not Used.
```

```
TCP_UDP_Port: Not Used.
```

```
DGS-3627:admin#
```

UTILIZATION COMMANDS

The Utilization commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
show utilization	[cpu ports dram { unit <unit_id>} flash {unit <unit_id>}]

Each command is listed, in detail, in the following sections.

show utilization

Purpose	Used to display real-time port utilization statistics.
Syntax	show utilization [cpu ports dram { unit <unit_id>} flash {unit <unit_id>}]
Description	The show utilization command displays real-time CPU, ports, DRAM or flash utilization statistics.
Parameters	<p><i>ports</i> - Specifies a range of ports to be displayed. (UnitID:port number).</p> <p><i>dram</i> - To show dram memory utilization.</p> <p><i>flash</i> - To show flash memory utilization.</p> <p><i>unit</i> - Specifies the unit to be displayed.</p>
Restrictions	None.

Example usage:

To display the ports utilization:

DGS-3627:admin# show utilization ports

Command: show utilization ports

Port	TX/sec	RX/sec	Util	Port	TX/sec	RX/sec	Util
1:1	0	0	0	1:22	0	0	0
1:2	0	0	0	1:23	0	0	0
1:3	0	0	0	1:24	0	0	0
1:4	0	0	0	1:25	0	0	0
1:5	0	0	0	1:26	19	49	1
1:6	0	0	0	2:1	0	0	0
1:7	0	0	0	2:2	0	0	0
1:8	0	0	0	2:3	0	0	0
1:9	0	0	0	2:4	0	0	0
1:10	0	0	0	2:5	0	0	0
1:11	0	0	0	2:6	0	0	0
1:12	0	0	0	2:7	0	30	1
1:13	0	0	0	2:8	0	0	0
1:14	0	0	0	2:9	30	0	1
1:15	0	0	0	2:10	0	0	0
1:16	0	0	0	2:11	0	0	0
1:17	0	0	0	2:12	0	0	0
1:18	0	0	0	2:13	0	0	0
1:19	0	0	0	2:14	0	0	0
1:20	0	0	0	2:15	0	0	0
1:21	0	0	0	2:16	0	0	0
Port	TX/sec	RX/sec	Util	Port	TX/sec	RX/sec	Util
2:17	0	0	0				
2:18	0	0	0				
2:19	0	0	0				
2:20	0	0	0				
2:21	0	0	0				
2:22	0	0	0				
2:23	0	0	0				
2:24	0	0	0				
2:25	0	0	0				
2:26	11	2	1				

To display the CPU utilization:

DGS-3627:admin# show utilization cpu

Command: show utilization cpu

CPU utilization :

 Five seconds - 20% One minute - 10% Five minutes - 70%

Success.

DGS-3627:admin#

To display DRAM utilization:

```
DGS-3627:admin# show utilization dram
Command: show utilization dram
DRAM Utilization :
Total DRAM   : 262,144 KB
Used DRAM    : 212,568 KB
Utilization  : 81%

Success.

DGS-3627:admin#
```

To display FLASH utilization:

```
DGS-3627:admin# show utilization flash
Command: show utilization flash
FLASH Memory Utilization :
Total FLASH : 16,384 KB
Used FLASH  : 13,440 KB
Utilization : 82%

Success.

DGS-3627:admin#
```


VLAN TRUNKING COMMANDS

The VLAN Trunking commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
enable vlan_trunk	
disable vlan_trunk	
config vlan_trunk	ports [<portlist> all] state [enable disable]
show vlan_trunk	

Each command is listed, in detail, in the following sections.

enable vlan_trunk

Purpose	Used to enable the VLAN trunk function.
Syntax	enable vlan_trunk
Description	When the VLAN trunk function is enabled, the VLAN trunk ports shall be able to forward all tagged frames with any VID.
Parameters	None.
Restrictions	Only Administrator can issue this command.

Example usage:

To enable the VLAN Trunk:

```
DGS-3627:admin# enable vlan_trunk
Command: enable vlan_trunk

Success.

DGS-3627:admin#
```

disable vlan_trunk

Purpose	Used to disable the VLAN trunk function.
Syntax	disable vlan_trunk
Description	This command disables the VLAN trunk function.
Parameters	None.
Restrictions	Only Administrator can issue this command.

Example usage:

To disable the VLAN Trunk:

```
DGS-3627:admin# disable vlan_trunk
```

```
Command: disable vlan_trunk
```

```
Success.
```

```
DGS-3627:admin#
```

config vlan_trunk

Purpose	Used to configure a port as a the VLAN trunk port.
Syntax	config vlan_trunk ports [<portlist> all] state [enable disable]
Description	<p>This command is used to configure a port as a VLAN trunk port. By default, none of the port is a VLAN trunk port.</p> <p>If the user enables the global VLAN trunk function and configure the VLAN trunk ports, then the trunk port will be member port of all VLANs. That is, if a VLAN is already configured by the user, but the trunk port is not member port of that VLAN, this trunk port will automatically become tagged member port of that VLAN. If a VLAN is not created yet, the VLAN will be automatically created, and the trunk port will become tagged member of this VLAN.</p> <p>When the user disables the VLAN trunk globally, all VLANs automatically created by VLAN Trunk enabled shall be destroyed, and all the automatically added port membership will be removed.</p> <p>A VLAN trunk port and a non-VLAN trunk port cannot be grouped as an aggregated link. To change the VLAN trunk setting for an aggregated link, the user must apply the command to the master port. However, this setting will disappear as the aggregated link is destroyed, and the VLAN trunk setting of the individual port will follow the original setting of the port.</p> <p>If the command is applied to link aggregation member port excluding the master, the command will be rejected.</p> <p>The ports with different VLAN configuration is not allowed to form an aggregated link. However, if they are specified as VLAN trunk port, they are allowed to form an aggregated link.</p> <p>For a VLAN trunk port, the VLANs on which the packets can be by passed will not be advertised by GVRP on this port. However, since the traffic on these VLANs are forwarded, this vlan trunk port should participate the MSTP instances corresponding to these VLAN.</p>
Parameters	<p><i>portlist</i> - Specify the list of ports to be configured.</p> <p><i>enable</i> - Specifies that the port is a VLAN trunk port.</p> <p><i>disable</i> - Specifies that the port is not a VLAN trunk port.</p>
Restrictions	Only Administrator can issue this command.

Example usage:

To config vlan_trunk port:

```
DGS-3627:admin# config vlan_trunk ports 1-5 state enable
```

```
Command: config vlan_trunk ports 1-5 state enable
```

```
Success.
```

```
DGS-3627:admin#
```

show vlan_trunk

Purpose	Used to show the VLAN trunk configuration.
Syntax	show vlan_trunk

show vlan_trunk

Description	Show the VLAN trunk information.
Parameters	None.
Restrictions	None.

Example usage:

To show the VLAN Trunk information:

```
DGS-3627:admin# show vlan_trunk
Command: show vlan_trunk

VLAN Trunk State           :Enabled
VLAN Trunk Member Ports   :1-5,7

DGS-3627:admin#
```

VRRP DEBUG COMMANDS

The VRRP Debug commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
debug vrrp show flag	
debug vrrp vr_state_change state	[enable disable]
debug vrrp packet	[all {receiving sending}(1)] state [enable disable]
debug vrrp mac_addr_update state	[enable disable]
debug vrrp interface_change state	[enable disable]
debug vrrp timers state	[enable disable]
debug vrrp show counter	
debug vrrp clear counter	
debug vrrp log state	[enable disable]
debug vrrp show log state	
debug vrrp state	[enable disable]

Each command is listed, in detail, in the following sections.

debug vrrp show flag

Purpose	Used to display VRRP debug flag settings.
Syntax	debug vrrp show flag
Description	This command is used to display VRRP debug flag settings.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display VRRP debug flag settings:

```
DGS-3627:admin# debug vrrp show flag
Command: debug vrrp show flag

Current VRRP Debug Level Settings
Virtual Router State Change
Packet Sending

DGS-3627:admin#
```

debug vrrp vr_state_change

Purpose	Used to enable or disable the VRRP debug flag for VR state change.
Syntax	debug vrrp vr_state_change state [enable disable]
Description	This command is used to enable or disable the VRRP debug flag for VR state change.
Parameters	<i>state</i> - The state of the VRRP change debug flags. The default setting is disabled. <i>enable</i> - Enable the VRRP state change debug flags. <i>disable</i> - Disable the VRRP state change debug flags.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable the VRRP virtual router state change debug flag:

```
DGS-3627:admin# debug vrrp vr_state_change state enable
Command: debug vrrp vr_state_change state enable

Success.

DGS-3627:admin#
```

debug vrrp packet

Purpose	Used to enable or disable VRRP debug flags about packet receiving and sending.
Syntax	debug vrrp packet [all {receiving sending}(1)] state [enable disable]
Description	This command is used to enable or disable VRRP debug flags for packet receiving and sending.
Parameters	<i>all</i> - Set VRRP all packet debug flags. <i>receiving</i> - Set the VRRP packet receiving flag. <i>sending</i> - Set the VRRP packet sending flag. <i>enable</i> - Enable the designated flags. <i>disable</i> - Disable the designated flags.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable all VRRP packet debug flags:

```
DGS-3627:admin# debug vrrp packet all state enable
Command: debug vrrp packet all state enable

Success.

DGS-3627:admin#
```

debug vrrp mac_addr_update

Purpose	Used to enable or disable VRRP debug flags for virtual MAC address operations.
Syntax	debug vrrp mac_addr_update state [enable disable]
Description	This command is used to enable or disable VRRP debug flags for virtual MAC address operations.

debug vrrp mac_addr_update

Parameters	<i>state</i> - The state of VRRP MAC debug flags. The default setting is disabled. <i>enable</i> - Enable VRRP MAC debug flags. <i>disable</i> - Disable VRRP MAC debug flags.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable VRRP virtual MAC address update debug flags:

```
DGS-3627:admin# debug vrrp mac_addr_update state enable
Command: debug vrrp mac_addr_update state enable
```

Success.

```
DGS-3627:admin#
```

debug vrrp interface_change

Purpose	Used to enable or disable debug flags for VRRP interface state changes.
Syntax	debug vrrp interface_change state [enable disable]
Description	The command is used to enable or disable debug flags for VRRP interface state changes.
Parameters	<i>state</i> - The state of VRRP interface debug flags. The default setting is disabled. <i>enable</i> - Enable VRRP interface debug flags. <i>disable</i> - Disable VRRP interface debug flags.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable VRRP interface state change debug flags:

```
DGS-3627:admin# debug vrrp interface_change state enable
Command: debug vrrp interface_change state enable
```

Success.

```
DGS-3627:admin#
```

debug vrrp timers

Purpose	Used to enable or disable debug flags for VRRP timers.
Syntax	debug vrrp timers state [enable disable]
Description	This command is used to enable or disable debug flags for VRRP timers.
Parameters	<i>state</i> - The state of VRRP timers debug flags. The default setting is disabled. <i>enable</i> - Enable VRRP timers debug flags. <i>disable</i> - Disable VRRP timers debug flags.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable VRRP timer debug flags:

```
DGS-3627:admin# debug vrrp timers state enable
Command: debug vrrp timers state enable

Success.

DGS-3627:admin#
```

debug vrrp show counter

Purpose	Used to display the VRRP debug statistic counters.
Syntax	debug vrrp show counter
Description	This command is used to display the VRRP debug statistic counters.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display VRRP statistic counters:

```
DGS-3627:admin# debug vrrp show counter
Command: debug vrrp show counter

VRRP Debug Statistic Counters

Received ADV : 9
Drop         : 52
Auth Fail    : 0
Sent ADV     : 0

DGS-3627:admin#
```

debug vrrp clear counter

Purpose	Used to reset the VRRP debug statistic counters.
Syntax	debug vrrp clear counter
Description	This command is used to reset the VRRP debug statistic counters.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To clear VRRP statistic counters:

```
DGS-3627:admin# debug vrrp clear counter
Command: debug vrrp clear counter

Success

DGS-3627:admin#
```

debug vrrp log state

Purpose	Used to enable or disable the VRRP debug log state.
Syntax	debug vrrp log state [enable disable]
Description	This command is used to enable or disable the VRRP debug log state.
Parameters	<i>state</i> - The state of the VRRP log. The default setting is disabled. <i>enable</i> - Enable the VRRP log state. <i>disable</i> - Disable the VRRP log state.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable the VRRP debug log state:

```
DGS-3627:admin# debug vrrp log state enable
Command: debug vrrp log state enable

Success.

DGS-3627:admin#
```

debug vrrp show log state

Purpose	Used to display the VRRP debug log state.
Syntax	debug vrrp show log state
Description	The command is used to display the VRRP debug log state.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To display the VRRP debug log state:

```
DGS-3627:admin# debug vrrp show log state
Command: debug vrrp show log state

VRRP Debug Log State: Disabled

DGS-3627:admin#
```

debug vrrp state

Purpose	Used to enable or disable the VRRP debug state.
Syntax	debug vrrp state [enable disable]
Description	The command is used to enable or disable the VRRP debug state.
Parameters	<i>state</i> - The state of the VRRP debug state. The default setting is disabled. <i>enable</i> - Enable the VRRP debug state. <i>disable</i> - Disable the VRRP debug state.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable the VRRP debug state:

```
DGS-3627:admin# debug vrrp state enable  
Command: debug vrrp state enable
```

```
Success.
```

```
DGS-3627:admin#
```

VRRP COMMANDS

VRRP or Virtual Routing Redundancy Protocol is a function on the Switch that dynamically assigns responsibility for a virtual router to one of the VRRP routers on a LAN. The VRRP router that controls the IP address associated with a virtual router is called the Master, and will forward packets sent to this IP address. This will allow any Virtual Router IP address on the LAN to be used as the default first hop router by end hosts. Utilizing VRRP, the administrator can achieve a higher available default path cost without needing to configure every end host for dynamic routing or routing discovery protocols.

Statically configured default routes on the LAN are prone to a single point of failure. VRRP is designed to eliminate these failures by setting an election protocol that will assign a responsibility for a virtual router to one of the VRRP routers on the LAN. When a virtual router fails, the election protocol will select a virtual router with the highest priority to be the Master router on the LAN. This retains the link and the connection is kept alive, regardless of the point of failure.

To configure VRRP for virtual routers on the Switch, an IP interface must be present on the system and it must be a part of a VLAN. VRRP IP interfaces may be assigned to every VLAN, and therefore IP interface, on the Switch. VRRP routers within the same VRRP group must be consistent in configuration settings for this protocol to function optimally.

The VRRP commands in the Command Line Interface (CLI) are listed, along with the appropriate parameters, in the following table.

Command	Parameters
enable vrrp	{ping}
disable vrrp	{ping}
create vrrp vrid	<vrid 1-255> ipif <ipif_name 12> ipaddress <ipaddr> {state [enable disable] priority <int 1-254> advertisement_interval <int 1-255> preempt [true false] critical_ip <ipaddr> critical_ip_state [enable disable]}
config vrrp vrid	<vrid 1-255> ipif <ipif_name 12> {state [enable disable] priority <int 1-254> ipaddress <ipaddr> advertisement_interval <int 1-255> preempt [true false] critical_ip <ipaddr> critical_ip_state [enable disable]}
config vrrp ipif	<ipif_name 12> [authtype [none simple authdata <string 8> ip authdata <string 16>]]
show vrrp	{ipif <ipif_name 12> {vrid <vrid 1-255>}}
delete vrrp	{vrid <vrid 1-255> ipif <ipif_name 12>}

Each command is listed, in detail, in the following sections.

enable vrrp

Purpose	To enable the VRRP function on the Switch.
Syntax	enable vrrp {ping}
Description	This command will enable the VRRP function on the Switch.
Parameters	<i>{ping}</i> – Adding this parameter to the command will allow the virtual IP address to be pinged from other host end nodes to verify connectivity. This will only enable the ping connectivity check function. To enable the VRRP protocol on the Switch, omit this parameter. This command is disabled by default.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example Usage:

To enable VRRP globally on the Switch:

```
DGS-3627:admin# enable vrrp
Command: enable vrrp

Success.

DGS-3627:admin#
```

Example usage:

To enable the virtual IP address to be pinged:

```
DGS-3627:admin# enable vrrp ping
Command: enable vrrp ping

Success.

DGS-3627:admin#
```

disable vrrp

Purpose	To disable the VRRP function on the Switch.
Syntax	disable vrrp {ping}
Description	This command will disable the VRRP function on the Switch.
Parameters	<i>{ping}</i> – Adding this parameter to the command will stop the virtual IP address from being pinged from other host end nodes to verify connectivity. This will only disable the ping connectivity check function. To disable the VRRP protocol on the Switch, omit this parameter.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable the VRRP function globally on the Switch:

```
DGS-3627:admin# disable vrrp
Command: disable vrrp

Success.

DGS-3627:admin#
```

Example usage:

To disable the virtual IP address from being pinged:

```
DGS-3627:admin# disable vrrp ping
Command: disable vrrp ping

Success.

DGS-3627:admin#
```

create vrrp vrid

Purpose	To create a VRRP router on the Switch.
Syntax	create vrrp vrid <vrid 1-255> ipif <ipif_name 12> ipaddress <ipaddr> {state [enable disable] priority <int 1-254> advertisement_interval <int 1-255> preempt [true false] critical_ip <ipaddr> critical_ip_state [enable disable]}
Description	This command is used to create a VRRP interface on the Switch.
Parameters	<p><i>vrid</i> <vrid 1-255> – Enter a value between 1 and 255 to uniquely identify this VRRP group on the Switch. All routers participating in this group must be assigned the same <i>vrid</i> value. This value MUST be different from other VRRP groups set on the Switch.</p> <p><i>ipif</i> <ipif_name 12> – Enter the name of a previously configured IP interface for which to create a VRRP entry. This IP interface must be assigned to a VLAN on the Switch.</p> <p><i>ipaddress</i> <ipaddr> – Enter the IP address that will be assigned to the VRRP router. This IP address is also the default gateway that will be statically assigned to end hosts and must be set for all routers that participate in this group.</p> <p><i>state</i> [enable disable] – Used to enable and disable the VRRP router on the Switch.</p> <p><i>priority</i> <int 1-254> – Enter a value between 1 and 254 to indicate the router priority. The VRRP Priority value may determine if a higher priority VRRP router overrides a lower priority VRRP router. A higher priority will increase the probability that this router will become the Master router of the group. A lower priority will increase the probability that this router will become the backup router. VRRP routers that are assigned the same priority value will elect the highest physical IP address as the Master router. The default value is 100. (The value of 255 is reserved for the router that owns the IP address associated with the virtual router and is therefore set automatically.)</p> <p><i>advertisement_interval</i> <int 1-255> – Enter a time interval value, in seconds, for sending VRRP message packets. This value must be consistent with all routers participating within the same VRRP group. The default is 1 second.</p> <p><i>preempt</i> [true false] – This entry will determine the behavior of backup routers within the VRRP group by controlling whether a higher priority backup router will preempt a lower priority Master router. A true entry, along with having the backup router's priority set higher than the masters priority, will set the backup router as the Master router. A false entry will disable the backup router from becoming the Master router. This setting must be consistent with all routers participating within the same VRRP group. The default setting is true.</p> <p><i>critical_ip</i> <ipaddr> – Enter the IP address of the physical device that will provide the most direct route to the Internet or other critical network connections from this virtual router. This must be a real IP address of a real device on the network. If the connection from the virtual router to this IP address fails, the virtual router will be disabled automatically. A new master will be elected from the backup routers participating in the VRRP group. Different critical IP addresses may be assigned to different routers participating in the VRRP group, and can therefore define multiple routes to the Internet or other critical network connections.</p> <p><i>critical_ip_state</i> [enable disable] – This parameter is used to enable or disable the critical IP address entered above. The default is disable.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To create a VRRP entry:

```
DGS-3627:admin# create vrrp vrid 1 ipif Tiberius ipaddress 11.1.1.1 state enable priority
200 advertisement_interval 1 preempt true critical_ip 10.53.13.224 critical_ip_state
enable
```

```
Command: create vrrp vrid 1 ipif Tiberius ipaddress 11.1.1.1 state enable priority 200
advertisement_interval 1 preempt true critical_ip 10.53.13.224 critical_ip_state enable
```

Success.

```
DGS-3627:admin#
```

config vrrp vrid

Purpose	To configure a VRRP router set on the Switch.
Syntax	config vrrp vrid <vrid 1-255> ipif <ipif_name 12> {state [enable disable] priority <int 1-254> ipaddress <ipaddr> advertisement_interval <int 1-255> preempt [true false] critical_ip <ipaddr> critical_ip_state [enable disable]}
Description	This command is used to configure a previously created VRRP interface on the Switch.
Parameters	<p><i>vrid <vrid 1-255></i> – Enter a value between 1 and 255 that uniquely identifies the VRRP group to configure. All routers participating in this group must be assigned the same <i>vrid</i> value. This value MUST be different from other VRRP groups set on the Switch.</p> <p><i>ipif <ipif_name 12></i> – Enter the name of a previously configured IP interface to configure a VRRP entry for. This IP interface must be assigned to a VLAN on the Switch.</p> <p><i>state [enable disable]</i> – Used to enable and disable the VRRP router on the Switch.</p> <p><i>priority <int 1-254></i> – Enter a value between 1 and 254 to indicate the router priority. The VRRP Priority value may determine if a higher priority VRRP router overrides a lower priority VRRP router. A higher priority will increase the probability that this router will become the Master router of the group. A lower priority will increase the probability that this router will become the backup router. VRRP routers that are assigned the same priority value will elect the highest physical IP address as the Master router. The default value is 100. (The value of 255 is reserved for the router that owns the IP address associated with the virtual router and is therefore set automatically.)</p> <p><i>ipaddress <ipaddr></i> – Enter the virtual IP address that will be assigned to the VRRP entry. This IP address is also the default gateway that will be statically assigned to end hosts and must be set for all routers that participate in this group.</p> <p><i>advertisement_interval <int 1-255></i> – Enter a time interval value, in seconds, for sending VRRP message packets. This value must be consistent with all routers participating within the same VRRP group. The default is 1 second.</p> <p><i>preempt [true false]</i> – This entry will determine the behavior of backup routers within the VRRP group by controlling whether a higher priority backup router will preempt a lower priority Master router. A true entry, along with having the backup router's priority set higher than the masters priority, will set the backup router as the Master router. A false entry will disable the backup router from becoming the Master router. This setting must be consistent with all routers participating within the same VRRP group. The default setting is <i>true</i>.</p> <p><i>critical_ip <ipaddr></i> – Enter the IP address of the physical device that will provide the most direct route to the Internet or other critical network connections from this virtual router. This must be a real IP address of a real device on the network. If the connection from the virtual router to this IP address fails, the virtual router will be disabled automatically. A new master will be elected from the backup routers participating in the VRRP group. Different critical IP addresses may be assigned to different routers participating in the VRRP group, and can therefore define multiple routes to the Internet or other critical network connections.</p> <p><i>critical_ip_state [enable disable]</i> – This parameter is used to enable or disable the critical IP address entered above. The default is <i>disable</i>.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure a VRRP entry:

```
DGS-3627:admin# config vrrp vrid 1 ipif Zira state enable priority 100
advertisement_interval 2
Command: config vrrp vrid 1 ipif Zira state enable priority 100 advertisement_interval 2

Success.

DGS-3627:admin#
```

config vrrp ipif

Purpose	To configure the authentication type for the VRRP routers of an IP interface.
Syntax	config vrrp ipif <ipif_name 12> [authtype [none simple authdata <string 8> ip authdata <string 16>]]
Description	This command is used to set the authentication type for the VRRP routers of an IP interface.
Parameters	<p><i>ipif <ipif_name 12></i> – Enter the name of a previously configured IP interface for which to configure the VRRP entry. This IP interface must be assigned to a VLAN on the Switch.</p> <p><i>authtype</i> – Specifies the type of authentication used. The authtype must be consistent with all routers participating within the VRRP group. The user may choose between:</p> <p><i>none</i> – Entering this parameter indicates that VRRP protocol exchanges will not be authenticated.</p> <p><i>simple authdata <string 8></i> – This parameter, along with an alphanumeric string of no more than eight characters, to set a simple password for comparing VRRP message packets received by a router. If the two passwords are not exactly the same, the packet will be dropped.</p> <p><i>ip authdata <string 16></i> – This parameter will require the user to set an alphanumeric authentication string of no more than 16 characters to generate a MD5 message digest for authentication in comparing VRRP messages received by the router. If the two values are inconsistent, the packet will be dropped.</p>
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To set the authentication type for a VRRP entry:

```
DGS-3627:admin# config vrrp ipif Zira authtype simple authdata tomato
Command: config vrrp ipif Zira authtype simple authdata tomato

Success.

DGS-3627:admin#
```

show vrrp

Purpose	To view the VRRP settings set on the Switch.
Syntax	show vrrp {ipif <ipif_name 12> {vrid <vrid 1-255>}}
Description	This command is used to view current VRRP settings of the VRRP Operations table.
Parameters	<p><i>ipif <ipif_name 12></i> – Enter the name of a previously configured IP interface for which to view the VRRP settings. This IP interface must be assigned to a VLAN on the Switch.</p> <p><i>vrid <vrid 1-255></i> – Enter the VRRP ID of a VRRP entry for which to view these settings.</p>
Restrictions	None.

Example Usage:

To view the global VRRP settings currently implemented on the Switch (VRRP Enabled):

```

DGS-3627:admin# show vrrp
Command: show vrrp

Global VRRP                :Enabled
Non-owner response PING    : Disabled

Interface Name             : System
Authentication type        : No Authentication

    VRID                    : 2
    Virtual IP Address       : 10.53.13.3
    Virtual MAC Address      : 00-00-5E-00-01-02
    Virtual Router State     : Master
    State                    : Enabled
    Priority                  : 255
    Master IP Address         : 10.53.13.3
    Critical IP Address      : 0.0.0.0
    Checking Critical IP     : Disabled
    Advertisement Interval   : 1 secs
    Preempt Mode             : True
    Virtual Router Up Time   : 2754089 centi-secs

Total Entries : 1

DGS-3627:admin#

```

delete vrrp

Purpose	Used to delete a VRRP entry from the switch.
Syntax	delete vrrp {vrid <vrid 1-255> ipif <ipif_name 12>}
Description	This command is used to remove a VRRP router running on a local device.
Parameters	<i>vrid <vrid 1-255></i> – Enter the VRRP ID of the virtual router to be deleted. Not entering this parameter will delete all VRRP entries on the Switch. <i>ipif <ipif_name 12></i> – Enter the name of the IP interface which holds the VRRP router to delete.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete a VRRP entry:

```

DGS-3627:admin# delete vrrp vrid 2 ipif Zira
Command: delete vrrp vrid 2 ipif Zira

Success.

DGS-3627:admin#

```

WEB-BASED ACCESS CONTROL (WAC) COMMANDS

WAC is “Web-based Access Control”. Web-Based Authentication Login is a feature designed to authenticate a user when the user is trying to access the Internet via the Switch.

The authentication process uses HTTP protocol. The switch enters the authenticating stage when users would like to browse web screen (ex: <http://www.kimo.com.tw>) through the web browser (ex: IE...). When the switch detects HTTP packets and this port or this host (host-based mode) is un-authenticated, the switch will pop out username/password screen to query users. The user can't access internet until he passes the authentication process.

The switch can be the authentication server itself and do the authentication based on a local database or be a RADIUS client and perform the authentication process via RADIUS protocol with remote RADIUS server.

The client user initiates the authentication process of WAC via a Web access.

The Web-based Access Control (WAC) commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
enable wac	
disable wac	
config wac ports	[<portlist> all] {state [enable disable] aging_time [infinite <min 1-1440>] idle_time [infinite <min 1-1440>] block_time [<sec 0-300>]}(1)
config wac method	[local radius]
config wac default_redirpath	<string 128>
config wac clear_default_redirpath	
config wac virtual_ip	{ < ipaddr > < ipv6addr > } (1)
config wac switch_http_port	< tcp_port_number 1-65535> { [http https] }
create wac user	<username 15> {[vlan <vlan_name 32> vlanid <vlanid 1-4094>]}
delete wac	[user <username 15> all_users]
config wac user	<username 15> [vlan <vlan_name 32> vlanid <vlanid 1-4094> clear_vlan]
config wac authorization attributes	{radius [enable disable] local [enable disable]}(1)
show wac	
show wac ports	{ <portlist> }
show wac user	
show wac auth_state ports	{ <portlist> }
clear wac auth_state	[ports [<portlist> all] { authenticated authenticating blocked } macaddr <macaddr>]

Each command is listed, in detail, in the following sections.

enable wac

Purpose	Used to enable WAC function.
Syntax	enable wac

enable wac

Description	The enable wac command enables WAC function. WAC and JWAC are mutual exclusive function. That is, they can not be enabled at the same time.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To enable WAC:

```
DGS-3627:admin# enable wac
Command: enable WAC

Success.

DGS-3627:admin#
```

disable wac

Purpose	Used to disable WAC function.
Syntax	disable wac
Description	The disable wac command disables WAC function; all authentication entries related to WAC will be deleted.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To disable WAC:

```
DGS-3627:admin# disable wac
Command: disable wac

Success.

DGS-3627:admin#
```

config wac ports

Purpose	Used to config state and other parameters of the ports.
Syntax	config wac ports [<portlist> all] {state [enable disable] aging_time [infinite <min 1-1440>] idle_time [infinite <min 1-1440>] block_time [<sec 0-300>]}(1)
Description	The config wac ports command allows you to configure port state and other parameters of WAC. The default value of aging time is 1440 minutes. The default value of idle time is infinite. The default value of block_time is 60 seconds.
Parameters	<i>portlist</i> - A port range to set their WAC state. <i>all</i> - All the Switch ports' WAC state is to be configured. <i>state</i> - To specify the port state of WAC

config wac ports

aging_time - A time period during which an authenticated host will keep in authenticated state. "infinite" indicates never to age out the authenticated host on the port

idle_time - If there is no traffic during idle time, the host will be moved back to unauthenticated state. "infinite" indicates never to check the idle state of the authenticated host on the port.

block_time - If a host fails to pass the authentication, it will be blocked for a period specified by "block_time".

Restrictions Only Administrator and Operator-level users can issue this command.

Example usage:

To config state and other parameters of the ports:

```
DGS-3627:admin# config wac ports 1-9 state enable
```

```
Command: config wac ports 1-9 state enable
```

Success.

```
DGS-3627:admin#
```

config wac method

Purpose	Used to configure WAC auth method.
Syntax	config wac method [local radius]
Description	The config wac radius_protocol command allows you to specify the RADIUS protocol used by WAC to complete RADIUS authentication. WAC shares other RADIUS configuration with 802.1x, when using this command to set the RADIUS protocol, you must make sure the RADIUS server added by "config radius ..." command supports the protocol.
Parameters	<i>local</i> - The authentication will be done via the local database. <i>radius</i> - The authentication will be done via the RADIUS server.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure WAC auth method:

```
DGS-3627:admin# config wac method radius
```

```
Command: config wac method radius
```

Success.

```
DGS-3627:admin#
```

config wac default_redirpath

Purpose	Used to config WAC default redirect URL.
Syntax	config wac default_redirpath <string 128>
Description	If default redirect path is configured, the user will be redirected to the default redirect path after successful authentication. When the string is cleared, the client will not be redirected to another URL after successful

config wac default_redirpath

	authentication.
Parameters	<i>string</i> - The URL that the client will be redirected to after successful authentication. By default, the redirected path is cleared
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To config WAC default redirect URL:

```
DGS-3627:admin# config wac default_redirpath http://www.dlink.com
Command: config wac default_redirpath http://www.dlink.com
```

Success.

```
DGS-3627:admin#
```

config wac clear_default_redirpath

Purpose	Used to clear WAC default redirect URL.
Syntax	config wac clear_default_redirpath
Description	When the string is cleared, the client will not be redirected to another URL after successful authentication.
Parameters	None.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To clear WAC default redirect URL:

```
DGS-3627:admin# config wac clear_default_redirpath
```

Success.

```
DGS-3627:admin#
```

config wac virtual_ip

Purpose	Used to config the virtual IP address for WAC.
Syntax	config wac virtual_ip { < ipaddr > < ipv6addr > } (1)
Description	The virtual IP of WAC is used to accept authentication request from unauthenticated host. Only requests sent to this IP will get response correctly. This IP does not respond to ARP request or ICMP packet!
Parameters	<i>ipaddr</i> - To specify the IP address of the virtual IP. <i>ipv6addr</i> - To specify the IPv6 address of the virtual IP.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

Set IPv4 virtual IP address:

```
DGS-3627:admin# config wac virtual_ip 1.1.1.1
Command: config wac virtual_ip 1.1.1.1

Success.

DGS-3627:admin#
```

Set IPv6 virtual IP address:

```
DGS-3627:admin# config wac virtual_ip 30::20
Command: config wac virtual_ip 30::20
Success.

DGS-3627:admin#
```

config wac switch_http_port

Purpose	Used to config HTTP(s) port of the switch used by WAC.
Syntax	config wac switch_http_port < tcp_port_number 1-65535> { [http https] }
Description	The TCP port for HTTP or HTTPS is used to identify the HTTP or HTTPS packets that will be trapped to CPU for authentication processing, or to access the login page. If not specified, the default port number for HTTP is 80, and the default port number for HTTPS is 443. If no protocol specified, the protocol is HTTP. The HTTP cannot run at TCP port 443, and the HTTPS cannot run at TCP port 80.
Parameters	<i>tcp_port_number</i> - A TCP port which the WAC Switch listens to and uses to finish the authenticating process. The range of port number is 1-65535. <i>http</i> - To specify the WAC runs HTTP protocol on this TCP port <i>https</i> - To specify the WAC runs HTTPS protocol on this TCP port
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To config HTTP(s) port of the switch used by WAC:

```
Used to config HTTP(s) port of the switch used by WAC.
DGS-3627:admin# config wac switch_http_port 8888 http
Command: config wac switch_http_port 8888 http

Success.
DGS-3627:admin#
```

create wac user

Purpose	Used to create a WAC local user.
Syntax	create wac user <username 15> {[vlan <vlan_name 32> vlanid <vlanid 1-4094>]}
Description	The create wac user command allows you to create account for web-base access control. This user account is independent with login user account. If VLAN is not specified, the user will not get a VLAN assigned after the authentication.
Parameters	<i>username</i> - User account for web-base access control. <i>vlan</i> - Authentication VLAN name.

create wac user

Restrictions	Only Administrator and Operator-level users can issue this command.
--------------	---

Example usage:

To create a WAC local user:

```
DGS-3627:admin# create wac user vlan Jim
Command: create wac user vlan Jim
Enter a case-sensitive new password:**
  Enter the new password again for confirmation:**
Success.

DGS-3627:admin#
```

delete wac user

Purpose	Used to delete a WAC local user.
Syntax	delete wac [user <username 15> all_users]
Description	The delete wac user command deletes WAC users from the local DB.
Parameters	<i>user</i> - To specify the user name to be deleted <i>all_users</i> - All user accounts in local DB will be deleted.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete a WAC local user:

```
DGS-3627:admin# delete wac user 123
Command: delete wac user 123

Success.

DGS-3627:admin#
```

config wac user

Purpose	Used to configure WAC local user.
Syntax	config wac user <username 15> [vlan <vlan_name 32> vlanid <vlanid 1-4094> clear_vlan]
Description	The config wac user command updates the local user DB. Only created user can be configured
Parameters	<i>username</i> - The user name to be configured <i>vlanid</i> - Target VLAN ID for authenticated host which uses this user account to pass authentication
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To configure WAC local user:

```
DGS-3627:admin# config wac user Jim vlan 3
Command: config wac user Jim vlan 3

Enter a case-sensitive new password:***
Enter the new password again for confirmation:***
Success.

DGS-3627:admin#
```

config wac authorization attributes

Purpose	The enable authorization command will enable acceptance of authorized configuration.
Syntax	config wac authorization attributes {radius [enable disable] local [enable disable]}(1)
Description	Used to enable or disable acceptance of authorized configuration. When the authorization is enabled for WAC's radius, the authorized data assigned by the RADIUS server will be accepted if the global authorization network is enabled. When the authorization is enabled for WAC's local, the authorized data assigned by the local database will be accepted.
Parameters	<i>radius</i> - If specified to enable, the authorized data assigned by the RADIUS server will be accepted if the global authorization network is enabled. The default state is enabled. <i>local</i> - If specified to enable, the authorized data assigned by the local database will be accepted if the global authorization network is enabled. The default state is enabled.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

The enable authorization command will enable acceptance of authorized configuration:

```
DGS-3627:admin# config wac authorization attributes local disable
Command: config wac authorization attributes local disable

Success.

DGS-3627:admin#
```

show wac

Purpose	Used to display web authentication global setting.
Syntax	show wac
Description	This command allows the user to display the WAC global setting.
Parameters	None.
Restrictions	None.

Example usage:

Show global configuration about WAC:

```
DGS-3627:admin# show wac
Command: show wac

Web-based Access Control
-----
State           : Enabled
Method          : RADIUS
Redirect Path   : http://tw.yaholl.com
Virtual IP      : 0.0.0.0
Virtual IPv6    : 2000::20
Switch HTTP Port : 80 (HTTP)
RADIUS Authorization : Enabled
Local Authorization : Enabled

DGS-3627:admin#
```

show wac ports

Purpose	Used to display web authentication port level setting.
Syntax	show wac ports { <portlist> }
Description	This command allows the user to display the port level setting.
Parameters	<i>ports</i> - A range of member ports to show the status.
Restrictions	None.

Example usage:

To show WAC port state and other parameters:

```
DGS-3627:admin# show wac ports 1-3
Command: show wac ports 1-3

Port          State      Aging Time      Idle Time      Block Time
              (min)      (min)          (sec)
-----
1:1           Enabled    60              30             120
1:2           Enabled    60              30             120
1:3           Enabled    120             60             120

Success.

DGS-3627:admin#
```

show wac user

Purpose	Used to user account for web authentication.
Syntax	show wac user
Description	The show wac user command allows you to show web authentication account.
Parameters	None.
Restrictions	None.

Example usage:

To show WAC local user:

```
DGS-3627:admin# show wac user
Command: show wac user
User Name      Password      VID
-----      -
Jim           pasx          1000

Total Entries: 1

DGS-3627:admin#
```

show wac auth_state

Purpose	Used to display the authentication state of a port.
Syntax	show wac auth_state ports { <portlist> }
Description	Used to display the authentication state for ports.
Parameters	<i>ports</i> - Specifies the list of ports whose WAC state will be displayed.
Restrictions	None.

Example usage:

Supposed that port 1 is in host-based mode:

1. MAC 00-00-00-00-00-01 is authenticated without VLAN assigned (may be the specified target VLAN does not exist or target VLAN has not been specified at all), the ID of RX VLAN will be displayed (RX VLAN ID is 4004 in this example).
2. MAC 00-00-00-00-00-02 is authenticated with target VLAN assigned, the ID of target VLAN will be displayed (target VLAN ID is 1234 in this example)
3. MAC 00-00-00-00-00-03 failed to pass authentication, the VID field will be shown as “-” indicating that packets with SA 00-00-00-00-00-03 will be dropped no matter which VLAN these packets are from.
4. MAC 00-00-00-00-00-04 attempts to start authentication, the VID field will be shown as “-“until authentication completed.

Supposed that port 2 is in port-based mode:

1. MAC 00-00-00-00-00-10 is the MAC which made port 2 pass authentication; MAC address is followed by “(P)” to indicate the port-based mode authentication. Supposed that port 3 is in port-based mode:
2. MAC 00-00-00-00-00-20 attempts to start authentication, MAC address is followed by “(P)” to indicate the port-based mode authentication.
3. MAC 00-00-00-00-00-21 failed to pass authentication, MAC address is followed by “(P)” to indicate the port-based mode authentication.

DGS-3627:admin# show wac auth_state ports

Command: show wac auth_state ports

P:Port-based Pri: Priority

Port	MAC Address	Original RX VID	State	VID	Pri	Aging Time/	Idle Block Time	Time
1:3	00-00-00-00-00-01	20	Authenticated	4004	3	Infinite	40	
1:3	00-00-00-00-00-02	20	Authenticated	1234	-	Infinite	50	
1:11	00-00-00-00-00-03	100	Blocked	-	-	60	-	
1:11	00-00-00-00-00-04	110	Authenticating	-	-	10	-	
2:2	00-00-00-00-00-10(P)	2040	Authenticated	1234	2	1440	20	
2:3	00-00-00-00-00-20(P)	2045	Authenticating	-	-	5	-	
12:13	00-00-00-00-00-21	2041	Authenticated	-	6	1100	80	
12:13	00-00-00-00-00-E4	2041	Blocked	-	-	100	-	

Total Authenticating Hosts :2

Total Authenticated Hosts :4

Total Blocked Hosts :2

DGS-3627:admin#

clear wac auth_state

Purpose	Used to delete the authentication entries.
Syntax	clear wac auth_state [ports [<portlist> all] { authenticated authenticating blocked } macaddr <macaddr>]
Description	Used to clear the authentication state of a port. If the port is port-based mode, the port will return to un-authenticated state. The entire timer associated with the port will be reset. If the port is host based mode, users on this port will be cleared. The user needs to be re-authenticated to access the network.
Parameters	<i>ports</i> - Specifies the list of ports whose WAC state will be cleared. <i>authenticated</i> - Specified to clear all authenticated users for a port. <i>authenticating</i> - Specified to clear all authenticating users for a port.
Restrictions	Only Administrator and Operator-level users can issue this command.

Example usage:

To delete WAC host:

DGS-3627:admin# clear wac auth_state ports 1-5

Command: clear wac auth_state ports 1-5

Success.

DGS-3627:admin#

A

PASSWORD RECOVERY COMMANDS

This section describes the procedure for resetting passwords on D-Link Switches.

Authenticating any user who tries to access networks is necessary and important. The basic authentication method used to accept qualified users is through a local login, utilizing a Username and Password. Sometimes, passwords get forgotten or destroyed, so network administrators need to reset these passwords. This document will explain how the Password Recovery feature can help network administrators reach this goal.

The following steps explain how to use the Password Recovery feature on D-Link devices to easily recover passwords.

Complete these steps to reset the password:

1. For security reasons, the Password Recovery feature requires the user to physically access the device. Therefore this feature is only applicable when there is a direct connection to the console port of the device. It is necessary for the user needs to attach a terminal or PC with terminal emulation to the console port of the switch.
2. Power on the switch. After the runtime image is loaded to 100%, the Switch will allow 2 seconds for the user to press the hotkey [^] (Shift + 6) to enter the "Password Recovery Mode". Once the Switch enters the "Password Recovery Mode", all ports on the Switch will be disabled.

```

Boot Procedure1.10-B09
-----
Power On Self Test ..... 100 %

MAC Address   : 00-1C-F0-B5-40-00
H/W Version   : A1

Please wait, loading V2.80.B31 Runtime image ..... 100 %
    
```

```

Password Recovery Mode
>
    
```

3. In the "Password Recovery Mode" only the following commands can be used.

Command	Parameters
reset config {force_agree(1)}	The reset config command resets the whole configuration will be back to the default value
reboot {force_agree(1)}	The reboot command exits the Reset Password Recovery Mode and restarts the switch. A confirmation message will be displayed to allow the user to save the current settings.
reset account	The reset account command deletes all the previously created accounts.
reset password {<username>}	The reset password command resets the password of the specified user. If a username is not specified, the password of all users will be reset.
show account	The show account command displays all previously created accounts.

TECHNICAL SPECIFICATIONS

Specifications listed here apply to all Switches in the DGS-3600 Series except where otherwise noted.

General			
Protocols	IEEE 802.3 10BASE-T Ethernet IEEE 802.3u 100BASE-TX Fast Ethernet IEEE 802.3ab 1000BASE-T Gigabit Ethernet IEEE 802.3z 1000BASE-T (SFP “Mini GBIC”) IEEE 802.3ae (10G Optional Modules) IEEE 802.1D/w/s Spanning Tree (Rapid, Multiple) IEEE 802.1P/Q VLAN IEEE 802.1p Priority Queues IEEE 802.1v Protocol VLAN IEEE 802.1X Port-based Network Access Control IEEE 802.3 NWay auto-negotiation IEEE 802.3ad Link Aggregation Control IEEE 802.3x Full-duplex Flow Control IEEE 802.1u Fast Ethernet		
Standards	CSMA/CD		
Data Transfer Rates:	<table border="0"> <tr> <td>Half-duplex</td> <td>Full-duplex</td> </tr> </table>	Half-duplex	Full-duplex
Half-duplex	Full-duplex		
Ethernet	<table border="0"> <tr> <td>10 Mbps</td> <td>20Mbps</td> </tr> </table>	10 Mbps	20Mbps
10 Mbps	20Mbps		
Fast Ethernet	<table border="0"> <tr> <td>100Mbps</td> <td>200Mbps</td> </tr> </table>	100Mbps	200Mbps
100Mbps	200Mbps		
Gigabit Ethernet	<table border="0"> <tr> <td>N/A</td> <td>2000Mbps</td> </tr> </table>	N/A	2000Mbps
N/A	2000Mbps		
Fiber Optic	SFP (Mini GBIC) Support IEEE 802.3u 100BASE-FX (DEM-210 transceiver) IEEE 802.3u 100BASE-FX (DEM-211 transceiver) IEEE 802.3z 1000BASE-LX (DEM-310GT transceiver) IEEE 802.3z 1000BASE-SX (DEM-311GT transceiver) IEEE 802.3z 1000BASE-SX (DEM-312GT2 transceiver) IEEE 802.3z 1000BASE-LH (DEM-314GT transceiver) IEEE 802.3z 1000BASE-ZX (DEM-315GT transceiver) IEEE 802.3z WDM Transceiver (DEM-330T transceiver)		

XFP Support	IEEE 802.3z WDM Transceiver (DEM-330R transceiver) IEEE 802.3z WDM Transceiver (DEM-331T transceiver) IEEE 802.3z WDM Transceiver (DEM-331R transceiver)
CX4 Support	IEEE 802.3ae 10G Fiber-Optic
Topology	Duplex Ring, Duplex Chain
Network Cables	Cat.5 Enhanced for 1000BASE-T UTP Cat.5, Cat. 5 Enhanced for 100BASE-TX UTP Cat.3, 4, 5 for 10BASE-T EIA/TIA-568 100-ohm screened twisted-pair (STP)(100m)
Number of Ports	DGS-3612: 12 x 10/100/1000Mbps copper ports 4 x Combo 100/1000Mbps SFP ports DGS-3612G: 12 x 100/1000Mbps SFP ports 4 x Combo 10/100/1000Mbps ports DGS-3627: 24 x 10/100/1000Mbps ports 4 x 1000Mbps Combo SFP ports 3 available slots for optional 10GE modules DGS-3627G: 24 x 1000Mbps SFP ports 4 x 10/100/1000Mbps Combo Ports 3 available slots for optional 10GE modules DGS-3650: 48 x 10/100/1000 Mbps ports 4 x 1000Mbps Combo SFP Ports 2 available slots for optional 10GE modules

Physical and Environmental	
Internal Power Supply	AC Input: 100 - 240 VAC, 50-60 Hz
Redundant Power Supply	Output: 12V, 10A (Max)
Power Consumption	DGS-3612 – 45W DGS-3612G – 50W DGS-3627 – 95W DGS-3627G – 77W DGS-3650 – 137W
DC Fans:	DGS-3612 - Two 40mm x 40mm x 20mm fans DGS-3612G – Three 40mm x 40mm x 20mm; one 50mm x 50mm x 20mm fans DGS-3627 – Four 40mm x 40mm x 20mm; one 50mm x 50mm x 20mm; one 44mm x 44mm x 11mm DGS-3627G – Four 40mm x 40mm x 20mm; one 50mm x 50mm x 20mm fans DGS-3650 – Two 40mm x 40mm x 20mm; three 40mm x 40mm x 10mm; one

Physical and Environmental	
	75.7mm x 75.7mm x 30mm fans; one 44mm x 44mm x 11mm
Operating Temperature	0 - 40°C
Storage Temperature	-40 - 70°C
Humidity	5 - 95% non-condensing
Dimensions	DGS-3612 – 441 mm x 310 mm x 44 mm DGS-3612G/DGS-3627/DGS-3627G/DGS-3650 - 441mm x 389mm x 44mm
Weight	DGS-3612 - 3.8kg (8.38 lbs) DGS-3612G – 5kg (11.02 lbs) DGS-3627, DGS-3627G – 5.5kg (12.13 lbs) DGS-3650 – 6kg (13.23 lbs)
EMI	CE class A, FCC Class A , C-Tick, VCCI
Safety	CB Report, CUL

Performance	
Transmission Method	Store-and-forward
Packet Buffer	2 MB per device
Packet Filtering / Forwarding Rate	14,881 pps (10M port) 148.810 pps (100M port) 1,488,100 pps (1Gbps port)
MAC Address Learning	Automatic update. Supports 16K MAC address.
Priority Queues	8 Priority Queues per port.
Forwarding Table Age Time	Max age: 10-1000000 seconds. Default = 300.