


How to open ports (setup port forwarding) in the DSL-3890 modem router

This document details how to setup port forwarding rules in your modem/router firewall

Please note: It is recommended to set the device you are opening ports for (PC, Xbox, PlayStation, etc.) with a static IP address. Please see your device instructions on how to manually set an IP address.

Step 1. Open your Internet browser e.g. Internet Explorer, Firefox, Chrome, Safari, etc. and enter the IP address of your D-Link modem in the **address bar**: <http://192.168.1.1>



D-Link Model Name: DSL-3890 Firmware Version: AU_1.00

Admin Password:

Please type the characters you see in the picture above:

C K C V J ↻

Log In

Step 2. When prompted type in the Password and (Characters in Picture), on the page and then click on the “Log In” button.


If you have not changed the password for the modem administration, the factory settings are:

Password: (check on the bottom of your router)


If you cannot recall the password you assigned to your modem you will need to reset the modem to factory defaults by pressing the reset button for 10 seconds. Please note that this will revert all the settings in the modem to factory settings and you will have to reconfigure it with your Internet settings and Wireless security. Make sure you have your Internet account details (given by your Internet Provider) handy.

Step 3. After logging in you will be presented with the modem's configuration pages.

Click on **Features > Port Forwarding**



Click on the “Add Rule” button



D-Link
DSL-3890 FW:AU_100

Home | Settings | Features | Management


Port Forwarding

The *D-Link* externally acts as server. It receives the requests of remote users under its public IP address and forwards them automatically to the Port Forwarding. So a client in your network behind NAT or firewall can provide services as a Port Forwarding. You have to enable specific ports or port ranges and protocols (UDP/TCP). File sharing or web services for e.g. HTTP, FTP or POP3 are possible. The private IP addresses of the servers in the local network remain safe. If you have a dynamic IP address, you may want to enable DynDNS additionally.

Features >> Port Forwarding [DMZ \(Exposed Host\)](#)

Status	Name	Internal	External	Protocol	Schedule	Edit	Delete
Add Rule	Remaining: 64						

Step 4. Fill in the details for your new port forwarding rule (we are opening port **3389** for **Remote Desktop** service as an example)



Create New Rule

Enable Rules: Enable

Name:

Internal IP:

Internal startport:

Internal endpoint:

External startport:

External endpoint:

Protocol Type: ▼


Schedule: ▼

Apply

- **Name:** Enter a name for your new rule.
- **Internal IP:** type in the IP address of the device you are opening ports for (PC, Xbox, PlayStation, etc.). It is recommended to set a static IP address on the device you want to open ports for.
- **Internal startport / Internal endpoint:** The first and last port number of the port range that you are opening. These are the port numbers that your device requires to be opened. In our example the Remote Desktop service requires port 3389 to be opened. You can specify a range of ports (e.g. for 3000-4000: Startport 3000; Endport 4000).
- **External startport / External endpoint:** The first and last port number of the port range that you are opening. These are the port numbers that will be opened to the Internet. Normally these are set to the same values as Internal ports.

- **Protocol Type:** TCP (or UDP): In this example its set to Both
- **Schedule:** Set to Always

Click on Apply to save:



Once the new rule is saved, you should see it in the Port Forwarding list.

D-Link
DSL-3890 FW:AU_1.00

Home | Settings | Features | Management

Port Forwarding

The *D-Link* externally acts as server. It receives the requests of remote users under its public IP address and forwards them automatically to the Port Forwarding. So a client in your network behind NAT or firewall can provide services as a Port Forwarding. You have to enable specific ports or port ranges and protocols (UDP/TCP). File sharing or web services for e.g. HTTP, FTP or POP3 are possible. The private IP addresses of the servers in the local network remain safe. If you have a dynamic IP address, you may want to enable DynDNS additionally.

Features >> Port Forwarding [DMZ \(Exposed Host\)](#)

Status	Name	Internal	External	Protocol	Schedule	Edit	Delete
Active	RDP	192.168.1.5 3389-3389	3389-3389	ALL	-		

[Add Rule](#) Remaining: 63