# How to setup IPTV on DSL-2740B (Rev F1 & Firmware AU-2.02)

- 1. Login to the web configuration page. By default it is <a href="http://192.168.1.1">http://192.168.1.1</a>
- 2. Enter in the Username and Password to login to your DSL-2740B.
- 3. Under SETUP > Internet Setup > Atm click on [Add] button

Froduce Fage: DOL 27	10011				Timware Version. No_2.02
<b>D-Lin</b>	k				
DSL-2740B	SETUP	ADVANCED	MAINTENANCE	STATUS	HELP
Wizard	WAN				Helpful Hints
Internet Setup	Atm	to configure ADSL in	terfaces.		When configuring the router to access the Internet, be
Wireless Settings	Eth	vci)			sure to choose the correct
Local Network	Wan Service	vely			list below. If you are unsure
IPv6	ADSI INTERFACE CO	NEIGURATION			contact your Internet
Time and Date					If you are baying trouble
Logout	Interface Vpi Vci DSL L atm0 8 35 Pa	atency Category Lin th0 UBR	k Type Connection Mode EoA DefaultMode	QoS Remove Disabled	accessing the Internet through the router, double check any settings you have entered on this page and verify them with your ISP if needed.
		Add	Remove		More

VPI is 0 and VCI is 35
 DSL Link type select [EoA]
 Connection type select [MSC Mode] then click on [Apply/Save] button

WAN
This screen allows you to configure an ATM PVC identifier (VPI and VCI), select DSL latency, select a service categoryS. Otherwise choose an existing interface by selecting the checkbox to enable it.
ATM PVC CONFIGURATION
VPI:         [0-255]         0           VCI:         [32-65535]         35
Select DSL Link Type (EoA is for PPPoE, IPoE, and Bridge.)
Encapsulation Mode: LLC/SNAP-BRIDGING
Service Category: UBR Without PCR 🔻
Select Connection Mode  Default Mode - Single service over one connection  VLAN MUX Mode - Multiple Vian service over one connection  MSC Mode - Multiple Service over one Connection
Enable Quality Of Service
Enabling packet level QoS for a PVC improves performance for selected classes of applications. QoS cannot be set for CBR and Realtime VBR. QoS consumes system resources; therefore the number of PVCs will be reduced. Use <b>Advanced Setup/Quality of Service</b> to assign priorities for the applications.
Enable Quality Of Service.
• •
Back Apply/Save Cancel

5. You will be able to see a new ADSL INTERFACE CONFIGURATION entry

Product Page: DSL-274	0B-F1			▶ <u>Site Map</u>	Firmware Version: AU_2.02
D-Lini	¢				
DSL-2740B	SETUP	ADVANCED	MAINTENANCE	STATUS	HELP
Wizard	WAN				Helpful Hints
Internet Setup	Choose Add, or Rem	ove to configure ADSL in	terfaces.		When configuring the router to access the Internet, be
Wireless Settings	Parameter is (portId	_vpi_vci)			sure to choose the correct Connection Type from the
Local Network					list below. If you are unsure of which option to choose,
IPv6	ADSL INTERFACE	CONFIGURATION			contact your Internet Service Provider (ISP).
Time and Date					If you are having trouble
Logout	Interface Vpi Vci	DSL Latency Category T	ink Connection Mode	QoS Remove	accessing the Internet through the router, double check any settings you have
	atm0 8 35	Path0 UBR E	oA DefaultMode	Disabled	entered on this page and verify them with your ISP if
	atm1 0 35	Path0 UBR E	OA MultipleServiceMode	e Disabled 📄	needed.
					More
	L				
		Add	Remove		
BROADBAND					

6. Click on blue [Edit] button under SETUP > Internet Setup > Wan Service

Product Page: DSL-274	40B-F1								▶ <u>Sit</u>	te Map	Firmw	are Version: A	AU_2.02
<b>D-Lin</b>	k												
DSL-27408	:	SETUP		ADVANCE	D	MAINT	ENANCE		STAT	US		HELP	
Wizard	WAN	r i											
Internet Setup	Atm		r Re	move to confi	gure WAN	interface	5.						
Wireless Settings	Eth				-								
Local Network	Wan Serv	vice	ETU	IP									_
IPv6		Interface	PVC	Description	Protocol	ConnId	Iamp	NAT	Firewall	State	Edit	Action	
Time and Date		0000	PVC:	pppoe atm0	PPPoE	N/A	Enabled	Enabled	Enabled	Enabled	Edit	DOWN	
Logout			8/35										
						Add	Remove						
BROADBAND													

# 7. Click on [Next] button

WAN
Select the type of network protocol and encapsulation mode.
WAN SERVICE CONFIGURATION
Select WAN service type: PPP over Ethernet (PPPoE) Prover Ethernet Bridging Enter Service Description: pppoe_atm0
Back

8. Tick [Enable IGMP Multicast] box under IGMP Multicast heading then click on [Next] button

PPP USERNAME AND	PASSWORD
PPP Username:	dlink2
PPP Password:	•••••
PPPoE Service Name:	
Authentication Method:	AUTO •
MRU:	1492
Enable NAT	
Enable Fullcone NA	т
Enable Firewall	
Dial on demand (with the second se	th idle timeout timer)
PPP IP extension	
Use Static IPv4 Add	iress
Enable PPP Debug I	Mode
Bridge PPPoE Frame	es Between WAN and Local Ports
IGMP Multicast	
Enable IGMP Multica	3ST
Enable VLAN	
	Back Next Cancel

## 9. Click on [Next] button

WAN				
Click "Apply" button to save the new configuration. You must reboot the router to make the new configuration effective.				
DNS SERVER CONFIGURATION				
<ul> <li>Obtain DNS server address automatically WAN Interface selected: pppoe_atm1/ppp0 </li> <li>Use the following DNS server addresses Preferred DNS server:</li> <li>Alternate DNS server:</li> </ul>				
Back Next Cancel				

#### 10. Click on [Next] button

WAN
Select a preferred wan interface as the system default gateway. Click "Apply" button to save it.
DEFAULT GATEWAY
Selected WAN Interface pppoe_atm1/ppp0 -
Back Next Cancel

# 11. Click on [Apply] button

WAN				
Make sure that the settings below match the settings provided by your ISP.				
Click "Apply" to save these settings. Click "Back" to make any modifications. NOTE: You need to reboot to activate this WAN interface and further configure services over this interface.				
SETUP - SUMMARY				
PORT / VPI / VCI:	0 / 8 / 35			
Connection Type:	PPPoE			
Description: pppoe_atm1				
Service Category: UBR				
IP Address:	Automatically Assigned			

Service State:	Enabled
NAT:	Enabled
Full Cone NAT:	Disabled
Firewall:	Enabled
IGMP Multicast:	Enabled



## 12. Click on blue [Add] button under SETUP > Internet Setup > Wan Service

Product Page: DSL-274	0B-F1				▶ <u>Site Map</u>	Firmware Version: AU_2.02
<b>D-Link</b>	¢					
DSL-2740B	SETUP	ADVANCE	D MAIN	ITENANCE	STATUS	HELP
Wizard	WAN					
Internet Setup	Atm	r Remove to config	gure WAN interfac	es.		
Wireless Settings	Eth					
Local Network	Wan Service	ETUP				
IPv6	Interface I	PVC Description	Protocol ConnI	d Igmp NA	T Firewall State	Edit Action
Time and Date		VC: pppoe atm0	PPPoE N/A	Enabled Enab	led Enabled Enabled	Edit DOWN
Logout	E 111	3/35				
			Add	Remove		
BROADBAND						

# 13. Click on [Next] button

WAN
Select a interface for wan service.
WAN SERVICE INTERFACE CONFIGURATION
Select a layer 2 interface for this service: atm1/(0_0_35) ▼
Back

13. Select [Bridging] option then click on [Next] button

WAN					
Select the type of network protocol and encapsulation mode.					
WAN SERVICE CONFIGURATION					
Select WAN service type: PPP over Ethernet (PPPoE) Pridging Enter Service Description: br_0_0_35					
Back					

## 14. Click on [Apply] button

WAN						
Make sure that the settings below match the settings provided by your ISP.						
nake sale and are seeings below match are seeings provided by your ibry						
Click "Apply" to save these settings. Click "Back" to make any modifications. NOTE: You need to reboot to activate this WAN interface and further configure services over this interface.						
SETUP - SUMMARY						
PORT / VPI / VCI:	0 / 0 / 35					
Connection Type:	Bridge					
Description:	br_atm1					
Service Category:	UBR					
IP Address:	Not Applicable					
Service State:	Enabled					
NAT:	Disabled					
Full Cone NAT:	Disabled					
Firewall:	Disabled					
IGMP Multicast:	Not Applicable					
В	ack Apply					

#### 15. You will be able to see a new WAN SERVICE SETUP entry

Product Page: DSL-274	0B-F1								▶ <u>Sit</u>	te Map	Firmv	vare Version	n: AU_2.02
D-Link													
DSL-2740B		SETUP		ADVANCE	D	MAIN	ENANCE		STAT	US		HEL	Р
Wizard	WAN	r											
Internet Setup	Choose Add, Edit, or Remove to configure WAN interfaces.												
Wireless Settings	Vireless Settings												
Local Network	WAN	I SERVICE	SETU	IP									
IPv6		Interface	PVC	Description	Protocol	ConnId	Igmp	NAT	Firewall	State	Edit	Action	
Time and Date		ppp0	PVC:	pppoe_atm0	PPPoE	N/A	Enabled	Enabled	Enabled	Enabled	Edit	DOWN	
Logout		atm1	8/35 PVC:	br atm1	Pridao	N/A	Enabled	Dicabled	Disphlad	Enabled	Edit		ר
		auni	0/35	DI_atilit	blidge	N/A	Ellableu	Disableu	Disableu	Ellapieu	Eule		
								_					
						Add	Remove	•					
BROADBAND													

16. Tick [Enable IGMP Snooping] box under ADVANCED > Network Tools > IGMP then click on [Apply] button

Product Page: DSL-27	408-F1 Site Map	Firmware Version: AU_2.02
<b>D-Lin</b>	k	
DSL-2740B	SETUP ADVANCED MAINTENANCE STATUS	HELP
Advanced Wireless	IGMP	Helpful Hints
Port Forwarding	Transmission of identical content, such as multimedia, from a source to a number of	With IGMP Snooping enabled, the device (1.2 switch) can
Port Triggering	recipients.	make intelligent multicast forwarding (only) toward
DMZ	IGMP SETUP	those hosts, i.e. IPSTBs etc., which request to join (as
Parental Control		members of) a specific multicast group, i.e. a IPTV
Filtering Options	Enable IGMP Snooping	channel etc., within the broadbast domain(same
Firewall Settings	Standard Mode	PVC/VLAN). As a result, it
DNS	Blocking Mode	flooding upon interfaces
Dynamic DNS		receivers of specific multicast
Network Tools	Port Mapping	More
Routing	IGMP Cancel	FIOI C
Schedules	QoS	
TR-069 Client	DSL	
WI-FI Protected Setup	SNMP	
Budget Quota	UPNP	
Power Management		
IPv6 Firewall		
IPv6 Routing		
Logout		
BROADBAND		

## 17. Click on [Reboot] button under MAINTENANCE > System

Allow the DSL-2740B to reboot with the new settings.

Product Page: DSL-274	40B-F1			▶ <u>Site Map</u>	Firmware Version: AU_2.02			
<b>D-Lin</b> l	k							
DSL-2740B	SETUP	ADVANCED	MAINTENANCE	STATUS	HELP			
System	SYSTEM REBOO	т			Helpful Hints			
Firmware Update	Click the button below	w to reboot the router.			This page allows you to reboot your router or save			
Access Controls		<b></b>			your router configuration to a file on your computer as a			
Diagnostics		Reb	pot		precaution in case you have to reset your router to			
Ping Test					factory default settings. You will be able to restore your			
System Log	SYSTEM BACKU	JP SETTINGS			router settings from a previously saved			
Logout	out       Backup DSL Router configurations. You may save your router configurations to a file on your PC.         Backup Settings         SYSTEM UPDATE SETTINGS         Update DSL Router settings. You may update your router settings by using your saved files.         Settings File Name:         Update Settings							
	Restore DSL Router s	ettings to the factory de Restore Defa	faults. ault Settings					