

## DCS-3112 FW 1.0





A http://1	92.168.0.20/setup.htm 🔎 – 🗟 🖒 🗙 🎑 D-LINK CORPORATION  IN 🗙	↑ ★ <sup>‡</sup>
Network Setup	NETWORK SETUP	Select 'DHCP
Dynamic DNS	You can configure your LAN and Internet settings here.	Connection'if you are running a DHCP server
Image Setup	Save Settings Don't Save Settings	on your network and would like an IP address
Audio and Video		assigned to your IP
Preset	LAN SETTINGS	camera automatically.
Motion Detection	OHCP	UPnP - Enabling UPnP settings will allow you to
Time and Date	Static IP Client	configure your IP camera as an UPnP device in the
Event Setup	IP address 192.168.0.20	network.
SD Card	Subnet mask 255.255.0	PPPoE Setting - If you
Logout	Default router 0.0.0.0	use the IP camera to connect directly to the
	Primary DNS         0.0.0.0           Secondary DNS         0.00.0	Internet, you will need to enter the username and
		password, which were
	Enable UPnP presentation	given to you when you set up your account with
	Enable UPnP port forwarding Forwarding Port 1024 Test	your Internet Service Provider. If the camera is
	Forwarding Status UPnP forwarding is inactive	behind a router or a gateway, you do not
		need to configure this
	PPPOE SETTINGS	setting.
	Enable     Disable	HTTP - HTTP Port is the port you allocate in order
	User Name	to connect to the IP camera via a standard
	Password	web browser.
	Confirm password	HTTPS - HTTPS Port in a
	PPPoE Status PPPoE is inactive.	IP camera connects it with a PC via a secure
		web browser.
	нттр	RTSP - RTSP Port is the port you allocate in order
	HTTP port 80	to connect to a IP
	Access name for stream1 video1.mjpg	camera by using streaming mobile device
	Access name for stream2 video2.mjpg	(s), such as a mobile phone or PDA.
	HTTPS	Traffic - Specifying the
		maximum download/
	HTTPS port 443	upload bandwidth for each socket is useful
	RTSP	when connecting your device to a busy or
		heavily loaded network.
	RTSP port 554	* The value '0' means it
	Access name for stream1 live1.sdp	will not monitor any traffic.
	Access name for stream2 live2.sdp	
	TRAFFIC	
	Maximum Upload Bandwidth: 0 Kilo Bytes Per Second	
	Maximum Download Bandwidth: 0 Kilo Bytes Per Second	-


							<u>×</u>
< 🔿 🥭 http://1	192.168.0.23/setup.htm	P - ⊠ d	🛛 🗙 🥔 D-LINK COR	PORATION  IN ×		ft 🖈	Ċ.
Product: DCS-3112					F	irmware Version : 1.00	A
<b>D-Lin</b>	K						
DCS-3112	LIVE VIDEO	SETUP	ADVANCED	MAINTENANCE	STATUS	HELP	
Setup Wizard	DYNAMIC DNS	;				Helpful Hints	Ш
Network Setup				at you have purchased		Dynamic DNS is useful if you have a DSL or Cable	
Dynamic DNS	broadband Interne	et service providers as	sign dynamic (changin	mically assigned IP add g) IP addresses. By usi	ng a DDNS	service provider that changes your modem IP	
Image Setup Audio and Video	service, you can e address is.	nter your domain nan	ne to connect to your I	P camera no matter wh	· ·	address periodically. This will allow you to assign a	
Preset	Sian up for D-Link	's Free DDNS service	at www.DLinkDDNS.co	m.		website domain name to your IP camera instead	н
Motion Detection						of connecting through an IP address.	
Time and Date		Save S	ettings Don't Save S	ettings			
Event Setup	DYNAMIC DNS	SETTING					
SD Card	Enable DDNS						
Logout	Server Address	www.dlinko	ddns.com	<< www.dlinkddns.com			
	Host Name			Select Dynamic DNS www.dlinkddns.com	Server		
	User Name			www.DynDNS.org			
	Password						
	Verify Password	24	]	(heurs)			
	Timeout	24 Active		(hours)			
		Active					
		Save S	ettings Don't Save S	ettings			
CCCUDIT!	•						

















DCS-3112	LIVE VIDEO	SETUP	ADVANCED	MAINTENANCE	STATUS	HELP
Setup Wizard	AUDIO AND V	IDEO				Helpful Hints
Network Setup			e sound and video of v	our camera. You can co	nfigure different	Higher frame size, frame
Dynamic DNS				a PC or a Mobile Phone		rate and bit rate gives better video quality. At
Image Setup		Save	Settings Don't Save S	Settings		the same time, it requires more network
Audio and Video			(			bandwidth.
Preset	VIDEO SETTIN	IGS				For best viewing results on a mobile phone, we
Motion Detection	Number of active	profiles	2 🔻			suggest setting the Frame Rate to 5fps and
Time and Date				hange the aspect ratio v		the Bit Rate to 64 kbps.
Event Setup	Aspect ratio		4:3 the settings motion detection	of privacy mask and pre ttion.	eset and	Number of active
SD Card			Save C	Default		profiles: Number of profiles that you wish to
Logout						active. The maximum profiles are three.
	VIDEO PROFI	LE 1				Aspect Ratio: An
	Mode		H.264 🔻			aspect ratio is the ratio
	Frame size		1280x1024 💌			between the width and height of an image.
	View window area	-	1280x1024 -			Mode: It can be H.264,
	Maximum frame r	ate	25 💌			JPEG, or MPEG4. In JPEG mode, the video frames
	Video quality Constant	bit rate	◎ 4M			are independent; MPEG4 consumes much less
	Fixed qu		Excellent			network bandwidth than
	Tixed qu	uncy				JPEG, and H.264 can use less bandwidth but better
	VIDEO PROFI	LE 2				image quality.
	Mode		JPEG 🔻			Frame Size: 8 options exist for the sizes of the
	Frame size		640x480 🔻			video display. It is recommended using
	View window area	9	640x480 💌			160x120 for mobile viewing and 1280x1024
	Maximum frame r	ate	15 💌			for computer viewing.
	Video quality		Excellent 💌			View window area:
						The viewing region of the current video stream.
	AUDIO SETTIN	IGS				Max frame rate: The
	Audio in off					maximum number of frames that is displayed
	Audio in gain leve		20dB 💌			in 1 second. 30fps is the
	Audio out off		10			highest video quality for this camera. In general,
	Audio out volume	level	10 -			any frame rate above 15 fps is imperceptible to
	<u>.</u>					the human eve












← →  Ø http://	/ <b>192.168.0.23</b> /advanced.	htm 🔎 🕶 🖸	🗴 🗙 🧔 D-LINK COF	PORATION IN ×		± =	x X
Product: DCS-3112						Firmware Version : 1.00	
D-Lin	k						
DCS-3112	LIVE VIDEO	SETUP	ADVANCED	MAINTENANCE	STATUS	HELP	
I and DO	DI AND DO					Helpful Hints	
S-485 CR TTPS				output (DO) and digit ces such as IR-Sensors		The network ipcam str provides a general I/O terminal block with one digital input and one relay switch for device control.	
ccess List	The digital input is taken and e-mailed		g external alarm devic	es and once triggered i	images will be	Pin DI+ and pin DI- can be connected to an	
gout	-	Save Sett	ings Don't Save	Settings		external sensor and the state of voltage will be monitored from the initial state 'LOW'. The relay	
	DI AND DO					switch of pin DO+ and pin DO- can be used to turn	
	Digital Input 1: Th	ne active state is N.	0. ▼ ; the current s	tate detected is Norm	al Open	on or off the external device. Please refer to	
	Digital Input 2: Th	ne active state is N.	0. ▼ ; the current s	tate detected is Norm	al Open	manual for detail connection diagram.	
	Digital Output: Th	ne active state is N.I N.C	D.			LED:In the near panel of your camera there is a	
	LED	N.C				LED beside the network adapter.ON: The LED will	
	LED	🖲 On 💿 Off	:			flash a light to indicate if the network is working or not.OFF: No light will	
	VIDEO OUTPUT					show, forth option is turn off.	
	VIDEO OUTPU	T 🖲 On 🔘 Off	:			TV Output: This function has two options: ON and	
		Save Sett	ings Don't Save	Settings		OFF.To enable this option, plug the cable connection into the TV output adapter. Connect the other and of the cable to your monitor.	
						Image form your cameras will be captured by a sensor and transmitted to your monitor. ON: Enables this option_OEE:	







							x
< 🔿 🥭 http://1	192.168.0.23/advanced.h	tm 🔎 🕶 🖻 🕻	👌 🗙 🔏 D-LINK COF	PORATION IN ×		<b>↑</b> ★	₽
Product: DCS-3112					Firi	mware Version : 1.00	L
<b>D-Lin</b>	<						
DCS-3112	LIVE VIDEO	SETUP	ADVANCED	MAINTENANCE	STATUS	HELP	
DI and DO		52101	Novinceo			Helpful Hints	=
RS-485	ACCESS LIST					Allow List:	
ICR	. Here you can set a	ccess permissions fo	or users to view your	IP camera.		'Start IP Address"	
	ALLOW LIST				C	The starting IP Address of the devices (such as a	
Access List	Start IP address				F	computer) that have permission to access the	
Logout						video of the IP camera. "End IP Address" The	
	End IP address Delete allow list			Add		ending IP Address of the devices (such as a	
	Delete allow list	-		Delete		computer) that have	
	DENY LIST				, N	video of the IP camera. "Delete Allow List"	
	Start IP address				F	Remove the customized	
	End IP address			Add		etting from the Allow .ist.	
	Delete deny list	<b>_</b>		Delete		Deny List:	
		<b>•</b>		Delete		"Start IP Address" The starting IP Address	
					0	of the devices (such as a	
						computer) that don't nave permission to	-

	92.168.0.23/maintenan	ce.htm 🔎 🕶 🖻 🖒	🗙 🗶 🎯 D-LINK COR				× ¢
Product: DCS-3112					l	Firmware Version : 1.00	Ŀ
D-Lini	K					$\prec$	
DCS-3112	LIVE VIDEO	SETUP	ADVANCED	MAINTENANCE	STATUS	HELP	
Admin	ADMIN					Helpful Hints	
System			r's password for your			Enabling OSD, the IP camera name and time	
Firmware Upgrade	via this page. You		gure the information, s OSD (On-Screen Displ video recordings.			will be displayed on the video screen for the user.	
	ADMIN PASSW	ORD SETTING				For security purposes, it is recommended that you change the password for	
	New Password		63	characters maximun	n	your administrator account. Be sure to write	
	Retype Password			ive		down the new password to avoid having to reset	н
						the IP camera in the event that it is forgotten.	
	ADD USER ACC	OUNT					
	User Name		20 us	sers maximum			
	New Password		63 cl	naracters maximum			
	Retype Password	Add					
		Add					
	USER LIST						
	Liser Name	Lines link	▼ Delete				
	User Name	User list	Delete				
	DEVICE SETTIN	G					
	IP camera Name	DCS-3112	63 cl	naracters maximum			
	🗷 Enable OSD						
	Label	DCS-3112	63 cl	naracters maximum			
	Show ti	me 🔽 Save					
							-

							×
	2.168.0.23/maintenan	ce.htm 🔎 🗕 🗟 (	🖒 🗙 🔏 D-LINK COR	PORATION  IN ×		<b>↑</b> ★	₽
Product: DCS-3112					Fi	rmware Version : 1.00	A
<b>D-Lin</b> l	Č						
DCS-3112	LIVE VIDEO	SETUP	ADVANCED	MAINTENANCE	STATUS	HELP	
Admin	SYSTEM					Helpful Hints	=
System	Here you may bac	kup, restore, and r	eboot your IP camera.			After the factory's default settings have	
Firmware Upgrade	SYSTEM					been restored, use the installation wizard	
	Save To Local Ha	rd Drive	Save Configuration			software provided with your IP camera to search and connect to the IP camera.	
	Load From Local F	Hard Drive		Browse			
			Load Configuration				
	Restore To Facto	ry Defaults	Restore Factory De	efaults			
	Reboot Device		Reboot Device				
							Ŧ

🧲 🔿 🩋 http://1	92.168.0.23/maintena	nce.htm 🔎 🗕 🖾 🕻	ジ× 🏉 D-LINK COR	PORATION  IN ×		<b>≜ ★</b> 3	æ
Product: DCS-3112	k				Fi	mware Version : 1.00	•
DCS-3112	LIVE VIDEO	SETUP	ADVANCED	MAINTENANCE	STATUS	HELP	
Admin System Firmware Upgrade Logout	camera firmware i internet IP camer available. To upgrade the fi version from the drive by clicking ti button, click the FIRMWARE IN	upgrade may be avail up-to-date to mainta a. Click here <u>D-Link S</u> irmware on your IP of D-Link Support Page he Browse button. C "Upload" button to s FORMATION a Version: 1.00.00 Name: DCS-3112 PGRADE	in and improve the fur support Page to check camera, please downloa to your local hard driv Drice you have found a start the firmware upgi	a. It is recommended to actionality and performs for the latest firmware ad and save the latest f e. Locate the file on yo and opened the file usin rade.	o keep your IP ance of your version firmware ur local hard ug the browse	Helpful Hints Firmware upgrade are released periodically to improve the functionality of your IP camera and also to add new features. If you run into a problem with a specific feature of the IP camera, check our support site by clicking upgrade and see if updated firmware is available for your IP camera.	E .

← → <sup>@</sup> / <sub>2</sub> http://19	2.168.0.23/status.htm	, <b>⊳</b> - ⊠ d	🗴 🗙 🙋 D-LINK COR	PORATION  IN ×		- □ <b>-</b> ↑ ★
Product: DCS-3112					Fi	rmware Version : 1.00
D-Link	¢					
DCS-3112	LIVE VIDEO	SETUP	ADVANCED	MAINTENANCE	STATUS	HELP
Device Info	DEVICE INFO					Helpful Hints
Log Logout	All of your network of displayed here.	connection details	are displayed on this p	page. The firmware ve	rsion is also	This page displays all the information about the IP camera and network settings.
	IP Subnet Mask Default Gateway Primary DNS	DCS-3112 Thu Sep 15 16 1.00.00 F0:7D:68:09:31 192.168.0.23 255.255.255.0 192.168.0.253 4.2.2.2 61.88.88.88 Disable Disable Disable Disable PAL	E:83			

