

DCS-4703E FW 1.00





Product: DCS-4703E Firmware Version: 1.00 **D-Link** MAINTENANCE DCS-4703E LIVE VIDEO SETUP ADVANCED STATUS HELP Helpful Hints.. Setup Wizard **NETWORK SETUP** Network Setup Select 'DHCP You can configure your LAN and Internet settings here. Connection'if you are Dynamic DNS running a DHCP server on your network and Save Settings Don't Save Settings Image Setup would like an IP address assigned to your IP Video LAN SETTINGS camera automatically. Motion Detection **UPnP:** Enabling UPnP O DHCP settings will allow you to configure your IP camera as an UPnP device in the Time and Date Static IP Client **Event Setup** IP address 192.168.20.3 network. Logout Subnet mask 255.255.255.0 PPPoE Setting: If you use the IP camera to Default router 192.168.20.254 connect directly to the Internet, you will need to Primary DNS 192,168,0,249 enter the username and password, which were Secondary DNS 192.168.0.243 given to you when you ✓ Enable UPnP presentation set up your account with your Internet Service Enable UPnP port forwarding Provider. If the camera is behind a router or a Forwarding Port 1024 Test gateway, you do not need to configure this Forwarding Status UPnP forwarding is inactive setting. PPPOE SETTINGS HTTP: HTTP Port is the port you allocate in order O Enable O Disable to connect to the IP camera via a standard User Name web browser. Password HTTPS: HTTPS Port in a IP camera connects it with a PC via a secure Confirm password PPPoE Status PPPoE is inactive. web browser. RTSP: RTSP Port is the HTTP port you allocate in order to connect to a IP camera by using streaming mobile device (s), such as a mobile phone or PDA. HTTP port 80 Access name for stream1 video1.mjpeg Access name for stream2 video2.mjpeg CoS (Class of Service): Coarsely-grained traffic control based on the L2 HTTPS protocol. Class of Service technologies do not HTTPS port 443 guarantee a level of service in terms of bandwidth and delivery time, they offer a "best-effort". RTSP Authentication Digest 🗸 **Qo5** (Quality of Service): Finely-grained traffic control, a resource RTSP port 554 Access name for stream1 live1.sdp reservation control mechanism. Quality of Access name for stream2 live2.sdp

COS SETTINGS	capacity is insufficient, especially for real-time
☐ Enable CoS	streaming multimedia
VLAN ID 1 [0~4095]	applications.
Live video 0 V	Enable IPv6: Select this option and click Save to
Live audio 0 🗸	enable IPv6 setting. Please note that this only
Event/Alarm 0 V	works if your network
Management 0 V	environment and hardware equipment
Management U V	support IPv6. The browser should be
QOS SETTINGS	Microsoft ® Internet
□ Farble Ove	Explorer 6.5, Mozilla Firefox 3.0 or above.
☐ Enable QoS	When IPv6 is enabled, by default, the Network
Live video 0 V	Camera will listen to router advertisements
Live audio 0 V	and be assigned a link-
Event/Alarm 0 🗸	local IPv6 address accordingly.
Management 0 V	IPv6 Information:
IPV6	Click this button to
-1740	obtain the IPv6 information. If your IPv6
Enable IPv6	setting are successful, the IPv6 address list will
IPv6 Information	be listed in the pop-up
✓ Manually setup the IP address	window. Please follow the steps below to link to
Optional IP address / Prefix length ::	/ 64 an IPv6 address: 1) Open your web
Optional default router	browser.
Optional primary DNS	2) Enter the link-global or link-local IPv6 address
	in the address bar of your web browser.
MULTICAST	3) Press Enter on the keyboard or click Refresh
☐ Enable multicast for stream 1	button to refresh the
Multicast group address 239,1,1,1	webpage.
Multicast video port 6550	Manually setup the IP address: Select this
Multicast RTCP video port 6551	option to manually configure IPv6 setting if
Multicast TTL [1~255] 64	your network
Enable multicast for stream 2	environment does not have DHCPv6 server and
Multicast group address 239.1.1.2	advertisements-enabled routers.
Multicast video port 6554	Multicast: Click the items to display the
Multicast RTCP video port 6555	detailed configuration information. Select the
Multicast TTL [1~255] 64	Always multicast option to enable multicast for
DONIOUR SETTINGS	stream 1 ~ 3.
BONJOUR SETTINGS	Unicast video transmission delivers a
✓ Enable Bonjour	stream through point-to- point transmission;
	ters maximum multicast, on the other
(Characters you may use in a Bonjour Name: "upper or lower case letters", "numbers" and "hyphens".)	
case recters , numbers and hyp	address and allows multiple clients to
Save Settings Don't Save Settings	acquire the stream at the
Save Settings Don't save Settings	same time by requesting a copy from the

