D-Link Buikding Networks for People			Wireles	s ADSL V	PN Router
DSL-G804V	Home Setup Wizar	Advanced	Tools	Status	Help
Wizard	The DSL-G804' small business G804V to conn setup will allor setup wizard s	V is a Wireless ADS networking. The se ect to your ISP (Inte w you to have Inter tep by step to confi	L VPN Router w etup wizard will ernet Service Pro net access within gure the DSL-G8	hich is ideal for h guide you to cont ovider). The DSL- n minutes. Please 04V.	ome and figure the DSL- G804V's easy follow the
Wireless			Run Wizard		0
DHCP DNS Relay Logout					Help

🕘 http://192.168.200.33 - Setup Wiz	ard - Microsoft Inter 🔳 🗖 🔀
D-Link DSL-0	804V Setup Wizard
Welcome to the DSL-G804V Setup Wizard these four quick steps.Begin by clicking or	.The Wizard will guide you through n Next.
······································	
Step 1. Set your new passw	/ord
Step 2. Set Internet connect	ion
Step 3. Set Wireless conne	ction
Step 4. Save configuration	
	ຄິ 👩
	Next Exit
E Done	😗 Internet

🕙 http://192.168.200.33	- Setup Wizard - Microsoft Inter 🔳 🗖	×
D -Link	DSL-0804V Setup Wizard	
Percent Second in the Proget		
	Set Password	
You may change the admin ad Click Next to continue.	account password by entering in a new password.	
Old Password		
New Password		
Reconfirm Password		
	3 3 3	
	Back Cancel Next Exit	
ど Done	🌍 Internet	

Microsof	ft Internet Explorer 🛛 🔀
?	For security issue, you must change password.
	OK Cancel

🙆 http://192	.168.200.33 -	Setup Wiza	rd - Mic	rosoft Inter 🔳 🗖	×
D ·Link		DSL.C	804\	Setup Wizard	
Beliding Networks for People			0020	/ Setup mizard	
	Detecting Ir	nternet Co	onnect	tion Type	
	Please	e wait for 5	secor	nds	
🕘 Done				🥝 Internet	:

🕙 http://192.168.200.33 - Seti	up Wizard - Microsoft Inter 🔳 🗖 🔀
D-Link Brown Million I Frage	SL-G804V Setup Wizard
Detected Inter	net Connection Type
1 found PPPoE PVC on 8/	35
	Gerica Sack Cancel Next Exit
iavascript:document.forms[0].su	🔮 Internet

🔮 http://192.168.200).33 - Setup Wizard - Microsoft Inter 🔲 🗖 🗙	
D-Link	DSL-6804V Setup Wizard	
Configu	ure Internet Connection Type	
Connection Type	PPPoE (RFC2516, PPP over Ethernet)	
VPI	8 PPPoE (RFC2516, PPP over Ethernet)	~
VCI	35 PPPoE (RFC2516, PPP over Ethernet)	
	PPPoA (RFC2864, PPP over AAL5) MPoA (RFC1483/RFC2684)	
PPP Information	IPoA (RFC1577, Classic IP and ARP ove	r ATM)
Username	user@isp.com.au	
Password	•••••	
Advanced PPP O	Option	
INAT		
IP Address	(0.0.0.0 (0.0.0 c) (0.0.0	
Netmask	0.0.0.0	
Gateway		
🗸 Enable Obtair		
Primary DNS	210.15.254.240	
Pacondary DNP	210.15.254.240	
Secondary Divo	210.13.234.241	
	(j) 🤤 🔮 🕕	
	Back Cancel Next Exit	
ど Done	🔮 Internet 💥	



http://192.168.200.33 -	Setup Wizard - Microsoft Inter 🔳 🗖 🔀
D-Link Harris Minarchi to Augu	DSL-G804V Setup Wizard
Set W	/ireless connection
For security reasons, the wi default. To enable this and s "Enable Wireless LAN" cheo	ireless portion of this device is disabled by setup wireless security, please check the ckbox below. Click Next to continue.
Enable W	Vireless LAN: 🔽
	Back Cancel Next Exit
E Done	Internet

🕘 http://192.168.200.33 - S	Setup Wizard - Microsoft Inter 🔳 🗖 🔀
D-Link	DSL-G804V Setup Wizard
Set Wi	reless connection
Enter in the SSID name and Wireless Access Point. Click	Channel number to be used for the Next to continue.
Network ID(SSID)	G804∨
Channel ID	Channel 1 (2.412 GHz)
Security Mode	Disable 🗸
	Disable
	WPA1 Pre-Shared Key WPA2 Pre-Shared Key
	WEP
	(9) (2) (3) (3)
	Back Cancel Next Exit
ど Done	🌍 Internet

🕘 http://192.168.200.33 -	Setup Wizard - Microsoft Inter 🔳 🔲 🔀
D-Link	DSL-G804V Setup Wizard
s	etup Complete
The Setup Wizard has comp mistakes. Click Save config DSL-G804V.	leted. Click on Back to modify changes or uration to save the current settings of the
	3
	Back Save Config Exit
E	🥥 Internet

Home	Adva	nced	Tools	Sta	atus	ŀ	lelp
To edit WAN Set (at bottom of thi WAN Settin	tings please s page) CIS	e using the pro	ofile at the WAN	Services	Table.		
Please select th	e appropria	te option to co	nnect to your IS	Ρ.			
PPPoE (RF	C2516, PPP ov	ver Ethernet)			*		
ATM VC Set	ting						
VPI		8					
VCI		35					
PPPoE							
Username							
Password							
IP Address		(0.0.0.0:Obta	in an IP addres	s automa	tically)		
Authenticat	ion Protocol	Chap(Auto)	~				
Connection	n	Always On	*				
Idle Timeo	ut	0	min	utes			
RIP				IP v2 Mult	icast		
MTU		1492					
NAT		💿 Enable (Disable				
TCP MSS (Clamp	💿 Enable (Disable				
ATM							
ATM Class		UBR 🔽					
To save settings	please do t	n Tools > Svst	em click Save				
To save settings	please go t	o Tools > Sysi	em, click Save.				
						Cancel	C) Help
						Janoet	
WAN Servic	es Table						
Name Descri	ption	Creator	VPI	VCI		-	
wanlink PPPoB	Routed	WebAdmin	8	35		-9	





CROAV	Home	Advanced	Tools	Status	Help
.00044	Port Group	aling K.			
- CO	Logical Eth	iernet Interface	Physical Ethernet F	Port(s)	
	ethernet		₽1 ₽2 ₽	3 🗹 P4	
Wizard	ethernet1		□ P1 □ P2 □ P	3 🗌 P4	
	ethernet2		🗌 P1 🗌 P2 🗌 P	3 🗌 P4	
WAN	ethernet3		□ P1 □ P2 □ P	3 🗌 P4	
LAN	Device Man	agement			
201000	Manageme	ent Interface	💿 ethernet		
Wireless					
				3 0	3 6
DHCP				Back Apply C	ancel Help
				· • • • • • • •	

0041	Home	Advanced	Tools	Status	Help
	LAN Settings	5			
		Configuration 💿	Ethernet Client Filter	O Ethernet Po	rt Setting
	Ethernet Clie	ent Filter			
	Filter Action	💿 Disable	O Allowed (Whiteli:	st) 🔘 Blocked (B	9lacklist)
	MAC Address Lis	t (MAC Address For	mat is tocococococ	xx) - Click to list act	tive clients
1					
			_		
	To save settings	 niease do to Tools >	System click Save		
	, o ouve ocumige,		Gyolofin, emeri Gave.	~	0 0
				V	
				Apply C	ancel Help





Home	Advance	d Tools	Status	Help		
DHCP Ser	ver					
The DSL-G80 network.	4V can be setup as a	DHCP Server to c	listribute IP addresses	to the LAN		
🔘 Disable	DHCP	Choose this optic assigned at each	on.The IP address mus device to connect to D	t be manually SL-G804V.		
⊙ DHCP :	Server	Choose this optic distribute IP addr	on to setup as a DHCP esses to the LAN netwo	server to ork.		
	Relay	Choose this optic	on to setup as a DHCP the target DHCP serve	Relay to Relay r		
DHCP Ser	ver			<i>ii</i> .		
Allow Boot	3	💿 Enable 🔘 Di	sable			
Allow Unkn	own Clients	Enable Di	sable			
Use Defau	lt Range					
Starting IP .	Address	192.168.10.200				
Ending IP A	ddress	192.168.10.199				
Default Lea	ise Time	43200	seconds			
Maximum L	.ease Time	86400				
Use Route	r as DNS Server					
Primary DN	IS Server Address					
Secondary	DNS Server Address	0.0.0.0				
Use Route	r as Default Gateway					
Static DHC	P					
Stand Dillo		> Suetom click S	1992			



DSL-GROAV	Home	Advanced	l Tools	Status	Help
552-50047	DNS Relay	Configuration			
- Co	The DNS config	uration allows the u	ser to set the configur	ation of DNS relay.	
	Obtain DN	S automatically	🗹 Enable		
Wizard	Primary DN	18	210.15.254.240]	
	Secondary	DNS	210.15,254.241]	
WAN	To save settings	please go to Tools	> System, click Save.	51	
				S	🙆 🔂
LAN				Apply	Cancel Help
Wireless					
DHCP					
DNS Relay					





Ho	me Ad	vanced	Tools	Status	H	elp
Virtua	Server					
•	Add Virtual Serv	er 🔘 Edit DM	IZ Host 💿 Edit	One-to-one NAT		
Globa	I IP Pool in '	inwan' IP ir	terface			
NAT Ty	pe	Disable	O Public to P	rivate Suhnet 🛛 Pul	blic to DMZ	7one
Global	IP Addresses	Subnet	O IP Range			20116
IP Addr	ess					
Netma	sk					
To save	settings please (go to Tools > Sy	/stem, click Sav	e.		
					23	0
				Apply	Cancel	Help
One-to-o	ne NAT Table <mark>A</mark> d	Id Entry				
Name	Schedule	Protocol Publ	ic Port(s) Privat	te Port(s) Private IP	+	

DSL-G804V	Home	Advanced	Tools	S	tatus	Н	elp
552-00044	Add Virtual	Server in 'ipwan'	IP interfac	e			
	Virtual Serve	er Entrv					
	Schedule	A	dways On 🔽				
Virtual Server	Name Helpo	er 🗍					
	Protocol Typ	ie to	op 🗸				
Firewall	Global IP						
VDN	Public Port(s) fro	om 0	to 0			
VPN	Private Port((s) fro	om O	to 0			
DDNS	Private IP Ca	andidates					
Routing				G	S	8	C
				Back	Apply (Cancel	Help
Wireless							



Once Security is enabled you can select the Policy

SL-CROAV	Home	Advanced	Tools	Status	Help
51-00044	Firewall				
ER	Firewall can be u	used to allow or deny tr	affic from passing th	rough the DSL-G80	4∨.
Virtual Server	General Set	tings		Medium security le	val 👽
	Security	⊙ Er	iable 🔘 Disable	High security level	
Firewall	Policy	Mediu	m security level 🛛 🔽	Medium security le	/el
	Block WAN	Request OEr	iable 💿 Disable	Low security level All blocked/User-de	fined
VPN			_		
DONE				2 💟 🕻	9 0
DDNS			N	ext Apply Ca	ncel Help
Routing					

NOTE: Before you can click next you need to click apply to enable the security.



Each Policy has different rules, see the next few pages for what each level has.



Low Security level



lei emtri	Alwaye On	0.0.0.0/0.0.0.0	TOP	0~65535	Block	📝 间
iei_anntp	Always Off	0.0.0.0/0.0.0.0	101	25 ~ 25	Allow	
loi non2	Alwove On	0.0.0.0/0.0.0.0	тер	0~65535	Block	🕑 间
iei_hoho	Always Off	0.0.0.0/0.0.0.0	TOP	110~110	Allow	
loi poto	Alwova On	0.0.0.0/0.0.0.0	TOP	0~65535	Block	📝 间
iei_nntp	Always On	0.0.0.0/0.0.0.0	TUP	119~119	Allow	
loi rou	Alwova On	0.0.0.0/0.0.0.0		0~65535	Allow	📝 间
iei_rav	Always On	0.0.0.0/0.0.0.0	ODP	7070 ~ 7070	Allow	
lai iaman	Alwaya On	0.0.0.0/0.0.0.0	IOMD	N/A	Block	📝 间
iei_icmp	Always On	0.0.0.0/0.0.0.0	ICIMP	N/A	Allow	
lei 6000	Alwaya On	0.0.0.0/0.0.0.0	TOD	0~65535	Allow	📝 间
iei_n323	Always On	0.0.0.0/0.0.0.0	TCP	1720~1720	Allow	
loi: #1.20	Alwaya On	0.0.0.0/0.0.0.0	TOD	0~65535	Allow	📝 间
iei_ti zu	Always On	0.0.0.0/0.0.0.0	TCP	1503~1503	Allow	
lai aab	Alwaya On	0.0.0.0/0.0.0.0	TOD	0~65535	Block	📝 间
iei_ssn	Always On	0.0.0.0/0.0.0.0	TCP	22 ~ 22	Allow	
loi onto	Alwova On	0.0.0.0/0.0.0.0		0~65535	Block	📝 间
iei_siitp	Always On	0.0.0.0/0.0.0.0	ODF	123~123	Allow	
lai httpa	Alwoud On	0.0.0.0/0.0.0.0	TOP	0~65535	Block	📝 📋
iei_nups	Always On	0.0.0.0/0.0.0.0	TOP	443 ~ 443	Allow	
loi ica	Alwova On	0.0.0.0/0.0.0.0	TOP	0~65535	Allow	📝 间
iei_icq	Always On	0.0.0.0/0.0.0.0	TOP	5190~5190	Allow	
loi monton	Alwove On	0.0.0.0/0.0.0.0	тер	0~65535	Allow	🛃 📋
iei_msnicp	Always On	0.0.0.0/0.0.0.0	TOP	1863~1863	Allow	
loi monudr	Alwovo On	0.0.0.0/0.0.0.0		0~65535	Allow	📝 间
iei_inshuuk	Always Off	0.0.0.0/0.0.0.0	ODF	7001 ~ 7001	Allow	
loi monudo	Alwova On	0.0.0.0/0.0.0.0	TOP	0~65535	Block	📝 间
iei_msnvdu	n Always Off	0.0.0.0/0.0.0.0	ICE	9000 ~ 9000	Allow	
loi httpp	Alwove On	0.0.0.0/0.0.0.0	тер	0~65535	Block	📝 间
iei_iiithh	Always Off	0.0.0.0/0.0.0.0	ICE	8080 ~ 8080	Allow	

Medium Security level



moi omta	Alwove On	0.0.0.0/0.0.0.0	тер	0~65535	Block	📝 📋
mei_smip	Arways On	0.0.0.0/0.0.0.0	ICF	25 ~ 25	Allow	
mai nan2	Alwova On	0.0.0.0/0.0.0.0	TOP	0~65535	Block	📝 📋
mei_boba	Arways On	0.0.0.0/0.0.0.0	ICP	110~110	Allow	
moi ente	Alwove On	0.0.0.0/0.0.0.0	тов	0~65535	Block	🛃 📋
mer_nmb	Always Off	0.0.0.0/0.0.0.0	ICF	119~119	Allow	
moi rou	Alwove On	0.0.0.0/0.0.0.0		0~65535	Allow	🛃 📋
mei_rav	Always Off	0.0.0.0/0.0.0.0	ODF	7070 ~ 7070	Allow	
mai jama	Alwove On	0.0.0.0/0.0.0.0		N/A	Block	📝 📋
mei_iump	Always Off	0.0.0.0/0.0.0.0	ICIME	N/A	Allow	
mai 6222	Alwove On	0.0.0.0/0.0.0.0	тор	0~65535	Block	📝 📋
mei_nszs	Arways On	0.0.0.0/0.0.0.0	ICF	1720~1720	Allow	
mai +1.20	Alwove On	0.0.0.0/0.0.0.0	тор	0~65535	Block	📝 📋
mei_ti zo	Always Off	0.0.0.0/0.0.0.0	ICE	1503~1503	Allow	
moi och	Alwove On	0.0.0.0/0.0.0.0	тер	0~65535	Block	📝 📋
iiiei_ssii	Always Off	0.0.0.0/0.0.0.0	ICE	22 ~ 22	Allow	
moi entr	Alwove On	0.0.0.0/0.0.0.0		0~65535	Block	📝 📋
mer_amp	Always Off	0.0.0.0/0.0.0.0	ODP	123~123	Allow	
moi http:	Alwove On	0.0.0.0/0.0.0.0	тор	0~65535	Block	📝 📋
mei_mups	Always Off	0.0.0.0/0.0.0.0	TOP	443 ~ 443	Allow	
moi httpp	Alwove On	0.0.0.0/0.0.0.0	TOP	0~65535	Block	📝 📋
mer_umhh	Aiways Off	0.0.0.0/0.0.0.0	TUP	8080 ~ 8080	Allow	

High Security level



hai nan2 (0.0.0.0/0.0.0.0	тор	0~65535	Block	📝 📋
nei_pops x	aiways on	0.0.0.0/0.0.0.0	ICP	110~110	Allow	
hai nata (0.0.0.0/0.0.0.0	тор	0~65535	Block	📝 📋
nei_nntp &	aiways Ori	0.0.0.0/0.0.0.0	TOP	119~119	Block	
bei reu (0.0.0.0/0.0.0.0		0~65535	Block	📝 📋
nei_rav A	Always Off	0.0.0.0/0.0.0.0	ODP	7070 ~ 7070	Block	
hai iaman (0.0.0.0/0.0.0.0		N/A	Block	📝 📋
nei_icmp #	aiways Ori	0.0.0.0/0.0.0.0	ICIMP	N/A	Allow	
hai 6222 (Alwaya On	0.0.0.0/0.0.0.0	тор	0~65535	Block	📝 📋
nei_nszs A	aways on	0.0.0.0/0.0.0.0	TCF	1720 ~ 1720	Block	
hoi +120 (Nuces On	0.0.0.0/0.0.0.0	тер	0~65535	Block	📝 📋
nei_ti zo x	Nivays Off	0.0.0.0/0.0.0.0	TUP	1503~1503	Block	
hai ach (Nuces On	0.0.0.0/0.0.0.0	тер	0~65535	Block	📝 📋
nei_ssii /	Nivays Off	0.0.0.0/0.0.0.0	TOP	22 ~ 22	Block	
hoi ontro (Nuove On	0.0.0.0/0.0.0.0		0~65535	Block	📝 📋
nei_ship /	Always On UE 0.0.0/0.0.0	ODF	123~123	Allow		

Once inside the firewall page there are 4 different settings as below.

```
Add TCP/UDP Filter
```



Add Raw IP Filter



Intrusion Detection Advanced Tools Home Status Help DSL-G804V Firewall Firewall can be used to allow or deny traffic from passing through the DSL-G804V. O Add TCP/UDP Filter O Add Raw IP Filter Intrusion Detection Virtual Server O URL Filter Firewall Log Intrusion Detection Firewall Intrusion Detection 🔘 Enable 💿 Disable VPN Victim Protection Block Duration 600 seconds Scan Attack Block Duration 86400 seconds DDNS DOS Attack Block Duration 1800 seconds Maximum TCP Open Handshaking Count 100 per second Routing Maximum Ping Count 15 per second Maximum ICMP Count 100 per second Wireless Clear Blacklist ADSL IP QoS Help Apply Cancel

URL Filter



This is the last option in the Firewall section.

GROAV	Home	Advanc	ed Tool	s St	atus	Help
00047	VPN					
-Co	○ PPTP	0	IPSec	€ L2TP		
Virtual Server	L2TP					
	Enable after	'Apply'	🔿 Yes 💿 NO	Remote Acc		
Firewall	Connection	Name		Remote Acc	ess	
	Connection	Туре	Remote Access	LAN to LAN		
VPN	Service Type	e	Dial out (Connect t	o below Server IF	address or P	ʻQDN) 🔽
DDNS	IP Address					
	Account Co	nfiguration				
Routing	Username					
	Password					
Wireless	Authenticati	on Type	Chap(Auto) 🔽			
	Idle Timeou	t	0 minute:	3		
ADSL	🔲 Active as	s default route				
IP OoS	📃 Enable I	PSec				
IF GOD	Authentica	ation	None 💌			
Time Slices	Encryption	1	NULL			
	Perfect Fo	irward Secrecy	None	\sim		
Email	Pre-share	id Key				
	📃 Enable 1	Funnel Authentic	ation			
Device	Secret					
	Remote Ho:	st Name		(Optional)	
IGMP	Local Host 1	Name		(Optiona	I)	
VLAN Bridge					Ø	3 0
					арріу С	апсет метр
Logout	VPN/L2TP L	ist	23	11	Vi	ew L2TP Status
	Name	Connection Type	Service Type	Status	Enable	
	T test	remoteacces	s dialin	Inactive	No	

IV	Home Adv	anced	Tools	Stat	us	Help
tor	Dynamic DNS					
0	Use Dynamic DNS if you w	/ant to use yo	ur DDNS account.		www.dyn	dns.org (dynamic)
al Server	Dynamic DNS	0 Er	iable 💽 Disable		www.dyne	dns.org (custom)
	Wildcard	Er	able) 💌	www.dyn www.zon	ans.org (static) eedit.com
311	Host Name				www.orgo www.dhs	Ins.org .org
	Username/Email				www.dyn:	s.cx main bk
	Password/Key				www.no-ij	o.com
	Refresh Period	25	Day(s) 🔽		dyndns.dk	2.org
	To save settings please go	to Tools > Sy	/stem, click Save.		www.tzo.i	com n.com

w 1	Home	Advanced	Tools	Status	Help
Sta	atic Route				
	Destination				
	Netmask				
	Gateway				
	Interface	vqi	van 🚩		
	Cost	1			
To	save settings p	lease go to Tools >	System, click Save.		
					📀 🔂
Ro	uting Tabl	e		. app of	ounoor noip
Des	stination	Netmask	Gateway	Valid	
0.0.	0.0	0.0.0.0	0.0.0.0/ ipwan	\checkmark	1

DSL-G804V	Home	Advanced	Tools	Status	Help
DSL-G804V Virtual Server Firewall VPN DDNS Routing Wireless ADSL IP QoS	Home ADSL Connect Mod Modulation Coding Gair Tx Attenuatio DSP Firmwa Operational Annex Type Upstream B Downstream	Advanced	Tools	auto V Apply	Help
IP QoS Time Slices Email Device IGMP VLAN Bridge		Dmt_0.9DB Dmt_1DB Dmt_2DB Dmt_2DB Dmt_3DB Dmt_5DB Dmt_6DB Dmt_6DB Dmt_7DB Dmt_8DB Dmt_9DB Dmt_10DB Dmt_10DB Dmt_11DB Bis_0DB Bis_0.1DB Bis_0.2DB Bis_0.3DB Bis_0.4DB Bis_0.5DB Bis_0.6DB Bis_0.7DB ♥	Bis_20DB Bis_21DB Bis_22DB Bis_22DB Bis_24DB Bis_25DB Bis_26DB Bis_26DB Bis_27DB Bis_27DB Bis_29DB Bis_30DB Bis_31DB Bis_32DB Bis_32DB Bis_35DB Bis_35DB Bis_35DB Bis_35DB Bis_37DB Bis_330B Bis_330B Bis_330B Bis_330B Bis_330B Bis_330B Bis_330B Bis_330B Bis_330B Bis_330B Bis_330B		

DSL-G804V	Hon	ne 🖊	dvanc	ed To	ols S	tatus	Ì	lelp
	IP QoS							
	۹ 🕥	Packet Prior	itization	Outbound	Throttling	🔘 Inbou	ind Throttli	ng
Virtual Server	Packet	Prioritiz	ation					
	Name							
Firewall	Sched	lule		Always On	*			11/20
	Priorit	/		High 🔽)isabled	×
VPN	Protoc	ol		any 💌		B	lest Effort remium	5
	Sourc	e port(s)		0 ~0		G	old service	(L) (M)
DDNS	Destir	ation port(s	5)	0 ~0		G	old service	(m) (H)
Routing	Sourc	e IP Addres	s Range	0.0.0	~0.0.0.0	s	ilver service ilver service	∋(L) ∋(M)
Kouring	Destir	nation IP Ad	dress Ran <u>o</u>	je 0.0.0.0	~0.0.0.0	IS IS	ilver service Ironze servi	e (H) ce (L)
Wireless	DSCP	Marking		Disabled	×	B B	Ironze servi Ironze servi	ce (M) ce (H)
	To save s	ettings plea	ise go to To	ols > System, c.	lick Save.			
ADSL						S	23	0
						Apply	Cancel	Help
IP QoS	Packet	Prioritiz	ation Lis	t				
Time Slices	Namee	Schedule	Protocol/ Priority	Source port(s)/ Destination port(s)	Source IP/ DDestination IF	r M)SCP larking	
Email								

	Home	Advanced	Tools	Status	He
1	Time Slices		1994 - C.		
1	D Name	Dav(s) in a we	ek Start Time	End Time	-
	I TimeS	lot1 sMTVVTFs	08:00	18:00	
3	2 TimeS	lot2 sMTVVTFs	08:00	18:00	📝 🗊
ž	3 TimeS	lot3 sMTVVTFs	08:00	18:00	📝 🗊
ł	4 TimeS	lot4 sMTVVTFs	08:00	18:00	📝 间
1	5 TimeS	lot5 sMTVVTFs	08:00	18:00	📝 🗎
1	6 TimeS	lot6 sMTVVTFs	08:00	18:00	📝 间
j,	7 TimeS	lot7 sMTWTFs	08:00	18:00	📝 间
1	3 TimeS	lot8 sMTWTFs	08:00	18:00	📝 间
j,	3 TimeS	lot9 sMTWTFs	08:00	18:00	📝 间
100	10 TimeS	lot10 sMTWTFs	08:00	18:00	📝 🗊
	11 TimeS	lot11 sMTWTFs	08:00	18:00	📝 间
100	12 TimeS	lot12 sMTVVTFs	08:00	18:00	📝 间
2	13 TimeS	lot13 sMTVVTFs	08:00	18:00	📝 间
	14 TimeS	lot14 sMTVVTFs	08:00	18:00	📝 间
3	15 TimeS	lot15 sMTVVTFs	08:00	18:00	📝 间
1	16 TimeS	lot16 sMTVVTFs	08:00	18:00	📝 间
	To save settings	please go to Tools >	System, click Save	Ļ.	
					н

DSL-GROAV	Home	Advanc	ed	Tools	s St	atus	Help
D32-00041	Device Manag	jement					
Citiz Contraction	Device Host N	lame					
	Host Name	Voirro		804\/	1		
Virtual Server	Hostinanie		000-00	,041			
	Embedded W	eb Server/					
Firewall	* HTTP Port		80		(80 is default	HTTP port)	
	Management	IP Address	0.0.0.0		('0.0.0.0' mea	ans Any)	
VPN	Auto-Logout 1	Timer	180		seconds		
	Universal Div	and Dias					
DDNS	Universal Plu	ig and Play	OPT				
	UPhP		🕑 Ena	able 🔾 Dis	able 1		
Routing	* UPnP Port		2800				
Wireless	SNMP V1 and	l V2					
	Read Comm	unity	public]		
ADSL	Read Restrict	ted IP Address	0.0.0.0]		
	Write Commu	unity	passw	ord]		
IP QoS	Write Restrict	ed IP Address	0.0.0.0]		
	Trap Commu	nity]		
Time Slices	Trap Restricte	ed IP Address]		
Email	SNMP V3						
	Username				Ĩ		
Device	Password				1		
	Access Right		Ret] MA(rito		
IGMP	IP Address						
	*: This setting will	become effect	tive after	you save to	flash and res	start the route	er.
VLAN Bridge	To save settings p	lease go to Too	ols > Sy	stem, click S	Save.		
Logout						V	😕 🕒
						Apply C	ancel Help

DSL-GROAV	Home	Advanced	Tools	Status	Help
DELGOVAN	Create VL	AN			
- Co	VLAN N	ame			
Virtual Server	VLAN ID	i i		(2~4094)	
	Tagged	Member Port(s)	🔲 ethernet 📃 w	rireless	
Firewall	To save setti	ngs please go to Tools > :	📃 ethernet 🛄 w System, click Save.	rireless	
VPN					-
				\checkmark	63
DDNS				Apply (Cancel Help
Routing	VLAN Brid	dge List	LINT	unad Dada	-
	Name Default/lan	1 None	Onia	agged Pons metwireless	
Wireless	Denadirman		0.1101	104111010004	
ADSI					
ABOL					
IP QoS					
Time Slices					
Email					
Device					
IGMP					
VLAN Bridge					

GROAV	Ho	ne A	dvanced	Tools	Status	Help
00047	Curre	nt Defined	Users			
- Com			Username			
Admin			New Password			
Admin		Reco	nfirm Password			
Date & Time			Valid f	alse 💌		
			Comment]	
System						
						0 0
Firmware					Apply	Cancel Help
	Valid	User	Comment			
emote Access	true	admin	Default adm	in user		
Lonout						
Logour						

	lome	Advanced	Tools	Status	Help
Da	te & Time	E.			
Dev	ce Time :Thi	u. 01 Jan 1970 - 00:	48:58		
۲	Enable NT	P to Synchronize Da	ate and Time Automa	tically	
	Default NT	'P Server			
	1. carl.css.	gov 2.	india.colorado.edu		
	3 time.nist.		time-b.nist.gov	=	
	Time Zone	Listby		te.	
	By City	O By Time Differe	nce		
	Time Zone	e (+-GMT Time)			
	(GMT)Gree	enwich Mean Time		~	
	Resync wi	th NTP Server after		02	
	1440	minute	es		
0	Pot Dovice	Data and Time Mar	ouolly		
	SetDevice				
	Year: 2002	2 🎽 Month: Jan	Y Day: 01 Y		
	Hour: 00	Minute: 00 💙	Second: 00 💌		
V	Automatic	Daylight Saving			
				S	🖸 🖸
				Apply C	ancel He
				Арріу С	ancer ne

DEL CROAV	Home	Advanced	Tools	Status	Help
D3L-G804V	System Set	tings			
	Save Settings T Backup Settin	o Local Hard Drive			
Admin Date & Time	Load Settings F Load	rom Local Hard Drive Browse			
System	Save Config to	Device Memory			
Firmware	Please click 'Sa saving as config Save	we' to start saving configu guration information is w	uration to device n ritten to device me	nemory. There will be emory.	e a delay while
Remote Access	Reboot Device				
	After restarting, all configuratior	please wait for a few sec 1 to factory default setting	onds for system t s, please select ti	to come up. If you wo he "Factory Default S	ould like to reset Settings" option.
Logout	Restart Router Reboot	with 💿 Current Settings	O Factory Defa	ult Settings	
					0
					Help

DEL CROAV	Home	Advanced	Tools	Status	Help
D3L-00044	Firmware U	lpgrade			
	There may be n The upgrade pr being upgraded	ew firmware for your DSI ocedure takes about 60 : I.	G804V to improve seconds. Note! Do	e functionality and pe not power off the un	erformance. it when it is
Admin		Current Firm	ware Version: 1	.00.05.dm2	
Date & Time			Bro	wse	
System				Ø	3 🕄
Firmware				Apply C	ancel Help

DSL-G804V	Home Adv	anced Tools	Status	Help
	ARP Table			
Device Info	IP Address	MAC Address	Interface	
ARP	132.100.1.113	00.00.70.32.70.31	ipian	🛟 Help
Wireless				

DSL-GROAV	Home	Advanced	Tools	Status	Help
D32-3804V	Connected	Wireless Client Li	st		onnonn i Addin,
and a second	The Wireless Cli	ent table below displays	Wireless clients	connected to the AP ((Access Point).
Device Info	_	IP Address		МАС	
ARP					0
Wireless					Help
Routing					

DSL-GROAV	Home	Advanced	Tools	Status 🗾	lelp
D3L-30041	Routing Ta	ble			
	Routing Ta	ble	Notmask	Gotowov/Interface	Cost
Device Info		0.0.0.0	0.0.0.0	0.0.0.0/ ipwan	1
ARP	RIP Routing	g Table			
Wireless	Valid	Destination	Netmask	Cost	
Routing					🛟 Help

DSL-G804V	Hon	1e	Advan	ced	т	ools	Sta	atus	Help
	PPTP S	tatus							
an Co	VPN/PI	PTP fo	r Remote	e Acce	ss Ap	oplicatior	1 I	Vie	w PPTP Setting
	Name	Туре	Enable	Act	ive	Tunnel Connected		Call Connecte	d Encryption
Device Info	VPN/PF	PTP fo	r LAN-to-	LAN A	pplic	ation			
ARP	Name	Туре	Enable	Active	Tunn Conr	el nected	Call Connec	ted E	Encryption
Wireless									0
Routing									Help
PPTP Status									

1								
	Hon	ne	Advan	ced	Tools	St	atus	Help
	L2TP S	tatus						
	VPN/L2	2TP fo	r Remote	Acce	ss Applica	tion	Vic	ew L2TP Setting
	Name	Type	Enable	Act	ive Tunne	el	Call	Encryption
	Name	Type	Cliable	Au	Conn	ected	Connecte	d
	VPN/L2	TP fo	r LAN-to-	LAN A	pplication			
	Name	Туре	Enable	Active	Tunnel	Call	eterd F	Encryption
					Connected	Conner	nea	
								•
								Hein
								пеф
	Hom		Advand	hes	Tools	Sta	tue	Help
	nom	e	Auvany	Jeu	10015		tus	пер
	DHCP S	status						
l					ooto truo			
			Allow Unki	nown Clie	ents true			
				En	able true			
	Subnet D	efinition	IS					
			5	Subnet Va	alue 192.168.	1.0		1
				SubNetm	ask 255.255.	255.0		
			Maximum	Lease T	ime 86400 se	econds		
	177 co. 25 co	1005000000	Default	t Lease T	ime 43200 se	econds		
	Usele	ocal hos	t address as	s DNS se	rver true			
	Use local	nost add	rress as defi	ault gate ND interf	way true			
		Get	sumernon	ID Ra	nde 102160	1 100- 107 16	81100	
				ir Na On	tion domain-i	name-servers	= 0 0 0 0	
				~P	don doniani		- 0.0.0.0	
	Expired	Table	3					
	IP Address	s M/	AC Address	Clie	ent Host Name	Expin	1	
	Perman	nent Ta	able	1000		in the second se		01
	Name	IP	Address	MAG	CAddress	Maxir	num Lease	Time
	Leased	Table						
	IP Address	s M/	AC Address	Clie	ent Host Name	Expin	/	
								0

Event Log

Help

