# How to change Wireless Channel
in your modem router

This document details how to change Wi-Fi Channel to avoid interference with other Wi-Fi networks

Step 1. Open your Internet Browser and in the address field type in http://192.168.1.1.


Step 2. When prompted type in the Username and Password then click on the "Log In" button. If you have not changed the password for the modem administration, the factory settings are:

Username: admin
Password: admin

Step 3. After logging in you will be presented with the modem's configuration pages. Please click on **Setup** tab and then on **Wireless 2.4G Setup**.

Step 4. In the [WIRELESS SETTING] section of the page please find the "Channel" option. Click on the drop down menu to select a channel number between 1 and 13. (Please note that although channels 12-13 are allowed in Australia/NZ some of your devices may not detect Wi-Fi on these channels due to restrictions in US).

PLEASE MAKE SURE CLICK ON [Apply] BUTTON AT THE BOTTOM OF THE PAGE TO SAVE THE SETTINGS.

Step 5. Repeat the same steps for the **Wireless 5G Setup**.