DSL-504G SNMP Community CLI commands

- To see a list of configured communities, enter:

$ get snmp comm.

- To create a community called public with read-only access, enter:

$ create snmp comm community public ro

- To delete a community called public with read-only access, enter:

$ delete snmp comm community public