D-Link ADSL Router - Internet Explorer

http://192.168.1.1/login.cgi

File Edit View Favorites Tools Help SnagIt

D-Link ADSL Router

Product Page: DVA-G3670B | Site Map | Firmware Version: AUS_1.27

D-Link

DVA-G3670B

SETUP | ADVANCED | VOICE | MAINTENANCE | STATUS | HELP

- Wizard
- Internet Setup
- Wireless Settings
- Local Network
- Time and Date
- Logout

LAN SETUP

This section allows you to configure the local network settings of your router. Please note that this section is optional and you should not need to change any of the settings here to get your network up and running.

ROUTER SETTINGS

Use this section to configure the local network settings of your router. The IP Address that is configured here is the IP Address that you use to access the Web-based management interface. If you change the IP Address here, you may need to adjust your PC's network settings to access the network again.

Router IP Address : 192.168.1.1

Subnet Mask : 255.255.255.0

☐ **Configure the second IP Address and Subnet Mask for LAN interface**

IP Address:

Subnet Mask:

DHCP SERVER SETTINGS (OPTIONAL)

Use this section to configure the built-in DHCP Server to assign IP addresses to the computers on your network.

Helpful Hints...

The IP address of your router is the same IP address you will use to access the web management interface of your router. If you already have a DHCP server on your network or are using static IP add on all the devices on your network, click on **Disable DHCP Server** to disable this feature.

UPnP helps other UPnP LAN hosts interoperate with the router. Leave the UPnP option enabled as long as the LAN has other UPnP applications.

More...

Internet 100%