


DPH-100S Peer-to-Peer function set up instruction


D-Link SIP phones can work without SIP server through phone book. For this mode, configure the phone book through browser. In this mode, the phones will work with configurations in the phone book.

* Note that the phone book entries of all the phones in one network should be consistent.

1.Click IP Phone Configuration :



2.Click SIP Configuration:



3.SIP Phone Book:

	SIP:	@	:
0.	102	10.52.63.20	5060
1.			
2.			
3.			
4.			
5.			
6.			
7.			
8.			
9.			

This is a table of 10 entries where we can enter the phone number, IP address and port of the phone. This feature allows the phone to be used without a SIP redirect server or proxy server. A set of 10 numbers can be programmed to the phone and the phone will directly contact these numbers without the help of SIP server.

*You need to set this table firstly before you start to use Peer-to-Peer function.

*As you use Peer-to-Peer function ,you need to push “ Speakerphone” button and “ *” key ,the LCD display will show the “phone book” you have set .Choose the one you want to dial and Push the “# “ key .