

D-Link[®] Quick Installation Guide

This product works with the following operating system software: Windows 2000 SP4 /XP



DUB-T210
USB 2.0 MPEG1/2/4
Encoder & TV Tuner

Before You Begin

You must have at least the following:

- CPU 1.2 GHz Processor or Above (CPU 2.4GHz Processor or Above is required for Real-Time Recording)
- Microsoft Windows 2000 SP4/XP
- Microsoft-DirectX8.1 or Above
- Minimum 256MB RAM
- CD-ROM , CD-R/RW , DVD+R/RW,DVD-R/RW
- 16 Bit or better Sound Card
- One Available USB 2.0 Port
- PCI/AGP VGA Card with minimum 64MB RAM

Check Your Package Contents

These are the items included with your purchase:

If any of the below items are missing, please contact your reseller.



**DUB-T210 USB 2.0 MPEG1/2/4
Encoder TV Tuner**



**CD-ROM(containing Drivers, Installation
Guide, Manual, Application Software and
Warranty)**



USB 2.0 Cable



AV Cable



Audio Cable(for Windows 2000 only)



S-Video to RCA Converter



Remote Controller



Run the Driver CD before you install the DUB-T210

For the initial installation of the DUB-T210 there are two steps involved: installing the driver then the TV Plus software. See further on for detailed descriptions of these steps.

1

DUB-T210 Driver Installation

Please bring out the attached CD-ROM and follow the steps listed below carefully to insure the installation of DUB-T210 will be complete.


Insert the software CD into CD-ROM. As you can see the below picture, D-Link DUB-T210 startup window will be displayed.

Click **Install DUB-T210 Driver**



The InstallShield Wizard window will show, please press "Next" to continue.

Click **Next**




1


DUB-T210 Driver Installation

(Continued)

After the execution, please select “Yes, I want to restart my computer now” and press “Finish”



Please press “Finish” to finish the installation




2

Installing TV PLUS



Click **Install TV Plus**

Please select the language for this application



Click **Next**

2

Installing TV Plus (Continued)


Please Click “Yes” to continue.

Click **Yes**



Please click “Yes” to agree the license and continue the installation.

Click **Yes**



Please click “Next” to continue.


Click **Next**




2

Installing TV Plus (Continued)


Please don't change the installing items & click "Next".



Please click "Next" to run Installing.



Please click "Finish" to finish the codec installation.




2

Installing TV Plus (Continued)


Please click “Next” to continue application installing.

Click **Next**




Check of “Yes” agree the license and continue the installation.

Click **Yes**



Click “Next” to continue or you can browse the installing folder.


Click **Next**



2


Installing TV Plus (Continued)

Click “Next” or you can change the program folder.




Click **Next**

Please select the correct device according to your operating system.



Click **Next**

Please Click “Yes” to continue.




Click **Yes**

2

Installing TV Plus (Continued)


Check of “Yes” agree the license and continue. the installation.

Click **Yes**




Please click “OK” to continue.

Click **OK**



Click “Finish” to finish all installation and please restart the computer.


Click **Finish**




3

Your Setup is Complete!

To confirm the DUB-T210 is properly installed, click "START"→"SETTINGS"→"CONTROL PANEL". Double-click "SYSTEM". Select the "HARDWARE" tab and click the "DEVICE MANAGER" button Confirm That "D-Link DUB-T210 Audio Device" and "D-Link DUB-T210 TV Tuner" section.



Congratulation ! The DUB-T210 is now installed and ready to use. Double-click the TV Plus 3.0 icon on your desktop and enjoy high performance audio and video capturing.



Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for customers within Australia:

D-Link Technical Support over the Telephone:

1300-766-868

Monday to Friday 8:00am to 8:00pm EST

Saturday 9:00am to 1:00pm EST

D-Link Technical Support over the Internet:

<http://www.dlink.com.au>

email: support@dlink.com.au

Tech Support for customers within New Zealand:

D-Link Technical Support over the Telephone:

0800-900-900

Monday to Friday 8:30am to 8:30pm

Saturday 9:00am to 5:00pm

D-Link Technical Support over the Internet:

<http://www.dlink.co.nz>

email: support@dlink.co.nz

D-Link[®]
Building Networks for People

Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for customers within South Eastern Asia and Korea:

D-Link South Eastern Asia and Korea Technical Support over the Telephone:

+65-6895-5355

Monday to Friday 9:00am to 12:30pm, 2:00pm-6:00pm
Singapore Time

D-Link Technical Support over the Internet:

email: support@dlink.com.sg

D-Link[®]

Building Networks for People

Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for customers within India

D-Link Technical Support over the Telephone:

+91-22-26526741

+91-22-26526696 –ext 161 to 167

Monday to Friday 9:30AM to 7:00PM

D-Link Technical Support over the Internet:

<http://www.dlink.co.in>

<http://www.dlink.co.in/dlink/drivers/support.asp>

<ftp://support.dlink.co.in>

email: techsupport@dlink.co.in

D-Link[®]
Building Networks for People

Technical Support

You can find software updates and user documentation on the D-Link website.

D-Link provides free technical support for customers for the duration of the warranty period on this product.

Customers can contact D-Link technical support through our web site or by phone.

Tech Support for customers within the Russia

D-Link Technical Support over the Telephone:

(095) 744-00-99

Monday to Friday 10:00am to 6:30pm

D-Link Technical Support over the Internet

<http://www.dlink.ru>

email: support@dlink.ru

D-Link®
Building Networks for People

Technical Support

You can find software updates and user documentation on the D-Link website.
Tech Support for customers within the U.A.E & North Africa:

D-Link Technical Support over the Telephone:
(971) 4-391-6480 (U.A.E)

Sunday to Wednesday 9:00am to 6:00pm GMT+4

Thursday 9:00am to 1:00pm GMT+4

D-Link Middle East & North Africa

D-Link Technical Support over the Internet:

<http://support.dlink-me.com>

[email:support@dlink-me.com](mailto:support@dlink-me.com)

Tech Support for customers within Israel:

D-Link Technical Support over the Telephone:

(972) 971-5701

Sunday to Thursday 9:00am to 5:00pm

D-Link Technical Support over the Internet:

<http://www.dlink.co.il/forum>

e-mail: support@dlink.co.il

Tech Support for customers within Turkey:

D-Link Technical Support over the Telephone:

(+90) 212-289 56 59

Monday to Friday 9:00am to 6:00pm

D-Link Technical Support over the Internet:

<http://www.dlink.com.tr>

e-mail: turkiye@dlink-me.com

Tech Support for customers within Egypt:

D-Link Technical Support over the Telephone:

(202) 414-4295

Sunday to Thursday 9:00am to 5:00pm

D-Link Technical Support over the Internet:

<http://support.dlink-me.com>

e-mail: amostafa@dlink-me.com

D-Link®
Building Networks for People

Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for customers within South Africa and Sub Sahara Region:

D-Link South Africa and Sub Sahara Technical Support over the Telephone:

+27-12-665-2165

08600 DLINK (For South Africa only)

Monday to Friday 8:30am to 9:00pm South Africa Time

D-Link Technical Support over the Internet:

<http://www.d-link.co.za>

[email:support@d-link.co.za](mailto:support@d-link.co.za)

D-Link[®]
Building Networks for People

Technical Support

You can find updates and user documentation on the D-Link website

Tech Support for Latin America customers:

D-Link Technical Support over the followings Telephones:

Argentina: 0800-666 1442	Monday to Friday 09:00am to 22:00pm
Chile: 800-214 422	Monday to Friday 08:00am to 21:00pm
Colombia: 01800-700 1588	Monday to Friday 07:00am to 20:00pm
Ecuador: 1800-777 711	Monday to Friday 07:00am to 20:00pm
El Salvador: 800-6137	Monday to Friday 06:00am to 19:00pm
Guatemala: 1800-300 0017	Monday to Friday 06:00am to 19:00pm
Panama: 0800-560 0193	Monday to Friday 07:00am to 20:00pm
Peru: 0800-52049	Monday to Friday 07:00am to 20:00pm
Venezuela: 0800-100 3470	Monday to Friday 08:00am to 21:00pm

D-Link Technical Support over the Internet:

www.dlinkla.com
www.dlinklatinamerica.com
email: support@dlink.cl

Tech Support for customers within Brazil:

D-Link Technical Support over the Telephone:

0800-7014104
Monday to Friday 8:30am to 18:30pm

D-Link Technical Support over the Internet:

www.dlinkbrasil.com.br
email: suporte@dlinkbrasil.com.br

D-Link®
Building Networks for People