DWL-6000AP SCREEN CAPTURES - F/W 2.02w

Created by: Scott Howell


D-Link
Building Networks for People

DWL-6000AP
2.4/5GHz, Multimode Wireless Access Point

| Home | Advanced | Tools | Status | Help |

Setup Wizard

Wizard

Wireless

LAN

The DWL-6000AP is a Multimode Wireless Access Point. The setup wizard will guide you through the configuration of the DWL-6000AP.The DWL-6000AP's easy setup will allow you to have wireless access within minutes. Please follow the setup wizard step by step to configure the DWL-6000AP.

[Run Wizard]

Help

D-Link
Building Networks for People

DWL-6000AP
2.4/5GHz, Multimode Wireless Access Point

Home	Advanced	Tools	Status	Help

Wizard

Wireless

LAN

Wireless Settings

Wireless Band	IEEE802.11a ▾
SSID	default
Channel	36 ▾
Radio Frequency	5.18 GHz

✔ Apply ✖ Cancel ➕ Help

D-Link
Building Networks for People

DWL-6000AP
2.4/5GHz, Multimode Wireless Access Point

Home | **Advanced** | **Tools** | **Status** | **Help**

Wizard

Wireless

LAN

LAN Settings

Get IP From	Static (Manual) ⌄
IP Address	192.168.0.50
Subnet Mask	255.255.255.0
Default Gateway	0.0.0.0

✓ Apply   ✕ Cancel   ✚ Help

D-Link
Building Networks for People

DWL-6000AP
2.4/5GHz, Multimode Wireless Access Point

Home	**Advanced**	Tools	Status	Help

Performance

Filters

Encryption

Advance Wireless Settings

Wireless Band	IEEE802.11a ▾
Data Rate	Auto ▾
Beacon Interval (20 - 1000)	100
DTIM (1 - 255)	1
Fragment Length (256 - 2346)	2346
RTS Length (256 - 2346)	2346
Transmit Power	full ▾

✓ Apply   ✗ Cancel   ✛ Help

D-Link
Building Networks for People

DWL-6000AP
2.4/5GHz, Multimode Wireless Access Point

Home	**Advanced**	Tools	Status	Help

Performance

Filters

Encryption

Wireless Access Settings / WLAN Partition

Wireless Band   IEEE802.11a ▾

Access Control   Disabled ▾

Access Control List

	Mac Address		Mac Address
1		9	
2		10	
3		11	
4		12	
5		13	
6		14	
7		15	
8		16	

✔ Apply   ✖ Cancel   ➕ Help

D-Link
Building Networks for People

DWL-6000AP
2.4/5GHz, Multimode Wireless Access Point

Home	**Advanced**	Tools	Status	Help

Security Settings

Wireless Band   IEEE802.11a ▾

Authentication   ⦿ Open System ○ Shared Key ○ Open System / Shared key ○ 802.1x

WEP   ⦿ Disabled ○ Enabled

Wep Key Type   HEX ▾

Wep Key Size   152 Bits ▾

Valid Key   First ▾

Key Table

First Key   [*********************************]

Second Key   [*********************************]

Third Key   [*********************************]

Fourth Key   [*********************************]

✓ Apply   ✗ Cancel   ✚ Help

Performance

Filters

Encryption

D-Link
Building Networks for People

DWL-6000AP
2.4/5GHz, Multimode Wireless Access Point

| Home | Advanced | Tools | Status | Help |

Administrator Settings

User Name   admin

Old Password

New Password   ●●●●●●●●●●●

Confirm New Password ●●●●●●●●●●●

Apply   Cancel   Help

Admin

System

Firmware

Misc.

D-Link
Building Networks for People

DWL-6000AP
2.4/5GHz, Multimode Wireless Access Point

Home **Advanced** **Tools** **Status** **Help**

Admin

System

Firmware

Misc.

System Settings

Apply Settings and Restart   [Restart]

Restore to Factory Default Settings   [Restore]

Help

D-Link
Building Networks for People

DWL-6000AP
2.4/5GHz, Multimode Wireless Access Point

Home	Advanced	**Tools**	Status	Help

Update Firmware From Local Hard Drive

Update File [   ] [Browse...] [OK]

➕
Help

Admin

System

Firmware

Misc.

D-Link
Building Networks for People

DWL-6000AP
2.4/5GHz, Multimode Wireless Access Point

Home	Advanced	Tools	Status	Help

Admin

System

Firmware

Misc.

Telnet Settings

Status   ☑ Enabled

Timeout   5 Mins ▾

✔   ✖   ✚

Apply   Cancel   Help

| Home | Advanced | Tools | Status | Help |

Device Information

Firmware Version:	**V2.02w**
MAC Address:	00:05:5d:75:84:27
Country:	Australia

Ethernet

Get IP From:	Manual
IP Address:	192.168.0.50
Subnet Mask:	255.255.255.0
Gateway:	0.0.0.0

Wireless (802.11a)

SSID:	default
Channel:	36
Rate:	Auto
Security Level:	Open System / WEP Disabled

Wireless (802.11b)

SSID:	default
Channel:	6
Rate:	Auto
Security Level:	Open System / WEP Disabled

Hel

Device Info

Stats

D-Link
Building Networks for People

DWL-6000AP
2.4/5GHz, Multimode Wireless Access Point

Home	Advanced	Tools	Status	Help

Device Info

Stats

Traffic Statistics

ThroughPut

Transmit Success Rate	57 %
Transmit Retry Rate:	0 %
Receive Success Rate:	17 %
Receive Duplicate Rate:	0 %
RTS Success Count:	0
RTS Failure Count:	0

Transmitted Frame Count

Transmitted Frame Count	302
Multicast Transmitted Frame Count	66
Transmitted Error Count:	237
Transmitted Total Retry Count:	0
Transmitted Multiple Retry Count:	0

Received Frame Count

Received Frame Count	473
Multicast Received Frame Count	0
Received Frame FCS Error Count:	2347
Received Frame Duplicate Count:	0
Ack Rcv failure Count:	1180

Wep Frame Error Count

WEP Excluded Frame Count	0
WEP ICV Error Count	0

Refresh   Help

D-Link
Building Networks for People

DWL-6000AP
2.4/5GHz, Multimode Wireless Access Point

Home
- Setup Wizard
- Wireless
- LAN Settings

Advanced
- Performance
- Filters
- Encryption

Tools
- Administrator Settings
- System Settings
- Firmware Upgrade

Status
- Device Information
- Statistics

FAQs