



Firmware Version: 1.00r014

Published Date: 2019/10/22

Content:

Upgrading Instructions:	2
Upgrading by using Web-UI.....	2
New Features:.....	3
Changes of MIB & D-View Module:.....	3
Problems Fixed:	3
Known Issues:	3
Related Documentation:	3

Revision History and System Requirement:

Firmware Version	Date	Model	Hardware Version
None			

Upgrading Instructions:

D-Link AP supports firmware upgrading via Web-UI. You may download the firmware from D-Link web site <http://tsd.dlink.com.tw>.

Upgrading by using Web-UI

1. Connect a work station to the LAN port of Access Point.
2. Open the web browser of work station and entering <http://dap2620.local>.
3. Enter administrator's username and password, user name is "admin" and the password field "admin" by default.

To update the AP's firmware, click **Maintenance > Firmware and SSL Certification Upload**

The screenshot displays the D-Link DAP-2620 Web-UI interface. The top navigation bar includes Home, Maintenance, Configuration, System, Logout, and Help. The left sidebar shows a tree view with Basic Settings (Wireless, LAN, IPv6) and Advanced Settings (Status). The main content area is titled 'System Information' and lists the following details:

Model Name	DAP-2620
Firmware Version	v1.00 16:08:24 2019/09/09
System Name	dap2620
Location	
System Time	2019/10/14 11:48:42
Up Time	00:01:57
Operation Mode (2.4GHz)	Access Point
Operation Mode (5GHz)	Access Point
MAC Address (2.4GHz)	00:1E:44:7A:88:A0
MAC Address (5GHz)	00:1E:44:7A:88:A8
IP Address	192.168.0.104

New Features:

First Release

Changes of MIB & D-View Module:

First Release

Problems Fixed:

Firmware Version	Problems Fixed
V1.00	None

Known Issues:

Firmware Version	Known Issues
V1.00	None

Related Documentation:

- DAP-2620 User Manual v1.00