

**DNS-323**

**PnP-X driver**


**V1.02**

**Supported 2 Volumes**

**Uninstallation Guide**


## Step 1

1. Double click *Network Explorer* on your desktop screen.
2. Find the DNS-323 device where you want to uninstall the PnP-X driver.
3. Select it and right click your mouse button.
4. Select **Uninstall**.




## Step 2

1. Double click *My Computer*.
2. Find the virtual folder marked DNS323-Volume\_1(xx. xx. xx. xx) and DNS323-Volume\_2(xx. xx. xx. xx)(If you have this one.)
3. Select it and right click your mouse button.
4. Select **Delete**.




### Step 3

1. Click the *Start* menu, and then the *Run* button and enter **REGEDIT** in the dialog box.
2. Go to *HKEY\_CLASSES\_ROOT/ NetworkExplorerPlugins*.
3. Find the *urn:www-dlink-com:device: NetworkAttachedStorage :1* folder.
4. Select it and right click your mouse button.
5. Select **Delete**.




## Step 4

1. Double click on *My Computer*.
2. Go to *C:\Windows\System32\*.
3. Find the *nascoins.dll* file. (※ if your CPU is 64 bit, that you need to find *Dns323NascoinsAmd64.dll*)
4. Select it and right click your mouse button.
5. Select **Delete**.




## Step 5

1. Find your *C:\Windows\inf* directory.
2. Select it and right click your mouse button.
3. Select **Search**.




## Step 6

1. After Step 5 is finished, a search utility will pop up.
2. Enter **NetworkAttachedStorage** in the search prompt.
3. If you receive a **No items match your search** message, then click on *Search in File Contents*.



## Step 7

The search result will be searched *oem#*.  
(For example: oem1)



## Step 8

1. Go to your `C:\Windows\inf` directory.
2. Delete `oem#.inf` and `oem#.PNF`.  
(For example: `oem1.inf` and `oem1.PNF`)

