

http://192.168.0.10/ - Microsoft Internet Explorer provided by D-Link Australia

File Edit View Favorites Tools Help

Address http://192.168.0.10/ Go


# D-Link<sup>®</sup>

Building Networks for People

## DP-301P+

Pocket Size Print Server

**Home** Configuration Tools Help



**System**

**Network**

**User**

### Device Status


Server Name	:	PS-5D9722
Model	:	DP-301P+
Firmware Version	:	3.50 (2005-09-02)
MAC Address	:	00 17 9A 5D 97 22
IP Address	:	192.168.0.10 (Manual)
Up Time	:	0 days, 01:56:04

### Printer Status

LPT	:	Printer Name	:	PS-5D9722-P1
		Printer Speed	:	High
		Printer Status	:	Off line
		Total Print Jobs	:	0
		Total Print Size	:	0 KBytes
		Printing Status	:	Idle
		Name	:	
		MAC	:	
		IP	:	
		Protocol	:	
		Spooling Size	:	0 Bytes
		Printing Size	:	0 Bytes

### Ethernet Status

Link	:	Yes
Speed	:	100M bps
Full Duplex	:	Yes
Tx Packets	:	45
Tx Errors	:	0
Rx Packets	:	142
Rx Errors	:	0





System

Network

User

Home

Configuration

Tools

Help

**Auto IP**

DHCP/BOOTP : Disable (IP : 0.0.0.0)  
UPnP : Enable (IP : 169.254.151.34)  
MAC Rendezvous : Enable (IP : 169.254.151.34)

**TCP/IP Printing**

LPR Printing : Status : Running  
Total Print Jobs : 0  
Total Print Size : 0 KBytes

Port (9100) Printing : Status : Running  
Total Print Jobs : 0  
Total Print Size : 0 KBytes

IPP Printing : Status : Running  
Total Print Jobs : 0  
Total Print Size : 0 KBytes

FTP Printing : Status : Running  
Total Print Jobs : 0  
Total Print Size : 0 KBytes

E-mail Printing : Status : Running  
Total Print Jobs : 0  
Total Print Size : 0 KBytes

**Microsoft Network Printing**

SMB (Over NetBEUI) Printing : Status : Running  
Total Print Jobs : 0  
Total Print Size : 0 KBytes

SMB (Over NBT) Printing : Status : Running  
Total Print Jobs : 0  
Total Print Size : 0 KBytes

**MAC AppleTalk Printing**

AppleTalk Printing : Status : Running  
Total Print Jobs : 0  
Total Print Size : 0 KBytes

Home Configuration Tools Help

Users Printing Log

	MAC	IP	Name	Jobs	Size(KBytes)
 Refresh					

System  
Network  
User

Home Configuration Tools Help

System Device

Server Name : PS-5D9722

Location :

Admin Contact :

Password : New Password :

Confirm Again :



Port Setting

LPT : Port Name : PS-5D9722-P1

Description :

Speed : High

PJL Printer : No

   
Apply Cancel

System  
Network  
User  
SNMP



System

Network

User

SNMP

Home

Configuration

Tools

Help

### TCP/IP

IP Address :  Manually Assign  
IP Address :   
Subnet Mask :   
Default Gateway :   
 Automatically Assign

DNS Server Address : 1.   
2.

UPnP :  Enable  Disable

MAC Rendezvous :  Enable  Disable

Second HTTP Port :  Enable  Disable  
Port Number :   
(For Remote Web Configuration and IPP Printing)

### Microsoft Network

Workgroup :

### AppleTalk

AppleTalk Zone :


LPT : Chooser Name :   
Printer Type :   
PostScript Level :   
Font Group :



Apply



Cancel



Home
Configuration
Tools
Help

System



Network

User

SNMP

**Printing Control**

Enable User Printing Control :  Yes  No



  
**Apply** **Cancel**

**Define Users**


Add User : User Name :

MAC Address :

(Example : 00 80 C8 A1 B2 C3)

Delete User :

User List	Name	MAC



Home
Configuration
Tools
Help

System

Network

User

SNMP

**SNMP Management**

Community 1    Name        :



Access Right    :  ▼

Community 2    Name        :

Access Right    :  ▼

Community 3    Name        :

Access Right    :  ▼



  
**Apply** **Cancel**



Print Test

E-mail

Reset

Upgrade

Backup

Home

Configuration

Tools

Help

### Print Test

Port Selection

LPT



Apply



Print Test

E-mail

Reset

Upgrade

Backup

Home

Configuration

Tools

Help

### E-mail Account

Print Server E-mail Address :

Incoming E-mail (POP3) Server Address :

Outgoing E-mail (SMTP) Server Address :

Account Name :

Password :



Apply Cancel

### E-mail Notification

Enable e-mail notification for printer status changing :  Yes  No

Admin E-mail Address :

(Use "," to separate multiple e-mail address)



Apply Cancel

E-mail test will send an e-mail to Admin's e-mail address.  
Do you want to test e-mail account?

Test

### E-mail Printing

E-mail Printing :  Enable  Disable

Receive E-mail Interval :  (minutes)




Apply Cancel

Do you want to receive e-mail and print out?


Receive

Home Configuration **Tools** Help




**Reset**

Do you want to reset this device?

 **Apply**

**Factory Reset**

Do you want to restore this device to factory default setting?

 **Apply**

Print Test


E-mail

**Reset**

Upgrade

Backup

Home Configuration **Tools** Help





**Upgrade**

Note: Please make sure that you use the correct firmware before you proceed. If you do not know which firmware you should use, please contact your local dealer for technical support.

Current Firmware Version and Date: 3.50 (2005-09-02)

**Firmware Upgrade**

Select A Firmware File :

 **Apply**  **Cancel**

Print Test

E-mail

Reset

**Upgrade**

Backup





Print Test

E-mail

Reset

Upgrade

Backup

Home

Configuration

Tools

Help

### Backup Device Configuration to File

Do you want to backup the configuration to file?



Apply

### Restore Device Configuration from File

Select A Configuration File :

Browse...



Apply



Cancel