







DWA-140  
Windows Vista

















Wireless Connection Wizard




**Please choose your wireless network from the list below.**

Wireless Network	Signal	Security
DLINK	100%	
zaman	100%	
demoroom	70%	
htc-wireless-ap	58%	
dlink	42%	
MainAP	38%	
rfsmart	34%	

D-Link Wireless N  
DWA-140

Exit Back Next

Wireless Connection Wizard



**Set Security!**

The network you are attempting to connect to is protected by encryption. Please enter the encryption key assigned to the wireless network.

WEP Encryption Key

D-Link Wireless N  
DWA-140

Exit Back Next

