


DWL-2000AP - Microsoft Internet Explorer


File Edit View Favorites Tools Help

Back Forward Stop Refresh Home Search Favorites Media Print Mail Stop

Address http://192.168.0.50




Building Networks for People



High-Speed 2.4GHz Wireless Access Point

DWL-2000AP



Wizard

Wireless

LAN

DHCP

Home Advanced Tools Status Help


Setup Wizard

The setup wizard will guide you through the process of configuring the unit. Please click on the button below to start.

Run Wizard

Help

DWL-2000AP - Microsoft Internet Explorer



Building Networks for People

## DWL-2000AP Setup Wizard

Welcome to the DWL-2000AP Setup Wizard. The Wizard will guide you through these four quick steps. Begin by clicking on **Next**.

- Step 1. Set your new password
- Step 2. Set the SSID, and Channel
- Step 3. Set Encryption
- Step 4. Restart

Next Exit

DWL-2000AP - Microsoft Internet Explorer

**D-Link**  
Building Networks for People




## DWL-2000AP Setup Wizard

### Set Password

You may change the **admin** account password by entering in a new password. Click **Next** to continue.

New Password

Confirm Password

Back Next Exit

DWL-2000AP - Microsoft Internet Explorer

**D-Link**  
Building Networks for People

## DWL-2000AP Setup Wizard

### Set Wireless LAN Connection

Enter in the SSID name and Channel number to be used for the Wireless Access Point. Click **Next** to continue.

SSID :

Channel : 6

Back Next Exit

DWL-2000AP - Microsoft Internet Explorer

**D-Link**  
Building Networks for People

## DWL-2000AP Setup Wizard

### Setup Encryption

If you wish to use encryption, enable it here and enter the encryption Key values. Click **Next** to continue.

Wep :  Enabled  Disabled

Encryption : 64Bit

WEP Mode : HEX

Key1 :

Key2 :

Key3 :

Key4 :

Back Next Exit




DWL-2000AP - Microsoft Internet Explorer

**D-Link**  
Building Networks for People

## DWL-2000AP Setup Wizard

### Setup Completed

The setup wizard has completed. Click **Back** to modify previous settings. Click **Restart** to save the current settings and reboot the DWL-2000AP

Back Restart Exit

**D-Link**  
Building Networks for People

**AirPlus XTREME G™**  
High-Speed 2.4GHz Wireless Access Point

**DWL-2000AP**

Wizard  
Wireless  
LAN  
DHCP

Home | **Advanced** | Tools | Status | Help

Wireless Settings

AP Name:

SSID:

Channel:

WEP:  Enabled  Disabled

WEP Encryption:

WEP Mode:

Key1:

Key2:

Key3:

Key4:

Apply Cancel Help

**D-Link**  
Building Networks for People

**AirPlus XTREME G™**  
High-Speed 2.4GHz Wireless Access Point

**DWL-2000AP**

Wizard  
Wireless  
**LAN**  
DHCP

Home | **Advanced** | Tools | Status | Help

LAN Settings

LAN IP  Dynamic IP Address  
 Static IP Address

IP Address

Subnet Mask

Gateway

Apply Cancel Help

**D-Link**  
Building Networks for People

**AirPlus XTREME G™**  
High-Speed 2.4GHz Wireless Access Point

DWL-2000AP

Wizard  
Wireless  
LAN  
DHCP

Home **Advanced** Tools Status Help

DHCP Server

The DWL-2000AP can be setup as a DHCP server to distribute IP addresses to the LAN network.

DHCP Server  Enabled  Disabled

Starting IP Address 192 . 168 . 0 .

Ending IP Address 192 . 168 . 0 .

DNS Server

Lease Time

Apply Cancel Help

DHCP Client Table

Host Name	IP Address	MAC Address	Expired Time
-----------	------------	-------------	--------------

**D-Link**  
Building Networks for People

**AirPlus XTREME G™**  
High-Speed 2.4GHz Wireless Access Point

DWL-2000AP

Mode  
Performance  
Filters  
802.1X

Home **Advanced** Tools Status Help

AP Mode

Access Point

Wireless Client Remote AP MAC

Wireless Bridge Remote Bridge MAC

Multi-point Bridge

Apply Cancel Help

**D-Link**  
Building Networks for People

**AirPlus XTREME G™**  
High-Speed 2.4GHz Wireless Access Point

DWL-2000AP

Mode  
Performance  
Filters  
802.1X

Home **Advanced** Tools Status Help

Wireless Performance

These are the settings to adjust wireless performance.

TX Rates :  (Mbps)

Beacon interval :  (msec, range: 1~1000, default: 100)

RTS Threshold :  (range: 256~2432, default: 2432)

Fragmentation :  (range: 256~2346, default: 2346, even number only)

DTIM interval :  (range: 1~255, default: 3)

Preamble Type :  Short Preamble  Long Preamble

Authentication :  Open System  Shared Key

11g Only Mode:  Enabled  Disabled

Apply Cancel Help

**D-Link**  
Building Networks for People

**AirPlus XTREME G™**  
High-Speed 2.4GHz Wireless Access Point

DWL-2000AP

Mode  
Performance  
Filters  
802.1X

Home **Advanced** Tools Status Help

MAC Filters

Filters are used to allow or deny Wireless Clients users from accessing the DWL-2000AP

Disabled MAC Filters

Only **allow** MAC address(es) listed below to connect to DWL-2000AP

Only **deny** MAC address(es) listed below to connect to DWL-2000AP

MAC Address  -  -  -  -  -

Connected PCs

MAC Filter List

MAC Address

Apply Cancel Help

DWL-2000AP



Mode

Performance

Filters

802.1X

Home Advanced Tools Status Help

802.1X

Enabled  Disabled

Encryption Key Length  64 bits  128 bits

Lifetime 30 Minutes

RADIUS Server 1 IP 0.0.0.0

Port 1812

Shared Secret

RADIUS Server 2 IP 0.0.0.0

(Optional) Port 0

Shared Secret

Apply Cancel Help

DWL-2000AP



Admin

System

Firmware

Home Advanced Tools Status Help

Administrator Settings

New Password .....


Confirm Password .....

Apply Cancel Help

**D-Link**  
Building Networks for People

**AirPlus XTREME G™**  
High-Speed 2.4GHz Wireless Access Point

DWL-2000AP



Admin

System

Firmware


Home Advanced **Tools** Status Help

System Settings

Save Settings to Local Hard Drive

Load Settings From Local Hard Drive


Restore to Factory Default Settings

 Help

**D-Link**  
Building Networks for People

**AirPlus XTREME G™**  
High-Speed 2.4GHz Wireless Access Point

DWL-2000AP



Admin

System

Firmware




Home Advanced **Tools** Status Help

Firmware Upgrade

[Click here to check for the latest firmware available for the D-Link AirPlus DWL-2000AP Wireless Access Point.](#)

To upgrade the firmware, locate the folder where the firmware was downloaded on the hard drive using the Browse button. Once you have found the file to be used, click the Apply button below to start the firmware upgrade.

**Current Firmware Version: 1.7**  
**Firmware Date: Mon, 12 May 2003**

    
Apply Cancel Help



DWL-2000AP



Device Info

Log

Stats

Wireless

Home Advanced Tools **Status** Help

Device Information

Firmware Version **1.7**, Mon, 12 May 2003

Ethernet

MAC Address 00400552d406  
IP Address 192.168.0.50  
Subnet Mask 255.255.255.0  
Gateway 0.0.0.0

Wireless

MAC Address 00-40-05-52-b0-c7  
SSID default  
Encryption Function Disabled  
Channel 6



Help

DWL-2000AP



Device Info

Log

Stats

Wireless

Home Advanced Tools **Status** Help

View Log



Help

page 1 of 1

Time	Message
Jul/01/2003 15:55:30	System started
Jul/01/2003 15:55:30	AP 2.4GHz mode Ready. Channel : 6 TxRate : best SSID : default

DWL-2000AP



Device Info

Log

Stats

Wireless

Home Advanced Tools **Status** Help

Traffic Statistics

Traffic Statistics display Receive and Transmit Packets Passing through the DWL-2000AP

**Ethernet**

Send	Good Packets	911
	Dropped Packets	0
Recv	Good Packets	1997
	Dropped Packets	0

**Wireless**

Send	Good Packets	0
	Dropped Packets	0
Recv	Good Packets	0
	Dropped Packets	0

 Help

DWL-2000AP



Device Info

Log

Stats

Wireless

Home Advanced Tools **Status** Help

Connected Wireless PCs List

 Help

Connected Time	MAC Address

DWL-2000AP



Menu

Home

Advanced

Tools

Status

Help

**Home**

- [Setup Wizard](#)
- [Wireless Settings](#)
- [LAN Settings](#)
- [DHCP Server](#)

**Advanced**

- [Mode](#)
- [Performance](#)
- [Filters](#)
- [802.1X](#)

**Tools**

- [Administrator Settings](#)
- [System Settings](#)
- [Firmware Upgrade](#)

**Status**

- [Device Information](#)
- [Log](#)
- [Stats](#)
- [Wireless](#)