

DWL-7000AP Screenies

FW: 1.00au

The screenshot displays the web management interface for a D-Link DWL-7000AP. At the top left is the D-Link logo with the tagline "Building Networks for People". To the right, the "AirXpert™ AG 802.11n" logo is prominently displayed, with "Tri-Mode Dualband Wireless Access Point" written below it. A navigation bar at the top contains five tabs: "Home" (highlighted in yellow), "Advanced", "Tools", "Status", and "Help".

On the left side, there is a vertical sidebar with the following elements:

- An image of the DWL-7000AP device.
- The text "DWL-7000AP" above the image.
- A yellow "Wizard" button.
- A blue "Wireless" button.
- A blue "LAN" button.

The main content area is titled "Setup Wizard" and contains the following text:

The DWL-7000AP is a Multimode Wireless Access Point. The setup wizard will guide you through the configuration of the DWL-7000AP. The DWL-7000AP's easy setup will allow you to have wireless access within minutes. Please follow the setup wizard step by step to configure the DWL-7000AP.

Below the text is a "Run Wizard" button. In the bottom right corner of the main area, there is a red circular icon with a white plus sign and the word "Help" underneath it.



DWL-7000AP - Microsoft Internet Explorer

D-Link
Building networks for People

DWL-7000AP Setup Wizard

Welcome to the DWL-7000AP Setup Wizard. The Wizard will guide you through these six quick steps. Begin by clicking on **Next**.

- Step 1. Set your new password
- Step 2. Set the SSID and Channel (802.11a)
- Step 3. Set Encryption (802.11a)
- Step 4. Set the SSID and Channel (802.11g)
- Step 5. Set Encryption (802.11g)
- Step 6. Restart

Next **Exit**

DWL-7000AP - Microsoft Internet Explorer

D-Link
Building networks for People



DWL-7000AP Setup Wizard

Set Password

You may change the password by entering in a new password. Click **Next** to continue.

Password

Verify Password

Back **Next** **Exit**

DWL-7000AP - Microsoft Internet Explorer

D-Link Building networks for People DWL-7000AP Setup Wizard

Set Wireless LAN 802.11a Connection

Enter in the SSID name and Channel number to be used for the Wireless LAN 802.11a Connection. Click **Next** to continue.

SSID:

Channel:

Back Next Exit

DWL-7000AP - Microsoft Internet Explorer

D-Link Building networks for People DWL-7000AP Setup Wizard

WEP Encryption for 802.11a

If you wish to use encryption, enable it here and enter the encryption Key Values. Click **Next** to continue.

WEP: Disabled Enabled

Key Size: 64 128 152

Key1:

Back Next Exit

DWL-7000AP - Microsoft Internet Explorer


D-Link
Building networks for People




DWL-7000AP Setup Wizard

Set Wireless LAN 802.11g Connection

Enter in the SSID name and Channel number to be used for the Wireless LAN 802.11g Connection. Click **Next** to continue.

SSID:

Channel 

Back Next Exit

DWL-7000AP - Microsoft Internet Explorer

D-Link
Building networks for People

DWL-7000AP Setup Wizard

WEP Encryption for 802.11g

If you wish to use encryption, enable it here and enter the encryption Key Values. Click **Next** to continue.

WEP: Disabled Enabled

Key Size: 64 128 152

First Key:

Back Next Exit




DWL-7000AP - Microsoft Internet Explorer

D-Link
Building networks for People

DWL-7000AP Setup Wizard

Setup Completed

The Setup Wizard has completed. Click **Back** to modify previous settings. Click **Restart** to save the current settings and reboot the DWL-7000AP .

Back Restart Exit

DWL-7000AP



Wizard

Wireless

LAN

Home

Advanced

Tools

Status

Help

Wireless Settings

Wireless Band: IEEE802.11a

SSID

SSID Broadcast

Channel

Radio Frequency

Wireless Band: IEEE802.11g

SSID

SSID Broadcast

Channel

Radio Frequency



Apply



Cancel



Help

DWL-7000AP



Wizard

Wireless

LAN

Home

Advanced

Tools

Status

Help

LAN Settings

Get IP From

IP Address

Subnet Mask

Default Gateway



Apply Cancel Help

DWL-7000AP



Performance

Filters

Encryption

Grouping

Home

Advanced

Tools

Status

Help

Advance Wireless Settings

Wireless Band: IEEE802.11a

Turbo Setting

Frequency

Channel

Data Rate

Beacon Interval (20 - 1000)

DTIM (1 - 255)

Fragment Length (256 - 2346)

RTS Length (256 - 2346)

Transmit Power

Wireless Band: IEEE802.11g

Turbo Setting

Frequency

Channel

Data Rate

Beacon Interval (20 - 1000)

DTIM (1 - 255)

Fragment Length (256 - 2346)

RTS Length (256 - 2346)

Transmit Power



Apply Cancel Help

DWL-7000AP



Performance

Filters

Encryption

Grouping

Home

Advanced

Tools

Status

Help

Wireless Access Settings / WLAN Partition

Wireless Band: IEEE802.11a

Access Control

Access Control List

	Mac Address
1	<input type="text"/>
2	<input type="text"/>
3	<input type="text"/>
4	<input type="text"/>
5	<input type="text"/>
6	<input type="text"/>
7	<input type="text"/>
8	<input type="text"/>
9	<input type="text"/>
10	<input type="text"/>
11	<input type="text"/>
12	<input type="text"/>
13	<input type="text"/>
14	<input type="text"/>
15	<input type="text"/>
16	<input type="text"/>

Wireless Band: IEEE802.11g

Access Control

Access Control List

	Mac Address
1	<input type="text"/>
2	<input type="text"/>
3	<input type="text"/>
4	<input type="text"/>
5	<input type="text"/>
6	<input type="text"/>
7	<input type="text"/>
8	<input type="text"/>
9	<input type="text"/>
10	<input type="text"/>
11	<input type="text"/>
12	<input type="text"/>
13	<input type="text"/>
14	<input type="text"/>
15	<input type="text"/>
16	<input type="text"/>



Apply Cancel Help

DWL-7000AP



Performance

Filters

Encryption

Grouping

Home

Advanced

Tools

Status

Help

AP Grouping Settings

Load Balance

User Limit (0 - 64)

Link Integrate

Ethernet Link Status



Apply Cancel Help

DWL-7000AP



Admin

System

Firmware

Misc.

Home

Advanced

Tools

Status

Help

Administrator Settings

User Name

Old Password

New Password

Confirm New Password



Apply



Cancel



Help

DWL-7000AP



Admin

System

Firmware

Misc.

Home

Advanced

Tools

Status

Help

System Settings

Apply Settings and Restart

Restore to Factory Default Settings



Help

DWL-7000AP



Admin

System

Firmware

Misc.

Home

Advanced

Tools

Status

Help

Update Firmware From Local Hard Drive

Update File

Browse...

OK



Help

DWL-7000AP



Admin

System

Firmware

Misc.

Home

Advanced

Tools

Status

Help

Telnet Settings

Status Enabled

Timeout 1 Mins



Apply



Cancel



Help

DWL-7000AP



Device Info

Stats

Home

Advanced

Tools

Status

Help

Device Information

Firmware Version: v1.00au
MAC Address: 00:0d:88:17:0a:a7

Ethernet

Get IP From: Manual
IP address: 192.168.0.53
Subnet Mask: 255.255.255.0
Gateway: 192.168.0.181

Wireless (802.11a)

SSID: 7000a
Channel: 44
Turbo Mode: Disabled
Rate: Auto
Security Level: Open System / WEP Disabled

Wireless (802.11g)

SSID: 7000b
Channel: 11
Turbo Mode: N/A
Rate: Auto
Security Level: Open System / WEP Disabled



Help

DWL-7000AP



Device Info

Stats

Home

Advanced

Tools

Status

Help

[WLAN 802.11A Traffic Statistics](#) / [WLAN 802.11G Traffic Statistics](#)

ThroughPut

Transmit Success Rate	100 %
Transmit Retry Rate:	0 %
Receive Success Rate:	100 %
Receive Duplicate Rate:	0 %
RTS Success Count:	0
RTS Failure Count:	0

Transmitted Frame Count

Transmitted Frame Count	2223
Multicast Transmitted Frame Count	2225
Transmitted Error Count:	0
Transmitted Total Retry Count:	0
Transmitted Multiple Retry Count:	0

Received Frame Count

Received Frame Count	0
Multicast Received Frame Count	2223
Received Frame FCS Error Count:	0
Received Frame Duplicate Count:	0
Ack Rcv failure Count:	0

Wep Frame Error Count

WEP Excluded Frame Count	0
WEP ICV Error Count	0



Refresh



Help

DWL-7000AP



Device Info

Stats

Home

Advanced

Tools

Status

Help

[WLAN 802.11G Traffic Statistics](#) / [WLAN 802.11A Traffic Statistics](#)

ThroughPut

Transmit Success Rate	100 %
Transmit Retry Rate:	0 %
Receive Success Rate:	100 %
Receive Duplicate Rate:	0 %
RTS Success Count:	0
RTS Failure Count:	0

Transmitted Frame Count

Transmitted Frame Count	2266
Multicast Transmitted Frame Count	2266
Transmitted Error Count:	0
Transmitted Total Retry Count:	0
Transmitted Multiple Retry Count:	0

Received Frame Count

Received Frame Count	0
Multicast Received Frame Count	0
Received Frame FCS Error Count:	0
Received Frame Duplicate Count:	0
Ack Rcv failure Count:	0

Wep Frame Error Count

WEP Excluded Frame Count	0
WEP ICV Error Count	0



Refresh



Help

DWL-7000AP



Home

Advanced

Tools

Status

Help

Home

- [Setup Wizard](#)
- [Wireless](#)
- [LAN Settings](#)

Advanced

- [Performance](#)
- [Filters](#)
- [Encryption](#)

Tools

- [Administrator Settings](#)
- [System Settings](#)
- [Firmware Upgrade](#)

Status

- [Device Information](#)
- [Statistics](#)

FAQs