# How to change ADSL Username and Password
in your modem router

This document details how to change ADSL Username and Password settings stored in your modem

Step 1. Open your Internet browser e.g. Internet Explorer, Firefox, Chrome, Safari, etc. and enter the IP address of your D-Link modem in the **address bar**: http://10.1.1.1

Step 2. When prompted type in the Username and Password, then click on the "OK" button. If you have not changed the password for the modem administration, the factory settings are:

Username: admin

Password: admin

If you cannot recall the password you assigned to your modem you will need to reset the modem to factory defaults by pressing the reset button for 10 seconds. Please note that this will revert all the settings in the modem to factory settings and you will have to reconfigure it with your Internet settings and Wireless security. Make sure you have your Internet account details (given by your Internet Provider) handy.

Step 3. After logging in you will be presented with the modem's configuration pages. Please click on [**Home]** tab, and then click on **[WAN]**:

Step 4.   Type in your NEW account details as given by you Internet Service Provider:
- In the "Username" field – type in your new username given by your Internet Service Provider
- In the "Password" field – type in your new password given by your Internet Service Provider

Step 5.   Click on the APPLY button at the bottom of the page.

Step 6. To save the new settings into the modem's memory click on the [Tools] tab and then on [System]. Click on the "Save and Reboot" button.

Step 7. After your modem reboots, log into it again and check the [Status] page. Please wait 1-2 minutes and your modem should report WAN Status as Connected.