D-Link ADSL Router - Internet Explorer

http://192.168.1.1/login.cgi

File Edit View Favorites Tools Help SnagIt

D-Link ADSL Router

Page Tools

Product Page: DVA-G3670B Site Map Firmware Version: AUS_1.27

D-Link

DVA-G3670B

SETUP | ADVANCED | VOICE | MAINTENANCE | STATUS | HELP

- Wizard
- Internet Setup
- Wireless Settings
- Local Network
- Time and Date
- Logout

1 > 2 > 3 > 4 > STEP 5: CONFIGURE LOCAL NETWORK > 6

Configure the DSL Router IP Address and Subnet Mask for LAN interface.

DEVICE SETUP

IP Address: 192.168.1.1

Subnet Mask: 255.255.255.0

○ Disable DHCP Server

◉ Enable DHCP Server

Start IP Address: 192.168.1.2

End IP Address: 192.168.1.254

Leased Time (hour): 24

☐ Configure the second IP Address and Subnet Mask for LAN interface

IP Address:

Subnet Mask:

Back Next Cancel

Done Internet 100%