D-Link®

WIRELESS N 150 ROUTER
DIR-600L

QUICK
INSTALLATION
GUIDE

РУКОВОДСТВО ПО БЫСТРОЙ УСТАНОВКЕ
GUÍA DE INSTALACIÓN RÁPIDA
GUIA DE INSTALAÇÃO RÁPIDA
快速安裝指南
PETUNJUK PEMASANGAN CEPAT

CONTENTS OF PACKAGING

CONTENTS

WIRELESS N 150 ROUTER
DIR-600L

POWER ADAPTER
ADAPTER

If any of these items are missing from your packaging contact your reseller

PRODUCT SETUP

INSTALL YOUR ROUTER

Step 1
Position your router close to your modem and the computer that is already online. Place this router in an open area of your intended work area for better wireless coverage.

Step 2
Unplug the Ethernet cable from your modem that is connected to your computer. Plug it into the LAN port labeled 1 on the back of your router. The router is now connected to your computer.

Step 3
Find another Ethernet cable and plug the of end of this cable into the port labeled INTERNET on the back of the router. Plug the other end of this cable into the Ethernet port on your modem.

Step 4
Connect the supplied power adapter into the power port on the back of the router and then plug into a power outlet or surge protector. Verify the power light is lit. Below is a basic network setup.

PRODUCT SETUP

RUN EASY SETUP WIZARD AND mydlink SERVICE

Step 1
From the computer you connected to the router, open a web browser and enter
http://192.168.0.1 or http://dlinkrouter Then, press Enter and you will be directed to the D-Link Setup
Wizard page, which detects INTERNET connection type.

WELCOME TO THE D-LINK EASY SETUP WIZARD

The router is detecting your Internet connection type. Please wait until the router provides suitable settings for your configuration.

Step 2
According to the detection result, follow the on-screen instructions to configure your INTERNET
setting. If your INTERNET setting is DHCP, the wizard will bring you to the page of "CURRENT
NETWORK SETTING".

CONFIGURE YOUR INTERNET CONNECTION

Please fill out the required fields and click "Connect"

Internet Connection : PPPoE   What is this?
User Name :   (is required field)
*Password :
*Confirm Password :

Connect

CONFIGURE YOUR INTERNET CONNECTION

The router can't detect your Internet connection type. Please select one of the connection types below and fill out the required fields. Click "Connect" to continue.

Internet Connection : Static IP   What is this?
IP Address : 0.0.0.0   (is required field)
*Subnet Mask : 255.255.255.0
*Gateway Address : 0.0.0.0
*Primary DNS Server : 0.0.0.0
Secondary DNS Server : 0.0.0.0

Connect

PRODUCT SETUP

RUN EASY SETUP WIZARD AND mydlink SERVICE

Step 3
In the page of "CURRENT NETWORK SETTING", you will see the INTERNET status is "connected".

Step 4
If you have not registered a mydlink account, please click "configure" In the section "mydlink account' and complete the registration form.

Click "Register"

PRODUCT SETUP

RUN EASY SETUP WIZARD AND mydlink SERVICE

Step 5
Now you can see the hint that a verification e-mail has been sent out. Open a new browser to login your e-mail account for receiving the verification mail.

CURRENT NETWORK SETTING

The current network settings and the connection status are displayed below. If you want to reconfigure your wireless settings, please click the "Configure" button. You can also enter advanced settings by clicking "Manual Setup".

Internet Settings

Internet Connection :	Dynamic IP (DHCP)	**Status :** Connected

Wireless Settings

Network Name (SSID) : dlink

Status : Encryption
Configure

Security : Auto (WPA or WPA2) - Personal

Network Key : 12345678

Device Info

User Name : admin

Password : admin

mydlink Account

Activation e-mail has been sent out. Please login your e-mail account test@test.com. After receiving the activation mail, please click "configure" to login mydlink service.

Status : Connected
Configure

☐ Save my network settings

Save

Once the account verification phase is complete, click "configure" In the section "mydlink account' and login mydlink account.

Click "Login"

Configure Your mydlink Account

Do you have mydlink account ?
◉ Yes, I have a mydlink account.
◯ No, I want to register and login with a new mydlink account.

E-mail Address (Account Name) : [   ]
Password : [   ]
Device User Name : [admin]
Device Passowrd : [   ]

Login   Back

PRODUCT SETUP

RUN EASY SETUP WIZARD AND mydlink SERVICE

Step 6
Now the router has successfully connected to mydlink service. You can download the App "mydlink lite" from android market or apple store to start enjoy mydink service!

TROUBLESHOOTING

SET-UP AND CONFIGURATION PROBLEMS

1. HOW DO I CONFIGURE MY DIR-600L ROUTER, OR CHECK MY WIRELESS NETWORK NAME (SSID) AND WIRELESS ENCRYPTION KEY?
- Connect your PC to the router using an Ethernet cable.
- Open a web browser and enter the address http:// dlinkrouter or http://192.168.0.1
- The default username is 'admin'. The default password is '' (leave the field blank).
- If you have changed the password and can not remember it, you will need to reset the router to set the password back to '' (leave the field blank).

2. HOW DO I RESET MY DIR-600L ROUTER TO FACTORY DEFAULT SETTINGS?
- Ensure the router is powered on.
- Press and hold the reset button on the rear of the device for 20 seconds.
  Note: Resetting the router to factory default will erase the current configuration settings. To re-configure your settings, log into the router as outlined in question 1, then run the Setup Wizard.

3. HOW DO I ADD A NEW WIRELESS CLIENT OR PC IF I HAVE FORGOTTEN MY WIRELESS NETWORK NAME (SSID) OR WIRELESS ENCRYPTION KEY?
- Every PC that needs to connect to the router wirelessly, you will need to ensure you use the correct Wireless Network Name (SSID) and encryption key.
- Use the web based user interface (as described in question 1 above) to check or choose your wireless settings.
- Make sure you write down these settings so that you can enter them into each wirelessly connected PC. You will find a dedicated area on the back of this document, this important information for future use.

4. WHY CAN I NOT GET AN INTERNET CONNECTION?
- For ADSL users please contact your ISP to make sure the service has been enabled/connected by your ISP and that your ISP username and password is correct.

TECHNICAL SUPPORT

You can find software updates and user documentation on the D-Link website.

Tech Support for customers in

Australia:
Tel: 1300-766-868
24/7 Technical Support
Web: http://www.dlink.com.au
E-mail: support@dlink.com.au

India:
Tel: +91-22-27626600
      Toll Free 1800-22-8998
Web: www.dlink.co.in
E-Mail: helpdesk@dlink.co.in

Singapore, Thailand, Indonesia, Malaysia, Philippines, Vietnam:
Singapore - www.dlink.com.sg
Thailand - www.dlink.co.th
Indonesia - www.dlink.co.id
Malaysia - www.dlink.com.my
Philippines - www.dlink.com.ph
Vietnam - www.dlink.com.vn

Korea:
Tel : +82-2-2028-1810
Monday to Friday 9:00am to 6:00pm
Web : http://d-link.co.kr
E-mail : g2b@d-link.co.kr

New Zealand:
Tel: 0800-900-900
24/7 Technical Support
Web: http://www.dlink.co.nz
E-mail: support@dlink.co.nz

South Africa and Sub Sahara Region:
Tel: +27 12 661 2025
      08600 DLINK (for South Africa only)
Monday to Friday 8:30am to 9:00pm South Africa Time
Web: http://www.d-link.co.za
E-mail: support@d-link.co.za

Saudi Arabia (KSA):
Tel: +966 01 217 0008
Fax: +966 01 217 0009
Saturday to Wednesday 9.30AM to 6.30PM
Thursdays 9.30AM to 2.00 PM
E-mail: Support.sa@dlink-me.com

D-Link Middle East - Dubai, U.A.E.
Plot No. S31102,
Jebel Ali Free Zone South,
P.O.Box 18224, Dubai, U.A.E.
Tel: +971-4-8809022
Fax: +971-4-8809066 / 8809069
Technical Support: +971-4-8809033
General Inquiries: info.me@dlink-me.com
Tech Support: support.me@dlink-me.com

Egypt
1, Makram Ebeid Street - City Lights Building
Nasrcity - Cairo, Egypt
Floor 6, office C2
Tel.: +2 02 26718375 - +2 02 26717280
Technical Support: +2 02 26738470
General Inquiries: info.eg@dlink-me.com
Tech Support: support.eg@dlink-me.com

Kingdom of Saudi Arabia
Office # 84 ,
Al Khaleej Building (Mujamathu Al-Khaleej)
Opp. King Fahd Road, Olaya
Riyadh - Saudi Arabia
Tel: +966 1 217 0008
Technical Support:
+966 1 2170009 / +966 2 6522951
General Inquiries: info.sa@dlink-me.com
Tech Support: support.sa@dlink-me.com

Pakistan
Islamabad Office:
61-A, Jinnah Avenue, Blue Area,
Suite # 11, EBC, Saudi Pak Tower,
Islamabad - Pakistan
Tel.: +92-51-2800397, 2800398
Fax: +92-51-2800399

Karachi Office:
D-147/1, KDA Scheme # 1,
Opposite Mudassir Park, Karsaz Road,
Karachi – Pakistan
Phone: +92-21-34548158, 34326649
Fax: +92-21-4375727
Technical Support: +92-21-34548310, 34305069
General Inquiries: info.pk@dlink-me.com
Tech Support: support.pk@dlink-me.com