

D-Link® Quick Installation Guide

This product can be used with the following operating systems: Windows XP, Windows 2000, Mac OS 8, 9, and 10.1 or above.



DUB-104
4-Port USB 2.0 Pocket Hub

Before You Begin

You must have at least the following:

- Pentium 233-MHz or faster or equivalent with 32MB RAM
- Available USB 1.1 Port For USB 1.1 Operation
- Available USB 2.0 Port For USB 2.0 Operation
- Windows XP, 2000, Mac OS 8, 9, or 10/X for USB 1.1 Operation
- Windows XP, 2000 or Mac OS X for USB 2.0 Operation

Check Your Package Contents

These are the items included with your purchase:

If any of the below items are missing, please contact your reseller.



DUB-104 4-Port USB 2.0 Pocket Hub



Power Adapter (5V 2.5A)



Using a power supply with a different voltage rating will damage and void the warranty for this product.

1

Installing the DUB-104

- A. Plug the AC adapter into the DUB-104 and into a power socket in a power-strip or a wall jack. (optional)



- B. Plug the USB type A dongle (found on the bottom of the DUB-104) into an available USB 2.0 port on your computer (or a USB 1.1 port if you don't have USB 2.0).



- C. Your computer will automatically detect and install the DUB-104. You may now connect USB 2.0 or USB 1.1 devices to an available USB port on the front of the DUB-104.



2 LED indicator

- The Power LED indicator is blue and lights up when the DUB-H4 is powered on by using the external power adapter or by running on power supplied from the computer (bus powered).



- If a port becomes overloaded, a “current exceeded” event will take place. The LED will go off and the message “USB HUB Current Limit Exceeded” appears on the monitor. Reset the DUB-104 by disconnecting the power adapter (if used) or disconnecting the dongle from the PC for 5 seconds and then powering it back on by connecting the AC power adapter or reconnecting the dongle to the PC.

3 Tips

- When connecting USB cables between USB devices and the DUB-104, make sure that the cables are connected securely.
- Remember that when connecting USB 1.1 devices to a USB 2.0 hub or host adapter, the USB 1.1 device will not work at USB 2.0 speeds.
- The DUB-104 does not have an on/off switch. It is always on once the external power adapter has been plugged into a power source or the dongle has been connected to a PC's USB port.
- Connecting USB 1.1 devices to the DUB-104 may cause all USB devices connected to the hub to work at USB 1.1 speed. To ensure 480Mbps throughput for your USB 2.0 devices, don't connect USB 1.1 and USB 2.0 devices to the hub at the same time.
- D-Link recommends that while using a USB device that includes an AC power adapter, that you use the power adapter to ensure proper power and current supply to that device.
- Please remember to unplug devices properly to ensure that no data loss or corruption takes place with your operating system.