



D-Link®

WIRELESS AC1200 DUAL BAND GIGABIT
RANGE EXTENDER
DAP-1650

**QUICK
INSTALLATION
GUIDE**

КРАТКОЕ РУКОВОДСТВО ПО УСТАНОВКЕ

GUÍA DE INSTALACIÓN RÁPIDA

GUIA DE INSTALAÇÃO RÁPIDA

快速安装指南

PETUNJUK PEMASANGAN CEPAT

CONTENTS OF PACKAGING

CONTENTS



**WIRELESS AC1200 DUAL BAND GIGABIT RANGE
EXTENDER**
DAP-1650



POWER ADAPTER
12V / 2A



ETHERNET CABLE (CAT5 UTP)
CONNECT THE RANGE EXTENDER TO YOUR PC DURING
SETUP



WI-FI CONFIGURATION NOTE
CONTAINS THE DEFAULT WI-FI INFORMATION



If any of these items are missing from your packaging, contact your reseller.


PRODUCT SETUP

EASY SETUP



POSITION THE RANGE EXTENDER

Place the range extender in an open area of your intended work area for better wireless coverage.



CONNECT TO YOUR PC

Use the included Ethernet cable to connect the DAP-1650 to your desktop or laptop PC. Connect the power adapter to the DAP-1650. Wait until the Power LED changes from orange to green.



CONFIGURE THE DAP-1650

Open a web browser and go to **<http://dlinkap.local>** (or **dlinkxxxx** (the last four digits of MAC address)). The default User name is admin, and the default Password is blank. Now you can use the setup wizard to configure AP, MediaBridge or Repeater mode on your DAP-1650.

ADVANCED SETUP (ACCESS VIA IP ADDRESS)

To configure DAP-1650 manually connect your computer to the DAP-1650 using the ethernet cable provided. Then connect the power cable on the DAP-1650. The power light will display as solid green.

Then simply open a browser window and enter the IP address in the browser address field:

IP ADDRESS: <http://dlinkap.local> or <http://192.168.0.50>

USERNAME: Admin

PASSWORD:

If you have more than one Access Point, enter <http://dlinkpxxxx> (the xxxx are the last four digits of the AP's MAC address which is located on the bottom of the device in the label).

TROUBLESHOOTING

SETUP AND CONFIGURATION PROBLEMS

1. HOW DO I CONFIGURE MY DAP-1650 AP WITHOUT THE CD, OR CHECK MY WIRELESS NETWORK NAME (SSID) AND WIRELESS ENCRYPTION KEY?

- Connect your PC to the range extender using an Ethernet cable.
- Open a web browser and enter the address <http://dlinkap.local> or <http://192.168.0.50>
- The default username is 'Admin'. The default password is blank (leave the field blank).
- If you have changed the password and can not remember it, you will need to reset the AP to revert the password back to blank (leave the field blank).

2. HOW DO I RESET MY DAP-1650 AP TO FACTORY DEFAULT SETTINGS?

- Ensure the range extender is powered on.
- Press and hold the reset button on the rear of the device for 5 seconds.

Note: Resetting the range extender to factory default will erase the current configuration settings. To re-configure your settings, log into the range extender as outlined in question 1, then run the Setup Wizard.

3. HOW DO I ADD A NEW WIRELESS CLIENT OR PC IF I HAVE FORGOTTEN MY WIRELESS NETWORK NAME (SSID) OR WIRELESS ENCRYPTION KEY?

- For every PC that needs to connect to the range extender wirelessly, you will need to ensure you use the correct Wireless Network Name (SSID) and encryption key.
- Use the web based user interface (as described in question 1 above) to check or choose your wireless settings.
- Make sure you write down these settings so that you can enter them into each wirelessly connected client. You will find a dedicated area on the back of this document, this important information for future use.

You can find software updates and user documentation on the D-Link website.

Tech Support for customers in

Australia:

Tel: 1300-766-868
24/7 Technical Support
Web: <http://www.dlink.com.au>
E-mail: support@dlink.com.au

India:

Tel: +91-22-27626600
Toll Free 1800-22-8998
Web: www.dlink.co.in
E-Mail: helpdesk@dlink.co.in

Singapore, Thailand, Indonesia, Malaysia, Philippines, Vietnam:

Singapore - www.dlink.com.sg
Thailand - www.dlink.co.th
Indonesia - www.dlink.co.id
Malaysia - www.dlink.com.my
Philippines - www.dlink.com.ph
Vietnam - www.dlink.com.vn

Korea:

Tel: +82-2-2028-1810
Monday to Friday 9:00am to 6:00pm
Web: <http://d-link.co.kr>
E-mail: g2b@d-link.co.kr

New Zealand:

Tel: 0800-900-900
24/7 Technical Support
Web: <http://www.dlink.co.nz>
E-mail: support@dlink.co.nz

South Africa and Sub Sahara Region:

Tel: +27 12 661 2025
08600 DLINK (for South Africa only)
Monday to Friday 8:30am to 9:00pm South Africa Time
Web: <http://www.d-link.co.za>
E-mail: support@d-link.co.za

Saudi Arabia (KSA):

Tel: +966 01 217 0008
Fax: +966 01 217 0009
Saturday to Wednesday 9.30AM to 6.30PM
Thursdays 9.30AM to 2.00 PM
E-mail: Support.sa@dlink-me.com

D-Link Middle East - Dubai, U.A.E.

Plot No. S31102,
Jebel Ali Free Zone South,
P.O.Box 18224, Dubai, U.A.E.
Tel: +971-4-8809022
Fax: +971-4-8809066 / 8809069
Technical Support: +971-4-8809033
General Inquiries: info.me@dlink-me.com
Tech Support: support.me@dlink-me.com

Egypt

1, Makram Ebeid Street - City Lights Building
Nasr City - Cairo, Egypt
Floor 6, office C2
Tel.: +2 02 26718375 - +2 02 26717280
Technical Support: +2 02 26738470
General Inquiries: info.eg@dlink-me.com
Tech Support: support.eg@dlink-me.com

Kingdom of Saudi Arabia

Office # 84 ,
Al Khaleej Building (Mujamathu Al-Khaleej)
Opp. King Fahd Road, Olaya
Riyadh - Saudi Arabia
Tel: +966 1 217 0008
Technical Support:
+966 1 2170009 / +966 2 6522951
General Inquiries: info.sa@dlink-me.com
Tech Support: support.sa@dlink-me.com

Pakistan

Islamabad Office:
61-A, Jinnah Avenue, Blue Area,
Suite # 11, EBC, Saudi Pak Tower,
Islamabad - Pakistan
Tel.: +92-51-2800397, 2800398
Fax: +92-51-2800399

Karachi Office:

D-147/1, KDA Scheme # 1,
Opposite Mudassir Park, Karsaz Road,
Karachi - Pakistan
Phone: +92-21-34548158, 34326649
Fax: +92-21-4375727
Technical Support: +92-21-34548310, 34305069
General Inquiries: info.pk@dlink-me.com
Tech Support: support.pk@dlink-me.com

TECHNICAL SUPPORT

Iran

Unit 5, 5th Floor, No. 20, 17th Alley , Bokharest
St. , Argentine Sq. ,
Tehran IRAN
Postal Code : 1513833817
Tel: +98-21-88880918,19
+98-21-88706653,54
General Inquiries: info.ir@dlink-me.com
Tech Support: support.ir@dlink-me.com

Morocco

M.I.T.C
Route de Nouaceur angle RS et CT 1029
Bureau N° 312 ET 337
Casablanca , Maroc
Phone : +212 663 72 73 24
Email: support.na@dlink-me.com

Lebanon RMA center

Dbayeh/Lebanon
PO Box:901589
Tel: +961 4 54 49 71 Ext:14
Fax: +961 4 54 49 71 Ext:12
Email: taoun@dlink-me.com

Bahrain

Technical Support: +973 1 3332904

Kuwait:

Technical Support: + 965 22453939 / +965
22453949

Türkiye Merkez İrtibat Ofisi

Ayazağa Maslak yolu
Erdebil Cevahir İş Merkezi No: 5/A Ayazağa /
Maslak İstanbul
Tel: +90 212 2895659
Ücretsiz Müşteri Destek Hattı: 0 800 211 00 65
Web:www.dlink.com.tr
Teknik Destek: support.tr@dlink.com.tr

ISRAEL

מטלון סנטר
רח' המגשימים 20
קרית מטלון, פ"ת 49348
ת.ד. 7060
טלפון: 073-796-2797
אי-מאייל כללי: info@dlink.co.il
אי-מאייל תמיכה: support@dlink.co.il

КОМПЛЕКТ ПОСТАВКИ

СОДЕРЖИМОЕ



БЕСПРОВОДНОЙ ДВУХДИАПАЗОННЫЙ ГИГАБИТНЫЙ ПОВТОРИТЕЛЬ AC1200 ДЛЯ УВЕЛИЧЕНИЯ ЗОНЫ ДЕЙСТВИЯ СЕТИ

DAP-1650



АДАПТЕР ПИТАНИЯ

12 В, 2 А



ETHERNET-КАБЕЛЬ (ВИТАЯ ПАРА 5 КАТЕГОРИИ)

ДЛЯ ПОДКЛЮЧЕНИЯ ПОВТОРИТЕЛЯ К ПК И НАСТРОЙКИ
ПАРАМЕТРОВ



УКАЗАНИЕ ПО НАСТРОЙКЕ WI-FI

СОДЕРЖИТ ИНФОРМАЦИЮ О СЕТИ WI-FI ПО УМОЛЧАНИЮ



Если что-либо из перечисленного отсутствует, обратитесь к поставщику.


УСТАНОВКА

ПРОСТАЯ УСТАНОВКА



РАСПОЛОЖЕНИЕ ПОВТОРИТЕЛЯ

Разместите данное устройство на открытом пространстве предполагаемой рабочей области для расширения зоны покрытия беспроводной сети.



ПОДКЛЮЧИТЕ К ПК

Используя входящий в комплект поставки Ethernet-кабель, подключите DAP-1650 к настольному ПК или ноутбуку. Подключите адаптер питания к DAP-1650. Подождите до тех пор, пока индикатор Power не загорится зеленым цветом вместо оранжевого.



НАСТРОЙТЕ DAP-1650

Откройте Web-браузер и перейдите на <http://dlinkap.local> (или dlinkxxxx (последние четыре знака MAC-адреса)). Именем пользователя по умолчанию является Admin, а поле пароля по умолчанию следует оставить пустым. Теперь можно воспользоваться Мастером для настройки DAP-1650 в режиме AP, MediaBridge или Repeater.

РАСШИРЕННАЯ НАСТРОЙКА (ЧЕРЕЗ WEB-ИНТЕРФЕЙС)

Чтобы настроить DAP-1650 вручную, подключите компьютер к DAP-1650, используя входящий в комплект поставки Ethernet-кабель. Затем подключите кабель питания к DAP-1650. Индикатор питания будет постоянно гореть зеленым цветом.

Просто откройте Web-браузер и введите IP-адрес в адресной строке:

IP-АДРЕС: <http://dlinkap.local> или <http://192.168.0.50>

USERNAME: Admin

PASSWORD:

Если у Вас несколько точек доступа, введите <http://dlinkapxxxx> (где xxxx – последние четыре знака MAC-адреса устройства, который указан на этикетке на нижней панели устройства).

ПОИСК И УСТРАНЕНИЕ НЕИСПРАВНОСТЕЙ

ПРОБЛЕМЫ УСТАНОВКИ И НАСТРОЙКИ

1. КАК НАСТРОИТЬ DAP-1650 БЕЗ КОМПАКТ-ДИСКА ИЛИ ПРОВЕРИТЬ ИМЯ БЕСПРОВОДНОЙ СЕТИ (SSID) И КЛЮЧ ШИФРОВАНИЯ БЕСПРОВОДНОЙ СЕТИ?

- Подключите ПК к DAP-1650, используя Ethernet-кабель.
- Откройте Web-браузер и введите адрес <http://dlinkar.local> или <http://192.168.0.50>
- Именем пользователя по умолчанию является 'Admin'. Пароль по умолчанию отсутствует (оставьте это поле пустым).
- Если Вы изменили пароль и забыли его, то необходимо сбросить настройки устройства для восстановления пароля в значение по умолчанию.

2. КАК СБРОСИТЬ DAP-1650 К ЗАВОДСКИМ НАСТРОЙКАМ?

- Убедитесь, что питание устройства включено.
- Нажмите и удерживайте кнопку сброса на задней панели устройства в течение 5 секунд.

Примечание: Сброс устройства к заводским настройкам удалит текущие параметры. Для того чтобы повторно настроить параметры, войдите в Web-интерфейс DAP-1650, как изложено в пункте 1, а затем запустите Мастер установки.

3. КАК ДОБАВИТЬ НОВОГО БЕСПРОВОДНОГО КЛИЕНТА ИЛИ ПК, ЕСЛИ ЗАБЫТО ИМЯ БЕСПРОВОДНОЙ СЕТИ (SSID) ИЛИ КЛЮЧ ШИФРОВАНИЯ БЕСПРОВОДНОЙ СЕТИ?

- Для каждого ПК, который требуется подключить к беспроводной сети повторителя DAP-1650, необходимо убедиться, что используются правильные имя беспроводной сети (SSID) и ключ шифрования.
- Используйте пользовательский Web-интерфейс (см. пункт 1), чтобы проверить или задать настройки беспроводной сети.
- Запишите или запомните эти настройки для возможности дальнейшего их использования каждым клиентом, подключающимся к беспроводной сети. На обратной стороне данного руководства есть специальный раздел для сохранения указанной информации.

ТЕХНИЧЕСКАЯ ПОДДЕРЖКА

Обновления программного обеспечения и документация доступны на Интернет-сайте D-Link. D-Link предоставляет бесплатную поддержку для клиентов в течение гарантийного срока. Клиенты могут обратиться в группу технической поддержки D-Link по телефону или через Интернет.

Техническая поддержка D-Link:

8-800-700-5465

Техническая поддержка через Интернет:

<http://www.dlink.ru>

e-mail: support@dlink.ru

ОФИСЫ

Россия

129626 г. Москва
Графский пер., 14
Тел.: +7 (495) 744-0099

Украина

04080 г. Киев, ул. Межигорская, 87-А, офис 18
Тел.: +38 (044) 545-64-40
E-mail: kiev@dlink.ru

Беларусь

220114, г. Минск, проспект Независимости,
169, БЦ "XXI Век"
Тел.: +375(17) 218-13-65
E-mail: minsk@dlink.ru

Казахстан

050008, г. Алматы, ул. Курмангазы, 143
(уг. Муқанова)
Тел./факс: +7 727 378-55-90
E-mail: almaty@dlink.ru

Армения

0038, г. Ереван, ул. Абяяна, 6/1, 4 этаж
Тел./Факс: + 374 (10) 398-667
E-mail: erevan@dlink.ru

Грузия

Тел./Факс: +995 (593) 98-3210

Lietuva

09120, Vilnius, Žirmūnu 139-303
Тел./факс. +370 (5) 236-3629
E-mail: info@dlink.lt

Eesti

Mustamae 55-314
10621, Tallinn
Tel +372 613 9771
e-mail: info@dlink.ee

Latvija

Mazā nometņu 45/53 (ieeja no Nāras ielas)
LV-1002, Rīga
Tel.:+371 7 618-703
Fax: +371 7 618-706
e-pasts: info@dlink.lv

CONTENIDO DEL EMPAQUE

CONTENIDO



**WIRELESS AC1200 DUAL BAND GIGABIT RANGE
EXTENDER**
DAP-1650



ADAPTADOR DE CORRIENTE
12V / 2A



CABLE ETHERNET (CAT5 UTP)
CONECTAR EL RANGE EXTENDER AL PC DURANTE LA
INSTALACIÓN



NOTA DE CONFIGURACIÓN WI-FI
CONTIENE LA INFORMACIÓN WI-FI POR DEFECTO



Si alguno de estos elementos falta en su empaque, póngase en
contacto con su distribuidor.


INSTALACIÓN DEL PRODUCTO

FÁCIL INSTALACIÓN



POSICIONAR EL EXTENSOR DE RANGO

Coloque el extensor de rango en un área abierta de su área de trabajo para una mejor cobertura inalámbrica.



CONEXIÓN AL PC

Utilice el cable Ethernet incluido para conectar el DAP-1650 a su PC de escritorio o portátil. Conecte el adaptador de corriente al DAP-1650. Espere hasta que el LED de encendido cambie de color desde el naranja al verde.



CONFIGURACIÓN DEL DAP-1650

Abra un navegador Web y vaya a <http://dlinkap.local> (o dlinkxxxx (los últimos cuatro dígitos de la dirección MAC)). El nombre de usuario predeterminado es admin y la contraseña predeterminada es en blanco (dejar el área vacía). Ahora usted puede utilizar el asistente de configuración para configurar el modo AP, MediaBridge o Repetidor en el DAP-1650.

CONFIGURACIÓN AVANZADA (ACCESO A TRAVÉS DE LA DIRECCIÓN IP)

Para configurar el DAP-1650, conecte manualmente su PC al DAP-1650 utilizando el cable Ethernet suministrado. A continuación, conecte el cable de alimentación del DAP-1650. La luz de encendido se mostrará verde.

Entonces sólo tiene que abrir una ventana del navegador y escriba la dirección IP en el campo de direcciones de su navegador:

DIRECCIÓN IP: <http://dlinkap.local> o <http://192.168.0.50>

USUARIO: Admin

CONTRASEÑA:

Si usted tiene más de un punto de acceso, introduzca <http://dlinkapxxxx> (xxxx son los últimos cuatro dígitos de la dirección MAC del AP que se encuentra en la parte inferior del dispositivo en la etiqueta).

SOLUCIÓN DE PROBLEMAS

PROBLEMAS DE INSTALACIÓN Y CONFIGURACIÓN

- 1. ¿CÓMO CONFIGURO MI DAP-1650 SIN EL CD, O COMPRUEBO MI NOMBRE DE RED WIRELESS (SSID) Y LA CLAVE WIRELESS ENCRIPTADA?**
 - Conecte su PC al extensor del rango DAP-1650 mediante un cable Ethernet.
 - Abra el navegador web e introduzca la dirección <http://dlinkap> ó <http://192.168.0.50>
 - El nombre de usuario predeterminado es admin. La contraseña predeterminada es en blanco (deje este campo vacío).
 - Si ha cambiado la contraseña y no la recuerda, tendrá que reiniciar el producto para restablecer la contraseña por defecto.

- 2. ¿CÓMO PUEDO RESTABLECER DAP-1650 A LA CONFIGURACIÓN PREDETERMINADA DE FÁBRICA?**
 - Asegúrese de que el extensor de rango esté encendido.
 - Mantenga pulsado el botón de Reset ubicado en la parte posterior del dispositivo durante 5 segundos.

Nota: Al restablecer el producto a los valores de fábrica, se borrará la configuración actual. Para volver a ajustar la configuración, inicie sesión en el extensor de rango como se indica en la pregunta 1, a continuación, ejecute el Asistente de configuración.

- 3. ¿CÓMO PUEDO AÑADIR UN NUEVO CLIENTE O PC INALÁMBRICO SI HE OLVIDADO MI NOMBRE DE RED WIRELESS (SSID) O LA CLAVE WIRELESS ENCRIPTADA?**
 - Por cada PC que necesita conectar al extensor de rango de forma inalámbrica, tendrá que asegurarse de que usa el nombre de red Wireless (SSID) y la clave wireless correcta.
 - Utilizar la interfaz de usuario basada en web (como se describe en la pregunta 1 arriba) para comprobar o elegir la configuración inalámbrica.
 - Asegúrese de anotar estos valores para que pueda ingresarlos en cada PC conectado de forma inalámbrica. Usted encontrará una zona dedicada en la parte posterior de este documento para anotar esta información importante para el uso futuro.

Usted puede encontrar actualizaciones de softwares o firmwares y documentación para usuarios a través de nuestro sitio www.dlinkla.com

SOPORTE TÉCNICO PARA USUARIOS EN LATINO AMERICA

Soporte técnico a través de los siguientes teléfonos de D-Link

PAIS	NUMERO
Argentina	0800 - 12235465
Chile	800 260200
Colombia	01800 - 510070
Costa Rica	0800 - 0521478
Ecuador	1800 - 035465
El Salvador	800 - 6335
Guatemala	1800 - 8350255
México	01800 - 0626270
Panamá	011 008000525465
Perú	0800 - 00968
Venezuela	0800 - 1005767

Soporte Técnico de D-Link a través de Internet

Horario de atención Soporte Técnico en www.dlinkla.com

e-mail: suporte@dlinkla.com & consultas@dlinkla.com

CONTEÚDOS DA EMBALAGEM

CONTEÚDOS



EXTENSOR DE ALCANCE GIGABIT WIRELESS DUAL BAND AC1200
DAP-1650




ADAPTADOR DE ENERGIA
12V / 0,5ª



CABO DE REDE ETHERNET (UTP CAT.5)
CONECTE O EXTENSOR DE ALCANCE EM SEU COMPUTADOR PARA REALIZAR AS CONFIGURAÇÕES



CARTÃO DE CONFIGURAÇÃO WI-FI
CONTÉM AS INFORMAÇÕES DE CONEXÃO WI-FI FORNECIDAS DE FÁBRICA



Se algum destes itens estiver ausente, contate seu revendedor.


CONFIGURAÇÕES DO PRODUTO

FÁCIL DE INSTALAR



POSICIONE MELHOR O EXTENSOR DE ALCANCE

Instale fisicamente o Extensor de Alcance em um local adequado que seja preferencialmente aberto para melhor abrangência de cobertura.



CONECTE O SEU COMPUTADOR

Utilize o cabo de rede Ethernet para conectar o DAP-1650 em seu computador ou notebook. Conecte o adaptador de energia no ponto de acesso. Aguarde até que as luzes indicadoras de funcionamento se acendam



CONFIGURE O DAP-1650

Abra um navegador de acesso à Internet e digite o endereço **http://dlinkap.local** (ou **dlinkxxxx** (os últimos 4 dígitos do endereço MAC)). Digite o nome de usuário admin e deixe o espaço da senha em branco. Agora você poderá utilizar o assistente de configuração para instalar o seu DAP-1650.

CONFIGURAÇÕES AVANÇADAS (ACESSO VIA ENDEREÇO IP)

Para configurar manualmente o DAP-1650 conecte seu computador ao DAP-1650 usando o cabo de rede fornecido com o produto. Então conecte o cabo de energia no DAP-1650. A luz verde de energia se acenderá.

Então simplesmente abra um software de navegação e digite o endereço IP na barra de endereços:

Endereço IP:	http://dlinkap.local ou http://192.168.0.50
Nome de usuário:	Admin
Senha:	(deixe em branco)

Se você possuir mais de um ponto de acesso, digite **http://dlinkapxxxx** (os últimos 4 dígitos do endereço MAC do AP que podem ser visualizados na etiqueta localizada embaixo do produto).

SOLUÇÃO DE PROBLEMAS

PROBLEMAS DE INSTALAÇÃO E CONFIGURAÇÃO

1. COMO EU CONFIGURO O MEU PONTO DE ACESSO DAP-1650 SEM UTILIZAR O CD, OU COMO VERIFICO O NOME DA REDE WIRELESS (SSID) E A SENHA DE ACESSO?

- Conecte seu computador diretamente ao DAP-1650, utilizando um cabo de rede Ethernet.
- Abra um navegador de acesso e digite o endereço <http://dlinkap.local> ou <http://192.168.0.50>
- O nome de usuário padrão é admin. O produto não tem senha definida de acesso às configurações (deixar esta espaço em branco).
- Se você alterou a senha e não se lembra da mesma, você terá que redefinir as configurações de fábrica do produto através de reset físico.

2. COMO REDEFINIR MEU PONTO DE ACESSO DAP-1650 PARA AS CONFIGURAÇÕES PADRÕES DE FÁBRICA?

- Verifique se o produto está ligado.
- Pressione e segure o botão de reset na parte traseira do aparelho por 5 segundos.

Nota: A restauração do produto para os padrões de fábrica irá apagar todas as configurações atuais. Para reconfigurar suas configurações, acesse novamente o DAP-1650 seguindo as orientações expostas na pergunta 1, e em seguida execute o Assistente de Configuração do produto.

3. COMO FAÇO PARA CONECTAR UM NOVO CLIENTE WIRELESS OU COMPUTADOR NO CASO DE TER ESQUECIDO O NOME DA REDE WIRELESS (SSID) OU A SENHA DE ACESSO?

- Para cada computador que necessitar se conectar ao DAP-1650 através da rede sem fios, você precisará se certificar de estar acessando a sua rede Wireless e digitar a senha corretamente.
- Utilize a interface web de usuário (como descrito acima na pergunta 1) para verificar ou configurar as configurações da rede sem fios.
- Anote essas configurações para que você possa inseri-las em cada computador que precisar ser conectado. Você encontrará uma área dedicada no verso deste documento para anotar essas informações importantes para uso futuro.

SUORTE TÉCNICO

Caso tenha dúvidas na instalação do produto, entre em contato com o Suporte Técnico D-Link.

Acesse o site: www.dlink.com.br/suporte

包裝內容

內容



AC1200 雙頻無線基地台
DAP-1650



電源供應器
12V / 2A



乙太網路線(CAT.5)
在設定時可用來連接電腦和基地台



無線資料卡
顯示DAP-1650預設的無線網路名稱(SSID)和密碼>Password)



若缺少上述任一項物品，請儘快聯絡您購買的經銷商。


產品設定

快速安裝



放置基地台

請將DAP-1650放置在您想使用區域內較無阻隔物的位置，並避開微波爐、無線電話等干擾源來取得較佳的無線訊號和涵蓋範圍。



連接網路線和電源

請將網路線的一端連接至DAP-1650背面的LAN埠，並將另一端連接至您的電腦的網路埠。若您的電腦是連接到一台交換器或路由器，請將DAP-1650連接至同一台設備。之後將DAP-1650接上電源，並確認電源指示燈由橘色變為綠色。



設定DAP-1650

請至電腦的「區域連線」內容，將TCP/IP(IPv4)設為「使用下列IP位址」，並在IP位址欄位內輸入192.168.0.x(除了50外，1-254皆可)，子網路遮罩欄位為255.255.255.0。之後開啟網頁瀏覽器，在網址列輸入「http://dlinkap.local」或「dlinkxxxx(xxxx為mac位址的末4碼)」來開啟設定網頁。出現登入畫面後，在使用者名稱(User Name)的欄位輸入「admin」，密碼(Password)不需輸入，再按下「登入」(Log In)按鈕即可開始依設定精靈的引導來設定。

進階設定 (透過IP位址來存取)

請將網路線的一端連接至DAP-1650背面的LAN埠，並將另一端連接至您的電腦的網路埠。若您的電腦是連接到一台交換器或路由器，請將DAP-1650連接至同一台設備。之後將DAP-1650接上電源，並確認電源指示燈由橘色變為綠色。

之後開啟網頁瀏覽器，並在網址列輸入以下IP位址:

IP位址:	http://dlinkap.local 或 http://192.168.0.50
USERNAME:	Admin
PASSWORD:	(無)

若您有一台以上的基地台，請輸入http://dlinkapxxxx(xxxx是DAP-1650的末4碼mac位址，您可以由設備上的標籤查看到此資料)。

常見問題

設定和安裝的疑問

1. 我要如何手動設定DAP-1650(如需更改使用模式時)?

- (1) 使用網路線連接電腦和DAP-1650。
- (2) 請至電腦的「區域連線」內容，將TCP/IP(IPv4)設為指定IP，IP位址輸入192.168.0.x(除了50外，1-254皆可)。
- (3) 請開啟網頁瀏覽器，在網址列輸入「http://dlinkap.local」或「http://192.168.0.50」。
- (4) 請以預設的使用者名稱(User Name)為「admin」，沒有密碼>Password)來登入設定網頁。(若您已經更改過登入密碼但忘記此資料，請將設備reset回復原廠預設值來重新設定。)

2. 我要如何將DAP-1650回復出廠預設值(RESET)?

- (1) 確認設備已連接電源並在待機中。
- (2) 用迴紋針等細物插入DAP-1650背面的reset孔約8-10秒再放開，再稍候設備重新啟動。
請注意! 此動作會將DAP-1650的設定全部清除，請在設備開機完成後依上述說明重新設定。

3. 我要如何使用無線方式連線至DAP-1650? 若忘記無線網路名稱或密碼時該如何處理?

請先開啟無線裝置端的無線(Wi-Fi)功能並搜尋DAP-1650的無線網路名稱連線(預設為「dlink」無密碼)。若您已忘記之前設定的無線名稱或密碼，您可以依照問題1的說明來開啟DAP-1650的設定網頁，至「設定」(SETUP)>「無線設定」(Wireless Setup)頁面來查看或修改已設定的無線資料，之後請記下這些資料以作為日後連線的參考。

4. DAP-1650在AP模式下，裝置的無線網路已顯示連線但無法連上網際網路時該如何檢查?

- 若DAP-1650上端直接連接數據機:

- (1) Cable電視寬頻(DHCP)的使用者-請確認裝置內的「無線連線」IP位址設定為「自動取得IP位址」。
 - (2) xDSL/ADSL的使用者-請確認在電腦上有執行寬頻連線(ADSL連線)，且連線的使用者名稱和密碼資料皆正確。若您使用的是行動裝置則無法適用於此種網路架構，請在DAP-1650上端加裝一台路由器，若數據機有DHCP伺服器則請將該功能啟用。
 - (3) 固定IP的使用者-請確認裝置內的「無線連線」IP位址設定為「固定IP位址(使用下列IP位址)」，並輸入由網路業者提供的IP位址。
- 若DAP-1650上端連接路由器: 請確認路由器已設定連通網際網路

如果您還有任何本使用手冊無法協助您解決的產品相關問題，台灣地區用戶可以透過我們的網站、電子郵件或電話等方式與D-Link台灣地區技術支援工程師聯絡。

D-Link 免付費技術諮詢專線

0800-002-615

手機付費電話 (02)6600-0123#8715

服務時間：週一至週五，早上9:00到晚上9:00

(不含周六、日及國定假日)

網 站：<http://www.dlink.com.tw>

電子郵件：dssqa_service@dlink.com.tw

如果您是台灣地區以外的用戶，請參考D-Link網站，全球各地分公司的聯絡資訊以取得相關支援服務。

產品保固期限、台灣區維修據點查詢，請參考以下網頁說明：

<http://www.dlink.com.tw>

產品維修：

使用者可直接送至全省聯強直營維修站或請洽您的原購買經銷商。

ISI KEMASAN

ISI




**WIRELESS AC1200 DUAL BAND GIGABIT RANGE
EXTENDER**
DAP-1650



ADAPTOR DAYA
12V / 2A



KABEL ETHERNET (CAT5 UTP)
MENGHUBUNGKAN RANGE EXTENDER KE PC PADA SAAT
PENGATURAN



CATATAN KONFIGURASI WI-FI
BERISI INFORMASI WI-FI BAWAAN PABRIKAN



Bila terdapat item yang hilang dari kemasan Anda, segera hubungi penjual.


PENGATURAN PERANGKAT

PENGATURAN MUDAH



POSISIKAN RANGE EXTENDER

Letakkan range extender di lokasi terbuka dimana Anda ingin mendapatkan jangkauan wireless yang lebih baik.



MENGHUBUNGKAN KE PC ANDA

Gunakan kabel Ethernet bawaan untuk menghubungkan DAP-1650 ke PC atau Laptop Anda. Hubungkan adaptor daya ke DAP-1650. Tunggu hingga lampu LED Power berubah dari warna oranye ke hijau.



MENGGONFIGURASI DAP-1650

Buka web browser dan masukkan alamat <http://dlinkap.local> (atau dlinkxxxx (empat digit terakhir dari MAC address)). User name bawaan adalah admin dan biarkan kolom password kosong. Sekarang anda dapat menggunakan layanan Setup Wizard untuk mengkonfigurasi DAP-1650 sebagai AP, MediaBridge atau Repeater

PENGATURAN TINGKAT LANJUT (AKSES MELALUI ALAMAT IP)

Untuk mengkonfigurasi DAP-1650 secara manual, hubungkan komputer dengan DAP-1650 dengan menggunakan kabel Ethernet bawaan. Kemudian hubungkan kabel daya ke DAP-1650. Lampu Power akan menyala hijau.

Kemudian cukup buka browser dan masukkan alamat IP pada kolom halaman di browser:

ALAMAT IP : <http://dlinkap.local> atau <http://192.168.0.50>

USERNAME: Admin

PASSWORD:

Bila anda memiliki lebih dari satu AP, masukkan <http://dlinkapxxxx> (xxxx diganti dengan 4 digit terakhir dari alamat MAC akses poin yang tertera pada label di bagian bawah perangkat).

PENANGANAN MASALAH

MASALAH PADA PENGATURAN DAN KONFIGURASI

1. BAGAIMANA CARA SAYA MENGATUR DAP-1650 AP TANPA CD, ATAU CARA MEMERIKSA NAMA JARINGAN WIRELESS (SSID) DAN PASSWORD WIRELESS?

- Hubungkan PC Anda ke range extender dengan menggunakan kabel Ethernet.
- Buka web browser dan masukkan <http://dlinkap.local> atau <http://192.168.0.50>
- Default username adalah 'Admin'. Default password adalah kosong (tinggalkan kolom kosong).
- Jika Anda telah mengubah password dan tidak dapat mengingatnya, Anda akan perlu untuk me-reset AP untuk mengembalikan password kembali kosong (tinggalkan kolom kosong).

2. BAGAIMANA CARA SAYA ME-RESET DAP-1650 AP KE BAWAAN PABRIK?

- Pastikan range extender dinyalakan.
- Tekan dan tahan tombol reset pada bagian belakang perangkat selama 5 detik.

Catatan: Mengatur ulang range extender ke pengaturan bawaan pabrik akan menghapus pengaturan konfigurasi saat ini. Untuk mengkonfigurasi ulang pengaturan Anda, login ke range extender seperti pada pertanyaan 1, kemudian jalankan Setup Wizard.

3. BAGAIMANA CARA MENAMBAH KLIEN NIRKABEL BARU ATAU PC JIKA SAYA TIDAK INGAT NAMA JARINGAN WIRELESS (SSID) ATAU PASSWORD WIRELESS?

- Untuk setiap PC yang akan di hubungkan ke range extender, pastikan Anda menggunakan Wireless Network Name (SSID) dan password yang benar.
- Gunakan antarmuka web (seperti yang dijelaskan dalam pertanyaan 1 di atas) untuk memeriksa atau melakukan pengaturan nirkabel.
- Pastikan Anda menuliskan pengaturan ini sehingga Anda dapat memasukkan data tersebut ke setiap klien yang akan terhubung secara nirkabel. Anda akan menemukan area khusus pada bagian belakang dokumen ini, informasi ini penting untuk penggunaan masa depan.

DUKUNGAN TEKNIS

Update perangkat lunak dan dokumentasi pengguna dapat diperoleh pada situs web D-Link.
Dukungan Teknis untuk pelanggan:

Dukungan Teknis D-Link melalui telepon:

Tel: +62-21-5731610

Dukungan Teknis D-Link melalui Internet:

Email : support@dlink.co.id

Website : <http://support.dlink.co.id>

NOTES

D-LINK GPL CODE STATEMENT

This D-Link product includes software code developed by third parties, including software code subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL"). As applicable, the terms of the GPL and LGPL, and information on obtaining access to the GPL code and LGPL code used in this product, are available to you at:

<http://tsd.dlink.com.tw/GPL.asp>

The GPL code and LGPL code used in this product are distributed WITHOUT ANY WARRANTY and is subject to the copyrights of one or more authors. For details, see the GPL code and the LGPL code for this product and the terms of the GPL and LGPL.

WRITTEN OFFER FOR GPL AND LGPL SOURCE CODE

Where such specific license terms entitle you to the source code of such software, D-Link will provide upon written request via email and/or traditional paper mail the applicable GPL and LGPL source code files via CD-ROM for a nominal cost to cover shipping and media charges as allowed under the GPL and LGPL.

Technical Support: For product support, please visit <http://support.dlink.com> for further assistance.

General Public License ("GPL") Inquiries: Please direct all GPL inquiries to the following email/ address. Note that technical support inquiries will not be supported at the below address.

Email:
GPLCODE@DLink.com

Snail Mail:
Attn: GPLSOURCE REQUEST
D-Link Systems, Inc.
17595 Mt. Herrmann Street
Fountain Valley, CA 92708

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.
51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

PREAMBLE

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it. For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

HOW TO APPLY THESE TERMS TO YOUR NEW PROGRAMS

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and a brief idea of what it does.>

Copyright (C) <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w`.

This is free software, and you are welcome to redistribute it under certain conditions; type `show c` for details.

The hypothetical commands `show w` and `show c` should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w` and `show c`; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program `Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon>, 1 April 1989
Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

WIRELESS NETWORK REMINDER

Wireless Network Name (SSID)

Wireless Network Password