

DSL-G604T Screenies

V2.00B01T01.AU

D-Link
Building Networks for People

DSL-G604T Wireless ADSL Router

Home | **Advanced** | **Tools** | **Status** | **Help**

Wizard

Wireless

WAN

LAN

DHCP

DNS


DynamicDNS

Logout

Setup Wizard

The DSL-G604T is an ADSL Router ideal for home networking and small business networking. The setup wizard will guide you to configure the DSL-G604T to connect to your ISP (Internet Service Provider). The DSL-G604T's easy setup will allow you to have Internet access within minutes. Please follow the setup wizard step by step to configure the DSL-G604T.

[Run Wizard](#)


Help



http://10.1.1.1 - DSL-G604T - Microsoft Internet Explor...

D-Link
Building Networks for People

DSL-G604T Wireless ADSL Router

Welcome to the DSL-G604T Setup Wizard. The Wizard will guide you through these four quick steps. Begin by clicking on **Next**.

- Step 1. Choose your time zone
- Step 2. Set Internet connection
- Step 3. Set wireless configuration
- Step 4. Restart

 
Next **Exit**

Done Internet

http://10.1.1.1 - DSL-G604T - Microsoft Internet Explor...




D-Link
Building Networks for People

DSL-G604T Wireless ADSL Router

Choose Time Zone

Select the appropriate time zone for your location and click **Next** to continue.

(GMT+10:00) Canberra,Melbourne,Sydney

  
Back **Next** **Exit**

Internet

http://10.1.1.1 - DSL-G604T - Microsoft Internet Explor...




D-Link
Building Networks for People

DSL-G604T Wireless ADSL Router

Select Internet Connection Type (WAN)

Select the connection type to connect to your ISP. Click **Next** to continue

- PPPoE/PPPoA
Choose this option if your ISP uses PPPoE/PPPoA. (For most DSL users)
- Dynamic IP Address
Choose this option to obtain an IP address automatically from your ISP.
- Static IP Address
Choose this option to set static IP information provided to you by your ISP.
- Bridge Mode
Choose this option if your ISP uses Bridge Mode.

  
Back Next Exit

Done Internet

http://10.1.1.1 - DSL-G604T - Microsoft Internet Explor...

D-Link
Building Networks for People

DSL-G604T Wireless ADSL Router

Set PPPoE / PPPoA

Enter the PPPoE/PPPoA information provided to you by your ISP. Click **Next** to continue.



User Name

Password

VPI

VCI

Connection Type ▼

  
Back Next Exit

javascript:uiSave() Internet

http://10.1.1.1/cgi-bin/webcm - Microsoft Internet Exp...

D-Link
Building Networks for People




DSL-G604T Wireless ADSL Router

Set Wireless LAN Connection

Enter the SSID name and channel number to be used for the Wireless LAN. If you wish to use encryption, enable it below and enter the correct values. Click **Next** to continue.

SSID:

Channel:

Back Next Exit

Done Internet




http://10.1.1.1 - DSL-G604T - Microsoft Internet Explor...

D-Link
Building Networks for People

DSL-G604T Wireless ADSL Router

Setup Completed

The Setup Wizard has completed. Click on **Back** to modify changes or mistakes. Click **Restart** to save the current settings and reboot the DSL-G604T.

Back Restart Exit

Done Internet



Wizard

Wireless

WAN

LAN

DHCP

DNS

DynamicDNS

Logout

Home

Advanced

Tools

Status

Help

Wireless Settings

These are the wireless settings for the AP(Access Point) Portion.

Enable AP

SSID:

Channel:

Security: None WEP WPA

Please save and reboot the device to take effect!



Apply



Cancel



Help



Wizard

Wireless

WAN

LAN

DHCP

DNS

DynamicDNS

Logout

Home

Advanced

Tools

Status

Help

Wireless Settings

These are the wireless settings for the AP(Access Point) Portion.

Enable AP

SSID:

Channel:

Security: None WEP WPA

Enable WEP Wireless Security

Authentication Type:

Select	Encryption Key	Cipher
<input checked="" type="radio"/>	<input type="text"/>	<input type="text" value="64 bits"/>
<input type="radio"/>	<input type="text"/>	<input type="text" value="64 bits"/>
<input type="radio"/>	<input type="text"/>	<input type="text" value="64 bits"/>
<input type="radio"/>	<input type="text"/>	<input type="text" value="64 bits"/>

Enter 10, 26, 58 hexadecimal digits(0~9,A~F) for 64, 128, or 256 bit Encryption Keys respectively. e.g., AAAAAAAAAA for a key length of 64 bits.

Please save and reboot the device to take effect !



Apply



Cancel



Help



Wizard

Wireless

WAN

LAN

DHCP

DNS

DynamicDNS

Logout

Home

Advanced

Tools

Status

Help

Wireless Settings

These are the wireless settings for the AP(Access Point) Portion.

Enable AP

SSID:

Channel:

Security: None WEP WPA

Group Key Interval:

Note: Group Key Interval is shared by all WPA options.

802.1x Server IP Address:

Port:

Secret:

PSK Hex Hex:

PSK String String:

Please save and reboot the device to take effect !



Apply



Cancel



Help



- Wizard
- Wireless
- WAN**
- LAN
- DHCP
- DNS
- DynamicDNS
- Logout

Home | **Advanced** | **Tools** | **Status** | **Help**

ATM VC Setting

PVC	<input type="text" value="Pvc0"/>
VPI	<input type="text" value="8"/>
VCI	<input type="text" value="35"/>
Virtual Circuit	<input type="text" value="Enabled"/>
WAN Setting	<input type="text" value="PPPoE/PPPoA"/>

PPPoE/PPPoA

User Name	<input type="text" value="username"/>
Password	<input type="password" value="••••"/>
Connection Type	<input type="text" value="PPPoE LLC"/>
MTU	<input type="text" value="1400"/> bytes
MRU	<input type="text" value="1492"/> bytes
Default Route	<input type="text" value="Enabled"/>
NAT	<input type="text" value="Enabled"/>
Firewall	<input type="text" value="Enabled"/>
IP Control	<input type="text" value="Dynamic IP"/>
Static IP	<input type="text" value="0.0.0.0"/>

ATM

Service Category	<input type="text" value="UBR"/>
PCR	<input type="text"/> kbps
SCR	<input type="text"/> kbps

 **Apply**  **Cancel**  **Help**



- Wizard
- Wireless
- WAN**
- LAN
- DHCP
- DNS
- DynamicDNS
- Logout

Home | **Advanced** | **Tools** | **Status** | **Help**

ATM VC Setting

PVC	<input type="text" value="Pvc0"/>
VPI	<input type="text" value="8"/>
VCI	<input type="text" value="35"/>
Virtual Circuit	<input type="text" value="Enabled"/>
WAN Setting	<input type="text" value="Dynamic IP Address"/>

Dynamic IP

Connection Type	<input type="text" value="1483 Bridged IP LLC"/>
Cloned MAC Address	<input type="text"/>
Cloned MAC Address	<input type="text" value="Clone MAC Address"/>
MTU	<input type="text" value="1400"/> bytes
NAT	<input type="text" value="Enabled"/>
Firewall	<input type="text" value="Enabled"/>

ATM

Service Category	<input type="text" value="UBR"/>
PCR	<input type="text"/> kbps
SCR	<input type="text"/> kbps

 **Apply**  **Cancel**  **Help**



- Wizard
- Wireless
- WAN**
- LAN
- DHCP
- DNS
- DynamicDNS
- Logout

Home | **Advanced** | **Tools** | **Status** | **Help**

ATM VC Setting

PVC	<input type="text" value="Pvc0"/>
VPI	<input type="text" value="8"/>
VCI	<input type="text" value="35"/>
Virtual Circuit	<input type="text" value="Enabled"/>
WAN Setting	<input type="text" value="Static IP Address"/>

Static IP

Connection Type	<input type="text" value="1483 Bridged IP LLC"/>
IP Address	<input type="text" value="0.0.0.0"/>
Subnet Mask	<input type="text"/>
Gateway Address	<input type="text"/>
Primary DNS Address	<input type="text" value="168.95.1.1"/>
Secondary DNS Address	<input type="text"/>
MTU	<input type="text" value="1400"/> bytes
NAT	<input type="text" value="Enabled"/>
Firewall	<input type="text" value="Enabled"/>

ATM

Service Category	<input type="text" value="UBR"/>
PCR	<input type="text"/> kbps
SCR	<input type="text"/> kbps

 **Apply**  **Cancel**  **Help**



- Wizard
- Wireless
- WAN**
- LAN
- DHCP
- DNS
- DynamicDNS
- Logout

Home | **Advanced** | **Tools** | **Status** | **Help**

ATM VC Setting

PVC	<input type="text" value="Pvc0"/>
VPI	<input type="text" value="8"/>
VCI	<input type="text" value="35"/>
Virtual Circuit	<input type="text" value="Enabled"/>
WAN Setting	<input type="text" value="Bridge Mode"/>

Bridge Mode

Connection Type	<input type="text" value="1483 Bridged IP LLC"/>
-----------------	--

ATM

Service Category	<input type="text" value="UBR"/>
PCR	<input type="text"/> kbps
SCR	<input type="text"/> kbps

 **Apply**  **Cancel**  **Help**



- Wizard
- Wireless
- WAN
- LAN**
- DHCP
- DNS
- DynamicDNS
- Logout

Home | **Advanced** | **Tools** | **Status** | **Help**

Management IP

These are the IP settings of the LAN interface for the DSL-G604T. These setting may be referred to as Private settings. You may change the LAN IP address if needed.

IP Address	<input type="text" value="10.1.1.1"/>
Subnet Mask	<input type="text" value="255.0.0.0"/>

- Apply**
- Cancel**
- Help**



- Wizard
- Wireless
- WAN
- LAN
- DHCP**
- DNS
- DynamicDNS
- Logout

Home | **Advanced** | **Tools** | **Status** | **Help**

DHCP Settings

The device can be setup as a DHCP Server to distribute IP addresses to the LAN network.

- No DHCP Choose this option. The IP address must be manually assigned at each device connected to DSL-G604T.
- DHCP Server Choose this option to setup as a DHCP server to distribute IP addresses to the LAN network.

DHCP Server

Starting IP Address

Ending IP Address

Lease Time seconds

DNS Mode Auto Manual

Primary DNS

Secondary DNS

Static IP Assignment

	MAC Address	IP Address
Static IP1:	<input type="text"/>	<input type="text"/>
Static IP2:	<input type="text"/>	<input type="text"/>
Static IP3:	<input type="text"/>	<input type="text"/>
Static IP4:	<input type="text"/>	<input type="text"/>
Static IP5:	<input type="text"/>	<input type="text"/>

Enter MAC Address format as xx-xx-xx-xx-xx-xx, i.e: 00-0C-8E-D5-11-22, and IP Address format as xxx.yyy.zzz.yyy, i.e: 10.1.1.2

  
Apply Cancel Help

DHCP Clients List

No DHCP Clients Available



- Wizard
- Wireless
- WAN
- LAN
- DHCP
- DNS**
- DynamicDNS
- Logout

Home | **Advanced** | **Tools** | **Status** | **Help**

DNS Configuration

The DNS Configuration allows the user to set the configuration of DNS relay.

DNS Relay Selection	<input type="text" value="Use Auto Discovered DNS Server Only"/>
User Configuration:	
Preferred DNS Server	<input type="text" value="168.95.1.1"/>
Alternate DNS Server	<input type="text"/>

 **Apply**  **Cancel**  **Help**



- Wizard
- Wireless
- WAN
- LAN
- DHCP
- DNS
- DynamicDNS**
- Logout

Home | **Advanced** | **Tools** | **Status** | **Help**

DDNS Configuration

The DDNS Configuration allows the user to set the configuration of DDNS.

DDNS Server	<input type="text" value="Disable DDNS Server"/>
User Configuration:	
UserName	<input type="text" value="UserName"/>
PassWord	<input type="password" value="....."/>
HostName	<input type="text" value="HostName"/>

- Apply**
- Cancel**
- Help**



UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless Management

Home **Advanced** **Tools** **Status** **Help**

UPnP

To enable UPnP, check Enable UPnP and then select a connection.

Enable UPnP

Select	Available Connections
<input type="radio"/>	Pvc0
<input type="radio"/>	Pvc1
<input type="radio"/>	Pvc2
<input type="radio"/>	Pvc3
<input type="radio"/>	Pvc4
<input type="radio"/>	Pvc5
<input type="radio"/>	Pvc6
<input type="radio"/>	Pvc7

Apply

Cancel

Help

Home

Advanced

Tools

Status

Help

Virtual Server

Connection: Pvc0

LAN IP: 10.1.1.2 **New IP**

Category	Available Rules	Applied Rules
<input checked="" type="radio"/> Games	Alien vs Predator	
<input type="radio"/> VPN	Asheron's Call	
<input type="radio"/> Audio/Video	Dark Rein 2	
<input type="radio"/> Apps	Delta Force	
<input type="radio"/> Servers	Doom	
<input type="radio"/> User	Dune 2000	
	DirectX (7,8) Games	
	EliteForce	
	EverQuest	
	Fighter Ace II	

Add > **< Remove**

View

You must save settings and reboot to take effect.



Apply



Cancel



Help

UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless
Management

Home

Advanced

Tools

Status

Help



UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless
Management

LAN Clients

IP Address

Host Name

Add

Valid IP Range: **10.1.1.2 - 10.1.1.254**

Static Addresses

Delete	IP Address	Host Names	Type
<input type="checkbox"/>	10.1.1.2	PC	Static

Dynamic Addresses

Reserve	IP Address	Host Names	Type
---------	------------	------------	------



Apply



Cancel



Help



UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless Management

Home **Advanced** Tools Status Help

SNMP Management

- Enable SNMP Agent
- Enable SNMP Traps

Name:

Location:

Contact:

Vendor OID: 1.3.6.1.4.1.294

Community

Name	Access Right
<input type="text" value="public"/>	<input type="text" value="ReadOnly"/>
<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>

Traps

Destination IP	Trap Community	Trap Version
<input type="text"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>
<input type="text"/>	<input type="text"/>	<input type="text"/>

Apply Cancel Help

Home

Advanced

Tools

Status

Help



UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless Management

Filters

Filters are used to allow or deny LAN or WAN users from accessing the internet or internal Network.

Outbound Filter Inbound Filter

IP Outbound Filter

Filters are used to allow or deny LAN users from accessing the internet.

Source IP ~ Any IP

Destination IP ~ Any IP

Source Port ~ Any Port

Destination Port ~ Any Port

Protocol

Action



Apply



Cancel



Help

ID	Category	Source IP	Destination IP	Prot.	Act.	Enable
----	----------	-----------	----------------	-------	------	--------

Home

Advanced

Tools

Status

Help



UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless Management

Filters

Filters are used to allow or deny LAN or WAN users from accessing the internet or internal Network.

Outbound Filter Inbound Filter

IP Inbound Filter

Allow or deny WAN IP address to the internal network.

Source IP ~ Any IP

Destination IP ~ Any IP

Source Port ~ Any Port

Destination Port ~ Any Port

Protocol

Action

Apply Cancel Help

ID	Category	Source IP	Destination IP	Prot.	Act.	Enable
----	----------	-----------	----------------	-------	------	--------



UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless Management

Home **Advanced** Tools Status Help

Bridge Filters

Enable Bridge Filters

Src MAC	Src Port	Dest MAC	Dest Port	Protocol	Mode
00-00-00-00-00-00	ANY	00-00-00-00-00-00	ANY	PPPoE Session	Deny

  
Apply Cancel Help

Src MAC	Src Port	Dest MAC	Dest Port	Protocol	Mode	Delete
---------	----------	----------	-----------	----------	------	--------



UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless Management

Home **Advanced** Tools Status Help

Routing Table

IP Routes are used to define gateways and hops used to route data traffic. Most users will not need to use this feature as the previous gateway and LAN IP settings on your host computers should be sufficient.

Destination

Netmask

Gateway

Connection

  
Apply Cancel Help

ID	Destination	Netmask	Gateway	Interface
----	-------------	---------	---------	-----------



UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless
Management

Home

Advanced

Tools

Status

Help

DMZ

DMZ (Demilitarized Zone) is used to allow a single computer on the LAN to be exposed to the Internet.

Enabled Disabled

IP Address:



Apply



Cancel



Help



UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless Management

Home **Advanced** Tools Status Help

Firewall Configuration

DoS Protection

DoS attacks can be checked based on your specific need.

State: Enabled Disabled

- SYN Flooding checking
- ICMP Redirection checking

Port Scan Protection

Port Scan attacks can be checked based on your specific need.

State: Enabled Disabled

- FIN/URG/PSH attack
- Xmas Tree attack
- Null Scan attack
- SYN/RST attack
- SYN/FIN attack

Service Filtering

The following services can be blocked based on your specific need.

- Ping from External Network
- Telnet from External Network
- FTP from External Network
- DNS from External Network
- IKE from External Network
- RIP from External Network
- DHCP from External Network
- ICMP from LAN



UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless
Management

Home

Advanced

Tools

Status

Help

RIP System Wide Configuration

RIP is an Internet protocol you can set up to share routing table information with other routing devices on your LAN, at your ISP's location, or on remote networks connected to your network via the ADSL line.

RIP

Protocol

Direction



Apply



Cancel



Help

Home

Advanced

Tools

Status

Help



UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless
Management

PPP Connection

This page is used to view and PPP connection status and setting.

PVC

PVC0

Connection Setting

Not Connected

Connect

Connection Setting

- Always ON
- Connection On Demand
- Manual

Recommended

Connection will close if idle for
 minutes

Use Connect/Disconnect button only



Apply



Cancel



Help

ATM VCs List

ID	PVC	VPI	VCI	Connection Type	
1	PVC0	8	35	PPPoE	

Home

Advanced

Tools

Status

Help



UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless
Management

ADSL Configuration

The ADSL Configuration page allows the user to set the configuration for ADSL protocol.

Modulation Type

Multi-mode	▼
Multi-mode	
T1.413	
G.dmt	
G.lite	



Apply



Cancel



Help

Home

Advanced

Tools

Status

Help

ATM VC Setting

PVC PVC0

VPI

VCI

Virtual Circuit

WAN Setting

PPPoE/PPPoA

User Name

Password

Connection Type

MTU bytes

MRU bytes

Default Route

NAT

Firewall

IP Control

Static IP



Apply



Cancel



Help

ATM VCs List

ID	PVC	VPI	VCI	Connection Type	Virtual Circuit	
1	PVC0	8	35	PPPoE/PPPoA	Enabled	
2	PVC1	0	36	Bridge Mode	Disabled	
3	PVC2	0	37	Bridge Mode	Disabled	
4	PVC3	0	38	Bridge Mode	Disabled	
5	PVC4	0	39	Bridge Mode	Disabled	
6	PVC5	0	40	Bridge Mode	Disabled	

UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless Management

Home

Advanced

Tools

Status

Help



UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless
Management

Wireless Management

Access List

Associated Stations

Multiple SSID

Access List

Enable Access List

Allow Deny

Mac Address:

Add

[Delete](#) [Mac Address](#)

Please save and reboot the device to take effect!



Apply



Cancel



Help



Home

Advanced

Tools

Status

Help

UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless Management

Wireless Management

Access List

Associated Stations

Multiple SSID

Associated Stations

There are no Associated Stations at this time.

Please save and reboot the device to take effect !



Apply



Cancel



Help



UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless
Management

Home

Advanced

Tools

Status

Help

Wireless Management

Access List

Associated Stations

Multiple SSID

Multiple SSID

Enable Multiple SSID

SSID:

Add

Delete

Key

SSID

Please save and reboot the device to take effect !



Apply



Cancel



Help



UPnP

Virtual Server

Lan Clients

SNMP

Filters

Bridge Filters

Routing

DMZ

Firewall

RIP

PPP

ADSL

ATM VCC

Wireless
Management

Wireless
Performance

Home

Advanced

Tools

Status

Help

Wireless Performance

These are the Wireless Performance feature for the AP(Access Point) portion.

Beacon interval: (msec, range:1~1000,default:200)

DTIM: (range:1~25,default:2)

Hidden SSID: Enabled

Antenna transmit power: ▾

RTS Threshold:

Frag Threshold:

b/g Mode: ▾



Apply



Cancel



Help

Home

Advanced

Tools

Status

Help



Admin

Time

Remotelog

System

Firmware

Miscellaneous

Test

Logout

Administrator Settings

There is only one account that can access the DSL-G604T's Web-Management interface.

Administrator (The Login Name is "admin")

New Password

Confirm Password

WebPort

(Change the port number of login web)

Remote Web Management

State

 Enabled Disabled

IP Address

Netmask

Remote Telnet Management

State

 Enabled Disabled

IP Address

Netmask



Apply



Cancel



Help



Admin

Time

Remotelog

System

Firmware

Miscellaneous

Test

Logout

Home

Advanced

Tools

Status

Help

Time

Set the DSL-G604T system time.

Local Time 06/08/2005 11:45:15

Synchronize the ADSL Router's clock with:

- Automatic (Simple Network Time Protocol)
- Your computer's clock
- Manual (Enter your own settings)

Date: Jun 08 2005

Time: 11 : 45 : 15



Apply



Cancel



Help



- Admin
- Time
- Remotelog**
- System
- Firmware
- Miscellaneous
- Test
- Logout

Home Advanced **Tools** Status Help

Remote Log Settings

Log Level	<input type="text" value="Notice"/>
Add an IP Address	<input type="text"/>
Select a logging destination	<input type="text"/>

- Notice
- Alert
- Critical
- Debug
- Error
- Info
- Notice**
- Panic
- Warning

Add

Remove



Apply



Cancel



Help



Admin

Time

Remotelog

System

Firmware

Miscellaneous

Test

Logout

Home

Advanced

Tools

Status

Help

System Settings

The current system settings can be saved as a file onto the local hard drive.

Save Settings To Local Hard Drive

Save

Load Settings From Local Hard Drive

Browse...

Load

Note: The system has to be restarted after the configuration is restored.

Save Settings and Reboot the System.

Save and Reboot

Restore To Factory Default Settings

Restore

Force the DSL-G604T Wireless LAN to restart.

Restart AP



Help



Admin

Time

Remotelog

System

Firmware

Miscellaneous

Test

Logout

Home

Advanced

Tools

Status

Help

Firmware Upgrade

There may be new firmware for your DSL-G604T to improve functionality and performance. To upgrade the firmware, locate the upgrade file on the local hard drive with the Browse button. Once you have found the file to be used, click the Apply button below to start the firmware upgrade.

Current Firmware Version : V2.00B01T01.AU

Note: The system has to be restarted after the firmware upgrade.



Apply



Cancel



Help



- Admin
- Time
- Remotelog
- System
- Firmware
- Miscellaneous**
- Test
- Logout

Home Advanced **Tools** Status Help

Miscellaneous Configuration

There are additional tools and features of the DSL-G604T

Ping Test

Ping IP Address

Ping Result :

Connetions

IGMP Proxy Disabled Enabled

Apply Cancel Help

Home

Advanced

Tools

Status

Help



Admin

Time

Remotelog

System

Firmware

Miscellaneous

Test

Logout

Diagnostic Test

The diagnostics feature executes a series of test of your system software and hardware connections. Use the feature when working with your ISP to troubleshoot problems.

Virtual Circuits :

OAM Type :

This Page is used for performing diagnostics on the system.

Testing Connectivity to modem

Testing Ethernet LAN connection	PASS
---------------------------------	------

Testing ADSL Connection

Testing ADSL Synchronization	PASS
------------------------------	------

Testing Network Connection

Testing ATM OAM segment ping	SKIPPED
------------------------------	---------

Testing ATM OAM end to end ping	SKIPPED
---------------------------------	---------

Testing Internet Connectivity

Ping Primary Domain Names Server	SKIPPED
----------------------------------	---------



Help



Device Info

DHCP Clients

Log

Statistics

ADSL

Logout

Home

Advanced

Tools

Status

Help

Device Information

Firmware Version : **V2.00B01T01.AU**

LAN

MAC Address	00:0d:08:00:03:02
IP Address	10.1.1.1
Subnet Mask	255.0.0.0
DHCP Server	Enabled
NAT	Enabled

WAN

Virtual Circuit	<input type="text" value="Pvc0"/>
Status	Not Connected
Connection Type	pppoe
IP Address	N/A
Subnet Mask	N/A
Default Gateway	N/A
DNS Server	N/A



Help



Device Info

DHCP Clients

Log

Statistics

ADSL

Logout

Home **Advanced** **Tools** **Status** **Help**

DHCP Clients

MAC Address	IP Address	Host Name
	10.1.1.2	PC



Help



Device Info

DHCP Clients

Log

Statistics

ADSL

Logout

Home

Advanced

Tools

Status

Help

View Log

View Log displays the activities occurring on the DSL-G604T.

First Page

Last Page

Previous

Next

Clear Log

Save Log



Help

page 1 of 2

Time	Message
------	---------

Jan 1 00:00:32>	Saved Session ID: 0
Jan 1 00:00:32>	Connecting PPPoE socket: 00:60:38:ed:40:12 3108 nas0 0x1000d378
Jan 1 00:00:32>	Default Asymmetric MTU for ppp0 1500
Jan 1 00:00:32>	Connect: ppp0 {-} nas0
Jan 1 00:00:32>	CHAP authentication failed
Jan 1 00:00:32>	Modem hangup
Jan 1 00:00:32>	Connection terminated.
Jan 1 00:00:32>	Doing disconnect
Jan 1 00:00:32>	Terminated: Modem Hang-Up
Jan 1 00:00:37>	pppd 2.4.1 started by root, uid 0
Jan 1 00:00:37>	Got connection: 3208
Jan 1 00:00:37>	Saved Session ID: 0
Jan 1 00:00:37>	Connecting PPPoE socket: 00:60:38:ed:40:12 3208 nas0 0x1000d378
Jan 1 00:00:37>	Default Asymmetric MTU for ppp0 1500
Jan 1 00:00:37>	Connect: ppp0 {-} nas0
Jan 1 00:00:38>	CHAP authentication failed
Jan 1 00:00:38>	Modem hangup
Jan 1 00:00:38>	Connection terminated.
Jan 1 00:00:38>	Doing disconnect
Jan 1 00:00:38>	Terminated: Modem Hang-Up

Home

Advanced

Tools

Status

Help

Traffic Statistics

Traffic Statistics display Receive and Transmit packets passing through the DSL-G604T.

Choose an interface to view your network status:

- Ethernet Display Receive and Transmit packages through Ethernet
- ADSL Display Receive and Transmit packages through ADSL
- Wireless Display Receive and Transmit packages through wireless connection

Refresh



Transmit

Good Tx Frames	1460
Good Tx Broadcast Frames	1
Good Tx Multicast Frames	0
Tx Total Bytes	946380
Collisions	0
Error Frames	0
Carrier Sense Errors	0

Receive

Good Rx Frames	12394
Good Rx Broadcast Frames	8534
Good Tx Multicast Frames	1338
Rx Total Bytes	2577435
CRC Errors	0
Undersized Frames	0
Overruns	0



Device Info

DHCP Clients

Log

Statistics

ADSL

Logout

Home

Advanced

Tools

Status

Help



Device Info

DHCP Clients

Log

Statistics

ADSL

Logout

Traffic Statistics

Traffic Statistics display Receive and Transmit packets passing through the DSL-G604T.

Choose an interface to view your network status:

- Ethernet Display Receive and Transmit packages through Ethernet
- ADSL Display Receive and Transmit packages through ADSL
- Wireless Display Receive and Transmit packages through wireless connection

Refresh



Transmit

Tx PDU's	579
Tx Total Bytes	27004
Tx Total Error Counts	0

Receive

Rx PDU's	720
Rx Total Bytes	37280
Rx Total Error Counts	0

Home

Advanced

Tools

Status

Help



Device Info

DHCP Clients

Log

Statistics

ADSL

Logout

Traffic Statistics

Traffic Statistics display Receive and Transmit packets passing through the DSL-G604T.

Choose an interface to view your network status:

- Ethernet Display Receive and Transmit packages through Ethernet
- ADSL Display Receive and Transmit packages through ADSL
- Wireless Display Receive and Transmit packages through wireless connection

Refresh



Help

Transmit

MPDUs	0
MSDUs	0
Multicast MSDUs	0
Failed MSDUs	0
Retry MSDUs	0

Receive

MPDUs	0
MSDUs	20067
Multicast MSDUs	0
FCS Error MPDUs	5682



Device Info

DHCP Clients

Log

Statistics

ADSL

Logout

Home

Advanced

Tools

Status

Help

ADSL Status

ADSL status shows the ADSL physical layer status.

ADSL Firmware Version: 4.03.03.00 - 3.02.00.03 - 3.02.06.00 Annex A - 01.07.02 - 0.49
ADSL Software Version: V2.00B01T01.AU
Line State Connected
Modulation Multi-mode
Annex Mode ANNEX_A
Max Tx Power -38 dBm/Hz

Item	Downstream	Upstream	Unit
SNR Margin	22	29	dB
Line Attenuation	29	17	dB
Data Rate	512	128	kbps



Help



Home

Advanced

Tools

Status

Help

Home

- [Setup Wizard](#)
- [Wireless](#)
- [WAN Settings](#)
- [LAN Settings](#)
- [DHCP Server](#)
- [DNS Settings](#)
- [Dynamic DNS Settings](#)

Advanced

- [UPNP](#)
- [Virtual Server](#)
- [SNMP](#)
- [Filters](#)
- [Bridge Filters](#)
- [Lan Clients](#)
- [Routing](#)
- [DMZ](#)
- [Firewall Rules](#)
- [RIP Configuration](#)
- [PPP Configuration](#)
- [ADSL Configuration](#)
- [ATM VCC Configuration](#)
- [Wireless management](#)
- [Wireless Performance](#)

Tools

- [Administrator Settings](#)
- [System Time](#)
- [Remote Log](#)
- [System Settings](#)
- [Firmware Upgrade](#)
- [Miscellaneous items](#)
- [Test](#)

Status

- [Device Information](#)
- [Log](#)
- [Statistics](#)
- [ADSL Status](#)