

D-Link[®]

4G LTE ROUTER

DWR-922

**QUICK
INSTALLATION
GUIDE**

A large, light gray watermark of the D-Link logo is positioned diagonally across the page, behind the main text. The logo consists of a stylized 'D' with a white triangle inside it.

CONTENTS OF PACKAGING



4G LTE ROUTER

DWR-922



12 V 1.5 A POWER ADAPTER



CAT5 ETHERNET CABLE



RJ11 PHONE CABLE



If any of these items are missing from your packaging, contact your reseller.


SYSTEM REQUIREMENTS

- A broadband Internet connection
- A phone handset with RJ11 connector (optional)
- Computer with:
 - Microsoft Windows® 8/7/Vista/XP, or Mac with OS X 10.6 or higher
 - PC with 1.3 GHz or above and at least 128 MB RAM
 - Internet Explorer 7, Firefox 12, Safari 4, or Chrome 20 or higher version with Java installed and enabled

PRODUCT SETUP


ZERO CONFIGURATION SETUP

Ensure that your DWR-922 4G LTE Router is powered off before performing the steps below.



Step 1:


Insert a standard USIM card into the SIM card slot on the back of the router with the gold contacts facing downward.



Step 2:


Insert your Ethernet cable into the WAN port on the back of the router.

Note: The 4G connection can also be used as a backup WAN. Once a backup is configured, the router will automatically use 4G for the Internet connection if the Ethernet WAN is not available.



Step 3:

Insert the Ethernet cable into a LAN port on the back panel of the DWR-922 4G LTE Router, and an available Ethernet port on the network adapter in the computer you will use to configure the unit.




Step 4:

(Optional) Connect a phone handset to the phone port (RJ11) on the back panel of the DWR-922.

Log in to the configuration page to set up your handset for Voice over IP (VoIP) calls (see below for information about how to configure the DWR-922).

Note: Do not directly connect the DWR-922 to a telecommunication network or a building's telephone socket.

**Step 5:**

Connect the power adapter to the power input on the back panel of your DWR-922 4G LTE Router, and plug the other end of the power adapter into a wall outlet or power strip.

The Status LED will light up to indicate that power has been supplied to the router.

**Step 6:**

To configure the DWR-922 4G LTE Router:

Open a web browser window and enter **192.168.1.1** into the address bar.

Enter **admin** for the username and **admin** for the password.

The home configuration page will appear. Please see the user manual for details on how to set up the DWR-922.

TROUBLESHOOTING

SETUP AND CONFIGURATION PROBLEMS

1. HOW DO I CONFIGURE MY DWR-922 ROUTER OR CHECK MY WIRELESS NETWORK NAME (SSID) AND WIRELESS ENCRYPTION KEY?

- Connect your PC to the router using an Ethernet cable.
- Open a web browser and enter the router's IP address: **http://192.168.1.1**
- Log into the router using the default username **admin**; the default password is **admin**.
- Once logged in, you can use the wizard to configure the router, or make changes manually.

Note: If you have changed the password and cannot remember it, you will need to reset the router to factory defaults.

2. HOW DO I RESET MY DWR-922 ROUTER TO FACTORY DEFAULT SETTINGS?

- If you cannot remember your router administrator password, you may use a paperclip to press and hold the reset button on the front of the router for about 10 seconds.

Note: Resetting the router to factory default will erase the current configuration. To reconfigure your router, log in as outlined in question 1, then run the Setup Wizard.

3. HOW DO I ADD A NEW WIRELESS CLIENT OR PC IF I HAVE FORGOTTEN MY WIRELESS NETWORK NAME (SSID) OR WIRELESS ENCRYPTION KEY?

- Every PC that needs to connect to the router wirelessly will need use the correct Wireless Network Name (SSID) and encryption key.
- Use the web-based user interface (as described in question 1 above) to check or choose your wireless settings.
- Make sure you write down these settings so that you can enter them into each wirelessly-connected PC. You will find a dedicated area on the back of this document to note this important information down for future use.

4. WHY AM I UNABLE TO ESTABLISH AN INTERNET CONNECTION?

- If connecting using a 4G mobile connection, make sure that you are within range of the mobile service provider, and that the service has been correctly configured.
- If connecting using the WAN via ADSL/Cable service, make sure the modem has been enabled/connected and is operational, and that the service is correctly configured.

TECHNICAL SUPPORT

You can find software updates and user documentation on the D-Link website.

Tech Support for customers in**Australia:**

Tel: 1300-766-868

24/7 Technical Support

Web: <http://www.dlink.com.au>

E-mail: support@dlink.com.au

New Zealand:

Tel: 0800-900-900

24/7 Technical Support

Web: <http://www.dlink.co.nz>

E-mail: support@dlink.co.nz

NOTES

WIRELESS NETWORK REMINDER

Wireless Network Name (SSID)

Wireless Network Password

TECHNICAL SUPPORT