

D-Link®

XTREME N™ DUAL BAND GIGABIT ROUTER



- Quick Installation Guide+
- Руководство по быстрой установке+
- Guía de Instalación Rápida+
- Guia de Instalação Rápida+
- 快速安裝指南+
- Petunjuk Pemasangan Cepat+

WIRELESS

Quick Installation Guide

DIR-825

XTREME N™ DUAL BAND GIGABIT ROUTER

Package Contents

If any of the items are missing, please contact your reseller.



DIR-825
XTREME N™ DUAL
BAND GIGABIT
ROUTER



CD-ROM
(Quick Router Setup
Wizard and Manual)



Ethernet (CAT5 UTP)
Cable



Power Adapter

Default IP: <http://192.168.0.1>
Default Username: Admin
Default Password:




Note :


Using a power supply with a different voltage rating will damage and void the warranty of this product.

Quick Installation

- 1** Remove the D-Link Click and Connect CD.



- 2** A. Be sure your Internet connection is active. DO NOT plug the router in yet.
B. Insert the Quick Router Setup Wizard CD into your computer.
(OS requirement:
WINDOWS 2000/XP/Vista).



- C. Click "Install Router"
(Follow the instruction on the screen and for more information please click "View Manual")

Troubleshooting

1. How do I configure my DIR-825 router without the CD, or check my Wireless Network Name (SSID) and Wireless Encryption Key?

- Connect your PC to the router using an Ethernet cable.
- Open a web browser and enter the address <http://192.168.0.1> or <http://dlinkrouter>. The default username is 'admin'. The default password is '' (leave the field blank).
- If you have changed the password and can not remember it, you will need to reset the router to set the password back to '' (leave the field blank).

2. How do I reset my router to factory default settings?

- Ensure the router is powered on.
- Press and hold the reset button on the rear of the device for 20 seconds.

Note: Resetting the router to factory default will erase the current configuration settings. To re-configure your settings, log into the router as outlined in question 1, then run the Setup Wizard.

3. How do I add a new wireless client or PC if I have forgotten my Wireless Network Name (SSID) or Wireless Encryption Key?

- For every PC that needs to connect to the router wirelessly, you will need to ensure you use the correct Wireless Network Name (SSID) and encryption key.
- Use the web based user interface (as described in question 1 above) to check or choose your wireless settings.
- Make sure you take a note of the settings so that you can enter them into each wirelessly connected PC.

4. What can I do if my router is not working correctly?

- The manual contains a full troubleshooting section and can be downloaded from the D-Link website (see below), however there are a few quick steps you can take to try and resolve any issues:
 - Check the LED's on the front of the router. The Power, Wireless and Internet LED should be on. One or more of the LAN LED should flash.
 - Check that all the cables are firmly connected at both ends.
 - Power the router off for 20 seconds, and then power it back on.

5. Why can I not get an Internet Connection?

- For Cable users make sure Clone MAC address option is ticked during Wizard installation (or enter the registered MAC) and make sure the service has been enabled/connected and is operational.
- For ADSL users please contact your ISP to make sure the service has been enabled/connected by your ISP and that your ISP username and password is correct.

Note: If you are unable to connect, see the Troubleshooting chapter of the product manual in the D-Link DIR-825 XTREME N™ DUAL BAND GIGABIT ROUTER CD.

Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for customers in

Australia:

Tel: 1300-766-868

24/7(24Hrs, 7days a week) technical support

<http://www.dlink.com.au>

e-mail: support@dlink.com.au

India:

Tel: 1800-222-002

9.00 AM to 9.00 PM. All days

<http://www.dlink.co.in/support/productsupport.aspx>

Indonesia, Malaysia, Singapore and Thailand:

Tel: +62-21-5731610 (Indonesia)

Tel: 1800-882-880 (Malaysia)

Tel: +65 66229355 (Singapore)

Tel: +66-2-719-8978/9 (Thailand)

24/7, for English Support Only

<http://www.dlink.com.sg/support/>

e-mail: support@dlink.com.sg

Korea:

Tel: +82-2-2028-1815

Monday to Friday 9:00am to 6:00pm

<http://www.d-link.co.kr>

e-mail: arthur@d-link.co.kr

New Zealand:

Tel: 0800-900-900

24/7(24Hrs, 7days a week) technical support

<http://www.dlink.co.nz>

e-mail: support@dlink.co.nz

D-Link®
Building Networks for People